


MONITOUCH

Connection Manual [1]

Contents

- | | |
|----------------------------|--|
| 1. Overview | 19. FESTO |
| 2. A&D | 20. FUFENG |
| 3. Agilent | 21. Fuji Electric |
| 4. ALLEN BRADLEY | 22. Gammaflux |
| 5. Automationdirect | 23. GE Fanuc |
| 6. Azbil | 24. Hitachi |
| 7. Banner | 25. Hitachi Industrial Equipment Systems |
| 8. Baumuller | 26. HYUNDAI |
| 9. BECKHOFF | |
| 10. Bosch Rexroth | |
| 11. CHINO | |
| 12. CIMON | |
| 13. DELTA | |
| 14. DELTA TAU DATA SYSTEMS | |
| 15. EATON Cutler-Hammer | |
| 16. EMERSON | |
| 17. FANUC | |
| 18. Fatek Automation | |



TECHNOSHOT TS2060

Record of Revisions

Reference numbers are shown at the bottom left corner on the back cover of each manual.

[illegible]

Preface

Thank you for selecting the MONITOUCH TS2060.

For correct set-up of the TS2060, you are requested to read through this manual to understand more about the product.

For more information about the TS2060, refer to the following related manuals.

| Manual Name | Contents | Reference No. |
|--------------------------------|--|---------------|
| TS2060 Reference Manual [1] | Explains the functions and operation of the TS2060. | 1204NE |
| TS2060 Reference Manual [2] | | 1205NE |
| V Series Macro Reference | Provides an overview of macros of V-SFT version 6 and explains macro editor operations and macro command descriptions in detail. | 1056NE |
| V9 Series Operation Manual | Explains the configuration of V-SFT version 6, the editing process of each part and limitations regarding operation in detail. | 1072NE |
| TS2060 Connection Manual [1] | Explains the connection and communication parameters for the TS2060 and controllers in detail. | 2204NE |
| TS2060 Connection Manual [2] | | 2205NE |
| TS2060 Connection Manual [3] | | 2206NE |
| TS2060 Hardware Specifications | Explains hardware specifications and precautions when handling the TS2060. | 2207NE |

For details on devices including PLCs, inverters, and temperature controllers, refer to the manual for each device.

Notes:

1. This manual may not, in whole or in part, be printed or reproduced without the prior written consent of Hakko Electronics Co., Ltd.
2. The information in this manual is subject to change without prior notice.
3. Windows and Excel are registered trademarks of Microsoft Corporation in the United States and other countries.
4. All other company names or product names are trademarks or registered trademarks of their respective holders.
5. This manual is intended to give accurate information about MONITOUCH hardware. If you have any questions, please contact your local distributor.

Types and Model Names of the TS2060

The MONITOUCH TS2060 comprises the following types.

| Generic Name | Model | Physical Ports | | | | | |
|--------------|---------|----------------|-----|-------|-----------|--------------|-------------------------------------|
| | | MJ1, MJ2 | LAN | USB-A | USB-miniB | SD Card Slot | Option/Communication Unit Connector |
| TS2060 | TS2060i | ○ | ○ | ○ | ○ | ○ | ○ |
| | TS2060 | ○* | × | × | ○ | × | × |

* The external power supply of +5 V is not available.

Note that model names are differentiated according to the above descriptions in this manual for operation explanations.

Notes on Safe Usage of MONITOUCH

In this manual, you will find various notes categorized under the following two levels with the signal words "Danger" and "Caution."




DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury and could cause property damage.

Note that there is a possibility that an item listed under  **CAUTION** may have serious ramifications.



DANGER

- Never use the output signal of the TS2060 for operations that may threaten human life or damage the system, such as signals used in case of emergency. Please design the system so that it can cope with a touch switch malfunction. A touch switch malfunction may result in machine accidents or damage.
- Turn off the power supply when you set up the unit, connect new cables, or perform maintenance or inspections. Otherwise, electrical shock or damage may occur.
- Never touch any terminals while the power is on. Otherwise, electrical shock may occur.
- You must cover the terminals on the unit before turning the power on and operating the unit. Otherwise, electrical shock may occur.
- The liquid crystal in the LCD panel is a hazardous substance. If the LCD panel is damaged, do not ingest the leaked liquid crystal. If leaked liquid crystal makes contact with skin or clothing, wash it away with soap and water.
- Never disassemble, recharge, deform by pressure, short-circuit, reverse the polarity of the lithium battery, nor dispose of the lithium battery in fire. Failure to follow these conditions will lead to explosion or ignition.
- Never use a lithium battery that is deformed, leaking, or shows any other signs of abnormality. Failure to follow these conditions will lead to explosion or ignition.
- Switches on the screen are operable even when the screen has become dark due to a faulty backlight or when the backlight has reached the end of its service life. If the screen is dark and hard to see, do not touch the screen. Otherwise, a malfunction may occur resulting in machine accidents or damage.



CAUTION

- Check the appearance of the unit when it is unpacked. Do not use the unit if any damage or deformation is found. Failure to do so may lead to fire, damage, or malfunction.
- For use in a facility or as part of a system related to nuclear energy, aerospace, medical, traffic equipment, or mobile installations, please consult your local distributor.
- Operate (or store) the TS2060 under the conditions indicated in this manual and related manuals. Failure to do so could cause fire, malfunction, physical damage, or deterioration.
- Observe the following environmental restrictions on use and storage of the unit. Otherwise, fire or damage to the unit may result.
 - Avoid locations where there is a possibility that water, corrosive gas, flammable gas, solvents, grinding fluids, or cutting oil can come into contact with the unit.
 - Avoid high temperatures, high humidity, and outside weather conditions, such as wind, rain, or direct sunlight.
 - Avoid locations where excessive dust, salt, and metallic particles are present.
 - Avoid installing the unit in a location where vibrations or physical shocks may be transmitted.
- Equipment must be correctly mounted so that the main terminal of the TS2060 will not be touched inadvertently. Otherwise, an accident or electric shock may occur.
- Tighten the mounting screw on the fixtures of the TS2060 to an equal torque of 4.43 lbf-in (0.5 N-m). Excessive tightening may distort the panel surface. Loose mounting screws may cause the unit to fall down, malfunction, or short-circuit.
- Check periodically that terminal screws on the power supply terminal block and fixtures are firmly tightened. Loosened screws or nuts may result in fire or malfunction.
- Tighten the terminal screws on the power supply terminal block of the TS2060 to an equal torque of 5 to 6 lbf-in (0.56 to 0.68 N-m). Improper tightening of screws may result in fire, malfunction, or other serious trouble.
- The TS2060 has a glass screen. Do not drop the unit or impart physical shocks to the unit. Otherwise, the screen may be damaged.
- Correctly connect cables to the terminals of the TS2060 in accordance with the specified voltage and wattage. Overvoltage, overwattage, or incorrect cable connection could cause fire, malfunction, or damage to the unit.
- Always ground the TS2060. The FG terminal must be used exclusively for the TS2060 with the level of grounding resistance less than 100 Ω . Otherwise, electric shock or a fire may occur.
- Prevent any conductive particles from entering the TS2060. Failure to do so may lead to fire, damage, or malfunction.

CAUTION

- After wiring is finished, remove the paper used as a dust cover before starting operation of the TS2060. Operation with the dust cover attached may result in accidents, fire, malfunction, or other trouble.
- Do not attempt to repair the TS2060 yourself. Contact Hakko Electronics or the designated contractor for repairs.
- Do not repair, disassemble, or modify the TS2060. Hakko Electronics Co., Ltd. is not responsible for any damages resulting from repair, disassembly, or modification of the unit that was performed by an unauthorized person.
- Do not use sharp-pointed tools to press touch switches. Doing so may damage the display unit.
- Only experts are authorized to set up the unit, connect cables, and perform maintenance and inspection.
- Lithium batteries contain combustible material such as lithium and organic solvents. Mishandling may cause heat, explosion, or ignition resulting in fire or injury. Read the related manuals carefully and correctly handle the lithium battery as instructed.
- Take safety precautions during operations such as changing settings when the unit is running, forced output, and starting and stopping the unit. Any misoperations may cause unexpected machine movement, resulting in machine accidents or damage.
- In facilities where the failure of the TS2060 could lead to accidents that threaten human life or other serious damage, be sure that such facilities are equipped with adequate safeguards.
- When disposing of the TS2060, it must be treated as industrial waste.
- Before touching the TS2060, discharge static electricity from your body by touching grounded metal. Excessive static electricity may cause malfunction or trouble.
- Insert an SD card into MONITOUCH in the same orientation as pictured on the unit. Failure to do so may damage the SD card or the slot on the unit.
- Removing the SD card while it is being accessed may destroy any data stored on it. Be sure to press the storage removal switch before removing an SD card.
- Do not press two or more positions on the screen at the same time. If two or more positions are pressed at the same time, the switch located between the pressed positions may be activated.
- Be sure to remove the protective sheet that is attached to the touch panel surface at delivery before use. If used with the protective sheet attached, MONITOUCH may not recognize touch operations or malfunctions may occur.

[General Notes]

- Never bundle control cables or input/output cables with high-voltage and large-current carrying cables such as power supply cables. Keep control cables and input/output cables at least 200 mm away from high-voltage and large-current carrying cables. Otherwise, malfunction may occur due to noise.
- When using the TS2060 in an environment where a source of high-frequency noise is present, it is recommended that the FG shielded cable (communication cable) be grounded at each end. However, when communication is unstable, select between grounding one or both ends, as permitted by the usage environment.
- Be sure to plug connectors and sockets of the TS2060 in the correct orientation. Failure to do so may lead to damage or malfunction.
- If a LAN cable is inserted into the MJ1 or MJ2 connector, the device on the other end may be damaged. Check the connector names on the unit and insert cables into the correct connectors.
- Do not use thinners for cleaning because it may discolor the TS2060 surface. Use commercially available alcohol.
- Clean the display area using a soft cloth to avoid scratching the surface.
- If a data receive error occurs when the TS2060 unit and a counterpart unit (PLC, temperature controller, etc.) are started at the same time, read the manual of the counterpart unit to correctly resolve the error.
- Avoid discharging static electricity on the mounting panel of the TS2060. Static charge can damage the unit and cause malfunctions.
- Avoid prolonged display of any fixed pattern. Due to the characteristic of liquid crystal displays, an afterimage may occur. If prolonged display of a fixed pattern is expected, use the backlight's auto OFF function.
- The TS2060 is identified as a class-A product in industrial environments. In the case of use in a domestic environment, the unit is likely to cause electromagnetic interference. Preventive measures should thereby be taken appropriately.

[Notes on the LCD]

Note that the following conditions may occur under normal circumstances.

- The response time, brightness, and colors of the TS2060 may be affected by the ambient temperature.
- Tiny spots (dark or luminescent) may appear on the display due to the characteristics of liquid crystal.
- Unevenness in brightness and flickering may occur depending on the screen display pattern due to the characteristics of liquid crystal.
- Each unit varies slightly with respect to brightness and colors.
- Display colors may vary depending on the viewing angle because a converging lens is used in the backlight unit.

Contents

1. Overview

| | | |
|-------|---|------|
| 1.1 | System Configuration | 1-1 |
| 1.1.1 | Overview | 1-1 |
| | TS2060i | 1-1 |
| | TS2060 | 1-2 |
| 1.1.2 | System Composition | 1-3 |
| | Serial Communication | 1-3 |
| | Ethernet Communication (TS2060i Only) | 1-4 |
| | Mixed Serial-Ethernet Communication (TS2060i only) | 1-4 |
| 1.2 | Physical Ports | 1-5 |
| 1.2.1 | CN1 (TS2060i + DUR-00) | 1-5 |
| 1.2.2 | MJ1/MJ2 | 1-6 |
| 1.2.3 | LAN (TS2060i Only) | 1-8 |
| 1.2.4 | EXT1 (Connection Port for Network Communication Unit/Optional Unit, TS2060i Only) | 1-9 |
| 1.2.5 | USB | 1-9 |
| 1.2.6 | DIP Switch (DIPSW) Settings | 1-10 |
| 1.3 | Connection Methods | 1-11 |
| 1.3.1 | Serial Communication | 1-11 |
| | 1 : 1 Connection | 1-11 |
| | 1 : n Connection (Multi-drop) | 1-18 |
| | n : 1 Connection (Multi-link2) | 1-21 |
| | n : 1 Connection (Multi-link2 (Ethernet)) (TS2060i Only) | 1-31 |
| | n : n Connection (1 : n Multi-link2 (Ethernet)) (TS2060i Only) | 1-34 |
| | n : 1 Connection (Multi-link) | 1-37 |
| 1.3.2 | Ethernet Communication (TS2060i Only) | 1-43 |
| 1.3.3 | Network Communication (TS2060i Only) | 1-48 |
| 1.3.4 | Slave Communication | 1-49 |
| | V-Link | 1-49 |
| | MODBUS RTU | 1-49 |
| | MODBUS TCP/IP (TS2060i Only) | 1-49 |
| 1.3.5 | Other Connections | 1-49 |
| 1.4 | Hardware Settings | 1-50 |
| 1.4.1 | PLC Settings | 1-50 |
| | Selecting a Device to be Connected | 1-51 |
| | PLC Properties | 1-51 |
| 1.4.2 | MONITOUCH Settings | 1-54 |
| | Select Edit Model | 1-54 |
| | Read/Write Area | 1-55 |
| | Buzzer | 1-63 |
| | Backlight | 1-63 |
| | Local IP Address (TS2060i Only) | 1-63 |
| | Ladder Transfer | 1-66 |
| 1.4.3 | Other Equipment | 1-67 |
| | Printer | 1-67 |
| | Card Recorder | 1-69 |
| | V-I/O | 1-69 |
| | Simulator | 1-69 |
| 1.5 | System Device Memory for Communication Confirmation | 1-70 |
| 1.5.1 | \$Pn (For 8-way Communication) | 1-70 |
| 1.5.2 | \$s518, 519 (Ethernet Status Confirmation) (TS2060i Only) | 1-78 |

| | | |
|--------|--|------|
| 2. | A&D | |
| 2.1 | Temperature Controller/Servo/Inverter Connection | 2-1 |
| | Serial Connection. | 2-1 |
| 2.1.1 | AD4402 (MODBUS RTU). | 2-2 |
| 2.1.2 | AD4404 (MODBUS RTU). | 2-3 |
| 2.1.3 | Wiring Diagrams | 2-4 |
| | When Connected at CN1:. | 2-4 |
| | When Connected at MJ1/MJ2:. | 2-4 |
| 3. | Agilent | |
| 3.1 | Temperature Controller/Servo/Inverter Connection | 3-1 |
| | Serial Connection. | 3-1 |
| 3.1.1 | 4263 Series | 3-2 |
| 3.1.2 | Wiring Diagrams | 3-17 |
| | When Connected at CN1:. | 3-17 |
| | When Connected at MJ1/MJ2:. | 3-18 |
| 4. | ALLEN BRADLEY | |
| 4.1 | PLC Connection | 4-1 |
| | Serial Connection. | 4-1 |
| | Ethernet Connection (TS2060i Only) | 4-1 |
| 4.1.1 | PLC-5 | 4-2 |
| 4.1.2 | PLC-5 (Ethernet). | 4-8 |
| 4.1.3 | Control Logix / Compact Logix | 4-11 |
| 4.1.4 | Control Logix (Ethernet). | 4-14 |
| 4.1.5 | SLC500. | 4-16 |
| 4.1.6 | SLC500 (Ethernet TCP/IP). | 4-20 |
| 4.1.7 | Micro Logix. | 4-23 |
| 4.1.8 | Micro Logix (Ethernet TCP/IP). | 4-26 |
| 4.1.9 | NET-ENI (SLC500 Ethernet TCP/IP). | 4-29 |
| 4.1.10 | NET-ENI (MicroLogix Ethernet TCP/IP) | 4-33 |
| 4.1.11 | Micro800 Controllers | 4-37 |
| 4.1.12 | Micro800 Controllers(Ethernet TCP/IP) | 4-39 |
| 4.1.13 | Wiring Diagrams | 4-41 |
| | When Connected at CN1:. | 4-41 |
| | When Connected at MJ1/MJ2:. | 4-44 |
| 5. | Automationdirect | |
| 5.1 | PLC Connection | 5-1 |
| | Serial Connection. | 5-1 |
| | Ethernet Connection (TS2060i Only) | 5-1 |
| 5.1.1 | Direct LOGIC (K-Sequence) | 5-2 |
| 5.1.2 | Direct LOGIC (Ethernet UDP/IP) | 5-4 |
| 5.1.3 | Direct LOGIC (MODBUS RTU) | 5-6 |
| 5.1.4 | Wiring Diagrams | 5-8 |
| | When Connected at CN1:. | 5-8 |
| | When Connected at MJ1/MJ2:. | 5-11 |
| 6. | Azbil | |
| 6.1 | PLC Connection | 6-1 |
| | Serial Connection. | 6-1 |
| 6.1.1 | MX Series | 6-2 |
| 6.1.2 | Wiring Diagrams | 6-4 |
| | When Connected at CN1:. | 6-4 |
| | When Connected at MJ1/MJ2:. | 6-5 |
| 6.2 | Temperature Controller/Servo/Inverter Connection | 6-6 |
| | Serial Connection. | 6-6 |
| | Ethernet Connection (TS2060i Only) | 6-7 |
| 6.2.1 | SDC10 | 6-8 |
| 6.2.2 | SDC15 | 6-8 |
| 6.2.3 | SDC20 | 6-9 |
| 6.2.4 | SDC21 | 6-9 |

| | | |
|--------|--|-------|
| 6.2.5 | SDC25/26 | 6-9 |
| 6.2.6 | SDC30/31 | 6-10 |
| 6.2.7 | SDC35/36 | 6-11 |
| 6.2.8 | SDC45/46 | 6-12 |
| 6.2.9 | SDC40A | 6-13 |
| 6.2.10 | SDC40G | 6-13 |
| 6.2.11 | DMC10 | 6-14 |
| 6.2.12 | DMC50 (COM) | 6-15 |
| 6.2.13 | AHC2001 | 6-19 |
| 6.2.14 | AHC2001+DCP31/32 | 6-22 |
| 6.2.15 | DCP31/32 | 6-25 |
| 6.2.16 | NX (CPL) | 6-26 |
| 6.2.17 | NX (MODBUS RTU) | 6-27 |
| 6.2.18 | NX (MODBUS TCP/IP) | 6-28 |
| 6.2.19 | Wiring Diagrams | 6-30 |
| | When Connected at CN1: | 6-30 |
| | When Connected at MJ1/MJ2: | 6-32 |
| 7. | Banner | |
| 7.1 | Temperature Controller/Servo/Inverter Connection | 7-1 |
| | Ethernet Connection (TS2060i Only) | 7-1 |
| 7.1.1 | PresencePLUS (Ethernet/IP (TCP/IP)) | 7-2 |
| 8. | Baumuller | |
| 8.1 | PLC Connection | 8-1 |
| | Serial Connection | 8-1 |
| 8.1.1 | BMx-x-PLC | 8-2 |
| 8.1.2 | Wiring Diagrams | 8-3 |
| | When Connected at CN1: | 8-3 |
| | When Connected at MJ1/MJ2: | 8-4 |
| 9. | BECKHOFF | |
| 9.1 | PLC Connection | 9-1 |
| | Ethernet Connection (TS2060i Only) | 9-1 |
| 9.1.1 | ADS Protocol (Ethernet) | 9-2 |
| 10. | Bosch Rexroth | |
| 10.1 | Temperature Controller/Servo/Inverter Connection | 10-1 |
| | Serial Connection | 10-1 |
| 10.1.1 | IndraDrive | 10-2 |
| 10.1.2 | Wiring Diagrams | 10-6 |
| | When Connected at CN1: | 10-6 |
| | When Connected at MJ1/MJ2: | 10-6 |
| 11. | CHINO | |
| 11.1 | Temperature Controller/Servo/Inverter Connection | 11-1 |
| | Digital Temperature Controller | 11-1 |
| | Graphic Recorder | 11-2 |
| 11.1.1 | DP1000 | 11-3 |
| 11.1.2 | DB1000B (MODBUS RTU) | 11-9 |
| 11.1.3 | LT230 (MODBUS RTU) | 11-10 |
| 11.1.4 | LT300 (MODBUS RTU) | 11-11 |
| 11.1.5 | LT400 Series (MODBUS RTU) | 11-12 |
| 11.1.6 | LT830 (MODBUS RTU) | 11-13 |
| 11.1.7 | KR2000 (MODBUS RTU) | 11-14 |
| 11.1.8 | Wiring Diagrams | 11-15 |
| | When Connected at CN1: | 11-15 |
| | When Connected at MJ1/MJ2: | 11-18 |

12. CIMON

| | | |
|--------|------------------------------------|-------|
| 12.1 | PLC Connection | 12-1 |
| | Serial Connection | 12-1 |
| | Ethernet Connection (TS2060i Only) | 12-1 |
| 12.1.1 | BP Series | 12-2 |
| 12.1.2 | CP Series | 12-5 |
| 12.1.3 | S Series | 12-8 |
| 12.1.4 | S Series (Ethernet) | 12-11 |
| 12.1.5 | Wiring Diagrams | 12-13 |
| | When Connected at CN1: | 12-13 |
| | When Connected at MJ1/MJ2: | 12-17 |

13. DELTA

| | | |
|--------|------------------------------------|------|
| 13.1 | PLC Connection | 13-1 |
| | Serial Connection | 13-1 |
| | Ethernet Connection (TS2060i Only) | 13-1 |
| 13.1.1 | DVP Series | 13-2 |
| 13.1.2 | DVP-SE (MODBUS ASCII) | 13-3 |
| 13.1.3 | DVP-SE (MODBUS TCP/IP) | 13-4 |
| 13.1.4 | Wiring Diagrams | 13-6 |
| | When Connected at CN1: | 13-6 |
| | When Connected at MJ1/MJ2: | 13-7 |

14. DELTA TAU DATA SYSTEMS

| | | |
|--------|--|-------|
| 14.1 | Temperature Controller/Servo/Inverter Connection | 14-1 |
| | Serial Connection | 14-1 |
| | Ethernet Connection (TS2060i Only) | 14-1 |
| 14.1.1 | PMAC | 14-2 |
| 14.1.2 | PMAC (Ethernet TCP/IP) | 14-5 |
| 14.1.3 | Wiring Diagrams | 14-9 |
| | When Connected at CN1: | 14-9 |
| | When Connected at MJ1/MJ2: | 14-10 |

15. EATON Cutler-Hammer

| | | |
|--------|----------------------------|------|
| 15.1 | PLC Connection | 15-1 |
| | Serial Connection | 15-1 |
| 15.1.1 | ELC | 15-2 |
| 15.1.2 | Wiring Diagrams | 15-3 |
| | When Connected at CN1: | 15-3 |
| | When Connected at MJ1/MJ2: | 15-3 |

16. EMERSON

| | | |
|--------|------------------------------|------|
| 16.1 | PLC Connection | 16-1 |
| | Serial Connection | 16-1 |
| 16.1.1 | EC10/EC20/EC20H (MODBUS RTU) | 16-2 |
| 16.1.2 | Wiring Diagrams | 16-3 |
| | When Connected at CN1: | 16-3 |
| | When Connected at MJ1/MJ2: | 16-4 |

17. FANUC

| | | |
|--------|----------------------------|------|
| 17.1 | PLC Connection | 17-1 |
| | Serial Connection | 17-1 |
| 17.1.1 | Power Mate | 17-2 |
| 17.1.2 | Wiring Diagrams | 17-3 |
| | When Connected at CN1: | 17-3 |
| | When Connected at MJ1/MJ2: | 17-5 |

| | | |
|---------|--|-------|
| 18. | Fatek Automation | |
| 18.1 | PLC Connection | 18-1 |
| | Serial Connection | 18-1 |
| 18.1.1 | FACON FB Series | 18-2 |
| 18.1.2 | Wiring Diagrams | 18-3 |
| | When Connected at CN1: | 18-3 |
| | When Connected at MJ1/MJ2: | 18-4 |
| 19. | FESTO | |
| 19.1 | PLC Connection | 19-1 |
| | Serial Connection | 19-1 |
| 19.1.1 | FEC | 19-2 |
| 19.1.2 | Wiring Diagrams | 19-3 |
| | When Connected at CN1: | 19-3 |
| | When Connected at MJ1/MJ2: | 19-3 |
| 20. | FUFENG | |
| 20.1 | PLC Connection | 20-1 |
| | Serial Connection | 20-1 |
| 20.1.1 | APC Series Controller | 20-2 |
| 20.1.2 | Wiring Diagrams | 20-4 |
| | When Connected at CN1: | 20-4 |
| | When Connected at MJ1/MJ2: | 20-5 |
| 21. | Fuji Electric | |
| 21.1 | PLC Connection | 21-1 |
| | Serial Connection | 21-1 |
| | Ethernet Connection (TS2060i Only) | 21-2 |
| | Network Connection (TS2060i Only) | 21-3 |
| | MICREX-SX Model Selection | 21-4 |
| 21.1.1 | MICREX-F Series | 21-5 |
| 21.1.2 | SPB (N Mode) & FLEX-PC Series | 21-8 |
| 21.1.3 | SPB (N Mode) & FLEX-PC CPU | 21-10 |
| 21.1.4 | MICREX-SX SPH/SPB/SPM/SPE/SPF Series (IEC Mode) | 21-11 |
| 21.1.5 | MICREX-SX SPH/SPB/SPM/SPE/SPF Series (N Mode / F Mode) | 21-13 |
| 21.1.6 | MICREX-SX SPH/SPB/SPM/SPE/SPF CPU (IEC Mode) | 21-14 |
| 21.1.7 | MICREX-SX SPH/SPB/SPM/SPF CPU (N Mode / F Mode) | 21-14 |
| 21.1.8 | MICREX-SX (Ethernet) (IEC Mode) | 21-15 |
| 21.1.9 | MICREX-SX (Ethernet) (N Mode / F Mode) | 21-17 |
| 21.1.10 | Wiring Diagrams | 21-18 |
| | When Connected at CN1: | 21-18 |
| | When Connected at MJ1/MJ2: | 21-20 |
| 21.2 | Temperature Controller/Servo/Inverter Connection | 21-23 |
| | Serial Connection | 21-23 |
| | Ethernet Connection (TS2060i Only) | 21-28 |
| 21.2.1 | PYX (MODBUS RTU) | 21-29 |
| 21.2.2 | PXR (MODBUS RTU) | 21-30 |
| 21.2.3 | PXF (MODBUS RTU) | 21-31 |
| 21.2.4 | PXG (MODBUS RTU) | 21-32 |
| 21.2.5 | PXH (MODBUS RTU) | 21-33 |
| 21.2.6 | PUM (MODBUS RTU) | 21-34 |
| 21.2.7 | F-MPC04P (Loader) | 21-36 |
| 21.2.8 | F-MPC Series / FePSU | 21-40 |
| 21.2.9 | FVR-E11S | 21-48 |
| 21.2.10 | FVR-E11S (MODBUS RTU) | 21-50 |
| 21.2.11 | FVR-C11S (MODBUS RTU) | 21-51 |
| 21.2.12 | FRENIC5000 G11S / P11S | 21-52 |
| 21.2.13 | FRENIC5000 G11S / P11S (MODBUS RTU) | 21-54 |
| 21.2.14 | FRENIC5000 VG7S (MODBUS RTU) | 21-55 |
| 21.2.15 | FRENIC-Mini (MODBUS RTU) | 21-57 |
| 21.2.16 | FRENIC-Eco (MODBUS RTU) | 21-59 |
| 21.2.17 | FRENIC-Multi (MODBUS RTU) | 21-61 |
| 21.2.18 | FRENIC-MEGA (MODBUS RTU) | 21-63 |
| 21.2.19 | FRENIC-MEGA SERVO (MODBUS RTU) | 21-65 |

| | | |
|---------|---|--------|
| 21.2.20 | FRENIC-HVAC/AQUA (MODBUS RTU) | 21-67 |
| 21.2.21 | FRENIC-VG1 (MODBUS RTU) | 21-69 |
| 21.2.22 | FRENIC-Ace (MODBUS RTU) | 21-70 |
| 21.2.23 | FRENIC Series (Loader) | 21-72 |
| 21.2.24 | HFR-C9K | 21-76 |
| 21.2.25 | HFR-C11K | 21-78 |
| 21.2.26 | HFR-K1K | 21-80 |
| 21.2.27 | PPMC (MODBUS RTU) | 21-82 |
| 21.2.28 | FALDIC- α Series | 21-83 |
| 21.2.29 | FALDIC-W Series | 21-85 |
| 21.2.30 | PH Series | 21-87 |
| 21.2.31 | PHR (MODBUS RTU) | 21-89 |
| 21.2.32 | WA5000 | 21-90 |
| 21.2.33 | APR-N (MODBUS RTU) | 21-98 |
| 21.2.34 | ALPHA5 (MODBUS RTU) | 21-99 |
| 21.2.35 | ALPHA5 Smart (MODBUS RTU) | 21-101 |
| 21.2.36 | WE1MA (Ver. A) (MODBUS RTU) | 21-103 |
| 21.2.37 | WE1MA (Ver. B) (MODBUS RTU) | 21-104 |
| 21.2.38 | WSZ Series | 21-105 |
| 21.2.39 | WSZ Series (Ethernet) | 21-107 |
| 21.2.40 | Wiring Diagrams | 21-109 |
| | When Connected at CN1: | 21-109 |
| | When Connected at MJ1/MJ2: | 21-117 |

22. Gammaflux

| | | |
|--------|---|------|
| 22.1 | Temperature Controller / Servo / Inverter | 22-1 |
| | Serial Connection | 22-1 |
| 22.1.1 | TTC2100 | 22-2 |
| 22.1.2 | Wiring Diagrams | 22-5 |
| | When Connected at CN1: | 22-5 |
| | When Connected at MJ1/MJ2: | 22-5 |

23. GE Fanuc

| | | |
|--------|--|-------|
| 23.1 | PLC Connection | 23-1 |
| | Serial Connection | 23-1 |
| | Ethernet Connection (TS2060i Only) | 23-2 |
| 23.1.1 | 90 Series | 23-3 |
| 23.1.2 | 90 Series (SNP-X) | 23-5 |
| 23.1.3 | 90 Series (SNP) | 23-6 |
| 23.1.4 | 90 Series (Ethernet TCP/IP) | 23-8 |
| 23.1.5 | RX3i (Ethernet TCP/IP) | 23-9 |
| 23.1.6 | Wiring Diagrams | 23-10 |
| | When Connected at CN1: | 23-10 |
| | When Connected at MJ1/MJ2: | 23-12 |

24. Hitachi

| | | |
|--------|---|-------|
| 24.1 | PLC Connection | 24-1 |
| | Serial Connection | 24-1 |
| | Ethernet Connection (TS2060i Only) | 24-1 |
| | Network Connection (TS2060i Only) | 24-1 |
| 24.1.1 | HIDIC-S10/2 α , S10mini | 24-2 |
| 24.1.2 | HIDIC-S10/2 α , S10mini (Ethernet) | 24-4 |
| 24.1.3 | HIDIC-S10/4 α | 24-6 |
| 24.1.4 | HIDIC-S10V | 24-7 |
| 24.1.5 | HIDIC-S10V (Ethernet) | 24-9 |
| 24.1.6 | Wiring Diagrams | 24-11 |
| | When Connected at CN1: | 24-11 |
| | When Connected at MJ1/MJ2: | 24-13 |

25. Hitachi Industrial Equipment Systems

| | | |
|--------|--|-------|
| 25.1 | PLC Connection | 25-1 |
| | Serial Connection | 25-1 |
| | Ethernet Connection (TS2060i Only) | 25-1 |
| 25.1.1 | HIDIC-H | 25-2 |
| 25.1.2 | HIDIC-H (Ethernet) | 25-8 |
| 25.1.3 | HIDIC-EHV | 25-10 |
| 25.1.4 | HIDIC-EHV (Ethernet) | 25-12 |
| 25.1.5 | Wiring Diagrams | 25-13 |
| | When Connected at CN1: | 25-13 |
| | When Connected at MJ1/MJ2: | 25-15 |
| 25.2 | Temperature Controller/Servo/Inverter Connection | 25-20 |
| | Inverter | 25-20 |
| 25.2.1 | SJ300 Series | 25-21 |
| 25.2.2 | SJ700 Series | 25-25 |
| 25.2.3 | Wiring Diagrams | 25-29 |
| | When Connected at CN1: | 25-29 |
| | When Connected at MJ1/MJ2: | 25-29 |

26. HYUNDAI

| | | |
|--------|----------------------------|------|
| 26.1 | PLC Connection | 26-1 |
| | Serial Connection | 26-1 |
| 26.1.1 | Hi4 Robot (MODBUS RTU) | 26-2 |
| 26.1.2 | Hi5 Robot (MODBUS RTU) | 26-4 |
| 26.1.3 | Wiring Diagrams | 26-7 |
| | When Connected at CN1: | 26-7 |
| | When Connected at MJ1/MJ2: | 26-9 |

Connection Compatibility List

1. Overview

- 1.1 System Configuration
- 1.2 Physical Ports
- 1.3 Connection Methods
- 1.4 Hardware Settings
- 1.5 System Device Memory for Communication Confirmation

1.1 System Configuration

1.1.1 Overview

The TS series comprises two models: the TS2060i and TS2060. The number of communication ports each model is equipped with differs.


TS2060i

The TS2060i is equipped with six physical ports consisting of two serial ports ^{*1}, one LAN port, one USB-A port, one USB mini-B port, and one network communication port ^{*2}. The LAN port can open eight ports simultaneously. Up to eight different models of devices can be connected to these ports. In addition, a printer and network camera can also be connected.

^{*1} There are three serial ports when the DUR-00 is attached to the TS2060i.

^{*2} The communication interface unit "CUR-xx" is required to perform network communication.

Connection example:




| Physical Ports | | | | No. of Ports | Connected Device | |
|----------------|------------|--|---------------------------|--------------|--|--|
| | | | | | 8-way communication | Other than 8-way |
| Serial | CN1 | RS-232C / RS-422/485 | The "DUR-00" is required. | 1 | PLC, temperature controller, servo, inverter, barcode reader, V-Link, slave communication (Modbus RTU) | - |
| | MJ1 | RS-232C/RS-485 (2-wire system) | | 1 | | Computer (screen program transfer, MJ1), serial printer |
| | MJ2 | RS-232C/RS-422 (4-wire system), RS-485 (2-wire system) | | 1 | | |
| Ethernet | LAN | | | 8 | PLC, slave communication (Modbus TCP/IP) | Computer, network camera |
| USB | USB-A | | | 1 | Barcode reader | USB flash drive, keyboard, mouse, USB-hub |
| | USB mini-B | | | 1 | - | Printer (PictBridge), computer (screen program transfer) |
| Network | EXT1 | OPCN-1 | CUR-00 | 1 | PLC | - |
| | | T-Link | CUR-01 | | | |
| | | CC-LINK | CUR-02 | | | |
| | | Ethernet | CUR-03 | | | |
| | | PROFIBUS-DP | CUR-04 | | | |
| | | SX BUS | CUR-06 | | | |
| | | DeviceNet | CUR-07 | | | |
| | | FL-Net | CUR-08 | | | |
| | | Serial (CN1) | DUR-00 | | PLC, temperature controller, servo, inverter, barcode reader, V-Link, slave communication (Modbus RTU) | - |

- Only the logical port PLC1 can be selected for the following devices and functions. Thus, they cannot be connected at the same time.
 - Devices
 - Network connection (CUR-xx), without PLC connection, Mitsubishi Electric A-Link + Net10, AB Control Logix, Allen-Bradley Micro800 controllers, Siemens S7-200PPI, Siemens S7-300/400 MPI connection
 - Functions
 - Multi-link2, Multi-link, ladder transfer, ladder monitor, MICREX SX variable name cooperation function

TS2060

The TS2060 is equipped with three physical ports consisting of two serial ports and one USB mini-B port. Up to two different models of devices can be connected to these ports for simultaneous communication. In addition, a PictBridge-compatible printer can be connected as well.

Connection example:



| Physical Ports | | | No. of Ports | Connected Device | |
|----------------|------------|--|--------------|--|--|
| | | | | 8-way communication | Other than 8-way |
| Serial | MJ1 | RS-232C/RS-485 (2-wire system) | 1 | PLC, temperature controller, servo, inverter, barcode reader, V-Link, slave communication (Modbus RTU) | Computer (screen program transfer, MJ1), serial printer |
| | MJ2 | RS-232C/RS-422 (4-wire system), RS-485 (2-wire system) | 1 | | |
| USB | USB mini-B | | 1 | - | Printer (PictBridge), computer (screen program transfer) |

- Only the logical port PLC1 can be selected for the following devices and functions. Thus, they cannot be connected at the same time.
 - Devices
 - Without PLC connection, Mitsubishi Electric A-Link + Net10, AB Control Logix, Allen-Bradley Micro800 controllers, Siemens S7-200PPI, Siemens S7-300/400 MPI connection
 - Functions
 - Multi-link2, Multi-link, ladder transfer, MICREX SX variable name cooperation function

1.1.2 System Composition

Serial Communication

- 1 : 1 Connection

A communication port is selectable from CN1 *, MJ1, and MJ2.

For more information, refer to "1 : 1 Connection" (page 1-11) in "1.3 Connection Methods".

* CN1 is available only when the TS2060i is attached the "DUR-00".




- 1 : n Connection

A communication port is selectable from CN1 *, MJ1, and MJ2. A maximum of 31 units of the same model can be connected to each port.

For more information, refer to "1 : n Connection (Multi-drop)" (page 1-18) in "1.3 Connection Methods".


* CN1 is available only when the TS2060i is attached the "DUR-00".



- 3-way Connection (TS2060i only; 2-way connection for TS2060)

The TS2060i is allowed to communicate with three different models of devices at the same time via three serial ports. A maximum of 31 units of the same model can be connected to each port.

The connection method is the same as those for 1 : 1 and 1 : n.



* CN1 is available only when the TS2060i is attached the "DUR-00".

- n : 1 Connection

Multiple TS2060 units can be connected to one PLC or temperature controller.

For more information, refer to "n : 1 Connection (Multi-link2)" (page 1-21), "n : 1 Connection (Multi-link2 (Ethernet)) (TS2060i Only)" (page 1-31), "n : 1 Connection (Multi-link)" (page 1-37) in "1.3 Connection Methods".


- n : n Connection

Multiple TS2060 units can be connected to multiple PLCs.


For more information, refer to "n : n Connection (1 : n Multi-link2 (Ethernet)) (TS2060i Only)" (page 1-34) in "1.3 Connection Methods".

Ethernet Communication (TS2060i Only)

Because eight communication ports can be opened, the TS2060i is allowed to communicate with eight models of PLCs at the same time.



When there are two or more PLCs of the same model, the TS2060i is allowed to carry out 1 : n communication via one port.




* Maximum units:
256 units per port for UDP/IP
64 units with eight ports for TCP/IP

* For more information, refer to "1.3.2 Ethernet Communication (TS2060i Only)" (page 1-43) in "1.3 Connection Methods".

Mixed Serial-Ethernet Communication (TS2060i only)

In the case of mixed serial-Ethernet communication, the TS2060i is allowed to communicate with eight different models of devices at the same time.

- Connection of 3 models for serial communication and 5 models for Ethernet communication



* For the connection method, refer to "1.3.1 Serial Communication" and "1.3.2 Ethernet Communication (TS2060i Only)".

1.2 Physical Ports

1.2.1 CN1 (TS2060i + DUR-00)

The CN1 port supports communication via RS-232C, RS-422 (4-wire system), and RS-485 (2-wire system).
The signal level can be changed between RS-232C and RS-422/485 under [Communication Setting] of the editor.



CAUTION

- The optional unit "DUR-00" is required. The "DUR-00" cannot be used together with the communication unit "CUR-xx".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i").
- When executing communication via RS-232C, set the terminating resistance DIP switches to OFF.
Set DIP switches 1 and 2 on the optional "DUR-00" to OFF. For more information on DIP switches, see "1.2.6 DIP Switch (DIPSW) Settings" (page 1-10).

Pin Arrangement

| TS2060i + DUR-00 CN1 Dsub 9pin, Female | No. | RS-232C | | RS-422/RS-485 | |
|--|-----|---------|--------------------|---------------|------------------------|
| | | Name | Contents | Name | Contents |
| | 1 | NC | Not used | +RD | Receive data (+) |
| | 2 | RD | Receive data | -RD | Receive data (-) |
| | 3 | SD | Send data | -SD | Send data (-) |
| | 4 | NC | Not used | +SD | Send data (+) |
| | 5 | 0V | Signal ground | 0V | Signal ground |
| | 6 | NC | Not used | +RS | RS send data (+) |
| | 7 | RS | RS request to send | -RS | RS send data (-) |
| | 8 | CS | CS clear to send | NC | Not used |
| | 9 | NC | Not used | +5V | Terminating resistance |

Recommended Connector for Communication Cable

| Recommended Connector | |
|-----------------------------|---|
| DDK's 17JE-23090-02(D8C)-CG | D-sub 9-pin, male, inch screw thread, with hood, RoHS compliant |

Applicable Devices

| Applicable Devices |
|--|
| PLC, temperature controller, inverter, servo, barcode reader |

1.2.2 MJ1/MJ2

The MJ1 and MJ2 ports support communication via RS-232C, RS-485 (2-wire system), and RS-422 (4-wire system, only with MJ2).


MJ1 is also usable as a screen program transfer port.

CAUTION

- MJ1 and MJ2 use the same type RJ-45 connector as the LAN connector.
To prevent damage to the device from an external power supply of the MJ, check the indication on the unit and insert a cable in the correct position.
- Only MJ2 supports RS-422 (4-wire system). MJ1 is not usable for connection via RS-422 (4-wire system). Use a commercially available RS-232C-to-RS-422 converter.

Pin Arrangement

MJ1

| MJ1 RJ-45 8pin | No. | Signal | Contents |
|---|-----|--------|--|
|  | 1 | +SD/RD | RS-485 + data |
| | 2 | –SD/RD | RS-485 – data |
| | 3 | +5V | Externally supplied +5 V ^{*1*2} |
| | 4 | | |
| | 5 | SG | Signal ground |
| | 6 | | |
| | 7 | RD | RS-232C receive data |
| | 8 | SD | RS-232C send data |


*1 Only available with TS2060i. The externally supplied +5 V signal is not output with the TS2060 (model name without "i").

*2 For MJ1 and MJ2, the maximum allowable current is 150 mA in total (only when the installation angle of MONITOUCH is within 60° to 120°).

MJ2

CAUTION

Before using MJ2, select whether it is used as an RS-232C/RS-485 (2-wire system) or RS-422 (4-wire system) port using the slide switch.
The switch is factory-set to RS-232C/RS-485 (2-wire system).

| MJ2 RJ-45 8-pin | No. | Slide Switch (RS-232C/RS-485) | | Slide Switch (RS-422) | |
|---|-----|-------------------------------|---|-----------------------|---|
| | | Signal | Contents | Signal | Contents |
|  | 1 | +SD/RD | RS-485 + data | +SD | RS-422 + send data |
| | 2 | –SD/RD | RS-485 – data | –SD | RS-422 – send data |
| | 3 | +5 V | Externally supplied +5 V ^{*1*2} Max. 150 mA | +5V | Externally supplied +5 V ^{*1*2} Max. 150 mA |
| | 4 | | | | |
| | 5 | SG | Signal ground | SG | Signal ground |
| | 6 | | | | |
| | 7 | RD | RS-232C receive data | +RD | RS-422 + receive data |
| | 8 | SD | RS-232C send data | –RD | RS-422 – receive data |


*1 Only available with TS2060i. The externally supplied +5 V signal is not output with the TS2060 (model name without "i").

*2 For MJ1 and MJ2, the maximum allowable current is 150 mA in total (only when the installation angle of MONITOUCH is within 60° to 120°).

Recommended Cable


| Recommended Cable |
|--|
| Hakko Electronics' cable "V6-TMP" 3, 5, 10 m |

Notes on Configuring a Cable


**CAUTION**

Pins No. 3 and 4 are provided for external power supply. To prevent damage to the device due to wrong connection, check the pin numbers and connect wires correctly.

Pin arrangement
on MONITOUCH



Pin arrangement
on the cable



Applicable Devices

| Port | Applicable Devices |
|------|--|
| MJ1 | Computer (screen program transfer) |
| | PLC, temperature controller, inverter, servo, barcode reader, V-Link, slave communication (Modbus RTU), serial printer |
| MJ2 | PLC, temperature controller, inverter, servo, barcode reader, V-Link, slave communication (Modbus RTU), serial printer |

1.2.3 LAN (TS2060i Only)


CAUTION

- Only the TS2060i is equipped with a LAN connector. Ethernet communication is not possible with the TS2060 (model name without "i").
- The LAN/LAN2 connector uses the same type RJ-45 connector as MJ1 and MJ2. Check the indication on the unit and insert a cable into the correct position.

LAN Port Specifications

| Item | Specifications | |
|---------------------------------------|--|----------------------|
| | 100BASE-TX (IEEE802.3u) | 10BASE-T (IEEE802.3) |
| Baud Rate | 100 Mbps | 10 Mbps |
| Transmission method | Base band | |
| Maximum segment length | 100 m (between the node and the hub, or between hubs) | |
| Connecting cable | 100 Ω, UTP cable, category 5 | |
| Protocol | UDP/IP, TCP/IP | |
| Port | Auto-MDIX, Auto-Negotiation functions compatible | |
| Number of concurrently opened ports | 8 ports | |
| Maximum number of connectable devices | UDP/IP: 256 units via each of ports PLC1 to PLC8 TCP/IP: 64 units in total via ports PLC1 to PLC8 | |

Maximum number of connectable devices



Pin Arrangement

| LAN RJ-45 | No. | Name | Contents |
|-----------|-----|------|------------------|
| | 1 | TX+ | Send signal + |
| | 2 | TX- | Send signal - |
| | 3 | RX+ | Receive signal + |
| | 4 | NC | Not used |
| | 5 | | |
| | 6 | RX- | Receive signal - |
| | 7 | NC | Not used |
| | 8 | | |

Applicable Devices

| Applicable Devices |
|--|
| PLC, slave communication (Modbus TCP/IP), computer (screen program transfer, etc.) |

1.2.4 EXT1 (Connection Port for Network Communication Unit/Optional Unit, TS2060i Only)



CAUTION



This communication port is supported only by the TS2060i. The "CUR-xx" and "DUR-00" cannot be attached to the TS2060 (model name without "i").

This communication port is used by connecting an optional communication interface unit "CUR-xx" or "DUR-00". For more information on network communication, refer to the specifications for each unit.

| Unit Model | Network | Unit Model | Network |
|------------|--|------------|-----------------------------------|
| CUR-00 | OPCN-1 | CUR-06 | SX BUS |
| CUR-01 | T-Link | CUR-07 | DeviceNet |
| CUR-02 | CC-Link Ver. 2.00/1.10/1.00 | CUR-08 | FL-net |
| CUR-03 | Ethernet (UDP/IP) * TCP/IP communication not possible | DUR-00 | Serial (CN1: RS-232C, RS-422/485) |
| CUR-04 | PROFIBUS-DP | | |

1.2.5 USB

USB Port Specifications

| Item | Specifications | |
|---|----------------------|---|
| USB-A ^{*1}  | Applicable standards | USB versions 2.0 |
| USB mini-B  | Baud Rate | High-speed 480 Mbps / Full-speed 12 Mbps / Low-speed 1.5 Mbps |

*1 Only available with TS2060i. The TS2060 (model name without "i") is not equipped with a USB-A port.


Applicable Devices

| Port | Applicable Devices |
|---------------------|--|
| USB-A ^{*1} | Printer (PR201, ESC/P-compatible (parallel connection)), barcode reader, USB flash drive, numeric keypad, keyboard, mouse, USB-hub |
| USB mini-B | Printer (PictBridge), computer (screen program transfer) |

*1 Only available with TS2060i. The TS2060 (model name without "i") is not equipped with a USB-A port.

1.2.6 DIP Switch (DIPSW) Settings

The TS2060 is equipped with DIP switches 1 to 8. When setting the DIP switch, turn the power off.



DIPSW1* (Storage Automatic Upload)

Set the DIPSW1 to ON when automatically uploading screen programs from storage such as an SD card or USB flash drive. For details, refer to the separate TS2060 Hardware Specifications manual.

* Be sure to set the DIPSW1 to OFF when automatic upload is not performed.

DIPSW4, 5 (Terminating Resistance for MPI/PPI Communication with Siemens PLC)

When connecting a Siemens PLC via MPI/PPI communication, set the DIPSW4 and DIPSW5 to ON.


DIPSW6, DIPSW7, and DIPSW8 (Terminating Resistance for Serial Communication)

- When connecting a controller at MJ1 via RS-422/485 (2-wire system), set the DIPSW6 to ON.
- When connecting a controller at MJ2 via RS-422/485 (2-wire system), set the DIPSW8 to ON.
- When connecting a controller at MJ2 via RS-422/485 (4-wire system), set the DIPSW7 and DIPSW8 to ON.

TS2060i with DUR-00

- When connecting a controller at CN1 via RS-422/485 (2-wire system), set DIPSW1 on the DUR-00 to the ON position.
- When connecting a controller at CN1 via RS-422/485 (4-wire system), set DIPSW1 and DIPSW2 on the DUR-00 to the ON position.
- DUR-00 DIP switches

Settings upon delivery (all OFF)



1.3 Connection Methods

1.3.1 Serial Communication

1 : 1 Connection

Overview

- One set of the TS2060 is connected to one PLC (1 : 1 connection).
- You can make settings for 1 : 1 communication in [Communication Setting] for the logical ports PLC1 - PLC8. A communication port is selectable from CN1 *, MJ1, and MJ2.

* CN1 is available only when the TS2060i is attached the "DUR-00".



RS-232C or RS-422 (RS-485) connection


Maximum length of wiring

RS-232C connection: 15 m

RS-422/RS-485 connection: 500 m

* The maximum length of wiring varies depending on the connected device. Check the specifications for each device.

- The TS2060 (master station) communicates with a PLC under the PLC's protocol. Therefore, there is no need to prepare a communication program for the PLC (slave station).
- The TS2060 reads from the PLC device memory for screen display. It is also possible to write switch data or numerical data entered through the keypad directly to the PLC device memory.




V-SFT Ver. 6 Settings

Hardware Settings


Selecting a device to be connected

Select the device for connection from [System Setting] → [Hardware Setting].



PLC properties

Configure [Communication Setting] on the [PLC Properties] window.



| Item | Contents |
|-------------------|--|
| Connection Mode | 1 : 1 |
| Signal Level | Configure according to the connected device. |
| Baud Rate | |
| Data Length | |
| Stop Bit | |
| Parity | |
| Target Port No. | |
| Transmission Mode | |

For settings other than the above, see “1.4 Hardware Settings” (page 1-50).

Settings of a Connected Device

Refer to the chapter of the respective manufacturer.
For descriptions of connecting PLCs, refer to the manual for each PLC.

Wiring



Be sure to turn off the power before connecting cables. Otherwise, electrical shock or damage may occur.


CN1




- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C connection

- Prepare a communication cable on your side. Twisted pairs of 0.3 mm sq. or above are recommended.
- The maximum length for wiring is 15 m.
 - * The maximum length varies depending on the connected device. Check the specifications for each device.
- Connect a shielded cable to either the TS2060i or the connected device. The connection diagram shows the case where the shielded cable is connected on the TS2060i side. Connect the cable to the FG terminal of the DUR-00.




- If noise disturbs communications, establish connections between SD and SG and between RD and SG as pairs respectively, and connect a shielded cable to both the TS2060i and the connected device.




RS-422/RS-485 connection


- Prepare a communication cable on your side. Twisted pairs of 0.3 mm sq. or above are recommended.
- The maximum length of wiring is 500 m.
 - * The maximum length varies depending on the connected device. Check the specifications for each device.
- Connect twisted pairs between +SD and –SD, and between +RD and –RD.
- If the PLC has a signal ground (SG) terminal, connect it.
- To use a terminal block for connection, use Hakko Electronics' optionally available "TC-D9".
- The DIP switch on the back of the TS2060i unit is used to set the terminating resistance. For more information on DIP switches, refer to "1.2.6 DIP Switch (DIPSW) Settings" (page 1-10).
- Connect a shielded cable to either the TS2060i or the connected device. The connection diagram shows the case where the shielded cable is connected on the TS2060i side. Connect the cable to the FG terminal of the DUR-00.
 - RS-422 (4-wire system)




- RS-485 (2-wire system)



- If noise disturbs communications, connect a shielded cable to both the TS2060i and the connected device.
 - RS-422 (4-wire system)



- RS-485 (2-wire system)




MJ1/MJ2

RS-232C connection




Set the slide switch for signal level selection to RS-232C/485 position (upper) when using the MJ2 port.

- Use Hakko Electronics' cable "V6-TMP" (3, 5, 10 m) as a communication cable.
- The maximum length of wiring is 15 m.
 - * The maximum length varies depending on the connected device. Check the specifications for each device.
- Connect a shielded cable to either the TS2060 or the connected device. Connect the cable to the FG terminal for communication on the backside of the TS2060.




- If noise disturbs communications, connect a shielded cable to both the TS2060 and the connected device.




RS-485 (2-wire system) connection**CAUTION**

Set the slide switch for signal level selection to RS-232C/485 position (upper) when using the MJ2 port.

- Use Hakko Electronics' cable "V6-TMP" (3, 5, 10 m) as a communication cable.
- The maximum length of wiring is 500 m.
 - * The maximum length varies depending on the connected device. Check the specifications for each device.
- If the PLC has a signal ground (SG) terminal, connect it.
- The DIP switch on the back of the TS2060 unit is used to set the terminating resistance. For more information, see "1.2.6 DIP Switch (DIPSW) Settings" (page 1-10).
- Connect a shielded cable to either the TS2060 or the connected device. Connect the cable to the FG terminal for communication on the backside of the TS2060.




- If noise disturbs communications, connect a shielded cable to both the TS2060 and the connected device.



RS-422 (4-wire system) connection


RS-422 (4-wire system) is supported by the MJ2 port only. Set the slide switch for signal level selection to RS-422 position (lower). The MJ1/MJ2 ports except these units are not usable for connection via RS-422 (4-wire system).

- Use Hakko Electronics' cable "V6-TMP" (3, 5, 10 m) as a communication cable.
- The maximum length of wiring is 500 m.
 - * The maximum length varies depending on the connected device. Check the specifications for each device.
- If the PLC has a signal ground (SG) terminal, connect it.
- The DIP switch on the back of the TS2060 unit is used to set the terminating resistance. For more information, see "1.2.6 DIP Switch (DIPSW) Settings" (page 1-10).
- Connect a shielded cable to either the TS2060 or the connected device. Connect the cable to the FG terminal for communication on the backside of the TS2060.



* Slide switch: RS-422 (lower)

- If noise disturbs communications, connect a shielded cable to both the TS2060 and the connected device.




* Slide switch: RS-422 (lower)

1 : n Connection (Multi-drop)

Overview

- Multi-drop connection connects one TS2060 unit to multiple PLCs of the same model as a 1 : n connection. (Maximum connectable units: 31)
- You can make settings for 1 : n communication in [Communication Setting] for the logical ports PLC1 - PLC8. A communication port is selectable from CN1 *, MJ1, and MJ2.
 - * CN1 is available only when the TS2060i is attached the "DUR-00".




- The ladder transfer function is not available for a 1 : n connection.
- For models that support multi-drop connection, refer to the Connection Compatibility List provided at the end of this manual or the chapters on individual manufacturers.

V-SFT Ver. 6 Settings

Hardware Settings


Selecting a device to be connected

Select the device for connection from [System Setting] → [Hardware Setting].



PLC properties

Configure [Communication Setting] on the [PLC Properties] window.




| Item | Contents |
|-------------------|--|
| Connection Mode | 1 : n |
| Signal Level | RS-422/485 |
| Baud Rate | Configure according to the connected device. |
| Data Length | |
| Stop Bit | |
| Parity | |
| Target Port No. | |
| Transmission Mode | |

For settings other than the above, see “1.4 Hardware Settings” (page 1-50).

Settings of a Connected Device


Refer to the chapter of the respective manufacturer.
For descriptions of connecting PLCs, refer to the manual for each PLC.

Wiring

**DANGER**

Be sure to turn off the power before connecting cables. Otherwise, electrical shock or damage may occur.

CN1


**CAUTION**

- The CN1 port is available only when the TS2060i is attached the optional “DUR-00”.
- The “DUR-00” cannot be attached to the TS2060 (model name without “i”). Use the MJ1 and MJ2 ports for connection.

The wiring between a TS2060i and a connected device is the same as that for 1 : 1 communication. For description of wiring between connected devices, refer to the manuals issued by the manufacturers.


RS-422 (4-wire system) connection

- Connection example



RS-485 (2-wire system) connection

- Connection example




MJ1/MJ2

The wiring between a TS2060 and a connected device is the same as that for 1 : 1 communication. For description of wiring between connected devices, refer to the manuals issued by the manufacturers.

RS-485 (2-wire system) connection

- Connection example




- * Set the slide switch for signal level selection to RS-232C/485 position (upper) when using the MJ2 port.

n : 1 Connection (Multi-link2)


Overview

- One PLC is connected to a maximum of four TS2060 units. The V9 and V8 series can be used together.
- Multi-link2 enables you to establish an original network consisting of a master TS2060 of local port No. 1 and slave TS2060 units of local port Nos. 2, 3, and 4. The master TS2060 communicates with the PLC directly, and the slave TS2060 units communicate with the PLC through the master.

- Connection example 1:



- Connection example 2:




- You can make settings for multi-link2 in [Communication Setting] for PLC1. Therefore, multi-link2 connection is not possible concurrently with a network connection that uses a "CUR-xx" communication interface unit (under development).
- Multi-link2 enables sharing of data stored in PLC1 device memory among the TS2060 units. However, sharing data in PLC2 - PLC8 is not possible.
- The V7 and V6 series cannot be used together.
 - * The V7 and V6 series can also be used together with certain PLC models. For details, see "Multi-link2 with V7/V6" (page 1-23).
- The communication speed between the master and the PLC depends on the setting made on the PLC. The maximum communication speed between TS2060 units is 115 kbps, which is higher than the one available with multi-link connection described in "n : 1 Connection (Multi-link)".
- For PLCs that support multi-link2 connection, see Connection Compatibility List provided at the end of this manual. The connection between the master and the PLC is the same as the one for 1 : 1 connection. RS-485 (2-wire system) connection is adopted to connect a master with slaves. At this time, use Hakko Electronics' cable "V6-MLT" for the multi-link2 master.
- If the master station becomes faulty (communication error), the master and slave stations do not work, and as a result, "Communication Error Time-Out" is displayed. If a slave station becomes faulty, a communication error is occurred only on the faulty station.
- The ladder transfer function is not available for a multi-link2 connection.
- Settings must be made in order to use together with the V9 series.
Location of setting: [Hardware Setting] → [PLC Properties] → [Detail] → [Multi-link 2 with V9]

V-SFT Ver. 6 Settings

Make settings on [System Setting] → [Hardware Setting] → [PLC Properties]. The differences with respect to a 1 : 1 connection and the points where caution is required are explained here.

For details on other settings, refer to Hardware Settings in “1 : 1 Connection” (page 1-11).

PLC Properties




| Item | | Contents |
|-----------------------|------------------------|--|
| Communication Setting | Connection Mode | Multi-link2 |
| | Multi-link2 | Click [Setting] to display the [Multi-link] dialog, then make the necessary settings in this dialog. For more information on settings, see “Multi-link2” (page 1-22). |
| Detail | Multi-link2 with V7/V6 | Select this when multi-link2 is used for connecting the TS2060 together with V7 or V6 units. For more information, see “Multi-link2 with V7/V6” (page 1-23). |
| | Multi-link2 with V9 | Select this when multi-link2 is used for connecting the TS2060 together with V9 units. |

Multi-link2

For a master, set all of the items. For a slave, set only those items marked “♦”.

• Master

• Slave

| | |
|------------------------|--|
| Local Port No. ♦ | 1 to 4 Specify a port number of the TS2060. For the master set “1”, and for the slaves set “2” to “4”. Note that if the port number specified is the same as that already set for another TS2060 unit, the system will not operate correctly. |
| Send Delay Time | Specify a delay time that elapses before the TS2060 sends the next command after receiving data from the PLC. Normally use the default setting (0).  |
| Total ♦ | 2 to 4 Set the total number of TS2060 units connected in the multi-link2 connection. The setting must be the same as other TS2060 on the same communication line. |
| Retry Cycle | Set the number of cycles before the master sends an inquiry for restoration to a slave that has a communication problem (= system down). When a slave has a problem, it is temporarily removed from the communication targets, and the master sends an inquiry for restoration every number of cycles specified for [Retry Cycle]. This setting does not affect the communication speed if no problem is occurring on the slave; however, if there is any problem, it does affect the communication speed. When the setting value is small: Restoration will not take long. When the setting value is large: Restoration will take a longer time. |
| Multi-Link Baud Rate ♦ | 4800/9600/19200/38400/57600/115K bps Set the baud rate for between TS2060 units. The setting must be the same as other TS2060 on the same communication line. |
| Connect Port | CN1/MJ1/MJ2 Set the port to be connected to slaves. |

Multi-link2 with V7/V6

- The V9 series cannot be used together if the V7 and V6 series are used together.
- When connecting together with the V6 series, note the following points:
 - When V609E, V606e, V606, or V606i is connected as a master, only V609E, V606e, V606, or V606i can be connected as a slave.
The TS2060 cannot be used as a slave in this case.
 - Multi-link2 cannot be used for the V6 series with which temperature control network/PLC2Way is used.
 - The V6 series may not support Multi-link2 connection depending on its hardware version. For more information, refer to the V6 Series Hardware Specifications manual.

Supported PLC Models


PLC models that support connection together with the V7 and V6 series are listed below.

| Manufacturer | PLC Selection on Editor |
|---------------------|---|
| MITSUBISHI ELECTRIC | A series link A series CPU QnA series link QnA series CPU QnH (Q) series link QnH (Q) series CPU QnU series CPU Q00J/00/01 CPU QnH (Q) series link (multi CPU) QnH (Q) series CPU (multi CPU) FX series CPU FX2N/1N series CPU FX1S series CPU FX series link (A protocol) FX3U/3UC/3G series CPU FX3U/3UC/3G series link (A protocol) |
| OMRON | SYSMAC C SYSMAC CV SYSMAC CS1/CJ1 |
| GE Fanuc | 90 series (SNP-X) |
| Keyence | KV-700 KV-1000 KV-3000/5000 |

System Configurations and Wiring Diagrams


Connection Method 1

Connecting the MJ1/MJ2 of the master to the MJ1/MJ2 ports of the slaves



- (a) Connection between master and PLC
Select the port for connection from among CN1, MJ1 and MJ2.
The communication settings and connection method are the same as those for 1 : 1 connection.
- (b) Connection between master and terminal block
Choose the connecting port of the master between MJ1 and MJ2.
For the cable, use "V6-MLT" (3 m). Connect the terminals of this cable to a terminal block prepared by the customer.
- (c) Connection between terminal block and slave
Choose the connecting port of the slave between MJ1 and MJ2.
Use the "V6-MLT" cable (3 m).
- (d) Connection between terminal blocks
Use the RS-485 (2-wire system) connection. Use twisted-pair cables of 0.3 mm sq or greater.
- (b), (c), (d) The maximum length of the wiring between the master and slave is 500 m.


Wiring diagram



* For MJ2, set the slide switch for changing signals to RS-232C/485 (up position).

Connection Method 2


Connecting the MJ1/MJ2 of the master to CN1 connectors of the slaves



- (a) Connection between master and PLC
Select the port for connection from among CN1, MJ1 and MJ2.
The communication settings and connection method are the same as those for 1 : 1 connection.
- (b), (c) Connection between master and slave
Choose the connecting port of the master between MJ1 and MJ2.
The connecting port of the slave should be CN1. It is convenient to install the optional terminal converter "TC-D9".
Use the "V6-MLT" cable (3 m). If the distance is greater than 3 meters the customer should prepare a terminal block and extension cable (c), and should make the connection through that terminal block.
- (d), (e) Connection between slaves
Use the RS-485 (2-wire system) connection. It is convenient to install the optional terminal converter "TC-D9". Use twisted-pair cables of 0.3 mm sq or greater.
- (b), (c), (d), (e) The maximum length of the wiring among the master and slave is 500 m.


Wiring diagrams

- When a TC-D9 is used:
Set the slide switch of "TC-D9" to ON (2-wire system).



- * As a measure against noise, connect the frame ground terminal of each TS2060 at one side only. The frame ground of V6-MLT must be connected to the TS2060.
- * Set the slide switch for signal level selection to RS-232C/485 position (upper) when using the MJ2 port.


- When no TC-D9 is used:
Install jumpers between +SD and +RD as well as -SD and -RD.



- * As a measure against noise, connect the frame ground terminal of each TS2060 at one side only. The frame ground of V6-MLT must be connected to the TS2060.
- * Set the slide switch for signal level selection to RS-232C/485 position (upper) when using the MJ2 port.

Connection Method 3

Connecting the CN1 of the master to the MJ1/MJ2 of the slaves



(a) Connection between master and PLC

Choose the connection port between MJ1 and MJ2.

The communication settings and connection method are the same as those for 1 : 1 connection.

(b), (d), (e) Connection between master and terminal block

For the connecting port of the master, choose CN1. For the slave, choose between MJ1 and MJ2.

Use the RS-485 (2-wire system) connection. Use twisted-pair cables of 0.3 mm sq or greater. The maximum length of the wiring is 500 m.


(c) Connection between terminal block and slave

The connecting port of the slave should be MJ1 or MJ2.


Use the "V6-MLT" cable (3 m).

Wiring diagrams

- When a TC-D9 is used:
Set the slide switch of "TC-D9" to ON (2-wire system).




- When no TC-D9 is used:
Install jumpers between +SD and +RD as well as –SD and –RD.



* Set the slide switch for signal level selection to RS-232C/485 position (upper) when using the MJ2 port.

Connection Method 4

Connecting the CN1 of the master to the CN1s of the slaves



(a) Connection between master and PLC

Choose the connection port between MJ1 and MJ2.


The communication settings and connection method are the same as those for 1 : 1 connection.

(b), (c), (d) Connection between master and slave

Use the RS-485 (2-wire system) connection. It is convenient to install the optional terminal converter "TC-D9". Use twisted-pair cables of 0.3 mm sq or greater. The maximum length of the wiring is 500 m.


Wiring diagrams

- When a TC-D9 is used:
Set the slide switch of "TC-D9" to ON (2-wire system).



* As a measure against noise, connect the frame ground terminal of each TS2060i at one side only.


- When no TC-D9 is used:
Install jumpers between +SD and +RD as well as -SD and -RD.



* As a measure against noise, connect the frame ground terminal of each TS2060i at one side only.


Terminating Resistance Setting

The terminating resistance should be set using the DIP switch.




When the PLC is connected to the master via RS-232C:

There is no terminating resistance setting for communications between the master and the PLC. Set terminating resistances for connections between TS2060 units.



When the PLC is connected to the master via RS-485:

Make terminating resistance settings for communications between the master and PLC, and between TS2060 units.




n : 1 Connection (Multi-link2 (Ethernet)) (TS2060i Only)

Overview

- One PLC is connected to a maximum of 32 TS2060i units. The V9 and V8 series can be used together.
- Multi-link2 (Ethernet) enables you to establish an original network consisting of a master TS2060i of local port No. 1 and slave TS2060i units of local port Nos. 2 to 32. The master TS2060i communicates with the PLC directly, and the slave TS2060i units communicate with the PLC through the master.

- Connection example




- You can make settings for multi-link2 (Ethernet) in [Communication Setting] for PLC1. Therefore, multi-link2 connection is not possible concurrently with a network connection that uses a "CUR-xx" communication interface unit.
- Multi-link2 (Ethernet) enables sharing of data stored in PLC1 device memory among the TS2060i units. However, sharing data in PLC2 - PLC8 is not possible.
- The V7 and V6 series cannot be used together.
- The communication speed between the master station and the PLC depends on the setting made on the PLC; however, communication among TS2060i units is performed via Ethernet, thus, high-speed communication is possible among them.
- For PLCs that support multi-link2 (Ethernet) connection, see Connection Compatibility List provided at the end of this manual.
The connection between the master and the PLC is the same as the one for 1 : 1 connection.
Ethernet connection is adopted to connect a master with slaves.
- If the master station becomes faulty (communication error), the master and slave stations do not work, and as a result, "Communication Error Time-Out" is displayed. If a slave station becomes faulty, a communication error is occurred only on the faulty station.
- The ladder transfer function is not available for a multi-link2 (Ethernet) connection.


V-SFT Ver. 6 Settings

Make settings on [System Setting] → [Hardware Setting] → [PLC Properties]. The differences with respect to a 1 : 1 connection and the points where caution is required are explained here.

For details on other settings, refer to Hardware Settings in “1 : 1 Connection” (page 1-11).

PLC Properties



| | Item | Contents |
|------------------------|------------------------------|---|
| Communication Setting | Connection Mode | Multi-link2 (Ethernet) |
| | Local Port No. | 1: Master 2 to 32: Slave * Note that if the port number specified is the same as that already set for another TS2060 unit, the system will not operate correctly. |
| | Send Delay Time | Specify a delay time that elapses before the TS2060 sends the next command after receiving data from the PLC. Normally use the default setting (0).  |
| | Total | 2 to 32 Set the total number of TS2060 units connected in the multi-link2 (Ethernet) connection. The setting must be the same as other TS2060 on the same communication line. |
| | Retry Cycle | Valid only when the local port is “1” (master). Set the number of cycles before the master sends an inquiry for restoration to a slave that has a communication problem (= system down). When a slave has a problem, it is temporarily removed from the communication targets, and the master sends an inquiry for restoration every number of cycles specified for [Retry Cycle]. This setting does not affect the communication speed if no problem is occurring on the slave; however, if there is any problem, it does affect the communication speed. When the setting value is small: Restoration will not take long. When the setting value is large: Restoration will take a longer time. |
| | LAN Port No. | Set a value in the range from 1024 to 65535 (excluding 8001 and 8020). Default: 64000 * Set the same port number for all master and slave stations. |
| | Connection Port | LAN Set a local port number for master or slave connection. |
| Multi-link2 (Ethernet) | Multi-link2 (Ethernet) Table | Click [Setting] to display the [Multi-link2 (Ethernet) Table] window. For details on settings, refer to the next section. |

Multi-link2 (Ethernet) table

• Master

| No. | IP Address |
|-----|--------------|
| 1 | 192.168.1.2 |
| 2 | 192.168.1.3 |
| 3 | 192.168.1.4 |
| 4 | 192.168.1.5 |
| 5 | 192.168.1.6 |
| 6 | 192.168.1.7 |
| 7 | 192.168.1.8 |
| 8 | 192.168.1.9 |
| 9 | 192.168.1.10 |
| 10 | 192.168.1.11 |
| 11 | 192.168.1.12 |
| 12 | 192.168.1.13 |
| 13 | |

Station number

Close

• Slave

| No. | IP Address |
|-----|-------------|
| 1 | 192.168.1.1 |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
| 6 | |
| 7 | |
| 8 | |
| 9 | |
| 10 | |
| 11 | |
| 12 | |
| 13 | |

Station number

Close

| Item | Contents |
|------------------------------|---|
| Multi-link2 (Ethernet) Table | <ul style="list-style-type: none">For local port 1 (master) Set the IP addresses of all TS2060 units used as slave to respective local port numbers.For local port 2 to 32 (slave) Set the IP address of the master TS2060i for No. 1. |


Wiring

The connection between the master and the PLC is the same as the one for 1 : 1 connection. Refer to "Wiring" (page 1-13) in "1 : 1 Connection".
Use a LAN cable to connect a master with slaves.

n : n Connection (1 : n Multi-link2 (Ethernet)) (TS2060i Only)

Overview

- A maximum of 32 units of TS2060i can be connected to a maximum of 31 units of PLCs. The V9 and V8 series can be used together.
- Multi-link2 (Ethernet) enables you to establish an original network consisting of a master TS2060i of local port No. 1 and slave TS2060i units of local port Nos. 2 to 32. The master TS2060i communicates with the PLC directly, and the slave TS2060i units communicate with the PLC through the master.





- You can make settings for 1 : n multi-link2 (Ethernet) in [Communication Setting] for PLC1. Therefore, multi-link2 connection is not possible concurrently with a network connection that uses a "CUR-xx" communication interface unit.
- 1 : n multi-link2 (Ethernet) enables sharing of data stored in PLC1 device memory among the TS2060i units. However, sharing data in PLC2 - PLC8 is not possible.
- The V7 and V6 series cannot be used together.
- The communication speed between the master station and the PLC depends on the setting made on the PLC; however, communication among TS2060i units is performed via Ethernet, thus, high-speed communication is possible among them.
- For PLCs that support 1 : n multi-link2 (Ethernet) connection, see Connection Compatibility List provided at the end of this manual.
The connection between the master and the PLC is the same as the one for 1 : n connection.
Ethernet connection is adopted to connect a master with slaves.
- If the master station becomes faulty (communication error), the master and slave stations do not work, and as a result, "Communication Error Time-Out" is displayed. If a slave station becomes faulty, a communication error is occurred only on the faulty station.
- The ladder transfer function is not available for a 1 : n multi-link2 (Ethernet) connection.

V-SFT Ver. 6 Settings

Make settings on [System Setting] → [Hardware Setting] → [PLC Properties]. The differences with respect to a 1 : n connection and the points where care is required are explained here.
For details on other settings, refer to “Hardware Settings” (page 1-18) in “1 : n Connection (Multi-drop)”.


PLC Properties




| Item | | Contents |
|------------------------|------------------------------|---|
| Communication Setting | Connection Mode | 1 : n Multi-link2 (Ethernet) |
| Multi-link2 (Ethernet) | Local Port No. | 1: Master 2 to 32: Slave * Note that if the port number specified is the same as that already set for another TS2060i unit, the system will not operate correctly. |
| | Send Delay Time | Specify a delay time that elapses before the TS2060i sends the next command after receiving data from the PLC. Normally use the default setting (0).  |
| | Total | 2 to 32 Set the total number of TS2060i units connected in the multi-link2 (Ethernet) connection. The setting must be the same as other TS2060i on the same communication line. |
| | Retry Cycle | Valid only when the local port is "1" (master). Set the number of cycles before the master sends an inquiry for restoration to a slave that has a communication problem (= system down). When a slave has a problem, it is temporarily removed from the communication targets, and the master sends an inquiry for restoration every number of cycles specified for [Retry Cycle]. This setting does not affect the communication speed if no problem is occurring on the slave; however, if there is any problem, it does affect the communication speed. When the setting value is small: Restoration will not take long. When the setting value is large: Restoration will take a longer time. |
| | LAN Port No. | Set a value in the range from 1024 to 65535 (excluding 8001 and 8020). Default: 64000 * Set the same port number for all master and slave stations. |
| | Connection Port | LAN Set a local port number for master or slave connection. |
| | Multi-link2 (Ethernet) Table | Click [Setting] to display the [Multi-link2 (Ethernet) Table] window. For details on settings, refer to the next section. |

Multi-link2 (Ethernet) table

• Master



• Slave



| Item | Contents |
|------------------------------|--|
| Multi-link2 (Ethernet) Table | <ul style="list-style-type: none">For local port 1 (master) Set the IP addresses of all TS2060i units used as slave to respective local port numbers.For local port 2 to 32 (slave) Set the IP address of the master TS2060i for No. 1. |

Wiring

The connection between the master and the PLC is the same as the one for 1 : n connection. Refer to “Wiring” (page 1-19) in “1 : n Connection (Multi-drop)”.


Use a LAN cable to connect a master with slaves.

n : 1 Connection (Multi-link)


Overview

- One PLC is connected to a maximum of 31 TS2060 units. Connection together with V8, V7, and V6 units is possible. Connection together with V9 units is not.

- Connection example 1:



- Connection example 2:



You can make settings for multi-link at the PLC1. Therefore, multi-link connection is not possible concurrently with a network connection that uses a "CUR-xx" communication interface unit. A physical port is selectable from CN1, MJ1, and MJ2.


- Only a PLC [Signal Level: RS422/RS485] and with a port number set. RS-485 (2-wire system) connection is adopted to connect a V-series unit and a PLC. For available models, see Connection Compatibility List provided at the end of this manual.
- Use twisted-pair cables of 0.3 mm sq. or greater between terminal blocks.
- The ladder transfer function is not available for a multi-link connection.

V-SFT Ver. 6 Settings

Make settings on [System Setting] → [Hardware Setting] → [PLC Properties]. The differences with respect to a 1 : 1 connection and the points where care is required are explained here.


For details on other settings, refer to Hardware Settings in “1 : 1 Connection” (page 1-11).


PLC Properties



| Item | | Contents |
|-----------------------|-----------------|---|
| Communication Setting | Connection Mode | Multi-link |
| | Multi-link | Display the [Multi-link] dialog by pressing the [Setting] button, then make the necessary settings in this dialog. For more information on settings, see “Multi-link” (page 1-38). |

Multi-link



| Item | Contents |
|---------------------------------|---|
| Local Port No. | 1 to 32 Specify a port number of the TS2060. * Note that if the port number specified is the same as that already set for another TS2060 unit, the system will not operate correctly. |
| Send Delay Time ^{*1} | 0 to 255 msec (Default setting: 20 msec) Specify a delay time that elapses before the TS2060 sends the next command after receiving data from the PLC.  |
| Total ^{*1} | 2 to 32 Set the maximum number of TS2060 units to be connected in multi-link connection. ^{*2} |
| Retry Cycle ^{*1} | 1 to 100 (× 10) When the TS2060 has a problem, it is temporarily removed from the communication targets, and the master sends an inquiry for restoration every number of cycles specified for [Retry Cycle]. This setting does not affect the communication speed if no problem is occurring; however, if there is any problem, it does affect the communication speed. When the setting value is small: Restoration will not take long. When the setting value is large: Restoration will take a longer time. |
| Set Local Port No. in Main Menu | Select this checkbox to set the local port number on the Main Menu screen of the TS2060. |


^{*1} For [Send Delay Time], [Total] and [Retry Cycle], the same values must be set on all the TS2060 that are connected in the same communication line.

^{*2} When connecting three units with the local port numbers 1, 2 and 10, specify “10” for [Total].


Settings on MONITOUCH

When [Set Local Port No. in Main Menu] is selected in the [Multi-link] window, the local port number must be set on the Main Menu screen of the TS2060.


1. Transfer the screen program.
2. Press [SYSTEM] and then the [F1] function switch on MONITOUCH to display the Main Menu screen.
3. Press the [Editor: MJ1] switch and the [F5] function switch at the same time.
The Extended Function Setting screen is displayed.



4. Select the [Local Port No.] menu using the upper [Up] and [Down] switches (No. 1 in the figure below), and then specify the local port number using the [Up] and [Down] switches on the right (No. 2 in the figure below).



5. Press the [Setting Finished] switch to confirm the setting.



* For more information, refer to the TS2060 Hardware Specifications manual.

The local port number specified here is commonly used for V-Link, Modbus slave and Multi-link communications. Set a number within the range of these communications.

- V-Link: 1 to 254
- Modbus slave: 1 to 31
- Multi-link: 1 to 32

Wiring


When Connected at CN1:




- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

This shows the situation when a multi-link connection is made at CN1. It is convenient to use the Hakko Electronics' optional terminal converter "TC-D9".

- When a TC-D9 is used:
Set the slide switch of "TC-D9" to ON (2-wire system).




- When no TC-D9 is used:
Install jumpers between +SD and +RD as well as -SD and -RD.




When connecting to Mitsubishi Electric's QnA CPU:

Use the GD port of Hakkō Electronics' optional dual port interface V-MDD for the PLC CPU port.

- When a TC-D9 is used:
Set the slide switch of "TC-D9" to ON (2-wire system).




- When no TC-D9 is used:
Install jumpers between +SD and +RD as well as -SD and -RD.



When Connected at MJ1/MJ2:


This shows the situation when a multi-link connection is made at MJ1 or MJ2.



* Set the slide switch for signal level selection to RS-232C/485 position (upper) when using the MJ2 port.

When connecting to Mitsubishi Electric's QnA CPU:

Use the GD port of Hakko Electronics' optional dual port interface V-MDD for the PLC CPU port.




* Set the slide switch for signal level selection to RS-232C/485 position (upper) when using the MJ2 port.


1.3.2 Ethernet Communication (TS2060i Only)

Overview


- Because eight communication ports can be opened, the TS2060i is allowed to communicate with eight models of PLCs at the same time.



- When there are two or more PLCs of the same model, the TS2060i is allowed to carry out 1 : n communication via one single port.



- If multiple TS2060i units are connected to one single PLC, the maximum permissible number of these units depends on the PLC specifications. Refer to the PLC manual issued by the manufacturer.




- You can make settings for Ethernet communication in [Communication Setting] for the logical ports PLC1 - PLC8.

V-SFT Ver. 6 Settings

Hardware Settings


Selecting a device to be connected

Select the device for connection from [System Setting] → [Hardware Setting].






PLC properties

Configure the [PLC Properties].



| Item | | Contents |
|-----------------------|-----------------|--|
| Communication Setting | Connection Mode | 1:1/1:n Set the number of PLCs that are to be communicated with. |
| | Port No. | Set the port number of the TS2060i to be used for communications with the PLCs. |
| | KeepAlive | <p>This setting is used when using the "KeepAlive" function. The "KeepAlive" function is used for periodically checking the connection with devices on the network. This function enables a prompt detection of a communication error, thus, significantly shortens the time to wait until a "disconnect" process takes place after an occurrence of the time-out error.</p> <p>* When using this function, select [Disconnect] for [Comm. Error Handling].</p> <ul style="list-style-type: none"> [Use KeepAlive] Select [Yes] when using the "KeepAlive" function. The following settings will take effect. <ul style="list-style-type: none"> [Retrials] Specify the number of retries. If a timeout persists even after as many retries as specified, an error handling routine will take place. 0 to 255 Default: 0 [Time-out Time] Specify a period of time allowed for the TS2060i to monitor a response from its connected device. If no response is given within the specified time, retrieval will be made. 1 to 999 (× 10 msec) Default: 30 (× 10 msec) [Checking Cycle] Set the cycle time of "KeepAlive" communication. 1 to 999 (× 10 msec) Default: 10 (× 10 msec) |

| Item | Contents |
|-----------------|--|
| Connect To | <p>These settings are valid when [1 : 1] is selected for [Connection Mode]. Select the IP address of the PLC registered in the PLC table. 1 : 1 communications are executed with the PLC selected here.</p>  |
| Target Settings | <p>Click [Setting] to display the [PLC Table] window. Set the IP address, port number and KeepAlive function of the PLC.</p>  |
| PLC Table |  |

* For settings other than the above, see "1.4 Hardware Settings" (page 1-50).


IP Address Setting of the TS2060i

An IP address must be set for the TS2060i to connect to devices via Ethernet. Set the IP address either on the TS2060i unit or for the screen program using the V-SFT editor.

Setting Using the V-SFT Editor

Set the IP address at [System Setting] → [Hardware Setting] → [Local Port IP Address].

Local port IP address setting



| Item | Contents |
|--------------------------------------|--|
| Select IP Address from Network Table | <p>This is valid when the IP address of the TS2060i has been registered in the network table. Select a network table number from 0 to 255 to set the IP address.</p> <p>* For more information on the network table, refer to "Network table" (page 1-64).</p> |
| IP Address * ¹ | Set the IP address for the TS2060i. |
| Default Gateway * ¹ | Set the default gateway. |
| Subnet Mask * ¹ | <p>Set the subnet mask.</p> <p>When this box is not checked, the subnet mask is automatically assigned based on the byte at the extreme left of the IP address.</p> <p>Example: When IP address is "172.16.200.185", "255.255.0.0" is set. When IP address is "192.168.1.185", "255.255.255.0" is set.</p> |
| Port No. * ¹ | Set a port number from 1024 to 65535. (Excluding 8001 and 8020) |
| Send Timeout | Specify the timeout time to send the EREAD/EWRITE/SEND/MES command. |


| Item | Contents |
|---|---|
| Retrials | 0 to 255 Set the number of retrials to be performed when a time-out occurs. |
| Device Protect Internal Device Memory Card Device | Check either check box to write-protect the device memory from computers or other stations. |

*1 For more information on each setting item, see "Basics of ethernet settings" (page 1-65).


Setting from the Main Menu Screen on MONITOUCH

Set the IP address on the Main Menu screen of MONITOUCH.


- Press [SYSTEM] and then the [F1] function switch on MONITOUCH to display the Main Menu screen.
- Press the [Main Menu] switch to display the drop-down menu. Then press the [Ethernet Information] switch to display the Ethernet Information screen and press the [Ethernet] switch. The Ethernet screen is displayed.



- Press the [EDIT] switch and make the settings.




- Press the [Setting Finished] switch to confirm the setting.




Connection example

With hub



Without hub




Wiring




- Use a commercially available cable. Using a self-made cable may cause an error in network connection.
- If the use of a cross cable cannot stabilize communication, use a hub.

- Straight cable



- Cross cable



1.3.3 Network Communication (TS2060i Only)

Overview

- The optional communication interface unit "CUR-xx" is required to enable a network communication listed below.

| Communication Interface Unit | Network | Available Models | |
|------------------------------|--------------------------------|---|---|
| CUR-00 | OPCN-1 | Mitsubishi Electric OMRON Fuji Electric | A series (OPCN-1) SYSMAC C (OPCN-1) MICREX-SX (OPCN-1) |
| CUR-01 | T-Link | Fuji Electric Fuji Electric | MICREX-F (T-LINK) MICREX SX (T-LINK) |
| CUR-02 | CC-LINK Ver. 2.00/1.10/1.00 | Mitsubishi Electric Mitsubishi Electric Mitsubishi Electric | A series (CC-LINK) QnA series (CC-LINK) QnH (Q) series (CC-LINK) |
| CUR-03 | Ethernet *1 | Various PLCs | Ethernet UDP/IP communication * TCP/IP communication is not supported. |
| CUR-04 | PROFIBUS-DP | Siemens Universal PROFIBUS-DP | S7 PROFIBUS-DP |
| CUR-06 | SX BUS | Fuji Electric | MICREX-SX (SX BUS) |
| CUR-07 | DeviceNet | Universal DeviceNet | |
| CUR-08 | FL-Net | Universal FL-Net | |

*1 In addition to UDP/IP communication with a PLC, screen program transfer, the MES interface function, and TELLUS & V-Server connection can be enabled by connecting a PC. Use the built-in LAN port for TCP/IP communication.

- You can make settings for network communication in [Communication Setting] for the logical port PLC1. Thus, devices available with only PLC1, as those used for multi-link or multi-link2, cannot be connected concurrently for network communication.
- The "CUR-xx" cannot be used when the "DUR-00" is already connected.

V-SFT Ver. 6 Settings

For more information, refer to the communication unit specifications provided for each network.

Wiring


For more information, refer to the communication unit specifications provided for each network.

1.3.4 Slave Communication

Connecting via V-Link, Modbus RTU, or Modbus TCP/IP is applicable to slave communication using the TS2060. V-Link and Modbus RTU are used for serial communication, and Modbus TCP/IP is used for Ethernet (TCP/IP) communication.

V-Link

- "V-Link" is the network where the PC reads from and writes to the internal device memory of the TS2060, memory card device memory, or PLC1 to 8 device memory using a dedicated protocol.



- You can make settings for V-Link communication in [Communication Setting] for the logical ports PLC2 - PLC8. A communication port is selectable from CN1^{*}, MJ1, and MJ2.
 - * CN1 is available only when the TS2060i is attached the "DUR-00".
- For more information, refer to "V-Link" in book 3 of the TS2060 Connection Manual.

MODBUS RTU

- The TS2060 is connected to a Modbus RTU master via serial connection.
- The device memory table for Modbus slave communication is prepared for the TS2060. The master is allowed to gain access to the device memory table and read/write the PLC data.
- For more information, refer to the Modbus Slave Communication Specifications manual separately provided.

MODBUS TCP/IP (TS2060i Only)


- The TS2060i is connected to a Modbus TCP/IP master via Ethernet communication.
- The device memory table for Modbus slave communication is prepared for the TS2060i. The master is allowed to gain access to the device memory table and read/write the PLC data.
- For more information, refer to the Modbus Slave Communication Specifications manual separately provided.

1.3.5 Other Connections

For connection to a serial printer that is not in 8-way communication, serial ports of MJ1 and MJ2 are used.

1.4 Hardware Settings


Select and set the devices to connect to the TS2060 on the Hardware Setting screen.



| | Item | Contents |
|----|-------------------------------------|--|
| 1. | PLC Setting | Set the devices (PLC, temperature controller, servo, inverter, barcode reader etc.) to connect to PLC1 to PLC8. |
| 2. | Connection Diagram | The devices which are set for connection are displayed. Devices as well as communication settings can be changed. |
| 3. | Built-in LAN / Ethernet unit switch | Select the Ethernet connection port on the TS2060i from the internal LAN communication unit. The icon changes each time it is clicked. |
| 4. | PLC Setting / Other Setting switch | Switch between PLC settings and other settings. The icon changes each time it is clicked. |
| 5. | MONITOUCH Settings | Make MONITOUCH settings on the TS2060. |


1.4.1 PLC Settings

To enable communication with a PLC, a temperature controller, an inverter, etc., the following settings are required to be set on the editor. You can see the contents of these settings on the TS2060 Main Menu screen. For information on the Main Menu screen, refer to the TS2060 Hardware Specifications.



Selecting a Device to be Connected


Double-click on a PLC icon in the [Hardware Setting] window to display the window shown below.





| Item | Contents |
|------------------|--|
| Connected Device | Select the device to connect. |
| Maker | Select the maker of the device. |
| Model | Select the model of the device to connect. Refer to the respective chapter of each maker and select the appropriate model. |
| Target Port No. | Select the port to which the device connects to on the TS2060. |

PLC Properties

Click on the PLC icon in [Hardware Setting] to display the window shown below.




| Item | Contents |
|-------------------------------|--|
| Communication Setting | Connection Mode Select a connection mode. 1 : 1 / 1 : n / Multi-link / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) Available options vary, depending on which device is connected. For details, see Connection Compatibility List provided at the end of this manual. |
| | Signal Level* ¹ Select a signal level. RS-232C/RS-422/485 |
| | Baud Rate* ¹ Select a baud rate. 4800/9600/19200/38400/57600/76800/115K/187.5K* bps * Available only when connecting via Siemens S7-200PPI or S7-300/400MPI and CN1. |
| | Data Length* ¹ Select a data length. 7 / 8 bits |
| | Stop Bit* ¹ Select a stop bit. 1 / 2 bits |
| | Parity* ¹ Select an option for parity bit. None / Odd / Even |
| Target Port No.* ¹ | Specify a port number of the connected device. 0 to 31 (Modbus RTU: 1 to 255) |

| Item | | Contents |
|-----------------------|---------------------------------|--|
| Communication Setting | Transmission Mode* ¹ | Select a transmission mode for the connected device. This setting is required if a device of Mitsubishi, Omron, Hitachi Industrial Equipment Systems, Yokogawa, JTEKT, or Yaskawa is in use. |
| | Retrials | Specify the number of retrials to be allowed in the event of a timeout during communication. If a timeout persists even after as many retrials as specified, an error handling routine will take place. 1 to 255 |
| | Time-out Time | Specify a period of time allowed for the TS2060 to monitor a response from its connected device. If no response is given within the specified time, retrial will be made. 0 to 999 (×10 msec) |
| | Send Delay Time | Specify a delay time that elapses before the TS2060 sends the next command after receiving a response from its connected device. Normally use the default setting. 0 to 255 (×1 msec)  |
| | Start Time | Specify a delay time that elapses before the TS2060 starts to send commands upon power-up. If the TS2060 and its connected device are turned on at the same time and the device is slower to start up, set [Start Time]. 0 to 255 (×1 sec) |
| | Code | Select a code for the connected device. The selected option is reflected through the data displayed on graphs or trending sampling parts. DEC/BCD |
| | Text Process | Specify a byte order in text data. This setting is valid for macro commands that handle text. LSB → MSB/MSB → LSB  |
| | Comm. Error Handling | Select an action to be taken in the event of a communication error. <ul style="list-style-type: none"> • [Stop] Communication will be stopped entirely and the communication error screen will be displayed. The [RETRY] switch is available for attempting reestablishment of communication. • [Continue] The communication error message will be displayed at the center of the screen. The same communication will continue until restoration, and screen operation is not allowed then. When communication has been returned to a normal state, the message disappears and screen operation is allowed. • [Disconnect] No error message will appear and communication will proceed to the next one.* However, communication with the device, in which a timeout was detected, will be disconnected. <p>* Internal device memory must be specified for [Read Area] and [Write Area].</p> |
| | Recovery Condition | Use Recovery Time |
| | | Recovery Time |
| | | Auto-restoration upon screen switch-over |

| Item | | Contents |
|-----------------|--|---|
| Detail | Priority | [1] (higher priority) - [8] (lower priority) Specify the priority taken during 8-way communication. If interrupts from two or more devices occur at the same time, communication with these devices will take place in order of priority. |
| | System device (\$s) V7 Compatible (PLC1) | This is set to [Yes] if the V7-series screen program (including temperature control network/PLC2Way settings) has been converted to data for the TS2060. System information relevant to 8-way communication will be stored in device memory addresses \$P1 and \$s. * For more information, see "1.5.1 \$Pn (For 8-way Communication)" (page 1-70). |
| | System device (\$s) V7 Compatible (PLC2) | This is set to [Yes] if the V7-series screen program (including temperature control network/PLC2Way settings) has been converted to data for the TS2060. <ul style="list-style-type: none"> • [None] \$P2:493/494/495 is used as the transfer table control device memory. • [Yes] \$s762/763/764 is used as the transfer table control device memory. * For more information, see "1.5.1 \$Pn (For 8-way Communication)" (page 1-70). |
| | Device Memory Map Control Device | Specify the device memory for controlling device memory maps of PLC1 - PLC8. The device memory specified here is the same as [Control Device] in [Device Memory Map Setting] ([System Setting] → [Device Memory Map] → [Device Memory Map Edit] window → [Device Memory Map Setting]). * For more information, refer to the TS2060 Reference Manual 2. |
| Target Settings | Connect To | Set this for Ethernet communication. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)" (page 1-43). |
| | PLC Table | |
| | Use Connection Check Device | Select [Yes] for connection confirmation using a desired device memory address at the start of communication. |
| | Connection Check Device | Specify a desired device memory address used for connection confirmation. |

*1 Be sure to match the settings to those made on the connected device.

1.4.2 MONITOUCH Settings




Select Edit Model

Set the model of the V series to edit.

For more information, refer to the TS2060 Reference Manual 1.

Read/Write Area



| Item | Contents |
|------------|--|
| Read Area | Specify a memory address used to give commands for display or operation from the PLC to MONITOUCH. Three words (at the minimum) ^{*1} of consecutive memory addresses are secured. For more information, see "Read area" (page 1-55). |
| Write area | This is the area, to which the screen numbers or overlaps displayed on MONITOUCH or a buzzer state will be written. Three words of consecutive memory addresses are secured. For more information, see "Write area" (page 1-59). |
| Calendar | This setting is valid when the TS2060's internal clock ^{*2} is not used. The setting allows the calendar data to be read from the device via the selected port at PLC1 - PLC8. The calendar data will be updated when: <ul style="list-style-type: none"> • The power is turned on. • STOP → RUN • The date changes. • Bit 11 in the read area "n" is set (ON) (0 → 1 leading edge) |

*1 More words are required if the sampling function is used:
sampling control memory (three words maximum), sampling data memory (variable depending on the setting)


*2 For more information on the internal clock, refer to the TS2060 Reference Manual 1.

Read area

The read area is the area where the PLC gives commands for display or operation to MONITOUCH.

Three words (at the minimum) of consecutive memory addresses are secured.

MONITOUCH always reads data from these three words to display and operate according to the commands.



Memory addresses are allocated as shown below.

| | Address | Contents | Operation |
|-------------|---------|-----------------------|--------------|
| Read area = | n | Sub command/data | TS2060 ← PLC |
| | n + 1 | Screen status command | |
| | n + 2 | Screen number command | |

* Data in these memory addresses is saved at \$s460 to 462 of the TS2060 internal memory. For more information on the internal memory (\$s), refer to the TS2060 Reference Manual 1.


| Read area "n" (sub command/data) | | | | | | | | | | | | | | | |
|----------------------------------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| 0 | 0 | 0 | 0 | | | | | | | | | | | | |

(1) Free
 (2) BZ0 [0 → 1] (leading edge)
 (3) BZ1 [0 → 1] (leading edge)
 (4) BZ2 [1] (level)
 (5) Calendar setting ([0 → 1] (leading edge))
 (6) System reserved


| | |
|------------------------------------|--|
| (1) Free | When data is saved in this area, the same data is written to [Write Area] "n" after the screen has been displayed. Utilizing this operation, these bits can be used for watch dog monitoring ^{*1} or display scanning ^{*2} . |
| (2) BZ0 | A beep (peep) sounds at the leading edge [0 → 1]. |
| (3) BZ1 | An error buzzer (peep-peep) sounds at the leading edge [0 → 1]. |
| (4) BZ2 | A buzzer (ffee) sounds continuously while the bit remains [1]. When setting this bit, check [Use Continuous Buzzer Sound] ([System Setting] → [Unit Setting] → [General Setting]). |
| (5) Calendar setting ^{*3} | <p>This bit is valid when the built-in clock is not used. This bit should be used differently depending on whether the connecting PLC is equipped with the calendar function.</p> <p>When MONITOUCH is connected to a PLC with calendar function: When calendar data in the PLC is updated, it can forcibly be read by setting this bit (at the leading edge of [0 → 1]). In addition to calendar data update using this bit, calendar data in the PLC is automatically read and updated when:</p> <ul style="list-style-type: none"> • The power is turned on. • STOP → RUN • The date changes (AM 00:00:00). <p>When MONITOUCH is connected to a PLC without calendar function: A virtual calendar area can be provided by setting [Calendar memory] in the [GD-80 Compatible] tab window ([Read/Write Area] → [GD-80 Compatible]). Then setting this bit (ON) updates the calendar data.</p> |
| (6) System reserved | This bit is reserved by the system. This bit must be "0". |

***1 Watchdog**

When the PLC is communicating with TS2060, there is no means for the PLC to know whether or not TS2060 is doing operations correctly. To solve this one-way communication, change data in bits 0 to 7 in [Read Area] "n" and check that the same data is saved in bits 0 to 7 in [Write Area] "n". This proves that the TS2060 is correctly doing operations through communications with the PLC. This verification is called "watchdog".

***2 Display scanning**

This operation can be utilized for display scanning. Forcibly change data in the [Read Area] "n" when giving a graphic change command and check that the same data is saved in the [Write Area] "n". This can prove that the graphic change command is received and executed correctly.



^{*3} If this bit is used during constant sampling, data sampling timing may be shifted. If this bit is set during constant sampling, we recommend you to reset the sampling as well.

| Read area "n + 1" (screen status command) | | | | | | | | | | | | | | | |
|---|----|---|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| | | | 0 | | | | | 0 | 0 | 0 | 0 | | | | |
| | | | | | | | | | | | | | | | |
| (1) Overlap 0 (2) Overlap 1 (3) Overlap 2 | | <p>These bits are used for controlling show/hide operations of overlaps.</p> <ul style="list-style-type: none"> Normal overlap or call-overlap [0 → 1] (leading edge ^{*1}): Show [1 → 0] (falling edge ^{*1}): Hide Multi-overlap [0] (level ^{*2}): Hide [1] (level ^{*2}): Show <p>It is necessary to specify library No. 0 to 1023 for [Overlap Library Number] for [Multi-Overlap] dialog.</p> | | | | | | | | | | | | | |
| (4) Overlap 3 | | <p>This bit is used for controlling show/hide operations of the global overlap screen.</p> <p>[0 → 1]: Show [1 → 0]: Hide</p> <p>It is necessary to specify library No. 0 to 9999 for [Overlap Library Number] in the [Global Overlap Setting] dialog.</p> | | | | | | | | | | | | | |
| (5) System reserved | | This bit is reserved by the system. This bit must be "0". | | | | | | | | | | | | | |
| (6) Global macro execution | | <p>The macro set for [Macro Block] is executed once at [0 → 1] (leading edge). The macro block number should be specified for [Global Macro Memory] in the dialog that is displayed by selecting [System Setting] → [Macro Setting]. For more information, refer to the Macro Reference manual provided separately.</p> | | | | | | | | | | | | | |
| (7) Data sheet output | | <p>The data sheet is printed out at [0 → 1] (leading edge). This bit becomes valid when the data sheet function is set.</p> | | | | | | | | | | | | | |
| (8) Screen hard copy | | <p>The TS2060 screen image is printed out at [0 → 1] (leading edge). This bit becomes valid when a printer is connected. It is also possible to make a screen hard copy using an internal switch [Function: Hard Copy].</p> | | | | | | | | | | | | | |
| (9) Backlight | | <p>This bit becomes valid when an option other than [Always ON] is selected in the [Backlight] tab window that is displayed by selecting [System Setting] → [Unit Setting].</p> <p>[0] (level): OFF when the conditions are satisfied [1] (level): ON</p> | | | | | | | | | | | | | |
| (10) System reserved | | This bit is reserved by the system. This bit must be "0". | | | | | | | | | | | | | |
| (11) Screen internal switching | | <p>This bit controls screen switching by internal switches.</p> <p>[0]: Screen switching by internal switches is enabled. [1]: Screen switching by internal switches is disabled.</p> <p>* An "internal switch" means a switch you can create for internal processing within MONITOUCH by selecting [Screen] or [Return] for [Function:] of the switch.</p> | | | | | | | | | | | | | |
| (12) Screen forced switching | | <p>This bit is used for switching the screen using the read area "n + 2" when the required screen number has already been specified in "n + 2". ^{*3}</p> | | | | | | | | | | | | | |
| (13) Data read refresh | | <p>All the data display items on the screen are refreshed at [0 → 1] (leading edge). This is applied to every data display item regardless of the setting for [Process Cycle].</p> | | | | | | | | | | | | | |

^{*1} It is possible to make this function work with the bit in the level. For more information, refer to the TS2060 Reference Manual 1 provided separately.

^{*2} As an exception, a multi-overlap may appear/disappear at the edge. For more information, refer to the TS2060 Reference Manual 1 provided separately.


*3 Usage Example

Step a: Screen change according to read area "n + 2"

Step b: Screen change with an internal switch

Step c: Screen change to the same screen number as step 1 according to read area "n + 2"

In this case, however, the same value is stored in read area "n + 2" so the command is not valid. In such a case, it is possible to forcibly switch the screen to the screen number contained in read area "n + 2" at the leading edge [0 → 1] of bit 14.




Reset to this bit after you check that bit 14 of write area "n+1" is set to "1" or the same value is stored in write area "n+2" as the value in read area "n+2".

| Read area "n + 2" (screen number command) | | | | | | | | | | | | | | | | |
|---|----|--|----|----|----|----|----|----|----|----|----|----|----|----|----|-------------------|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 | |
| | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | (1) Screen number |
| (1) Screen number command *1 | | 0 to 9999 These bits are used for switching the screen by an external command. When a screen number is specified in these bits, the screen is displayed. Even if the screen has been switched using an internal switch, it is possible to switch the screen using an external command from the PLC. External commands have priority over internal switches. | | | | | | | | | | | | | | |

*1 Screen No. Error

When MONITOUCH has started communications with the PLC, the screen of the screen number specified in read area "n + 2" is displayed. If the screen number specified in read area "n + 2" does not exist in the screen data, "Screen No. Error" is displayed on MONITOUCH.



Before starting communications with the PLC, check the data in [Read Area] "n + 2" and confirm that the screen number to be displayed at first is specified.

Write area "n + 1" (screen status)


| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| | | | 0 | | | | | | 0 | 0 | 0 | | | | |

(1) Overlap 0
(2) Overlap 1
(3) Overlap 2
(4) Overlap 3
(5) System reserved
(6) Serial extension I/O
(7) Global macro execution
(8) Printer busy
(9) Print data transferring
(10) Backlight
(11) System reserved
(12) Screen internal switching
(13) Screen forced switching
(14) Data read refresh

| | |
|--|---|
| (1) Overlap 0 (2) Overlap 1 (3) Overlap 2 (4) Overlap 3 | Overlap status ^{*1} [0]: Hide [1]: Show |
| (5) System reserved | Always "0" |
| (6) Serial extension I/O | Serial extension I/O (V-I/O) status [0]: Normal [1]: Error |
| (7) Global macro execution | This bit reflects the data in bit 8 of read area "n + 1". |
| (8) Printer busy | Printer status ^{*2} [0]: Not busy [1]: Busy |
| (9) Print data transferring | Print data transferring status when a print command (hard copy, sample print or data sheet) is executed ^{*2} [0 → 1]: Print data transferring start [1 → 0]: Print data transferring end |
| (10) Backlight | Backlight ON/OFF status ^{*3} [0]: OFF [1]: ON * Even if bit 11 (backlight) in read area "n + 1" is reset (0: OFF), this bit shows "1" if the backlight is on. |
| (11) System reserved | Always "0" |
| (12) Screen internal switching | This bit reflects the data in bit 13 of read area "n + 1". |
| (13) Screen forced switching | This bit reflects the data in bit 14 of read area "n + 1". |
| (14) Data read refresh | This bit reflects the data in bit 15 of read area "n + 1". |

*1 Example:

- a. Display overlap No. 0 from read area (n + 1) using an external command.
b. Display overlap No. 0 internally using the [Function: Overlap = ON] switch.
In either case (a or b), bit 0 of write area "n + 1" is set (ON).
In the case of b, the bit in read area "n + 1" remains "0".




- *2 Data of bits 9 and 10 is output to internal memory address \$s16. For more information on the internal memory (\$s), refer to the TS2060 Reference Manual 1.
- *3 Data of bit 11 is output to internal memory address \$s17. For more information on the internal memory (\$s), refer to the TS2060 Reference Manual 1.

Write area "n + 2" (displayed screen number)

| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| | | | | | | | | | | | | | | | |

_____ (1) Screen number

GD-80 Compatible



| | |
|---|--|
| <input type="checkbox"/> GD-80 Compatible Read/Write Area | <p>When converting screen data files created on the MONITOUCH GD-80/81S series into those of the TS2060, this option is automatically checked.</p> <ul style="list-style-type: none"> • Unchecked: The memory addresses allocated to the TS2060 are applied to the read and write areas. (See page 1-54.) • Checked: The memory addresses allocated to the GD-80/81S series are applied to the read and write areas. For more information on [Read Area] and [Write Area] of the GD-80/81S series, refer to the GD-80 User's Manual provided separately. |
| Calendar | Use this device memory when the connected device is not equipped with the calendar function and the TS2060 built-in clock is not used. |

Calendar memory

Follow the steps below to set the calendar memory.

1. Specify the desired memory address for [Calendar]. Six words are occupied consecutively.
2. Save calendar data in the calendar memory addresses specified in step 1 in BCD notation.
The allocation of calendar memory is shown below.

| Memory | Contents |
|--------|-------------------------|
| n | Year (BCD 0 to 99) |
| n + 1 | Month (BCD 1 to 12) |
| n + 2 | Day (BCD 1 to 31) |
| n + 3 | Hour (BCD 0 to 23) |
| n + 4 | Minute(s) (BCD 0 to 59) |
| n + 5 | Second(s) (BCD 0 to 59) |

The day of the week is automatically recognized from the above data. It is not necessary to input any data.

3. Set bit 11 (calendar setting) of read area "n". At the leading edge of this bit (0 → 1), data in calendar memory is set for calendar data.

- *1 Calendar data is cleared when the power is turned off. When the power is turned on, set calendar data according to the procedure mentioned above.
- *2 When using the calendar device memory, neither automatic reading of calendar data at the time of PLC connection nor once-a-day automatic correction is performed. Consequently, errors may result. Perform the procedure described above at regular intervals.


Buzzer

Make settings for the buzzer.
For more information, refer to the TS2060 Reference Manual 1.

Backlight

Make settings for the backlight.
For more information, refer to the TS2060 Reference Manual 1.

Local IP Address (TS2060i Only)




| Item | Contents |
|---|---|
| Select IP Address from Network Table | This is valid when the IP address of the TS2060i has been registered in the network table. Select a network table number from 0 to 255 to set the IP address. * For more information on the network table, refer to "Network table" (page 1-64). |
| IP Address ^{*1} | Set the IP address for the TS2060i. |
| Default Gateway ^{*1} | Set the default gateway. |
| Subnet Mask ^{*1} | Set the subnet mask. When this box is not checked, the subnet mask is automatically assigned based on the byte at the extreme left of the IP address. Example: When IP address is "172.16.200.185", "255.255.0.0" is set. When IP address is "192.168.1.185", "255.255.255.0" is set. |
| Port No. ^{*1} | Set a port number from 1024 to 65535. Other than 8001. |
| Send Timeout | Specify the timeout time to send the EREAD/EWRITE/SEND/MES command. |
| Retrials | 0 to 255 Set the number of retrials to be performed when a time-out occurs. |
| Device Protect Internal Device Memory Card Device | Check either check box to write-protect the device memory from computers or other stations. |

^{*1} For more information on each setting item, see "Basics of ethernet settings" (page 1-65).


Network table

This is an area for registering IP addresses of the MONITOUCH, PC and other devices.

Select [System Setting] → [Ethernet Communication] → [Network Table] and register.



Double-click a number in the No. column to display the [Network Table Setting] dialog. An IP address and other items can be registered.



| Item | Contents |
|---|---|
| Port Name | Set the name of the TS2060i or the computer. |
| IP Address ^{*1} | Set the IP address of the TS2060i or the computer. |
| Send Timeout ^{*2} | Specify the timeout time to send the EREAD/EWRITE/SEND/MES command. |
| Port No. ^{*1} | Set the port number of the TS2060i or the computer. |
| Retrials ^{*2} | 0 to 255 Set the number of retrials to be performed when a time-out occurs. |
| Device Protect ^{*2} Internal Device Memory Card Device | Check either check box to write-protect the device memory from computers or other stations. |
| Default Gateway ^{*1 *2} | Set the default gateway. |
| Subnet Mask ^{*1 *2} | Set the subnet mask. |

^{*1} For more information on each setting item, see "Basics of ethernet settings" (page 1-65).

^{*2} Invalid if TS2060i units or PCs at other ports are registered. Only valid when set as the local port IP of the TS2060i unit.

Basics of ethernet settings

IP address

This is an address that is used for recognizing each node on the Ethernet and should be unique. The IP address is 32-bit data which consists of the network address and the host address and can be classified into classes A to C depending on the network size.

| | | | |
|---------|-----|----------------------|-------------------|
| Class A | 0 | Network address (7) | Host address (24) |
| Class B | 10 | Network address (14) | Host address (16) |
| Class C | 110 | Network address (14) | Host address (8) |

<Notation>

A string of 32-bit data is divided into four, and each segment delimited with a period is in decimal notation.

Example: The IP address in class C shown below is represented as "192.128.1.50".
11000000 10000000 00000001 00110010

<Unusable IP addresses>

- "0" is specified for one byte at the extreme left.
- "127" is specified for one byte at the extreme left (loop back address).
- "224" or more is specified for one byte at the extreme left (for multi-cast or experiment).
- The host address consists of only "0" or "255" (broadcast address).

Example: 0.x.x.x

Example: 127.x.x.x

Example: 224.x.x.x

Example: 128.0.255.255, 192.168.1.0

Port No.

Multiple applications are running on each node, and communications are carried out for each application between the nodes. Consequently, it is necessary to have a means to identify the application that data should be transferred to. The port number works as this identifier. Each port number is 16-bit data (from 0 to 65535).

The TS2060i uses the port for screen program transfer (8001), PLC communication (as desired), and the simulator (8020). Set a unique number in the range of 1024 to 65535. For a PLC or a computer, set the port number in the range of 256 to 65535. It is recommended to set a greater number.

Default gateway

A gateway and a router are used for communication between different networks.

The IP address of the gateway (router) should be set to communicate with the node(s) on other networks.

Subnet mask

A subnet mask is used for dividing one network address into multiple networks (subnet).


The subnet is assigned by specifying a part of the host address in the IP address as a subnet address.

| | | | |
|-------------|-----------------|----------------------|-------------------|
| Class B | 10 | Network address (14) | Host address (16) |
| Subnet mask | 255. | 255. | 255.0 |
| | 11111111 | 11111111 | 11111111 00000000 |
| | Network address | Subnet address | Host address |

<Unusable subnet masks>


- All bits are set to "0"..... 0.0.0.0
- All bits are set to "1"..... 255.255.255.255

Ladder Transfer



| Item | Contents |
|---------------------|--|
| Use ladder transfer | Select the check box and specify the port to connect with PC when using the ladder transfer function. * For more information, refer to the TS2060 Reference Manual 2. |


1.4.3 Other Equipment



Printer


Configure these settings when connecting a printer.










Selecting the printer model



| Item | Contents |
|-----------------|---|
| Model | Select the model of the printer to connect. |
| Target Port No. | <p>Select the port to connect the printer cable to.</p> <p>USB A: Select when connecting an EPSON, ESC/P-R compatible printer. Also use this setting when connecting a parallel printer using a commercially available parallel-to-USB cable.</p> <p>USB B: Select when connecting a PictBridge-compatible printer.</p> <p>MJ1/MJ2: Select when connecting with the serial interface of a printer. Also select whether to use MJ1 or MJ2 of the TS2060.</p> |

Printer properties



| Item | | Contents | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|--|----------|------------|----------|---|---|--|----|----|----|----|----|----|-----|--|--|-----|--|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|--|---|---|---|---|---|---|---|---|---|---|---|---|---|---|--|
| Always Output Status Bit | | <p>The TS2060 outputs [0 → 1] when starting to transfer data upon receiving a print command, and outputs [1 → 0] upon finishing transfer. However, these signals may not be output if the print data is small. Select [Yes] to output a signal regardless of the data size.</p> <p>The output area is as follows:</p> <ul style="list-style-type: none">• Bit 1 of the device memory for printer information output• Bit 0 of internal device memory \$s16 <p>\$s16</p> <table><tr><td colspan="15">MSB</td><td colspan="2">LSB</td></tr><tr><td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>09</td><td>08</td><td>07</td><td>06</td><td>05</td><td>04</td><td>03</td><td>02</td><td>01</td><td>00</td></tr><tr><td></td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr></table> <p>0: End (standby) 1: Transferring print data</p> | MSB | | | | | | | | | | | | | | | LSB | | 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| MSB | | | | | | | | | | | | | | | LSB | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Hard Copy | Orientation | <p>Specify the printing orientation of the screen on paper. In vertical output, the screen is rotated 90° clockwise with respect to the printing paper and printed out.</p> <ul style="list-style-type: none">• Printing examples of hard copies: <table><tr><td></td><td>Horizontal</td><td>Vertical</td></tr><tr><td></td><td></td><td></td></tr></table> | | Horizontal | Vertical |  |  |  | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Horizontal | Vertical | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  |  |  | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reversed Image | <p>Reversed: Screens are printed with black and white inverted. Normal: Screens are printed as they are displayed on MONITOUCH.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Data Sheet | Data Sheet Setting | Make settings for printing data sheets. For more information, refer to the TS2060 Reference Manual 1. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Use PictBridge only on USB-B port. | | Make this setting when using a PictBridge-compatible printer. Select [Yes] when starting up the USB-B port as the connection port for a PictBridge printer in the RUN mode. When transferring screen programs via the USB-B port, display the Main Menu screen on MONITOUCH. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Serial Port | Baud Rate | Set the communication baud rate. 4800/9600/19200/38400/57600/76800/115K BPS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Parity | Select an option for parity bit. None / Odd / Even | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Data Length | Select a data length. 7 bits / 8 bits | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Stop Bit | Select a stop bit. 1 bit / 2 bits | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

* For details on printing, refer to the TS2060 Reference Manual 1.

Card Recorder

Configure this setting when connecting a "CREC" card recorder.

V-I/O

Configure this setting when connecting a "V-I/O" unit.

Simulator

Configure this setting when saving a simulator communication program to a storage device* (SD card or USB flash drive) in addition to a screen program using the storage manager.

* This function is available only with TS2060i. Storage devices cannot be used with the TS2060 (model name without "i").

1.5 System Device Memory for Communication Confirmation

The TS2060 has addresses \$s and \$Pn as system device memory.

- \$Pn
This is the system device memory for 8-way communications, and 512 words are allocated for each logical port. For more information, see "1.5.1 \$Pn (For 8-way Communication)".
- \$s518, 519
This is the system device memory for confirming the Ethernet status. For more information, see "1.5.2 \$s518, 519 (Ethernet Status Confirmation) (TS2060i Only)".

For the device memory address \$s, \$s0 to 2047 (2 K words) are assigned and data can be read from written to this area. For more information on addresses other than \$s518, 519, refer to the TS2060 Reference Manual 1.

1.5.1 \$Pn (For 8-way Communication)

This is the system device memory for 8-way communications, and 512 words are assigned for each logical port. Refer to the next section for more information.

| | |
|-------------------------------|-----------|
| \$P1: 0000 : \$P1: 0511 | PLC1 area |
| \$P2: 0000 : \$P2: 0511 | PLC2 area |
| \$P3: 0000 : \$P3: 0511 | PLC3 area |
| \$P4: 0000 : \$P4: 0511 | PLC4 area |
| \$P5: 0000 : \$P5: 0511 | PLC5 area |
| \$P6: 0000 : \$P6: 0511 | PLC6 area |
| \$P7: 0000 : \$P7: 0511 | PLC7 area |
| \$P8: 0000 : \$P8: 0511 | PLC8 area |

\$Pn List

The \$Pn list is presented below. Part of the information of logical ports PLC1/PLC2 can also be stored in \$.^{*1}

| \$Pn (n = 1 to 8) | \$. ^{*1} | Contents | Device Type |
|----------------------|-----------------------------|---|----------------|
| 000 | 111 (PLC1) | TS2060 local port number Stores the local port number of the TS2060. (Universal serial communication, slave communication, etc.) | ← TS2060 |
| : | - | : | |
| 004 | 130 (PLC1) ^{*2} | Modbus TCP/IP Sub Station communications Relay station No. designated device memory When a relay station number is set with a MOV macro command, the error information of the sub station number that is connected to that relay station is stored in \$Pn010 to 025. | → TS2060 |
| : | - | : | |
| 010 | 128 (PLC1) | Link down information (station No. 0 - 15) 0: Normal 1: Down | ← TS2060 |
| 011 | 129 (PLC1) | Link down information (station No. 16 - 31) 0: Normal 1: Down | |
| 012 | 114 (PLC1) | Link down information (station No. 32 - 47) 0: Normal 1: Down | |
| 013 | 115 (PLC1) | Link down information (station No. 48 - 63) 0: Normal 1: Down | |
| 014 | 116 (PLC1) | Link down information (station No. 64 - 79) 0: Normal 1: Down | |
| 015 | 117 (PLC1) | Link down information (station No. 80 - 95) 0: Normal 1: Down | |
| 016 | 118 (PLC1) | Link down information (station No. 96 - 111) 0: Normal 1: Down | |
| 017 | 119 (PLC1) | Link down information (station No. 112 - 127) 0: Normal 1: Down | |
| 018 | 120 (PLC1) | Link down information (station No. 128 - 143) 0: Normal 1: Down | |
| 019 | 121 (PLC1) | Link down information (station No. 144 - 159) 0: Normal 1: Down | |
| 020 | 122 (PLC1) | Link down information (station No. 160 - 175) 0: Normal 1: Down | |
| 021 | 123 (PLC1) | Link down information (station No. 176 - 191) 0: Normal 1: Down | |
| 022 | 124 (PLC1) | Link down information (station No. 192 - 207) 0: Normal 1: Down | |
| 023 | 125 (PLC1) | Link down information (station No. 208 - 223) 0: Normal 1: Down | |
| 024 | 126 (PLC1) | Link down information (station No. 224 - 239) 0: Normal 1: Down | |
| 025 | 127 (PLC1) | Link down information (station No. 240 - 255) 0: Normal 1: Down | |
| : | - | : | |
| 099 | - | Error information hold (page 1-74) Setting for the update timing of the \$Pn: 010 to 025 link down information 0: Always updated with the latest information Other than 0: Only updated when a communication error occurs | → TS2060 |
| 100 | 730 (PLC2) | Error status Station No. 00 status (page 1-75) | ← TS2060 |
| 101 | 731 (PLC2) | Error status Station No. 01 status (page 1-75) | |
| 102 | 732 (PLC2) | Error status Station No. 02 status (page 1-75) | |
| 103 | 733 (PLC2) | Error status Station No. 03 status (page 1-75) | |
| 104 | 734 (PLC2) | Error status Station No. 04 status (page 1-75) | |
| 105 | 735 (PLC2) | Error status Station No. 05 status (page 1-75) | |
| 106 | 736 (PLC2) | Error status Station No. 06 status (page 1-75) | |
| 107 | 737 (PLC2) | Error status Station No. 07 status (page 1-75) | |
| 108 | 738 (PLC2) | Error status Station No. 08 status (page 1-75) | |
| 109 | 739 (PLC2) | Error status Station No. 09 status (page 1-75) | |

| \$Pn (n = 1 to 8) | \$S*1 | Contents | Device Type |
|----------------------|---------------|---|----------------|
| 110 | 740 (PLC2) | Error status Station No. 10 status (page 1-75) | ← TS2060 |
| : | : | : | |
| 120 | 750 (PLC2) | Error status Station No. 20 status (page 1-75) | |
| : | : | : | |
| 130 | 760 (PLC2) | Error status Station No. 30 status (page 1-75) | |
| 131 | 761 (PLC2) | Error status Station No. 31 status (page 1-75) | |
| 132 | 820 (PLC2) | Error status Station No. 32 status (page 1-75) | |
| 133 | 821 (PLC2) | Error status Station No. 33 status (page 1-75) | |
| : | : | : | |
| 140 | 828 (PLC2) | Error status Station No. 40 status (page 1-75) | |
| : | : | : | |
| 150 | 838 (PLC2) | Error status Station No. 50 status (page 1-75) | |
| : | : | : | |
| 160 | 848 (PLC2) | Error status Station No. 60 status (page 1-75) | |
| : | : | : | |
| 170 | 858 (PLC2) | Error status Station No. 70 status (page 1-75) | |
| : | : | : | |
| 180 | 868 (PLC2) | Error status Station No. 80 status (page 1-75) | |
| : | : | : | |
| 190 | 878 (PLC2) | Error status Station No. 90 status (page 1-75) | |
| : | : | : | |
| 199 | 887 (PLC2) | Error status Station No. 99 status (page 1-75) | ← TS2060 |
| 200 | - | Error status Station No. 100 status (page 1-75) | |
| : | : | : | |
| 350 | - | Error status Station No. 250 status (page 1-75) | |
| : | : | : | |
| 355 | - | Error status Station No. 255 status (page 1-75) | |
| 356 | - | Device memory map 0 Status | |
| 357 | - | Device memory map 0 Error code 1 | |
| 358 | - | Device memory map 0 Error code 2 | |
| 359-361 | - | Device memory map 1 Status, error code | |
| 362-364 | - | Device memory map 2 Status, error code | |
| 365-367 | - | Device memory map 3 Status, error code | |
| 368-370 | - | Device memory map 4 Status, error code | |
| 371-373 | - | Device memory map 5 Status, error code | |
| 374-376 | - | Device memory map 6 Status, error code | |
| 377-379 | - | Device memory map 7 Status, error code | |
| 380-382 | - | Device memory map 8 Status, error code | |
| 383-385 | - | Device memory map 9 Status, error code | |
| 386-388 | - | Device memory map 10 Status, error code | |
| 389-391 | - | Device memory map 11 Status, error code | |
| 392-394 | - | Device memory map 12 Status, error code | |
| 395-397 | - | Device memory map 13 Status, error code | |
| 398-400 | - | Device memory map 14 Status, error code | |
| 401-403 | - | Device memory map 15 Status, error code | |
| 404-406 | - | Device memory map 16 Status, error code | |
| 407-409 | - | Device memory map 17 Status, error code | |
| 410-412 | - | Device memory map 18 Status, error code | |
| 413-415 | - | Device memory map 19 Status, error code | |
| 416-418 | - | Device memory map 20 Status, error code | |

| \$Pn (n = 1 to 8) | \$s*1 | Contents | Device Type |
|----------------------|-----------------|--|----------------|
| 419-421 | - | Device memory map 21 Status, error code | ← TS2060 |
| 422-424 | - | Device memory map 22 Status, error code | |
| 425-427 | - | Device memory map 23 Status, error code | |
| 428-430 | - | Device memory map 24 Status, error code | |
| 431-433 | - | Device memory map 25 Status, error code | |
| 434-436 | - | Device memory map 26 Status, error code | |
| 437-439 | - | Device memory map 27 Status, error code | |
| 440-442 | - | Device memory map 28 Status, error code | |
| 443-445 | - | Device memory map 29 Status, error code | |
| 446-448 | - | Device memory map 30 Status, error code | |
| 449 | - | Device memory map 31 Status | |
| 450 | - | Device memory map 31 Error code 1 | |
| 451 | - | Device memory map 31 Error code 2 | |
| : | : | : | |
| 493 | 762 (PLC2)*3 | Device memory map reading prohibited flag (refer to the TS2060 Reference Manual 2). 0: Periodical reading/synchronized reading executed Other than 0: Periodical reading/synchronized reading stopped | → TS2060 |
| 494 | 763 (PLC2)*3 | Forced execution of the device memory map TRL_READ/TBL_WRITE macro Setting for macro operation when there is a station with a communication error 0: The macro is not executed in relation to any of the stations. Other than 0: The macro is executed in relation to connected stations. | |
| 495 | 764 (PLC2)*3 | Device memory map writing prohibited flag (refer to the TS2060 Reference Manual 2). 0: Periodical writing/synchronized writing executed Other than 0: Periodical writing/synchronized writing stopped | |
| : | - | : | |
| 500 | 800 (PLC3) | Device memory for Modbus slave communications Used for setting the number of the reference device memory map and the device memory for referring free area 31.Used for setting the number of the reference device memory map and the device memory for referring free area 31. \$Pn500 to 505 are exclusively used for monitoring: \$s800 to 805 are used for writing from the Modbus master. Refer to the Modbus Slave Communication Specifications. | → TS2060 |
| 501 | 801 (PLC3) | | |
| 502 | 802 (PLC3) | | |
| 503 | 803 (PLC3) | | |
| 504 | 804 (PLC3) | | |
| 505 | 805 (PLC3) | | |
| : | : | : | |
| 508 | 765 (PLC2) | Error response code (page 1-77) If "800BH" (error code received) is stored for the error status (\$Pn100 to 355), it is possible to check the error code. | ← TS2060 |
| 509 | 766 (PLC2) | | |
| 510 | 767 (PLC2) | | |
| 511 | 768 (PLC2) | | |

*1 For PLC1, select [Yes] for [System device (\$s) V7 Compatible] under [Detail] on the [PLC Properties] window. The same information is stored in the \$P1 and \$s.

*2 If designating the relay station number using \$s130, select [Yes] for [System device (\$s) V7 Compatible] under [Detail] on the [PLC Properties] window for PLC1. \$P1: 004 cannot be used in this case.

*3 If executing device memory map control using \$s762, \$s763 and \$s764, select yes for [System device (\$s) V7 Compatible] under [Detail] on the [PLC Properties] window for PLC2. Note that \$P2: 493/494/495 cannot be used in this case.


Details

\$Pn: 10 to 25

The bit corresponding to the station where a link down was detected is set (ON).

0: Normal

1: Down



\$Pn:99


The update timing for the link down information stored in \$Pn: 010 to 025 and the error status stored in \$Pn: 100 to 355 are set here.

0: Always updated with the latest information

Other than 0: Only updated when a communication error occurs


- Example:

An error has occurred at station No. 18. 2nd bit of \$Pn: 011 is set (ON).




After resetting communications

- If \$Pn: 99 = 0, the link down information is updated.



- If \$Pn: 99 = other than 0, the link down information is not updated.




\$Pn: 100 to 355

The results of communication with each station are stored here. The status codes are shown below.

| Code (HEX) | Contents |
|------------|---|
| 0000H | Normal |
| FFFFH | Time-out |
| 8001H | Check code error |
| 8002H | Data error |
| 800BH | Receives the error code from the connected device |

Errors other than the above are stored as shown below.



| Error | Details | Solution |
|---------------------|--|---|
| Time-out | Although a request to send is given, no answer is returned within the specified time. | Implement solutions 1, 2, and 3. |
| Check code | The check code of the response is incorrect. | Implement solutions 1 and 3. |
| Data error | The code of the received data is invalid. | Implement solutions 1, 2, and 3. |
| Error code received | An error occurred on the connected device. | Refer to the instruction manual for the PLC. |
| Buffer full | The TS2060 buffer is full. | Contact your local distributor. |
| Parity | An error occurred in parity check. | Implement solutions 2 and 3. |
| Overrun | After receiving one character, the next character was received before internal processing was completed. | Implement solutions 1 and 3. |
| Framing | Although the stop bit must be "1", it was detected as "0". | Implement solutions 1, 2, and 3. |
| Break detection | The connected device's SD is remaining at the low level. | Examine the connection with the connected device's SD and RD. |

- Solution

- 1) Check if the communication settings of the TS2060 and the connected device are matched.
- 2) Check the cable connection.
- 3) Data may be disrupted because of noise. Fix noise.

If you still cannot solve the error even after following the solutions above, contact your local distributor.

\$Pn: 356 to 451

This device memory is valid when an Omron ID controller (V600/620/680) is connected with [Guarantee synchronism of the data] checked on the [Device Memory Map Setting] dialog.

- Status (\$Pn 356, 359, ...)

The execution status of the device memory map is stored here.

The bit is set (ON) when reading or writing of the first data in the device memory map is correctly finished.

When the control device memory (command bit) is set (ON), the bit is reset.

| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 |

System reserve

1: ID tag recognized

- Error code 1 (\$Pn 357, 360, ...)

An error code is stored when an error occurs in the reading or writing of data in the device memory map.

If multiple errors occur in the device memory map, the last error code is stored.

When the control device memory (command bit) is set (ON), the bit is reset.

| Code (HEX) | Contents |
|------------|---|
| FFFFH | Time-out |
| 8001H | Check code error |
| 8002H | Data error |
| 800BH | Receives the error code from the connected device |

Errors other than the above are stored as shown below.

| | | | | | | | | | | | | | | | | | |
|-----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|-----|---|
| MSB | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | LSB | 0 |
| | | | | | | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Buffer-full error
 Parity error
 Overrun error
 Framing error
 Break detection
 Error
 0: Bits 0 to 14 are all "0".
 1: Any bit from 0 to 14 is other than "0".

- Error code 2 (\$Pn 358, 361, ...)

The exit code is stored here when "800BH" of error code 1 is stored.

| Exit Code (HEX) | Contents |
|-----------------|--|
| 10 | Parity error |
| 11 | Framing error |
| 12 | Overrun error |
| 13 | FCS error |
| 14 | Format error, execution status error |
| 18 | Frame length error |
| 70 | Tag communication error |
| 71 | Inconsistency error |
| 72 | Tag absence error |
| 76 | Copy error |
| 7A | Address error |
| 7C | Antenna disconnection error |
| 7D | Write protect error |
| 75 | Tag device memory warning Data check command Exit code stored when the writing count management command has been successfully processed (without any error) |
| 76 | Tag device memory warning Data check command Exit code stored when the writing count management command has abnormally been processed (comparison error, excessive writing counts) |
| 92 | System error Abnormal mains voltage at antenna |
| 93 | System error Internal device memory error |

\$Pn: 508 to 511


If "800BH" is stored for the error status information (\$Pn: 100 to 355), on transferring the data of that station number to any internal device memory address, the reception code will be obtained at \$Pn: 508 to 511.

Notes on use


- Use \$u/\$T as the target internal device memory.
- Use the macro command MOV (W). MOV (D) cannot be used.
- "0" is stored to device memory addresses that have no expansion error code.

- Example PLC2: Fuji Electric PXR station No. 1


- 1) On receipt of an error code at station No. 1 of PLC2, "800BH" is stored in \$P2:101.



- 2) The data of \$P2: 101 is transferred to \$u1000 by a MOV command.
\$u1000 = \$P2: 101 (W)



- 3) The reception code is stored in \$P2: 508.
\$P2:508 = 0002H



- 4) The PXR manual shows that code 002H means "device memory address range exceeded".
Amend the screen program address designation.

1.5.2 \$s518, 519 (Ethernet Status Confirmation) (TS2060i Only)

Stores the current status of the Ethernet.

| Address | Contents | Stored Value |
|---------|---|--|
| \$s518 | Ethernet status (for built-in LAN port) | <ul style="list-style-type: none"> • [0]: Normal • [Other than 0]: Error * For details on errors, refer to the next section. |
| \$s519 | Ethernet status (for Ethernet unit) | |

Error details

| No. | Built-in LAN | CUR-03 | Contents | Solution |
|--------------|--------------|--------|--|---|
| 200 | × | ○ | Failed in send request | Check cable connection and network table setting of the target station. |
| 201 | ○ | ○ | Send error | Check that the setting on the target station is consistent with the network table setting. |
| 202 | × | ○ | Internal port error | The communication unit is in the older version or is faulty. |
| 203 | ○ | × | TCP socket creation error | The TCP socket cannot be created. Turn the power off and back on again, or check the communication line status, e.g., if the port number is duplicated. |
| 204 | ○ | × | TCP connection over | The number of connections reaches the maximum (64), and no more connection is possible. Check the communication lines. |
| 205 | ○ | × | TCP connection error | Connection cannot be established. Check the communication lines, or turn the power off and on. |
| 207 | ○ | × | TCP send error | TCP communication has failed. Check the communication lines. |
| 208 | ○ | × | TCP connection interruption notification from the connected device | Check the connected device and communication lines. |
| 261 | ○ | × | Send processing full error | Sending process is disabled. Check the communication lines. The line is busy. Consult the network administrator of your company. The communication unit is in the older version or is faulty. |
| 300 | × | ○ | 16 times of collision errors | |
| 301 | × | ○ | Send buffer full error | |
| 350 | ○ | ○ | Send buffer full | |
| 351 | × | ○ | IC receive buffer overflow | |
| 352 | × | ○ | Driver receive buffer overflow | |
| 801 | ○ | ○ | Link down error | Check the HUB or the link confirmation LED on the communication unit. If the LED is not on, check cable connection and the port setting on the network table. |
| 900 | ○ | ○ | No IP address at local port | Check that the IP address of the local port is set on the network table. Check if the same IP address is set on the network. |
| 901 | ○ | ○ | Duplicated IP address error | |
| 910 | ○ | × | Local IP address setting error | The local IP address setting is not correct. Check if the IP address and the subnet mask settings are made properly. |
| 911 | ○ | × | Gateway setting error | The default gateway setting is not correct. Check if the default gateway setting is made properly for the specified IP address and subnet mask. |
| 1000 | × | ○ | Ethernet I/F unit not mounted | Check whether the Ethernet I/F unit is mounted correctly, and then turn the power off and on. If the problem persists, the unit may be faulty. Contact your local distributor. |
| 1001 | × | ○ | Ethernet I/F unit not ready | |
| 1002 | × | ○ | Ethernet I/F unit DPRAM error | |
| 1003 | × | ○ | No response from Ethernet I/F unit | |
| 1004 | × | ○ | Ethernet receive buffer over | |
| 1005 | ○ | ○ | Ethernet send registration error | |
| 1006 | ○ | ○ | I/F unit unregistered interrupt | |
| 1007 | ○ | × | ETHER_INIT_FAIL | Turn the power off and back on again. If the problem persists, the unit may be faulty. Contact your local distributor. |
| 1100 to 1115 | × | ○ | Initialization error (communication unit) | Check whether the Ethernet I/F unit is mounted correctly, and then turn the power off and on. If the problem persists, the unit may be faulty. Contact your local distributor. |
| 1120 | × | ○ | Dual port access error | |
| 1200 | × | ○ | Undefined register | |
| 1201 | × | ○ | Send/receive buffer area over | |
| 1202 | ○ | ○ | MAC address error | The MAC address is not registered. Repair is necessary. |
| 1203 | × | ○ | Port error | Check whether the Ethernet I/F unit is mounted correctly, and then turn the power off and on. If the problem persists, the unit may be faulty. Contact your local distributor. |
| 1301 | × | ○ | Watch dog overflow | |
| 1302 | × | ○ | JAVA error LANC error | |
| 1303 | × | ○ | Dual port timeout | |
| 2000 | × | ○ | Boot mode error | |
| 2001 | ○ | ○ | Undefined error | |

2. A&D

2.1 Temperature Controller/Servo/Inverter Connection

2.1 Temperature Controller/Servo/Inverter Connection

Serial Connection

Weighing Indicator

| PLC Selection on the Editor | Model | Port | Signal Level | Wiring Diagram | | | Lst File |
|-----------------------------|---------------------|----------------|--------------|-----------------------|-----------------------|--------------|-------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| AD4402 (MODBUS RTU) | AD-4402 AD-4402D | Terminal block | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | AD4402.List |
| AD4404 (MODBUS RTU) | AD-4404 | Terminal block | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | AD4404.List |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

2.1.1 AD4402 (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|------------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Parity | <u>None</u> / Odd / Even | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Target Port No. | 1 to 99 | |

AD-4402

| Function Number | Item | Setting | Remarks |
|-----------------|----------------------|--|---------|
| RSF-02 | Data transfer mode | 7: Modbus | |
| RSF-03 | Baud Rate | 4: 4800 bps 5: 9600 bps 6: 19200 bps | |
| RSF-04 | Parity | 0: None 1: Odd 2: Even | |
| RSF-05 | Character bit length | 7: 7 bits 8: 8 bits | |
| RSF-06 | Stop bit length | 1: 1 bit 2: 2 bits | |
| RSF-08 | Address number | 1 to 99 | |

Available Device Memory

The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used.

Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|-----------|
| 0 (output coil) | 00H | |
| 1 (input relay) | 01H | Read only |
| 4 (holding register) | 02H | |
| 3 (input register) | 03H | Read only |

2.1.2 AD4404 (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|------------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Parity | <u>None</u> / Odd / Even | |
| Data Length | 7 / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Target Port No. | <u>1</u> to 99 | |

AD-4404

| Function Number | Item | Setting | Remarks |
|-----------------|----------------------|--|---------|
| RSF-02 | Data transfer mode | 7: Modbus | |
| RSF-03 | Baud Rate | 4: 4800 bps 5: 9600 bps 6: 19200 bps | |
| RSF-04 | Parity | 0: None 1: Odd 2: Even | |
| RSF-05 | Character bit length | 7: 7 bits 8: 8 bits | |
| RSF-06 | Stop bit length | 1: 1 bit 2: 2 bits | |
| RSF-08 | Address number | 1 to 99 | |

Available Device Memory

The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used.

Use [TYPE] when assigning indirect device memory for macro programs.


| Device Memory | TYPE | Remarks |
|----------------------|------|-----------|
| 0 (output coil) | 00H | |
| 1 (input relay) | 01H | Read only |
| 4 (holding register) | 02H | |
| 3 (input register) | 03H | Read only |

2.1.3 Wiring Diagrams

When Connected at CN1:

RS-422/RS-485


Wiring diagram 1 - C4



When Connected at MJ1/MJ2:

RS-422/RS-485

Wiring diagram 1 - M4



3. Agilent

3.1 Temperature Controller/Servo/Inverter Connection

3.1 Temperature Controller/Servo/Inverter Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Wiring Diagram | | | Ladder Transfer ^{*3} |
|--------------------------------|-------|----------------|--------------|-----------------------|-----------------------|----------------------------|----------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | |
| 4263 series | 4263B | GP1B-RS232C | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | 4263A | GP1B-RS485/422 | RS-422/485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | Wiring diagram 2 - M4 | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*3} For the ladder transfer function, see the TS2060 Reference Manual 2.

3.1.1 4263 Series

Communication Setting

Editor

Communication Setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1</u> : <u>1</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 / 57600 115200 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| CR/LF | <u>CR</u> / LF | |

PLC

4263 Series

Set the GPIB address on the front panel.

| Item | Setting | Remarks |
|-----------|---------|---------|
| GBIP Adrs | 1 to 30 | |

GPIB-RS232C / GPIB-RS485/422

Make communication settings using "NI GPIB-Serial Converter Wizard".
For more information, refer to the manual for the GPIB-RS232C / GPIB-RS485/422.

Select mode

| Item | Setting | Remarks |
|-------------|---------------|---------|
| Select Mode | C Mode | |

Serial settings

(Underlined setting: default)

| Item | Setting | Remarks |
|--------------|---|---------|
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 / 57600 115200 | |
| Data Bits | 7 / <u>8</u> | |
| Parity | <u>None</u> / Odd / Even | |
| Stop Bits | <u>1</u> / 2 | |
| Flow Control | None | |

GBIP settings

| Item | Setting | Remarks |
|----------------------|--|---------|
| Termination Mode | CR / LF | |
| EOI | ON | |
| GPIB Primary Address | Set the GPIB address of the 4263 series. | |

Available Device Memory

There are no device memory.

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---|-----------------------|--------------|--|----|
| Resets the trigger system | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 0 | |
| Sets measurement parameters *1 | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 1 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n + 3 | 0: REAL (real part of vector) 1: MLINear (absolute value of vector) 2: CP (equivalent parallel capacitance) 3: CS (equivalent series capacitance) 4: LP (equivalent parallel inductance) 5: LS (equivalent series inductance) 6: IMAGinary (imaginary part of vector) 7: PHASe (impedance phase) 8: D (dissipation factor) 9: Q (quality factor (reciprocal of D)) 10: REAL 11: LP 12: RP (equivalent parallel resistance) 13: INV 1/N (reciprocal of turns ratio (N): inverse) | |
| Queries measurement parameters | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 2 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n + 3 | Measurement parameter (character string) | |
| | | n + 4 | | |
| Defines comparator output to the beeper | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 3 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n+3 | 0: FAIL 1: PASS | |
| Queries the definition for comparator output to the beeper | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 4 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n+3 | Definition for comparator output to the beeper (character string) | |
| | | n + 4 | | |
| Sets whether or not to enable the comparator output to the beeper | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 5 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n + 3 | 0: OFF (disables output to beeper) 1: ON (enables output to beeper) | |
| Queries whether or not the comparator output to the beeper is enabled | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 6 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n + 3 | Setting of comparator output to beeper | |

| Contents | F0 | F1 (= \$u n) | | F2 | |
|--|-----------------------|--------------|---|-----|--------------------------|
| Clears comparator results of measurement parameters | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 | |
| | | n + 1 | Command: 7 | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | |
| Queries comparator results of measurement parameters | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 | |
| | | n + 1 | Command: 8 | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | |
| | | n + 3 | Comparator result | | |
| Sets the lower limit of a measurement parameter | 1 to 8 (PLC1 to 8) | n | Target Port No. | 6/4 | |
| | | n + 1 | Command: 9 | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | |
| | | n + 3 | 0: Numeric value | | 1: MAXimum 2: MINimum |
| | | n + 4 | Numeric value (real number) | | - |
| | | n + 5 | | | - |
| Queries the lower limit of a measurement parameter | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 | |
| | | n + 1 | Command: 10 | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | |
| | | n + 3 | Measurement parameter lower limit (real number) | | |
| | | n + 4 | | | |
| Sets whether or not to enable the lower limit of a measurement parameter | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 | |
| | | n + 1 | Command: 11 | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | |
| | | n + 3 | 0: OFF (not use) 1: ON (use) | | |
| Queries if the lower limit of a measurement parameter is enabled | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 | |
| | | n + 1 | Command: 12 | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | |
| | | n + 3 | Query response on whether or not lower limit is enabled | | |
| Sets the comparator function ON/OFF | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 | |
| | | n + 1 | Command: 13 | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | |
| | | n + 3 | 0: OFF 1: On | | |
| Queries the comparator function | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 | |
| | | n + 1 | Command: 14 | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | |
| | | n + 3 | Comparator function | | |

| Contents | F0 | F1 (= \$u n) | | F2 | | |
|--|-----------------------|--------------|--|--------------------------|-----|---|
| Sets the upper limit of a measurement parameter | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 6/4 | |
| | | n + 1 | Command: 15 | | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | | |
| | | n + 3 | 0: Numeric value | 1: MAXimum 2: MINimum | | |
| | | n + 4 | Numeric value (real number) | | | - |
| | | n + 5 | | | | - |
| Queries the upper limit of a measurement parameter | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 | |
| | | n + 1 | Command: 16 | | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | | |
| | | n + 3 | Measurement parameter upper limit (real number) | | | |
| | | n + 4 | | | | |
| Sets whether or not to enable the upper limit of a measurement parameter | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 4 | |
| | | n + 1 | Command: 17 | | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | | |
| | | n + 3 | 0: OFF (not use) 1: ON (use) | | | |
| Queries if the upper limit of a measurement parameter is enabled | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 | |
| | | n + 1 | Command: 18 | | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | | |
| | | n + 3 | Query response on whether or not upper limit is enabled | | | |
| Queries the parameter to use for the setting command of deviation measurement mode | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 | |
| | | n + 1 | Command: 19 | | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | | |
| | | n + 3 | Parameter (character string) | | | |
| | | n + 4 | | | | |
| Sets the deviation measurement mode | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 4 | |
| | | n + 1 | Command: 20 | | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | | |
| | | n + 3 | 0: DEV (deviation) 1: PCNT (percentage of deviation based on reference value) | | | |
| Queries the deviation measurement mode | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 | |
| | | n + 1 | Command: 21 | | | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | | | |
| | | n + 3 | Deviation measurement mode (character string) | | | |
| | | n + 4 | | | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|--|-----------------------|--------------|---|----|
| Sets the deviation measurement status | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 22 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n + 3 | 0: OFF (no setting) 1: ON (with setting) | |
| Queries the deviation measurement setting | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 23 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n + 3 | Sets deviation measurement. | |
| Returns each CALCulate subsystem command in the order they are to be performed | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 24 | |
| | | n + 2 | 1: Primary parameter 2: Secondary parameter | |
| | | n + 3 | CALCulate subsystem command (FORM) (character string) | |
| | | n + 4 | | |
| | | n + 5 | CALCulate subsystem command (MATH) (character string) | |
| | | n + 6 | | |
| | | n + 7 | CALCulate subsystem command (LIM) (character string) | |
| | | n + 8 | | |
| Sets the level monitor function ON/OFF | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 25 | |
| | | n + 2 | 3: Current monitor 4: Voltage monitor | |
| | | n + 3 | 0: ON 1: OFF | |
| Queries the level monitor function | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 26 | |
| | | n + 2 | 3: Current monitor 4: Voltage monitor | |
| | | n + 3 | Level monitor function | |
| Sets the cable length | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 27 | |
| | | n + 2 | 0: 0 m 1: 1 m 2: 2 m 4: 4 m | |
| Queries the cable length | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 28 | |
| | | n + 2 | Cable length | |
| Stores the reference value for deviation measurement to the data buffer | 1 to 8 (PLC1 to 8) | n | Target Port No. | 5 |
| | | n + 1 | Command: 29 | |
| | | n + 2 | Data buffer 0: REF1 (reference value for primary parameter) 1: REF2 (reference value for secondary parameter) | |
| | | n + 3 | Numeric value (real number) | |
| | | n + 4 | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|---|-----------------------|--------------|---|----|
| Queries data in a data buffer | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 30 | |
| | | n + 2 | Data buffer 0: REF1 (reference value for primary parameter) 1: REF2 (reference value for secondary parameter) | |
| | | n + 3 | Data (real number) | |
| | | n + 4 | | |
| Queries data in a data buffer (BUF1/BUF2) *2 | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 31 | |
| | | n + 2 | Data buffer 0: BUF1 1: BUF2 | |
| | | n + 3 | Internal device memory address *3 | |
| Queries the level monitor value | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 32 | |
| | | n + 2 | 0: IMON (monitored current) 1: VMON (monitored voltage) | |
| | | n + 3 | Level monitor value (real number) | |
| | | n + 4 | | |
| Sets whether or not to feed measurement data to a data buffer | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 33 | |
| | | n + 2 | Data buffer 0: BUF1 1: BUF2 | |
| | | n + 3 | 0: " " (no feeding) 1: "CALCulate1" (primary parameter) 2: "CALCulate2" (secondary parameter) | |
| Queries whether or not measurement data is to be fed to a data buffer | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 34 | |
| | | n + 2 | Data buffer 0: BUF1 1: BUF2 | |
| | | n + 3 | Output result (7 characters) (character string) | |
| | | n + 4 | | |
| | | n + 5 | | |
| | | n + 6 | | |
| Sets whether or not to feed data to a data buffer *4 | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 35 | |
| | | n + 2 | Data buffer 0: BUF1 1: BUF2 | |
| | | n + 3 | 0: NEVer (no feeding) 1: ALWays (feed data each time measurement is performed) | |
| Queries whether or not data is to be fed to a data buffer | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 36 | |
| | | n + 2 | Data buffer 0: BUF1 1: BUF2 | |
| | | n + 3 | Output result (3 characters) (character string) | |
| | | n + 4 | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|---|-----------------------|--------------|---|----|
| Sets the data buffer size *4 | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 37 | |
| | | n + 2 | Data buffer 0: BUF1 1: BUF2 | |
| | | n + 3 | Numeric value (1 to 200) | |
| Queries the data buffer size | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 38 | |
| | | n + 2 | Data buffer 0: BUF1 1: BUF2 | |
| | | n + 3 | Data buffer size | |
| Sets the display ON or OFF | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 39 | |
| | | n + 2 | 0: OFF (not use) 1: ON (use) | |
| Queries whether the display is set to ON or OFF | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 40 | |
| | | n + 2 | Display setting | |
| Sets the number of display digits | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 41 | |
| | | n + 2 | Number of digits (3 to 5) | |
| Queries the number of display digits | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 42 | |
| | | n + 2 | Number of display digits | |
| Sets the displayed data | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 43 | |
| | | n + 2 | Display mode 1: Measurement display 2: Comparator result display | |
| Queries what data is selected to be displayed | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 44 | |
| | | n + 2 | Display mode | |
| Sets the instrument setting display mode on the right side of the display | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 45 | |
| | | n + 2 | Display mode 1: Displays the frequency and signal level. 2: Displays the DC bias setting and averaging rate. 3: Displays the trigger delay and cable length. 4: Displays the comparator limit value for the primary parameter. 5: Displays the comparator limit value for the secondary parameter. 6: Displays the level monitor value. | |
| Queries the selected mode for the instrument setting display on the right side of the display | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 46 | |
| | | n + 2 | Display mode | |

| Contents | F0 | F1 (= \$u n) | | F2 | |
|---|-----------------------|--------------|--|--|-----|
| Places measurement results in the output buffer | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 47 | | |
| | | | When command 48 is "0": ASCII specification | When command 48 is "1": REAL specification | |
| | | n + 2 | Measurement status | Measurement status (real number) | |
| | | n + 3 | Measurement value of primary parameter (real number) | | |
| | | n + 4 | | Measurement value of primary parameter (real number) | |
| | | n + 5 | Measurement value of secondary parameter (real number) | | |
| | | n + 6 | | Measurement value of secondary parameter (real number) | |
| | | n + 7 | Comparator result of primary parameter (when command 13 is "ON") | | |
| | | n + 8 | | Comparator result of primary parameter (when command 13 is "ON") (real number) | |
| | | n + 9 | Comparator result of primary parameter (when command 13 is "ON") (real number) | | |
| | | n + 10 | | Comparator result of primary parameter (when command 13 is "ON") (real number) | |
| | | n + 11 | | | |
| Sets the data transfer format | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 |
| | | n + 1 | Command: 48 | | |
| | | n + 2 | Display mode 0: ASCII 1: REAL (real number) | | |
| Queries the data transfer format | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 49 | | |
| | | n + 2 | Data transfer format (Max. 7 characters) (character string) | | |
| | | n + 3 | | | |
| | | n + 4 | | | |
| | | n + 5 | | | |
| Initiates the trigger system | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 50 | | |
| Sets whether the trigger system is continuously initiated or not | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 |
| | | n + 1 | Command: 51 | | |
| | | n + 2 | 0: OFF (no continuous initiation) 1: ON (continuous initiation) | | |
| Queries whether the trigger system is continuously initiated or not | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 52 | | |
| | | n + 2 | Output result | | |
| Sets the averaging rate for measurement results | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 4/3 |
| | | n + 1 | Command: 53 | | |
| | | n + 2 | 0: Numeric value | 1: MAXimum 2: MINimum | |
| | | n + 3 | Numeric value (1 to 256) | - | |
| Queries the averaging rate for measurement results | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 54 | | |
| | | n + 2 | Averaging rate | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|---|-----------------------|--------------|---|----|
| Sets whether or not to enable averaging for measurement results | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 55 | |
| | | n + 2 | 0: OFF (Disables averaging) 1: ON (Enables averaging) | |
| Queries whether or not averaging is enabled for measurement results | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 56 | |
| | | n + 2 | Output result | |
| Sets the reference value for load correction | 1 to 8 (PLC1 to 8) | n | Target Port No. | 6 |
| | | n + 1 | Command: 57 | |
| | | n + 2 | Resistance R (real number) | |
| | | n + 3 | | |
| | | n + 4 | Reactance (real number) | |
| | | n + 5 | | |
| Queries the reference value for load correction | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 58 | |
| | | n + 2 | Primary parameter (real number) | |
| | | n + 3 | | |
| | | n + 4 | Secondary parameter (real number) | |
| | | n + 5 | | |
| Measures the standard and saves the result as correction data | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 59 | |
| | | n + 2 | 0: STANdard1 (open correction) 1: STANdard2 (short correction) 2: STANdard3 (load correction) | |
| Sets the measurement error correction method | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 60 | |
| | | n + 2 | 0: REFL2 (open/short correction) 1: REFL3 (open/short/load correction) | |
| Queries the measurement error correction method | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 61 | |
| | | n + 2 | Setting result of measurement error function (5 characters) (character string) | |
| | | n + 3 | | |
| | | n + 4 | | |
| Queries the correction data | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 62 | |
| | | n + 2 | 0: STANdard1 (open correction) 1: STANdard2 (short correction) 2: STANdard3 (load correction) | |
| | | n + 3 | Primary parameter (real number) | |
| | | n + 4 | | |
| | | n + 5 | Secondary parameter (real number) | |
| | | n + 6 | | |
| Sets whether or not to enable the measurement error correction function | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 63 | |
| | | n + 2 | 0: OFF (Disables the correction function) 1: ON (Enables the correction function) | |

| Contents | F0 | F1 (= \$u n) | | F2 | |
|---|-----------------------|--------------|---|-----|--|
| Queries whether or not the measurement error correction function is enabled | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 | |
| | | n + 1 | Command: 64 | | |
| | | n + 2 | ON/OFF result of measurement error correction function | | |
| Sets the measurement time mode | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 | |
| | | n + 1 | Command: 65 | | |
| | | n + 2 | Numeric value (s) (real number) 0.025/0.065/0.500 | | |
| | | n + 3 | | | |
| Queries the measurement time mode | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 | |
| | | n + 1 | Command: 66 | | |
| | | n + 2 | Query response of measurement time (real number) | | |
| | | n + 3 | | | |
| Sets whether or not to enable the contact check function | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 | |
| | | n + 1 | Command: 67 | | |
| | | n + 2 | 0: OFF (not use) 1: ON (use) | | |
| Queries whether or not the contact check function is enabled | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 | |
| | | n + 1 | Command: 68 | | |
| | | n + 2 | Contact check function status | | |
| Sets whether or not to enable the auto range mode | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 | |
| | | n + 1 | Command: 69 | | |
| | | n + 2 | 0: OFF (hold mode) 1: ON (auto range mode) | | |
| Queries whether or not the auto range mode is enabled | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 | |
| | | n + 1 | Command: 70 | | |
| | | n + 2 | Auto range mode status | | |
| Sets the measurement range | 1 to 8 (PLC1 to 8) | n | Target Port No. | 5/3 | |
| | | n + 1 | Command: 71 | | |
| | | n + 2 | 0: Numeric value | | 1: MAXimum 2: MINimum 3: UP 4: DOWN |
| | | n + 3 | Numeric value (Ω) (real number) | | - |
| | | n + 4 | | | - |
| Queries the measurement range | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 | |
| | | n + 1 | Command: 72 | | |
| | | n + 2 | Query response of measurement time (real number) | | |
| | | n + 3 | | | |
| Sets whether or not to allow up to two <sensor_function>s at the same time *5 | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 | |
| | | n + 1 | Command: 73 | | |
| | | n + 2 | 0: OFF (Use only one) 1: ON (Use up to two simultaneously) | | |
| Queries whether or not up to two <sensor_function>s can be selected at the same time *5 | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 | |
| | | n + 1 | Command: 74 | | |
| | | n + 2 | Output result | | |

| Contents | F0 | F1 (= \$u n) | | | F2 |
|--|-----------------------|--------------|--|---|-----|
| Queries the number of <sensor_function>s | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 75 | | |
| | | n + 2 | Output result | | |
| Sets the specified measurement function to ON | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 |
| | | n + 1 | Command: 76 | | |
| | | | When command 73 is “OFF” | When command 73 is “ON” | |
| | | n + 2 | 0: Impedance measurement 1: Admittance measurement | 2: DCR measurement (equivalent series circuit) 3: DCR measurement (equivalent parallel circuit) 4: Turns ratio measurement of transformer 5: Mutual inductance measurement of transformer 6: Resistance measurement of transformer | |
| Queries which measurement function is ON | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 77 | | |
| | | n + 2 | Query response of specified measurement function (Max. 9 characters) (character string) | | |
| | | n + 3 | | | |
| | | n + 4 | | | |
| | | n + 5 | | | |
| | | n + 6 | | | |
| Sets the measurement frequency | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 5/3 |
| | | n + 1 | Command: 78 | | |
| | | n + 2 | 0: Numeric value | 1: MAXimum 2: MINimum | |
| | | n+3 | Numeric value (Hz) (real number) | - | |
| | | n+4 | | - | |
| Queries the measurement frequency | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 79 | | |
| | | n + 2 | Setting result of measurement frequency (real number) | | |
| | | n + 3 | | | |
| Sets the measurement signal level | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 5/3 |
| | | n + 1 | Command: 80 | | |
| | | n + 2 | 0: Numeric value | 1: MAXimum 2: MINimum | |
| | | n + 3 | Numeric value (0.02 to 1 V) (real number) Specified in steps of 0.004. | - | |
| | | n + 4 | | - | |
| Queries the measurement signal level | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 81 | | |
| | | n + 2 | Query response of measurement signal level (real number) | | |
| | | n + 3 | | | |

| Contents | F0 | F1 (= \$u n) | | | F2 |
|---|-----------------------|--------------|--|--------------------------|-----|
| Sets the DC bias voltage level | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 5/3 |
| | | n + 1 | Command: 82 | | |
| | | n + 2 | 0: Numeric value | 1: MAXimum 2: MINimum | |
| | | n + 3 | Numeric value (V) (real number) 0/1.5/2.1 | - | |
| | | n + 4 | | - | |
| Queries the DC bias voltage level | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 83 | | |
| | | n + 2 | Setting result of voltage level (real number) | | |
| | | n + 3 | | | |
| Sets the DC bias voltage source | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 |
| | | n + 1 | Command: 84 | | |
| | | n + 2 | 0: INT (Internal voltage source) 1: EXT (External voltage source) | | |
| Queries the DC bias voltage source | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 85 | | |
| | | n + 2 | Query response of voltage source (3 characters) (character string) | | |
| | | n + 3 | | | |
| Sets whether or not to enable DC bias output | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 |
| | | n + 1 | Command: 86 | | |
| | | n + 2 | 0: OFF (Disables DC bias output.) 1: ON (Enables DC bias output.) | | |
| Queries whether or not DC bias output is enabled | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 87 | | |
| | | n + 2 | Query response of whether or not DC bias output is enabled. | | |
| Queries the contents of the event register for the standard operation status group | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 88 | | |
| | | n + 2 | Output result | | |
| Queries the contents of the condition register of the standard operation status group | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 89 | | |
| | | n + 2 | Output result | | |
| Sets the enable register of the standard operation status group | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 3 |
| | | n + 1 | Command: 90 | | |
| | | n + 2 | Numeric value | | |
| Queries the contents of the enable register of the standard operation status group | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 91 | | |
| | | n + 2 | Output result | | |
| Clears the operation status and questionable status groups | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 92 | | |
| Queries the contents of the event register of the standard questionable status group | 1 to 8 (PLC1 to 8) | n | Target Port No. | | 2 |
| | | n + 1 | Command: 93 | | |
| | | n + 2 | Response (always "0" for 4263B) | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|--|-----------------------|--------------|--|----|
| Queries the contents of the condition register of the standard questionable status group | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 94 | |
| | | n + 2 | Response (always "0" for 4263B) | |
| Sets the enable register of the standard questionable status group | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 95 | |
| | | n + 2 | Numeric value (always "0" for 4263B) | |
| Queries the contents of the enable register of the standard questionable status group | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 96 | |
| | | n + 2 | Output result | |
| Produces a beep | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 97 | |
| Sets whether or not to enable the beeper | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 98 | |
| | | n + 2 | 0: OFF (Disables the beeper.) 1: ON (Enables the beeper.) | |
| Queries whether or not the beeper is enabled | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 99 | |
| | | n + 2 | Query response of whether or not beeper is enabled | |
| Queries the number and message of an existing error in the error queue | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 100 | |
| | | n + 2 | Error number and message (Max. 48 characters) (character string) | |
| | | : | | |
| | | n + 25 | | |
| Sets whether or not to lock the front-panel keys | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 101 | |
| | | n + 2 | 0: OFF (Does not lock the keys.) 1: ON (Locks the keys.) | |
| Queries whether or not the front-panel keys are locked | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 102 | |
| | | n + 2 | Query response of lock status | |
| Sets the power line frequency | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 103 | |
| | | n + 2 | Power line frequency (50, 60) | |
| Queries the power line frequency | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 104 | |
| | | n + 2 | Power line frequency (50, 60) | |
| Resets to the default state | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 105 | |
| Queries the value corresponding to the SCPI version | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 106 | |
| | | n + 2 | YYYY.V (YYYY: Year-version in four digits, V: revision number for that year) (real number) | |
| | | n+3 | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|--|-----------------------|--------------|--|----|
| Sets the trigger delay time | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 107 | |
| | | n + 2 | Delay time (0 to 9.999) (real number) | |
| | | n + 3 | | |
| Queries the trigger delay time | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 108 | |
| | | n + 2 | Delay time (real number) | |
| | | n + 3 | | |
| Causes the trigger to execute a measurement immediately | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 109 | |
| Sets the trigger mode | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 110 | |
| | | n + 2 | Trigger mode 0: BUS (Triggers single measurements with the GET and *TRG commands.) 1: EXternal (Inputs a TTL pulse for the external trigger terminal or the handler interface on the rear panel.) 2: INTERNAL (Executes measurement by internal trigger signals.) 3: MANUAL (Executes measurements by the trigger key on the front panel.) | |
| Queries the trigger mode | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 111 | |
| | | n + 2 | Trigger mode (3 characters) (character string) | |
| | | n + 3 | | |
| Clears the status byte register, operation status event register, questionable status register, and standard event status register | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 112 | |
| Sets the bits of the standard event status enable register | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 113 | |
| | | n + 2 | Numeric value: Sets the bit weight. | |
| Queries the bits of the standard event status enable register | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 114 | |
| | | n + 2 | Value in register | |
| Queries the bits of the standard event status register | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 115 | |
| | | n + 2 | Value in register | |
| Queries an identification string | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 116 | |
| | | n + 2 | Manufacturer (15 characters), model number (5 characters), serial number in Agilent's format (10 characters), firmware version number (5 characters) | |
| | | : | | |
| | | n + 15 | | |
| Queries the sequence of commands which defines the current state | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 117 | |
| | | n + 2 | Command (Max. 48 characters) (character string) | |
| | | : | | |
| | | n+25 | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|--|-----------------------|--------------|--|----|
| Sets bit "0" in the standard event status register when all pending operations are completed | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 118 | |
| Queries the completion of all pending operations | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 119 | |
| | | n + 2 | Output result | |
| Queries option identification numbers | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 120 | |
| | | n + 2 | Option identification number (3 characters) (character string) | |
| | | n + 3 | | |
| Calls the instrument setting stored in the specified register number | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 121 | |
| | | n + 2 | Register number (0 to 9) | |
| Returns to the default setting | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 122 | |
| Saves the instrument setting to the specified register number | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 123 | |
| | | n + 2 | Register number (0 to 9) | |
| Sets the bits of the service request enable register | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 124 | |
| | | n + 2 | Sets the bit weight. | |
| Queries the contents of the service request enable register | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 125 | |
| | | n + 2 | Content of service request enable register | |
| Queries the status byte | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 126 | |
| | | n + 2 | Content of status byte register | |
| Executes the trigger | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 127 | |
| Queries error codes | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 128 | |
| | | n + 2 | Sum of error codes Error Code 1: RAM 2: EPROM 4: Calibration data (EEPROM) 8: User's data (EEPROM) 16: A/D converter 32: Backup RAM | |
| Waits until all commands are completed | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 129 | |

Return data: Data stored from the panel meter to the TS2060

*1 "Sets the specified measurement function to ON. (command 76)" must be specified.

*2 "Sets the data buffer size. (command 37)" must be specified.

*3 Data is stored from the specified internal device memory (\$u).

*4 Specify the data to feed using "Sets whether or not to feed measurement data to a data buffer. (command 33)".

*5 Only when option 001 is available.


3.1.2 Wiring Diagrams

A GPIB serial converter is necessary to connect the TS2060 series with the 4263 series.
This section shows the wiring diagrams for the TS2060 series and the GPIB serial converter.

When Connected at CN1:


RS-232C

Wiring diagram 1 - C2



RS-422/485


Wiring diagram 1 - C4



When Connected at MJ1/MJ2:


RS-232C

Wiring diagram 1 - M2




RS-422/485

Wiring diagram 1 - M4



Wiring diagram 2 - M4



4. ALLEN BRADLEY

4.1 PLC Connection

4.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*3} |
|-------------------------------|---|-------------|--------------|---|--|----------------------------|-------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | |
| PLC-5 | PLC-5/10, PLC-5/12, PLC-5/15, PLC-5/25 | 1785-KE | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 4 - M2 | | × |
| | | 1770-KF2 | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 5 - M2 | | |
| | | | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | |
| | PLC-5/11, PLC-5/20, PLC-5/20E, PLC-5/30, PLC-5/40, PLC-5/40L, PLC-5/40E, PLC-5/60, PLC-5/60L, PLC-5/80, PLC-5/80E | Channel 0 | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 5 - M2 | | |
| | | | RS-422 | Wiring diagram 3 - C4 | × | Wiring diagram 3 - M4 | |
| | | 1785-KE | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 4 - M2 | | |
| | | 1770-KF2 | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 5 - M2 | | |
| | | | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | |
| Control Logix / Compact Logix | 1756 Control Logix | Logix 5550 | RS-232C | Wiring diagram 1 - C2 ^{*4} | Wiring diagram 1 - M2 | | × |
| | 1769 Compact Logix | Channel 0 | | | | | ○ |
| SLC500 | SLC5/03 and later | Channel 0 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | × |
| | | 1747-KE DF1 | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | |
| MicroLogix | MicroLogix 1000 MicroLogix 1100 MicroLogix 1500 | Channel 0 | RS-232C | AB's "1761-CBL-PM02" + Gender changer ^{*5} | AB's "1761-CBL-PM02" + Wiring diagram 3 - M2 | | × |
| Micro800 Controllers | 2080-LC20 2080-LC30 2080-LC50 | Serial port | RS-232C | Wiring diagram 5 - C2 | Wiring diagram 6 - M2 | | × |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*3} For the ladder transfer function, see the TS2060 Reference Manual 2.

^{*4} Can be connected using the AB's "1756-CP3" cable + D-sub gender changer (9-pin, female-to-male) commercially available.

^{*5} Use a D-sub gender changer (9-pin, female-to-male) commercially available.

| Manufacturer | Model |
|--------------|----------|
| Black Box | FA440-R2 |
| Misumi | DGC-9PP |

Ethernet Connection (TS2060i Only)

| PLC Selection on the Editor | CPU | Unit | TCP/IP ^{*1} | UDP/IP | Port No. | Keep Alive ^{*2} | Ladder Transfer ^{*3} |
|---|--|-------------------------------------|----------------------|--------|----------------------------------|--------------------------|-------------------------------|
| PLC-5 (Ethernet) | PLC-5/20E PLC-5/40E PLC-5/80E | - | ○ | × | 44818 fixed | × | × |
| Control Logix (Ethernet) | Logix 5550 | 1756-ENBT/A | ○ | × | 44818 fixed | × | × |
| | 1769-L32E 1769-L35E 1769-L27ERM-QBFC1B ^{*2} | - | | | | | |
| SLC500 (Ethernet TCP/IP) | SLC 5/05 | 1747-L551 1747-L552 1747-L553 | | | | | |
| MicroLogix (Ethernet TCP/IP) | MicroLogix 1100 | - | ○ | × | Fixed to 44818 (Max. 6 units) | × | × |
| NET-ENI (SLC500 Ethernet TCP/IP) | SLC 5/03 SLC 5/04 SLC 5/05 | 1761-NET-ENI 1761-NET-ENI W | ○ | × | Fixed to 44818 (Max. 6 units) | × | × |
| NET-ENI (MicroLogix Ethernet TCP/IP) | MicroLogix 1000 MicroLogix 1100 MicroLogix 1200 MicroLogix 1500 | 1761-NET-ENI 1761-NET-ENI W | ○ | × | Fixed to 44818 (Max. 6 units) | × | × |
| Micro800 Controllers (Ethernet TCP/IP) | 2080-LC20 2080-LC50 | - | ○ | × | Fixed to 44818 | ○ | × |

^{*1} Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

^{*2} For KeepAlive functions, see "1.3.2 Ethernet Communication (TS2060i Only)".

^{*3} For the ladder transfer function, see the TS2060 Reference Manual 2.

4.1.1 PLC-5

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--------------------------------------|
| Connection Mode | <u>1:1</u> / 1 : n / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> bps | |
| Data Length | 7 / <u>8</u> bits | Fixed to 8 bits except for Channel 0 |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Even</u> | |
| Target Port No. | <u>0</u> to 31 | |

PLC

Series A 1785-KE

SW-1 (RS-232C link features)

| No. | Item | Setting | Remarks |
|---------|---------------------------|----------------------------------|---|
| 1, 2, 5 | RS-232C Link Features | SW1: OFF SW2: OFF SW5: OFF | Error check: BCC Parity: None Embedded response: No |
| | | SW1: ON SW2: OFF SW5: OFF | Error check: BCC Parity: Even Embedded response: No |
| 3 | Detect duplicate messages | ON | Detect and ignore duplicate messages |
| 4 | Hand shaking signals | OFF | Ignore handshaking signals |

SW-2 (for future use)

| No | Setting | Remarks |
|------|--|---------|
| 1, 2 | OFF Always OFF (system reserved) | |

SW-3, SW-4 (node number)

| SW | Item | Setting | Remarks |
|------|--------------------|---|--|
| SW-3 | First digit (OCT) | No. 0 1 2 3 4 5 6 7 | Setting example: Station number 15 (DEC) = 17 (OCT) |
| | | SW1 OFF ON OFF ON OFF ON OFF ON | |
| | | SW2 OFF OFF ON ON OFF OFF ON ON | |
| | | SW3 OFF OFF OFF OFF ON ON ON ON | |
| SW-4 | Second digit (OCT) | No. 0 1 2 3 4 5 6 7 | SW-3: ON, OFF, OFF SW-4: ON, ON, ON |
| | | SW1 OFF ON OFF ON OFF ON OFF ON | |
| | | SW2 OFF OFF ON ON OFF OFF ON ON | |
| | | SW3 OFF OFF OFF OFF ON ON ON ON | |

SW-5 (network link communication rate)

| No. | Item | Setting | Remarks |
|-----|----------------------------|------------------|--------------|
| 1 | Network Communication Rate | ON | For DH+ port |
| 2 | | ON | |
| | | 57600 bps | |

SW-6 (RS-232C communication rate and diagnostic commands)

| No. | Item | Setting | | | | Remarks |
|-----|----------------------------|---------|-----------------------------|----------|-----------|--|
| 1 | RS-232C Communication Rate | | | | | Set the same value as the one set on TS2060. |
| 2 | | | 4800 bps | 9600 bps | 19200 bps | |
| 3 | | SW1 | ON | OFF | ON | |
| | | SW2 | OFF | ON | ON | |
| | | SW3 | ON | ON | ON | |
| 4 | Diagnostic Commands | ON | Execute diagnostic commands | | | |

Series B 1785-KE**SW-1 (RS-232C link features)**

| No. | Item | Setting | | Remarks |
|-----|---------------------------|----------------------------------|---|---------|
| 1-3 | RS-232C Link Features | SW1: OFF SW2: OFF SW3: OFF | Error check: BCC Parity: None Embedded response: No | |
| | | SW1: ON SW2: OFF SW3: OFF | Error check: BCC Parity: Even Embedded response: No | |
| 4 | Detect duplicate messages | ON | Detect and ignore duplicate messages | |
| 5 | Hand shaking signals | OFF | Ignore handshaking signals | |
| 6 | Diagnostic Commands | ON | Execute diagnostic commands | |

SW-2 (node number)

| No. | Item | Setting | | | | | | | | | Remarks | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----|---------------|---|--------------------|-----|-----|-----|-----|-----|-----|----|---------|---|---|---|---|---|---|---|---|-----|-----|----|-----|----|-----|----|-----|----|-----|-----|-----|----|----|-----|-----|----|----|-----|-----|-----|-----|-----|----|----|----|----|--|
| 1 | Octal Digit 0 | 0 | SW1: ON SW2: ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3-5 | Octal Digit 1 | <table><tr><td>No.</td><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td></tr><tr><td>SW3</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td></tr><tr><td>SW4</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td></tr><tr><td>SW5</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td></tr></table> | | | | | | | | | No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | SW3 | OFF | ON | OFF | ON | OFF | ON | OFF | ON | SW4 | OFF | OFF | ON | ON | OFF | OFF | ON | ON | SW5 | OFF | OFF | OFF | OFF | ON | ON | ON | ON | Setting example: Station number 15 (DEC) = 17 (OCT) |
| | | No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | SW3 | OFF | ON | OFF | ON | OFF | ON | OFF | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | SW4 | OFF | OFF | ON | ON | OFF | OFF | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | SW5 | OFF | OFF | OFF | OFF | ON | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6-8 | Octal Digit 2 | <table><tr><td>No.</td><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td></tr><tr><td>SW6</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td></tr><tr><td>SW7</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td></tr><tr><td>SW8</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td></tr></table> | | | | | | | | | No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | SW6 | OFF | ON | OFF | ON | OFF | ON | OFF | ON | SW7 | OFF | OFF | ON | ON | OFF | OFF | ON | ON | SW8 | OFF | OFF | OFF | OFF | ON | ON | ON | ON | SW3-5: ON, OFF, OFF SW6-8: ON, ON, ON |
| | | No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | SW6 | OFF | ON | OFF | ON | OFF | ON | OFF | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | SW7 | OFF | OFF | ON | ON | OFF | OFF | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | SW8 | OFF | OFF | OFF | OFF | ON | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

SW-3 (communication rates and local/remote option)

| No. | Item | Setting | | | | Remarks |
|-----|----------------------------|---------|------------|----------|-----------|--|
| 1 | Network Communication Rate | ON | 57600 bps | | | For DH+ port |
| 2 | | ON | | | | |
| 3-5 | RS-232 Link Baud Rate | | 4800 bps | 9600 bps | 19200 bps | Set the same value as the one set on TS2060. |
| | | SW3 | ON | OFF | ON | |
| | | SW4 | OFF | ON | ON | |
| | | SW5 | ON | ON | ON | |
| 6 | Local / Remote operation | ON | Local mode | | | |

SW-4 (for future use)

| No. | Setting | | Remarks |
|-----|---------|------------------------------|---------|
| 1-4 | OFF | Always OFF (system reserved) | |

* Series B 1785-KE switch: ON = 0: DOWN (lower), OFF = 1: UP (upper)

1770-KF2

Setting changes will take effect when the power is turned on. After changing a setting, turn the power off and back on again.

SW-1 (asynchronous link features)

| No. | Item | Setting | | Remarks |
|---------|----------------------------|----------------------------------|---|---------|
| 1, 2, 5 | Asynchronous Link Features | SW1: OFF SW2: OFF SW5: OFF | Error check: BCC Parity: None Embedded response: No | |
| | | SW1: ON SW2: OFF SW5: OFF | Error check: BCC Parity: Even Embedded response: No | |
| 3 | Detect duplicate messages | ON | Detect and ignore duplicate messages | |
| 4 | Hand shaking signals | OFF | Ignore handshaking signals | |

SW-2, SW-3, SW-4 (station number)

| SW | Item | Setting | | | | | | | | | Remarks |
|------|-----------------------|---------|--------------------|-----|-----|-----|-----|-----|-----|----|--|
| SW-2 | First Digit | 0 | SW1: ON SW2: ON | | | | | | | | |
| SW-3 | Second Digit (OCT) | | | | | | | | | | Setting example: Station number 15 (DEC) = 17 (OCT) |
| | | No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | |
| | | SW3 | OFF | ON | OFF | ON | OFF | ON | OFF | ON | |
| | | SW4 | OFF | OFF | ON | ON | OFF | OFF | ON | ON | |
| SW-4 | Third Digit (OCT) | | | | | | | | | | SW-3: ON, OFF, OFF SW-4: ON, ON, ON |
| | | No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | |
| | | SW6 | OFF | ON | OFF | ON | OFF | ON | OFF | ON | |
| | | SW7 | OFF | OFF | ON | ON | OFF | OFF | ON | ON | |
| SW-4 | Third Digit (OCT) | | | | | | | | | | SW-3: ON, OFF, OFF SW-4: ON, ON, ON |
| | | No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | |
| | | SW8 | OFF | OFF | OFF | OFF | ON | ON | ON | ON | |
| | | SW8 | OFF | OFF | OFF | OFF | ON | ON | ON | ON | |

SW-5 (network link communication rate)

| No. | Item | Setting | | Remarks |
|-----|----------------------------|-----------|------------------|--------------|
| 1 | Network Communication Rate | ON | 57600 bps | For DH+ port |
| 2 | | ON | | |

SW-6 (asynchronous link communication rate and diagnostic commands)

| No. | Item | Setting | | | Remarks |
|---------|---------------------------------|-----------|---|----------|--|
| 1, 2, 3 | Asynchronous Communication Rate | | 4800 bps | 9600 bps | Set the same value as the one set on TS2060. |
| | | SW1 | ON | OFF | |
| | | SW2 | OFF | ON | |
| | | SW3 | ON | ON | |
| 4 | Diagnostic Commands | ON | Execute Received Diagnostic Commands | | |

SW-7 (selecting the network link)

| No. | Item | Setting | | Remarks |
|-----|----------------------------|------------|--------------------------------|---------|
| 1 | Selecting the Network Link | ON | Peer Communication Link | |
| 2 | | OFF | | |

SW-8 (RS-232-C/RS-422-A selection)

| No. | Item | Setting | | | Remarks |
|------|---------------------------------|---------|---------|--------|---------|
| 1, 2 | Selection of RS-232C / RS-422-A | | RS-232C | RS-422 | |
| | | SW1 | OFF | ON | |
| | | SW2 | ON | OFF | |

Channel 0

SW-2 (selection of RS-232C/RS-422A)

| SW | Setting | | | Remarks |
|-----|---------|---------|-----|---|
| No. | RS-232C | RS-422A | | |
| SW2 | 1 | ON | OFF | ON: Lower position OFF: Upper position |
| | 2 | ON | OFF | |
| | 3 | ON | ON | |
| | 4 | OFF | OFF | |
| | 5 | OFF | OFF | |
| | 6 | ON | OFF | |
| | 7 | ON | OFF | |
| | 8 | OFF | OFF | |
| | 9 | ON | ON | |
| | 10 | OFF | OFF | |

Channel configuration


| Item | Setting | Remarks |
|-------------|-----------------------------|--------------------------------|
| Channel 0 | Communication Mode | System (Point-To-Point) |
| | Remote Mode Change | Unchecked |
| Serial Port | Baud Rate | 4800 / 9600 / 19.2 K |
| | Bits Per Char | 7 / 8 |
| | Stop Bits | 1 / 2 |
| | Control Line | No Handshaking |
| | Parity | None / Even |
| | Error Detect | BCC |
| Options | Detect Duplicate Messages | Checked |
| | NAK Receive | 3 |
| | DF1 ENQs | 3 |
| | ACK Timeout (20 msec) | 50 |
| | Message application timeout | 30 seconds |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|-------------|
| N | (integer) | 00H | |
| B | (bit) | 01H | |
| T.ACC | (timer/current value) | 02H | |
| T.PRE | (timer/set value) | 03H | |
| C.ACC | (counter/current value) | 04H | |
| C.PRE | (counter/set value) | 05H | |
| I | (input) | 06H | |
| O | (output) | 07H | |
| S | (status) | 08H | |
| T | (timer/control) | 09H | |
| C | (counter/control) | 0AH | |
| R | (control) | 0BH | |
| R.LEN | (control/data length) | 0CH | |
| R.POS | (control/data position) | 0DH | |
| D | (BCD) | 0EH | |
| A | (ASCII) | 0FH | |
| F | (FLOAT) | 10H | Real number |
| ST | (STRING) | 11H | |


Make settings for "Data Files" using the ladder tool. Otherwise, "Error Code F007", etc. is displayed on MONITOUCH. For more information, refer to the PLC manual issued by the manufacturer.




Address denotations

The assigned device memory is expressed as shown below when editing the screen.

Example: For word access



For bit access



The file number will not be displayed for the input, output or status device memory.

Indirect Device Memory Designation

- For the file numbers 0 to 65:

| | | | | | | |
|-------|-------------|-----|---|---|-----------------|---|
| | 15 | MSB | 8 | 7 | LSB | 0 |
| n + 0 | Model | | | | Device type | |
| n + 1 | Address No. | | | | | |
| n + 2 | 00 | | | | Bit designation | |
| n + 3 | 00 | | | | Station number | |

- For the file numbers 66 to 255:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-------|--------------------|-----|---|---|-----------------|---|
| n + 0 | Model | | | | Device type | |
| n + 1 | Lower address No. | | | | | |
| n + 2 | Higher address No. | | | | | |
| n + 3 | 00 | | | | Bit designation | |
| n + 4 | 00 | | | | Station number | |

- Specify the file number as well as the element number for the address number.

Example: When specifying N007:123
Specify "7123" (DEC) for the address number.

Example: When specifying N120:123
Specify "120123" (DEC) for the address number.
120123 (DEC) is equivalent to 1D53B (HEX). Specify "D53B (HEX)" for the lower address number and "0001" for the upper address number.

- When specifying an address for the timer (control), counter (control) or control device memory in bit designation, specify the bit number in decimal notation as shown below:
 - T: Timer (control)
DN = 13, TT = 14, EN = 15
 - C: Counter (control)
UA = 10, UN = 11, OV = 12, DN = 13, CD = 14, CU = 15
 - R: Control
FD = 08, IN = 09, UL = 10, ER = 11, EM = 12, DN = 13, EU = 14, EN = 15

4.1.2 PLC-5 (Ethernet)

Communication Setting

Editor

Make the following settings on the editor. For more information, see “1.3.2 Ethernet Communication (TS2060i Only)”.

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 44818) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

Channel 2

Channel configuration (channel 2)

Edit Channel Properties

Channel 0 | Channel 1A | Channel 1B | Channel 2

Diagnostics File: 0

Ethernet Configuration

Ethernet Address: 00:00:BC:1C:BF:D2

Network Configuration Type

☒ Static ☐ Dynamic

☐ Use DHCP to obtain network configuration

☒ Use BOOTP to obtain network configuration

IP Address: 192 168 1 2

Message Connect Timeout (msec): 15000

Message Reply Timeout (msec): 3000

Inactivity Timeout (minutes): 30

Link ID: 0

Advanced Functions

Subnet Mask: 255 255 255 0

Gateway Address: 0 0 0 0


| Item | Setting | Remarks |
|----------------------------|---------------------------------------|---------|
| Network Configuration Type | Static | |
| IP Address | Set the IP address of the PLC. | |
| Subnet Mask | Set the subnet mask of the PLC. | |
| Gateway Address | Specify according to the environment. | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|-------------|
| N | (integer) | 00H | |
| B | (bit) | 01H | |
| T.ACC | (timer/current value) | 02H | |
| T.PRE | (timer/set value) | 03H | |
| C.ACC | (counter/current value) | 04H | |
| C.PRE | (counter/set value) | 05H | |
| I | (input) | 06H | |
| O | (output) | 07H | |
| S | (status) | 08H | |
| T | (timer/control) | 09H | |
| C | (counter/control) | 0AH | |
| R | (control) | 0BH | |
| R.LEN | (control/data length) | 0CH | |
| R.POS | (control/data position) | 0DH | |
| D | (BCD) | 0EH | |
| A | (ASCII) | 0FH | |
| F | (FLOAT) | 10H | Real number |
| ST | (STRING) | 11H | |


Make settings for "Data Files" using the ladder tool. Otherwise, "Error Code F007", etc. is displayed on MONITOUCH. For more information, refer to the PLC manual issued by the manufacturer.




Address denotations

The assigned device memory is expressed as shown below when editing the screen.

Example: For word access



For bit access



The file number will not be displayed for the input, output or status device memory.

Indirect Device Memory Designation

- For the file numbers 0 to 65:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-----|-------------|-----|---|-----------------|-----|---|
| n+0 | Model | | | Device type | | |
| n+1 | Address No. | | | | | |
| n+2 | 00 | | | Bit designation | | |
| n+3 | 00 | | | Station number | | |

- For the file numbers 66 to 255:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-----|--------------------|-----|---|---|-----------------|---|
| n+0 | Model | | | | Device type | |
| n+1 | Lower address No. | | | | | |
| n+2 | Higher address No. | | | | | |
| n+3 | 00 | | | | Bit designation | |
| n+4 | 00 | | | | Station number | |

- Specify the file number as well as the element number for the address number.

Example: When specifying N007:123
Specify "7123" (DEC) for the address number.

Example: When specifying N120:123
Specify "120123" (DEC) for the address number.
120123 (DEC) is equivalent to 1D53B (HEX). Specify "D53B (HEX)" for the lower address number and "0001" for the higher address number.

- When specifying an address for the timer (control), counter (control) or control device memory in bit designation, specify the bit number in decimal notation as shown below:
 - T: Timer (control)
DN = 13, TT = 14, EN = 15
 - C: Counter (control)
UA = 10, UN = 11, OV = 12, DN = 13, CD = 14, CU = 15
 - R: Control
FD = 08, IN = 09, UL = 10, ER = 11, EM = 12, DN = 13, EU = 14, EN = 15

4.1.3 Control Logix / Compact Logix

The logical port PLC1 can only be selected because the tag table is used.

Communication Setting

Editor

Communication setting


(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---|
| Connection Mode | <u>1</u> : <u>1</u> / Multi-link2 | For multi-link2, be sure to use the same tag table. |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 115k bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>0</u> to 31 | |

PLC

Control Logix

Serial port



| Item | Setting | Remarks |
|--------------|--------------|---------|
| Mode | System | |
| Baud Rate | 38400 | |
| Data Bits | 8 | |
| Parity | None | |
| Stop Bits | 1 | |
| Control Line | No Handshake | |

System protocol

Controller Properties - hhh

Minor Faults | Date/Time | Advanced | SFC Execution | File | Memory
General | Serial Port* | System Protocol | User Protocol | Major Faults

Protocol: DF1 Point to Point

Station Address: 0

NAK Receive Limit: 3

ENQ Transmit Limit: 3

ACK Timeout: 50 (x20 ms)

Embedded Responses: Autodetect

Error Detection: ☒ BCC ☐ CRC

☒ Enable Duplicate Detection

| Item | Setting | Remarks |
|----------------------------|--------------------|---------|
| Protocol | DF1 Point to Point | |
| Station Address | 0 | |
| NAK Receive Limit | 3 | |
| ENQ Transmit Limit | 3 | |
| ACK Timeout | 50 | |
| Embedded Responses | Autodetect | |
| Error Detection | BCC | |
| Enable Duplicate Detection | Checked | |

Compact Logix

CH0 - serial port

Controller Properties - hhh

Advanced | SFC Execution | File | Nonvolatile Memory | Memory
CH1 - Serial Port | CH1 - System Protocol | Major Faults | Minor Faults | Date/Time
General | CH0 - Serial Port | CH0 - System Protocol | CH0 - User Protocol

Mode: System

Baud Rate: 38400

Data Bits: 8

Parity: None

Stop Bits: 1

Control Line: No Handshake

☐ Continuous Carrier


RTS Send Delay: 0 (x20 ms)

RTS Off Delay: 0 (x20 ms)

Show Offline Values

| Item | Setting | Remarks |
|--------------|--------------|---------|
| Mode | System | |
| Baud Rate | 38400 | |
| Data Bits | 8 | |
| Parity | None | |
| Stop Bits | 1 | |
| Control Line | No Handshake | |

CH0 - system protocol



| Item | Setting | Remarks |
|----------------------------|--------------------|---------|
| Protocol | DF1 Point to Point | |
| Station Address | 0 | |
| NAK Receive Limit | 3 | |
| ENQ Transmit Limit | 3 | |
| ACK Timeout | 50 | |
| Embedded Responses | Autodetect | |
| Error Detection | BCC | |
| Enable Duplicate Detection | Checked | |

Available Device Memory

Create a CSV file by exporting “tag” created by using the ladder tool of the PLC. Then import the CSV file into the editor to set the PLC device memory.
For more information on importing, exporting and creating a tag, refer to “Connection with A•B Control Logix” provided separately.

Indirect Device Memory Designation

Not available

4.1.4 Control Logix (Ethernet)


The logical port PLC1 can only be selected because the tag table is used.

Communication Setting


Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 44818) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].



- Others
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting] → [Use CPU Slot No. Setting]
 - [None] (default)
The CPU slot No. is fixed to "0".



| CPU | Ethernet | | |
|-----------|-----------|-----------|-----------|
| Slot No.0 | Slot No.1 | Slot No.2 | Slot No.3 |

- [Yes]
Specify the CPU slot number at the [PLC Table] under [Target Settings] on the [PLC Properties] window ([System Setting] → [Hardware Setting]).
Setting range: 0 to 16

The screenshot shows the 'PLC1 Properties Allen-Bradley ControlLogix(Ethernet)' window. In the 'Target Settings' section, 'Use CPU Slot No. Setting' is set to 'Yes'. A red circle highlights the 'Setting...' button. A red arrow points from this button to the 'PLC Table' window below.

The 'PLC Table' window displays a table with the following data:

| No. | Port Name | IP Address | Port No. | CPU SlotNo |
|-----|-----------|-------------|----------|------------|
| 0 | | | | |
| 1 | PLC | 192.168.1.1 | 44818 | 2 |
| 2 | | | | |
| 3 | | | | |
| 4 | | | | |
| 5 | | | | |
| 6 | | | | |
| 7 | | | | |
| 8 | | | | |
| 9 | | | | |
| 10 | | | | |
| 11 | | | | |
| 12 | | | | |
| 13 | | | | |

A red circle highlights the 'CPU SlotNo' column in the table. A red arrow points from the 'Setting...' button in the 'PLC1 Properties' window to the 'CPU SlotNo' column in the 'PLC Table' window.

Valid only for 1 : 1 connection

CPU slot No. 0 to 16

PLC

Use one of the following utilities to set an IP address. For more information, refer to the PLC manual issued by the manufacturer.

- BOOTP utility
- RSLinx software
- RSLogix 5000 software

Available Device Memory

Create a CSV file by exporting "tag" created by using the ladder tool of the PLC. Then import the CSV file into the editor to set the PLC device memory.

For more information on importing, exporting and creating a tag, refer to "Connection with A•B Control Logix" provided separately.

Indirect Device Memory Designation

Not available

4.1.5 SLC500

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1</u> :1 / 1:n / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Even</u> | |
| Target Port No. | <u>0</u> to 31 | |

PLC

Channel 0

Channel configuration (chan. 0 - system)



The screenshot shows the 'Channel Configuration' dialog box with the 'Chan. 0 - System' tab selected. The settings are as follows:

- Driver: DF1 Full Duplex
- Baud: 19200
- Parity: NONE
- Stop Bits: 1
- Source ID: 9 (decimal)
- Control Line: No Handshaking
- Error Detection: BCC
- Embedded Responses: Auto Detect
- ☒ Duplicate Packet Detect
- ACK Timeout (x20 ms): 50
- NAK Retries: 3
- ENQ Retries: 3

(Underlined setting: default)

| Item | Setting | Remarks |
|-------------------------|------------------------|---------|
| Driver | DF1 Full Duplex | |
| Baud | 9600 / 19200 / 38400 | |
| Parity | <u>None</u> / Even | |
| Stop Bits | <u>1</u> / 2 | |
| Control Line | No Handshaking | |
| Error Detection | BCC | |
| Embedded Responses | Auto Detect | |
| Duplicate Packet Detect | Checked | |

1747-KE**Jumper JW2**

| Item | Setting | Remarks |
|--------|---|---------|
| RS-232 |  | |
| RS-422 |  | |

DF1 port setup menu

| Item | Setting | Remarks |
|--------------------|---------|---------|
| Baudrate | 19200 | |
| Bits Per Character | 8 | |
| Parity | Even | |
| Stop Bits | 1 | |

DF1 full-duplex setup menu


| Item | Setting | Remarks |
|----------------------------|-------------|---------|
| Duplicate Packet Detection | Enabled | |
| Checksum | BCC | |
| Constant Carrier Detect | Disabled | |
| Message Timeout | 400 | |
| Hardware Handshaking | Disabled | |
| Embedded Response Detect | Auto Detect | |
| ACK Timeout (× 5 ms) | 90 | |
| ENQuiry Retries | 3 | |
| NAK Received Retries | 3 | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|-------------|
| N | (integer) | 00H | |
| B | (bit) | 01H | |
| T. ACC | (timer/current value) | 02H | |
| T. PRE | (timer/set value) | 03H | |
| C. ACC | (counter/current value) | 04H | |
| C. PRE | (counter/set value) | 05H | |
| I | (input) | 06H | |
| O | (output) | 07H | |
| S | (status) | 08H | |
| T | (timer/control) | 09H | |
| C | (counter/control) | 0AH | |
| R | (control) | 0BH | |
| R. LEN | (control/data length) | 0CH | |
| R. POS | (control/data position) | 0DH | |
| D | (BCD) | 0EH | |
| A | (ASCII) | 0FH | |
| F | (FLOAT) | 10H | Real number |
| ST | (STRING) | 11H | |


Make settings for "Data Files" using the ladder tool. Otherwise, "Error Code 10 00" is displayed on MONITOUCH. For more information, refer to the PLC manual issued by the manufacturer.




Address denotations

The assigned device memory is expressed as shown below when editing the screen.

- Address other than input/output
 - For word access




For bit access




The file number will not be displayed for the input, output or status device memory.

- Input/output address
 - For word access



For bit access



Indirect Device Memory Designation

- For the file or slot numbers 0 to 65:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-------|-------------|-----|---|---|-----------------|---|
| n + 0 | Model | | | | Device type | |
| n + 1 | Address No. | | | | | |
| n + 2 | 00 | | | | Bit designation | |
| n + 3 | 00 | | | | Station number | |

- For the file or slot numbers 66 to 255:

| | 15 | MSB | 8 | 7 | LSB | 0 | |
|-------|--------------------|-----|---|---|-----------------|---|--|
| n + 0 | Model | | | | Device type | | |
| n + 1 | Lower address No. | | | | | | |
| n + 2 | Higher address No. | | | | | | |
| n + 3 | 00 | | | | Bit designation | | |
| n + 4 | 00 | | | | Station number | | |

- Specify the file number or slot number and the element number for the address number.

Example: When specifying N007:123
Specify "7123" (DEC) for the address number.

Example: When specifying N120:123
Specify "120123" (DEC) for the address number.
120123 (DEC) is equivalent to 1D53B (HEX). Specify "D53B (HEX)" for the lower address number and "0001" for the upper address number.

- When specifying an address for the timer (control), counter (control) or control device memory in bit designation, specify the bit number in decimal notation as shown below:

- T: Timer (control)
DN = 13, TT = 14, EN = 15
- C: Counter (control)
UA = 10, UN = 11, OV = 12, DN = 13, CD = 14, CU = 15
- R: Control
FD = 08, IN = 09, UL = 10, ER = 11, EM = 12, DN = 13, EU = 14, EN = 15

4.1.6 SLC500 (Ethernet TCP/IP)

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 44818) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

Channel 1

Channel configuration (channel 1)


| Item | Setting | Remarks |
|-----------------|---|---------|
| Driver | Ethernet | |
| IP Address | PLC's IP address | |
| Subnet Mask | PLC's subnet mask | |
| Gateway Address | Make settings in accordance with the network environment. | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|-------------|
| N | (integer) | 00H | |
| B | (bit) | 01H | |
| T. ACC | (timer/current value) | 02H | |
| T. PRE | (timer/set value) | 03H | |
| C. ACC | (counter/current value) | 04H | |
| C. PRE | (counter/set value) | 05H | |
| I | (input) | 06H | |
| O | (output) | 07H | |
| S | (status) | 08H | |
| T | (timer/control) | 09H | |
| C | (counter/control) | 0AH | |
| R | (control) | 0BH | |
| R. LEN | (control/data length) | 0CH | |
| R. POS | (control/data position) | 0DH | |
| A | (ASCII) | 0FH | |
| F | (FLOAT) | 10H | Real number |
| ST | (STRING) | 11H | |


Make settings for "Data Files" using the ladder tool. Otherwise, "Error Code 10 00" is displayed on MONITOUCH. For more information, refer to the PLC manual issued by the manufacturer.




Address denotations

The assigned device memory is expressed as shown below when editing the screen.

- Address other than input/output
- For word access




For bit access




The file number will not be displayed for the input, output or status device memory.

- Input/output address
- For word access



For bit access



Indirect Device Memory Designation

- For the file or slot numbers 0 to 65:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-------|-------------|-----|---|---|-----------------|---|
| n + 0 | Model | | | | Device type | |
| n + 1 | Address No. | | | | | |
| n + 2 | 00 | | | | Bit designation | |
| n + 3 | 00 | | | | Station number | |

- For the file or slot numbers 66 to 255:

| | | | | | | |
|-------|--------------------|-----|---|---|-----------------|---|
| | 15 | MSB | 8 | 7 | LSB | 0 |
| n + 0 | Model | | | | Device type | |
| n + 1 | Lower address No. | | | | | |
| n + 2 | Higher address No. | | | | | |
| n + 3 | 00 | | | | Bit designation | |
| n + 4 | 00 | | | | Station number | |

- Specify the file number or slot number and the element number for the address number.

Example: When specifying N007:123
Specify "7123" (DEC) for the address number.

Example: When specifying N120:123
Specify "120123" (DEC) for the address number.
120123 (DEC) is equivalent to 1D53B (HEX). Specify "D53B (HEX)" for the lower address number and "0001" for the upper address number.

- When specifying an address for the timer (control), counter (control) or control device memory in bit designation, specify the bit number in decimal notation as shown below:

- T: Timer (control)
DN = 13, TT = 14, EN = 15
- C: Counter (control)
UA = 10, UN = 11, OV = 12, DN = 13, CD = 14, CU = 15
- R: Control
FD = 08, IN = 09, UL = 10, ER = 11, EM = 12, DN = 13, EU = 14, EN = 15

4.1.7 Micro Logix

Communication Setting

Editor

Communication setting


(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1 : 1</u> / 1 : n / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | 1 bit | |
| Parity | <u>None</u> / Even | |
| Target Port No. | <u>0</u> to 31 | |

PLC

Channel Configuration


Micro Logix 1000



(Underlined setting: default)

| Item | Setting | Remarks |
|------|------------------------------------|---------|
| Baud | 4800 / <u>9600</u> / 19200 / 38.4K | |

Micro Logix 1100, 1500



(Underlined setting: default)

| Item | Setting | Remarks |
|-----------|-------------------------|------------------------------------|
| Channel 0 | Driver | DF1 Full Duplex |
| | Baud | 4800 / 9600 / <u>19200</u> / 38.4K |
| | Parity | <u>None</u> / Even |
| | Control Line | No Handshaking |
| | Error Detection | BCC |
| | Embedded Responses | Auto Detect |
| | Duplicate Packet Detect | Checked |

Calendar


This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|-------------|
| N | (integer) | 00H | |
| B | (bit) | 01H | |
| T. ACC | (timer/current value) | 02H | |
| T. PRE | (timer/set value) | 03H | |
| C. ACC | (counter/current value) | 04H | |
| C. PRE | (counter/set value) | 05H | |
| I | (input) | 06H | |
| O | (output) | 07H | |
| S | (status) | 08H | |
| T | (timer/control) | 09H | |
| C | (counter/control) | 0AH | |
| R | (control) | 0BH | |
| R. LEN | (control/data length) | 0CH | |
| R. POS | (control/data position) | 0DH | |
| D | (BCD) | 0EH | |
| A | (ASCII) | 0FH | |
| F | (FLOAT) | 10H | Real number |
| ST | (STRING) | 11H | |
| L | (LONG) | 12H | Double-word |


Make settings for "Data Files" using the ladder tool. Otherwise, "Error Code 10 00" is displayed on MONITOUCH. For more information, refer to the PLC manual issued by the manufacturer.




Address denotations

The assigned device memory is expressed as shown below when editing the screen.

- Address other than input/output
- For word access




For bit access




The file number will not be displayed for the input, output or status device memory.

- Input/output address
- For word access



For bit access



Indirect Device Memory Designation

- For the file or slot numbers 0 to 65:

| | | | | | | |
|-------|-------------|-----|---|---|-----------------|---|
| | 15 | MSB | 8 | 7 | LSB | 0 |
| n + 0 | Model | | | | Device type | |
| n + 1 | Address No. | | | | | |
| n + 2 | 00 | | | | Bit designation | |
| n + 3 | 00 | | | | Station number | |

- For the file or slot numbers 66 to 255:

| | 15 | MSB | 8 | 7 | LSB | 0 | | |
|-------|--------------------|-----|---|---|-----------------|---|--|--|
| n + 0 | Model | | | | Device type | | | |
| n + 1 | Lower address No. | | | | | | | |
| n + 2 | Higher address No. | | | | | | | |
| n + 3 | 00 | | | | Bit designation | | | |
| n + 4 | 00 | | | | Station number | | | |

- Specify the file number or slot number and the element number for the address number.

Example: When specifying N007:123
Specify "7123" (DEC) for the address number.

Example: When specifying N120:123
Specify "120123" (DEC) for the address number.
120123 (DEC) is equivalent to 1D53B (HEX). Specify "D53B (HEX)" for the lower address number and "0001" for the upper address number.

- When specifying an address for the timer (control), counter (control) or control device memory in bit designation, specify the bit number in decimal notation as shown below:
 - T: Timer (control)
DN = 13, TT = 14, EN = 15
 - C: Counter (control)
UA = 10, UN = 11, OV = 12, DN = 13, CD = 14, CU = 15
 - R: Control
FD = 08, IN = 09, UL = 10, ER = 11, EM = 12, DN = 13, EU = 14, EN = 15

4.1.8 Micro Logix (Ethernet TCP/IP)

Communication Setting

Editor

Make the following settings on the editor. For more information, see “1.3.2 Ethernet Communication (TS2060i Only)”.

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 44818) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

Channel 1

Channel configuration (channel 1)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Driver | Ethernet | |
| IP Address | PLC's IP address | |
| Subnet Mask | PLC's subnet mask | |
| Gateway Address | Make settings in accordance with the network environment. | |

Calendar


This model is not equipped with the calendar function. Use the built-in clock of the TS2060i.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|-------------|
| N | (integer) | 00H | |
| B | (bit) | 01H | |
| T. ACC | (timer/current value) | 02H | |
| T. PRE | (timer/set value) | 03H | |
| C. ACC | (counter/current value) | 04H | |
| C. PRE | (counter/set value) | 05H | |
| I | (input) | 06H | |
| O | (output) | 07H | |
| S | (status) | 08H | |
| T | (timer/control) | 09H | |
| C | (counter/control) | 0AH | |
| R | (control) | 0BH | |
| R. LEN | (control/data length) | 0CH | |
| R. POS | (control/data position) | 0DH | |
| A | (ASCII) | 0FH | |
| F | (FLOAT) | 10H | Real number |
| ST | (STRING) | 11H | |
| L | (LONG) | 12H | Double-word |


Make settings for "Data Files" using the ladder tool. Otherwise, "Error Code 10 00" is displayed on MONITOUCH. For more information, refer to the PLC manual issued by the manufacturer.




Address denotations

The assigned device memory is expressed as shown below when editing the screen.

- Address other than input/output
 - For word access




For bit access




The file number will not be displayed for the input, output or status device memory.

- Input/output address
 - For word access



For bit access



Indirect Device Memory Designation

- For the file or slot numbers 0 to 65:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-------|-------------|-----|---|---|-----------------|---|
| n + 0 | Model | | | | Device type | |
| n + 1 | Address No. | | | | | |
| n + 2 | 00 | | | | Bit designation | |
| n + 3 | 00 | | | | Station number | |

- For the file or slot numbers 66 to 255:

| | | | | | | |
|-------|--------------------|-----|---|---|-----------------|---|
| | 15 | MSB | 8 | 7 | LSB | 0 |
| n + 0 | Model | | | | Device type | |
| n + 1 | Lower address No. | | | | | |
| n + 2 | Higher address No. | | | | | |
| n + 3 | 00 | | | | Bit designation | |
| n + 4 | 00 | | | | Station number | |

- Specify the file number or slot number and the element number for the address number.

Example: When specifying N007:123
Specify "7123" (DEC) for the address number.


Example: When specifying N120:123
Specify "120123" (DEC) for the address number.
120123 (DEC) is equivalent to 1D53B (HEX). Specify "D53B (HEX)" for the lower address number and "0001" for the upper address number.

- When specifying an address for the timer (control), counter (control) or control device memory in bit designation, specify the bit number in decimal notation as shown below:

- T: Timer (control)
DN = 13, TT = 14, EN = 15
- C: Counter (control)
UA = 10, UN = 11, OV = 12, DN = 13, CD = 14, CU = 15
- R: Control
FD = 08, IN = 09, UL = 10, ER = 11, EM = 12, DN = 13, EU = 14, EN = 15

4.1.9 NET-ENI (SLC500 Ethernet TCP/IP)

The TS2060 establishes communication with SLC500 via NET-ENI.



Communication Setting

Editor


Make the following settings on the editor. For more information, see “1.3.2 Ethernet Communication (TS2060i Only)”.

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 44818) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

NET-ENI / NET-ENIW

ENI / ENIW utility



| Item | | Setting | Remarks |
|-------------|----------------|---|---------|
| ENI IP Addr | 232 Baud Rate | Auto | |
| | ENI IP Address | Set the IP address of NET-ENI. | |
| | Subnet Mask | Set the subnet mask of NET-ENI. | |
| | Gateway | Make settings in accordance with the network environment. | |

Press [ENI ROM] to save the settings.

SLC500

Channel configuration

Channel Configuration

General

Chan. 1 - System

Chan. 0 - System

Chan. 0 - User

Driver

DF1 Full Duplex

Source ID

9 (decimal)

Baud

19200

Parity

NONE

Stop Bits

1

Protocol Control

Control Line

No Handshaking

ACK Timeout (<20 ms)

50

Error Detection

CRC

Embedded Responses

Auto Detect

☒ Duplicate Packet Detect

NAK Retries

3

ENQ Retries

3


| Item | | Setting | Remarks |
|------------------|-------------------------|------------------------|---------|
| Chan. 0 - System | Driver | DF1 Full Duplex | |
| | Baud | 9600 / 19200 / 38400 | |
| | Parity | NONE | |
| | Stop Bits | 1 | |
| | Control Line | No Handshaking | |
| | Error Detection | CRC | |
| | Embedded Responses | Auto Detect | |
| | Duplicate Packet Detect | Checked | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|-------------|
| N | (integer) | 00H | |
| B | (bit) | 01H | |
| T. ACC | (timer/current value) | 02H | |
| T. PRE | (timer/set value) | 03H | |
| C. ACC | (counter/current value) | 04H | |
| C. PRE | (counter/set value) | 05H | |
| I | (input) | 06H | |
| O | (output) | 07H | |
| S | (status) | 08H | |
| T | (timer/control) | 09H | |
| C | (counter/control) | 0AH | |
| R | (control) | 0BH | |
| R. LEN | (control/data length) | 0CH | |
| R. POS | (control/data position) | 0DH | |
| A | (ASCII) | 0FH | |
| F | (FLOAT) | 10H | Real number |
| ST | (STRING) | 11H | |


Make settings for "Data Files" using the ladder tool. Otherwise, "Error Code 10 00" is displayed on MONITOUCH. For more information, refer to the PLC manual issued by the manufacturer.




Address denotations

The assigned device memory is expressed as shown below when editing the screen.

- Address other than input/output
 - For word access




For bit access




The file number will not be displayed for the input, output or status device memory.

- Input/output address
 - For word access



For bit access



Indirect Device Memory Designation

- For the file or slot numbers 0 to 65:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-------|-------------|-----|---|---|-----------------|---|
| n + 0 | Model | | | | Device type | |
| n + 1 | Address No. | | | | | |
| n + 2 | 00 | | | | Bit designation | |
| n + 3 | 00 | | | | Station number | |

- For the file or slot numbers 66 to 255:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-------|--------------------|-----|---|---|-----------------|---|
| n + 0 | Model | | | | Device type | |
| n + 1 | Lower address No. | | | | | |
| n + 2 | Higher address No. | | | | | |
| n + 3 | 00 | | | | Bit designation | |
| n + 4 | 00 | | | | Station number | |

- Specify the file number or slot number and the element number for the address number.

Example: When specifying N007:123
Specify "7123" (DEC) for the address number.


Example: When specifying N120:123
Specify "120123" (DEC) for the address number.
120123 (DEC) is equivalent to 1D53B (HEX). Specify "D53B (HEX)" for the lower address number and "0001" for the upper address number.

- When specifying an address for the timer (control), counter (control) or control device memory in bit designation, specify the bit number in decimal notation as shown below:

- T: Timer (control)
DN = 13, TT = 14, EN = 15
- C: Counter (control)
UA = 10, UN = 11, OV = 12, DN = 13, CD = 14, CU = 15
- R: Control
FD = 08, IN = 09, UL = 10, ER = 11, EM = 12, DN = 13, EU = 14, EN = 15

4.1.10 NET-ENI (MicroLogix Ethernet TCP/IP)

The TS2060 establishes communication with MicroLogix via NET-ENI.



Communication Setting

Editor


Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 44818) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

NET-ENI / NET-ENIW

ENI / ENIW utility



| Item | | Setting | Remarks |
|-------------|----------------|---|---------|
| ENI IP Addr | 232 Baud Rate | Auto | |
| | ENI IP Address | Set the IP address of NET-ENI. | |
| | Subnet Mask | Set the subnet mask of NET-ENI. | |
| | Gateway | Make settings in accordance with the network environment. | |

Press [ENI ROM] to save the settings.

MicroLogix

Channel Configuration

Channel Configuration

GeneralChannel 0Channel 1

Driver

DF1 Full Duplex

Baud

19200

Parity

NONE

Source ID

1

(decimal)

Protocol Control

Control Line

No Handshaking

Error Detection

CRC

Embedded Responses

Auto Detect

☒ Duplicate Packet Detect

ACK Timeout (<20 ms)

50

NAK Retries

3

ENQ Retries

3

(Underlined setting: default)

| Item | | Setting | Remarks |
|---------|-------------------------|------------------------------------|---------|
| Chan. 0 | Driver | DF1 Full Duplex | |
| | Baud | 4800 / 9600 / <u>19200</u> / 38.4K | |
| | Parity | NONE | |
| | Control Line | No Handshaking | |
| | Error Detection | CRC | |
| | Embedded Responses | Auto Detect | |
| | Duplicate Packet Detect | Checked | |

Calendar


This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|-------------|
| N | (integer) | 00H | |
| B | (bit) | 01H | |
| T. ACC | (timer/current value) | 02H | |
| T. PRE | (timer/set value) | 03H | |
| C. ACC | (counter/current value) | 04H | |
| C. PRE | (counter/set value) | 05H | |
| I | (input) | 06H | |
| O | (output) | 07H | |
| S | (status) | 08H | |
| T | (timer/control) | 09H | |
| C | (counter/control) | 0AH | |
| R | (control) | 0BH | |
| R. LEN | (control/data length) | 0CH | |
| R. POS | (control/data position) | 0DH | |
| A | (ASCII) | 0FH | |
| F | (FLOAT) | 10H | Real number |
| ST | (STRING) | 11H | |
| L | (LONG) | 12H | Double-word |


Make settings for "Data Files" using the ladder tool. Otherwise, "Error Code 10 00" is displayed on MONITOUCH. For more information, refer to the PLC manual issued by the manufacturer.




Address denotations

The assigned device memory is expressed as shown below when editing the screen.

- Address other than input/output
 - For word access




For bit access




The file number will not be displayed for the input, output or status device memory.

- Input/output address
 - For word access



For bit access



Indirect Device Memory Designation

- For the file or slot numbers 0 to 65:

| | 15 | MSB | 8 | 7 | LSB | 0 |
|-------|-------------|-----|---|---|-----------------|---|
| n + 0 | Model | | | | Device type | |
| n + 1 | Address No. | | | | | |
| n + 2 | 00 | | | | Bit designation | |
| n + 3 | 00 | | | | Station number | |

- For the file or slot numbers 66 to 255:

| | | | | | | |
|-------|--------------------|-----|---|---|-----------------|---|
| | 15 | MSB | 8 | 7 | LSB | 0 |
| n + 0 | Model | | | | Device type | |
| n + 1 | Lower address No. | | | | | |
| n + 2 | Higher address No. | | | | | |
| n + 3 | 00 | | | | Bit designation | |
| n + 4 | 00 | | | | Station number | |

- Specify the file number or slot number and the element number for the address number.

Example: When specifying N007:123
Specify "7123" (DEC) for the address number.

Example: When specifying N120:123
Specify "120123" (DEC) for the address number.
120123 (DEC) is equivalent to 1D53B (HEX). Specify "D53B (HEX)" for the lower address number and "0001" for the upper address number.

- When specifying an address for the timer (control), counter (control) or control device memory in bit designation, specify the bit number in decimal notation as shown below:

- T: Timer (control)
DN = 13, TT = 14, EN = 15
- C: Counter (control)
UA = 10, UN = 11, OV = 12, DN = 13, CD = 14, CU = 15
- R: Control
FD = 08, IN = 09, UL = 10, ER = 11, EM = 12, DN = 13, EU = 14, EN = 15

4.1.11 Micro800 Controllers

The logical port PLC1 can only be selected because the tag table is used.

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---|
| Connection Mode | <u>1</u> : <u>1</u> / Multi-link2 | For multi-link2, be sure to use the same tag table. |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / 19200 / <u>38400</u> / 57600 115K bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | 0 to 31 | |

PLC

Make settings using the ladder tool software “Connected Components Workbench”.

Controller - Serial Port

Controller - Serial Port

Common Settings

Driver:

CIP Serial

Baud Rate:

38400

Parity:

None

Station Address:

1

Protocol Control

DF1 Mode:

DF1 Full-Duplex

Control Line:

No Handshake

Error Detection:

CRC

Embedded Responses:

After One Received

☒ Duplicate Packet Detection

ACK Timeout (x20ms):

50

ENQ Retries:

3

| Item | Setting | Remarks |
|------------------|--------------------|-----------------------------|
| Common Settings | Driver | CIP Serial |
| | Baud Rate | 4800 / 9600 / 19200 / 38400 |
| | Parity | None / Odd / Even |
| | Station Address | 0 to 31 |
| Protocol Control | Error Detection | BCC |
| | Embedded Responses | After One Received |

Available Device Memory

Export "tags" created using the ladder tool of the PLC programming software to an ISAXML file. Then import the ISAXML file into the editor to set the PLC device memory.

For details on importing, exporting and creating a tag, refer to the Allen-Bradley PLC Connection Manual.

| Data Type | | Range ^{*2} of Number of Elements for Arrays | | | Tag Name |
|-----------|--------------------------------|--|-------------------------|-------------------------|---------------------|
| | | Dim0 | Dim1 | Dim2 | |
| BOOL | (1-bit integer) | 0 to 65535 | - | - | Up to 40 characters |
| SINT | (1-byte integer) ^{*1} | 0 to 1023 ^{*3} | 0 to 1023 ^{*3} | 0 to 1023 ^{*3} | |
| INT | (2-byte integer) | 0 to 023 | 0 to 023 | 0 to 023 | |
| DINT | (4-byte integer) | 0 to 023 | 0 to 023 | 0 to 023 | |
| REAL | (4-byte floating-point) | 0 to 023 | 0 to 023 | 0 to 023 | |
| STRING | (text) | 0 to 023 | 0 to 023 | 0 to 023 | |

*1 Specify in units of 2 bytes (word). 1-byte tags cannot be accessed.

*2 The ranges given are based on when a maximum value is specified. Ranges differ according to the created tag.

*3 The address range differs depending on the specified "Dim".

| Dim0 | Dim1 | Dim2 |
|-----------|-----------|-----------|
| 0 to 1022 | None | None |
| 0 to 023 | 0 to 1022 | None |
| 0 to 023 | 0 to 023 | 0 to 1022 |

Indirect Device Memory Designation

Not available

4.1.12 Micro800 Controllers(Ethernet TCP/IP)


The logical port PLC1 can only be selected because the tag table is used.

Communication Setting

Editor


Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 44818) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].



PLC

Set the IP address using the ladder tool software "Connected Components Workbench". For details, refer to the PLC manual issued by the manufacturer.



Available Device Memory

Export "tags" created using the ladder tool of the PLC programming software to an ISAXML file. Then import the ISAXML file into the editor to set the PLC device memory.

For details on importing, exporting and creating a tag, refer to the Allen-Bradley PLC Connection Manual.

| Data Type | | Range ^{*2} of Number of Elements for Arrays | | | Tag Name |
|-----------|--------------------------------|--|-------------------------|-------------------------|---------------------|
| | | Dim0 | Dim1 | Dim2 | |
| BOOL | (1-bit integer) | 0 to 65535 | - | - | Up to 40 characters |
| SINT | (1-byte integer) ^{*1} | 0 to 1023 ^{*3} | 0 to 1023 ^{*3} | 0 to 1023 ^{*3} | |
| INT | (2-byte integer) | 0 to 023 | 0 to 023 | 0 to 023 | |
| DINT | (4-byte integer) | 0 to 023 | 0 to 023 | 0 to 023 | |
| REAL | (4-byte floating-point) | 0 to 023 | 0 to 023 | 0 to 023 | |
| STRING | (text) | 0 to 023 | 0 to 023 | 0 to 023 | |

^{*1} Specify in units of 2 bytes (word). 1-byte tags cannot be accessed.

^{*2} The ranges given are based on when a maximum value is specified. Ranges differ according to the created tag.

^{*3} The address range differs depending on the specified "Dim".

| Dim0 | Dim1 | Dim2 |
|-----------|-----------|-----------|
| 0 to 1022 | None | None |
| 0 to 023 | 0 to 1022 | None |
| 0 to 023 | 0 to 023 | 0 to 1022 |

Indirect Device Memory Designation

Not available

4.1.13 Wiring Diagrams


When Connected at CN1:




- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.




RS-232C

Wiring diagram 1 - C2




Wiring diagram 2 - C2




Wiring diagram 3 - C2**Wiring diagram 4 - C2****Wiring diagram 5 - C2**

RS-422/RS-485


Wiring diagram 1 - C4



Wiring diagram 2 - C4




Wiring diagram 3 - C4




When Connected at MJ1/MJ2:

RS-232C


Wiring diagram 1 - M2




Wiring diagram 2 - M2




Wiring diagram 3 - M2




Wiring diagram 4 - M2



Wiring diagram 5 - M2




Wiring diagram 6 - M2




RS-422/RS-485


Wiring diagram 1 - M4



Wiring diagram 2 - M4



Wiring diagram 3 - M4



5. Automationdirect

5.1 PLC Connection

5.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | PLC | Port | Signal Level | Connection | | | Ladder Transfer *3 |
|--------------------------------|----------------------------|--------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| Direct LOGIC (K-Sequence) | D4-430 D4-440 | Port 0 | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 4 - M2 | | × |
| | | Port 1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | |
| | D4-450 | Port 0 | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 4 - M2 | | |
| | | Port 1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | |
| | | Port 2 | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | |
| | | Port 3 | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | |
| | | D2-230 | PORT1 | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | |
| | D2-240 DL05 | PORT1 | | | | | |
| | | PORT2 | | | | | |
| | D2-250-1 D2-260 DL06 | PORT1 | | | | | |
| | | PORT2 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | RS-422 | | Wiring diagram 3 - C4 | × | Wiring diagram 3 - M4 | | |
| Direct LOGIC (MODBUS RTU) | D4-450 | Port 1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | |
| | | Port 3 | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | |
| | D2-250-1 D2-260 | PORT2 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | | | RS-422 | Wiring diagram 3 - C4 | × | Wiring diagram 3 - M4 | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*3 For the ladder transfer function, see the TS2060 Reference Manual 2.

Ethernet Connection (TS2060i Only)

| PLC Selection on the Editor | CPU | Unit | TCP/IP ^{*1} | UDP/IP | Port No. | Ladder Transfer ^{*2} |
|-----------------------------------|------------------------------|-----------------------|----------------------|--------|---------------|-------------------------------|
| Direct LOGIC (Ethernet UDP/IP) | DL05 DL06 | H0-ECOM H0-ECOM100 | × | ○ | 28784 (fixed) | × |
| | D2-240 D2-250-1 D2-260 | H2-ECOM H2-ECOM100 | | | | |

*1 Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

*2 For the ladder transfer function, see the TS2060 Reference Manual 2.

5.1.1 Direct LOGIC (K-Sequence)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1-1</u> / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Odd</u> / Even | |
| Target Port No. | 0 to 31 | |

D4-450

PORT0

No particular setting is necessary on the PLC. The PLC always performs communication functions using the following parameters. Set the following parameters under [Communication Setting] of the editor.

| Item | Setting | |
|-------------|----------|--|
| Baud Rate | 9600 bps | |
| Parity | Odd | |
| Data Length | 8 | |
| Stop Bit | 1 | |
| Data Type | HEX | |

PORT1

Set parameters into the special register "R772, 773", then set "AA5A" (HEX) into the setting complete register "R767". When the set value at R767 is changed to "AAAA" (HEX), it is regarded as normal; if it is changed to "AAEA" (HEX), it is regarded as erroneous.

Parameter setting register

(Underlined setting: default)

| Register | Setting | Setting Example |
|----------|---|---|
| R772 | <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> <div style="display: flex; justify-content: space-between; padding: 0 5px;"> 00E0 </div> </div> <div> <p>Communication protocol 80: K-Sequence <u>E0</u>: Automatic recognition (Modbus, CCM, K-Sequence)</p> <p>Communication timeout 0: 800 ms</p> <p>Response delay time 0: 0 ms</p> </div> </div> | 00E0H K-Sequence |
| R773 | <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> <div style="display: flex; justify-content: space-between; padding: 0 5px;"> 8701 </div> </div> <div> <p>Station number 01 to 1F (HEX)</p> <p>Baud rate 4: 4800 bps 5: 9600 bps <u>6: 19200 bps</u> 7: 38400 bps</p> <p>Parity stop bit 0: Without parity, stop bit 1 2: Without parity, stop bit 2 <u>8: Odd parity, stop bit 1</u> A: Odd parity, stop bit 2 C: Even parity, stop bit 1 E: Even parity, stop bit 2</p> </div> </div> | 8701H 38400 bps Odd parity Stop bit 1 Station number 01 |

PORT2

Set parameters into the special register "R774, 775", then set "A5AA" (HEX) into the setting complete register "R767". When the set value at R767 is changed to "AAAA" (HEX), it is regarded as normal; if it is changed to "AEAA" (HEX), it is regarded as erroneous.

Parameter setting register

| Register | Setting | Setting Example |
|----------|---|-----------------|
| R774 | Same as the setting register R772 for PORT1 | 00E0H |
| R775 | Same as the setting register R773 for PORT1 | 8701H |

PORT3

Set parameters into the special register "R776, 777", then set "5AAA" (HEX) into the setting complete register "R767". When the set value at R767 is changed to "AAAA" (HEX), it is regarded as normal; if it is changed to "EAAA" (HEX), it is regarded as erroneous.

Parameter setting register

| Register | Setting | Setting Example |
|----------|---|-----------------|
| R776 | Same as the setting register R772 for PORT1 | 00E0H |
| R777 | Same as the setting register R773 for PORT1 | 8701H |

D2-240/D2-250-1

PORT1 / PORT2

No particular setting is necessary on the PLC. The PLC performs communication functions using the following parameters. Set the following parameters under [Communication Setting] of the editor.

| Item | Setting | Remarks |
|-------------|----------|---|
| Baud Rate | 9600 bps | For PORT2: 19200 bps can be set in the special register. |
| Parity | Odd | |
| Data Length | 8 | |
| Stop Bit | 1 | |
| Data Type | HEX | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---|------|---------|
| V (data register) | 00H | |
| X (input) | 01H | |
| Y (output) | 02H | |
| C (internal relay) | 03H | |
| S (stage) | 04H | |
| GX (transmission relay for all stations) | 05H | |
| GY (transmission relay for specified station) | 06H | |
| T (timer/contact) | 07H | |
| CT (counter/contact) | 08H | |


5.1.2 Direct LOGIC (Ethernet UDP/IP)

Communication Setting


Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".


- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- Others
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
 - For [Transfer Speed], select the same setting as the specification of the connected communication module.*
For Hx-ECOM: 10BASE-T
For Hx-ECOM100: 100BASE-TX
 - * If the transfer speed is not selected correctly, a check code error occurs.



- IP address and port number (No. 28784) of the PLC
Register on the [PLC Table] window in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].



Valid only for 1 : 1 connection
Select the PLC for connection from those registered on the PLC table.



Set the IP address and port number for the PLC.

DirectLOGIC/SU Series

Make PLC settings by using the software "DirectSOFT". For more information, refer to the PLC manual issued by the manufacturer.

Link wizard

| Contents | Setting | Remarks |
|--------------------|---|---|
| Transport Protocol | UDP/IP | |
| Module ID | Make settings in accordance with the network environment. | "0" cannot be set. Set all DIP switches on Hx-ECOM to the OFF positions. |
| IP Address | | |


* The port number is fixed to "28784".

* The module ID or IP address can also be set by using the Hx-ECOM configuration software "NetEdit3" or HTML of the module (only for Hx-ECOM100). For more information, refer to the PLC manual issued by the manufacturer.

DIP switch

The module ID can be set by the DIP switch.

When any of the DIP switches is set in the ON position upon power-on, the module ID set by the DIP switch will take effect.

| DIP Switch | Setting Example | Remarks |
|---|--------------------------|--|
|  | $14 (= 2^1 + 2^2 + 2^3)$ | Setting range: 1 to 63 Set the value in binary notation by referring to the figures printed on the PCB. Note that the DIP switches 6 and 7 are not used. |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---|------|---------|
| V (data register) | 00H | |
| X (input) | 01H | |
| Y (output) | 02H | |
| C (internal relay) | 03H | |
| S (stage) | 04H | |
| GX (transmission relay for all stations) | 05H | |
| GY (transmission relay for specified station) | 06H | |
| T (timer/contact) | 07H | |
| CT (counter/contact) | 08H | |

5.1.3 Direct LOGIC (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1</u> : 1 / 1 : n / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / Even | |
| Target Port No. | 1 | |

D4-450

PORT1

Set parameters into the special register "R772, 773", then set "AA5A" (HEX) into the setting complete register "R767". When the set value at R767 is changed to "AAAA" (HEX), it is regarded as normal; if it is changed to "AAEA" (HEX), it is regarded as erroneous.

Parameter setting register

(Underlined setting: default)

| Register | Setting | Setting Example |
|----------|---|---|
| R772 | <p>0 0 E 0</p> <p>Communication protocol 0: MODBUS RTU <u>E</u>: Automatic recognition (Modbus, CCM, K-Sequence)</p> <p>Communication timeout 0: 800 ms</p> <p>Response delay time 0: 0 ms</p> | 00E0H |
| R773 | <p>8 6 0 1</p> <p>Station number 01 to 1F (HEX)</p> <p>Baud rate 4: 4800 bps 5: 9600 bps <u>6</u>: <u>19200 bps</u> 7: 38400 bps</p> <p>Parity stop bit 0: Without parity, stop bit 1 2: Without parity, stop bit 2 <u>8</u>: <u>Odd parity, stop bit 1</u> A: Odd parity, stop bit 2 C: Even parity, stop bit 1 E: Even parity, stop bit 2</p> | 8701H 38400 bps Odd parity Stop bit 1 Station number 01 |

PORT3

Set parameters into the special register "R776, 777", then set "5AAA" (HEX) into the setting complete register "R767". When the set value at R767 is changed to "AAAA" (HEX), it is regarded as normal; if it is changed to "EAAA" (HEX), it is regarded as erroneous.

Parameter setting register

| Register | Setting | Setting Example |
|----------|---|-----------------|
| R776 | Same as the setting register R772 for PORT1 | 00E0H |
| R777 | Same as the setting register R773 for PORT1 | 8701H |

D2-250-1

PORT2

Set parameters into the special register "R7655, 7656", then set "0500" (HEX) into the setting complete register "R7657". When the set value at R7657 is changed to "0A00" (HEX), it is regarded as normal; if it is changed to "0E00" (HEX), it is regarded as erroneous.

Parameter setting register

(Underlined setting: default)

| Register | Setting | Setting Example |
|----------|--|---|
| R7655 | <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;">0 0 2 0</div> <div> <p>Communication protocol 20: MODBUS RTU</p> <p>Communication timeout 0: Specified time</p> <p>Response delay time 0: 0 ms</p> </div> </div> | 0020H |
| R7656 | <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;">8 7 0 1</div> <div> <p>Station number 01 to 7A (HEX)</p> <p>Baud rate 4: 4800 bps 5: 9600 bps <u>6: 19200 bps</u> 7: 38400 bps</p> <p>Parity stop bit 0: Without parity, stop bit 1 2: Without parity, stop bit 2 <u>8: Odd parity, stop bit 1</u> A: Odd parity, stop bit 2 C: Even parity, stop bit 1 E: Even parity, stop bit 2</p> </div> </div> | 8701H 38400 bps Odd parity Stop bit 1 Station number 01 |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---|------|---------|
| V (data register) | 00H | |
| X (input) | 01H | |
| Y (output) | 02H | |
| C (internal relay) | 03H | |
| S (stage) | 04H | |
| GX (transmission relay for all stations) | 05H | |
| GY (transmission relay for specified station) | 06H | |
| T (timer/contact) | 07H | |
| CT (counter/contact) | 08H | |

5.1.4 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C


Wiring diagram 1 - C2




Wiring diagram 2 - C2



Wiring diagram 3 - C2




Wiring diagram 4 - C2




RS-422/RS-485

Wiring diagram 1 - C4




Wiring diagram 2 - C4



* SU-6M: Terminal block connectable


Wiring diagram 3 - C4




When Connected at MJ1/MJ2:

RS-232C


Wiring diagram 1 - M2




Wiring diagram 2 - M2



Wiring diagram 3 - M2




Wiring diagram 4 - M2




RS-422/RS-485


Wiring diagram 1 - M4



Wiring diagram 2 - M4



Wiring diagram 3 - M4



6. Azbil

6.1 PLC Connection

6.2 Temperature Controller/Servo/Inverter Connection

6.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Ladder Transfer *2 |
|-----------------------------|-------|-----------------------|--------------|-----------------------|-----------------------|--------------|--------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| MX series | MX50 | LOAD connector (CN7) | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | ASCII connector (CN8) | | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | MX200 | LOAD connector | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | | ASCII connector | | | | | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

6.1.1 MX Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Even</u> | |
| Target Port No. | <u>1</u> to 63, 127 | |

PLC

MX50

Communication setting



Make the following settings using the application software. For more information, refer to the PLC manual issued by the manufacturer.

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------|---|---------|
| Baud rate | 4800 / <u>9600</u> / 19200 bps | |
| Data type | <u>Even parity 1 STOP</u> No parity 2 STOP | |

Station number

Set a station number using the DIP switches.

| DipSW | Setting | Remarks |
|---|--|---|
|  | 1 to 63, 127 (Set a binary number using bits 0 to 6.) | Example: Station No. 50 50(DEC) = 0110010(BIN)  |

* Set SW No. 1 to OFF at all times.

Calendar

This model is equipped with a calendar function; however, the calendar data cannot be written from the TS2060. Thus, time correction must be performed on the PLC side.

MX200

Make the following settings on the front panel. For more information, refer to the PLC manual issued by the manufacturer.

LOAD connector

(Underlined setting: default)

| Communication Setup Mode | | Setting | Remarks |
|--------------------------|----------------------------|--|--|
| LOAD connector setting | Item 0: Address setting | <u>1</u> to 63 (DEC): 1 to 63 7F(HEX): 127 | Settings can also be made in the PLC application software. For more information, refer to the PLC manual issued by the manufacturer. |
| | Item 1: Baud rate | 48: 4800 bps <u>96</u> : 9600 bps 192: 19200 bps | |
| | Item 2: Communication mode | <u>8E1</u> : data length 8 bits, even parity, 1 stop bit 8n2: data length 8 bits, without parity, 2 stop bits | |

ASCII connector

(Underlined setting: default)

| Communication Setup Mode | | Setting | Remarks |
|--------------------------|-------------------------------------|--|--|
| ASCII connector setting | Item 0: Baud rate | 48: 4800 bps <u>96</u> : 9600 bps 192: 19200 bps | Settings can also be made in the PLC application software. For more information, refer to the PLC manual issued by the manufacturer. |
| | Item 1: Data length | 7b: 7 bits <u>8b</u> : 8 bits | |
| | Item 2: Parity bit | <u>EP</u> : Even oP: Odd nP: None | |
| | Item 3: Stop bit | <u>1S</u> : 1 bit 2S: 2 bits | |
| | Item 4: Connector usage | Ldr: LOAD connector | |
| | Item 5: Connecting device selection | CPL: Azbil communication support device | |
| | Item 7: RTS control | non: No RTS control | |
| | Item 8: Signal level selection | 232: RS-232C | |

Station number

Make the following setting on the front panel.

(Underlined setting: default)

| MX Address Display/Setting Mode | Setting | Remarks |
|---------------------------------|----------------|---------|
| Addr | <u>1</u> to 63 | |

Calendar

This model is equipped with a calendar function; however, the calendar data cannot be written from the TS2060. Thus, time correction must be performed on the PLC side.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------|------|---|
| R | (data register) | 00H | R910, 929, 930, 956 to 987, 994 to 997: Read only |
| M | (auxiliary relay) | 01H | M920 to 940, 970 to 990: Read only |
| L | (latch relay) | 02H | |
| X | (input relay) | 03H | |
| Y | (output relay) | 04H | |
| TP | (timer/current value) | 05H | Data format: BCD |
| TS | (timer/set value) | 06H | Data format: BCD |
| CP | (counter/current value) | 07H | Data format: BCD |
| CS | (counter/set value) | 08H | Data format: BCD |
| T | (timer/contact) | 09H | |
| C | (counter/contact) | 0AH | |
| P | (link register) | 0BH | |

6.1.2 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C

Wiring diagram 1 - C2




Wiring diagram 2 - C2




When Connected at MJ1/MJ2:

RS-232C

Wiring diagram 1 - M2



Wiring diagram 2 - M2



6.2 Temperature Controller/Servo/Inverter Connection

Serial Connection

Digital Indicating Controller

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|--|---------------------------------|--------------|-----------------------|-----------------------|----------------------------|------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | |
| SDC10 | SDC10xxxx05xx | Terminal on the back | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | SDC10.Lst |
| SDC15 | SDC15xxxx03xx SDC15xxxx06xx | Terminal on the back | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | SDC15.Lst |
| SDC20 | SDC20xxxx02xx SDC20xxxx04xx SDC20xxxx09xx | Terminal on the back | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | SDC20.Lst |
| | SDC20xxxx03xx SDC20xxxx05xx SDC20xxxx10xx | Terminal on the back | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| SDC21 | SDC21xxxx03xx SDC21xxxx06xx SDC21xxxx08xx | Terminal on the back | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | |
| | SDC21xxxx04xx SDC21xxxx07xx SDC21xxxx09xx | Terminal on the back | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| SDC25/26 | SDC25TxUxx2xx SDC26TxUxx2xx | Terminal on the back | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | SDC25.Lst |
| SDC30/31 | SDC30xxxx040xx SDC30xxxx041xx | Terminal on the back | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | SDC30.Lst |
| | SDC31xxxx045xx SDC31xxxx446xx SDC31xxxx546xx | | | | | | |
| SDC35/36 | SDC35xxxxx2xx SDC35xxxxx4xx SDC36xxxxx2xx SDC36xxxxx4xx | Terminal on the back | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | SDC36.Lst |
| SDC45/46 | SDC45Axxxxxx3xx SDC45Axxxxxx7xx SDC45Vxxxxxx3xx SDC45Vxxxxxx7xx SDC46Axxxxxx3xx SDC46Axxxxxx7xx SDC46Vxxxxxx3xx SDC46Vxxxxxx7xx SDC45A0x1 SDC46A0x1 SDC45RxxxxR08xx SDC46RxxxxRx8xx | Terminal on the back | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | SDC45.Lst |
| SDC40A | SDC40Axxxxxx2xx | Terminal on the back | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | SDC40A.Lst |
| | SDC40Axxxxxx3xx | | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| SDC40G | SDC40Gxxxx095xx | Additional terminal on the back | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | SDC40G.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Module-type Controller

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|--|---------------------------------|--------------|-----------------------|-----------------------|-----------------------|---------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| DMC10 | DMC10S DMC10D | CPL communication terminal | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | DMC10.Ls t |
| DMC50 (COM) | DMC50ME20X DMC50MR20X | RS-485 port 1 | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | DMC50.Ls t |
| | | Display communication port | RS-485 | Wiring diagram 3 - C4 | Wiring diagram 3 - M4 | | |
| | DMC50CH40X DMC50CH20X DMC50CS40X DMC50CS20X | Display communication port | RS-485 | | | | |
| AHC2001 | AHC2001 | CPU | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | AHC2001.Lst |
| | | SCU | RS-232C | | | | |
| | | | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | Wiring diagram 6 - M4 | |
| AHC2001 +DCP31/32 | AHC2001 | SCU | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | Wiring diagram 6 - M4 | AHC_DCP.Lst |
| | DCP31Axx0ASxx 2xx DCP32AxxxASxx 2xx | Additional terminal on the back | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | |
| | IBS | Terminal block | | | | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Program Controller

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|--|---------------------------------|--------------|-----------------------|-----------------------|-----------------------|-----------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| DCP31/32 | DCP31Axx0ASxx 2xx DCP32AxxxASxx 2xx | Additional terminal on the back | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | DCP32.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Instrumentation Network Module

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Lst File |
|-----------------------------|----------------------------|--|--------------|-----------------------|-----------------------|--------------|------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2*1 | MJ2 (4-wire) | |
| NX (CPL) | NX-D15 NX-D25 NX-D35 | Built-in terminal | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | NX_CPL.Lst |
| NX (MODBUS RTU) | | NX-CB1N (terminal) NX-CB1R (terminal) | | | | | NX_Mod.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Ethernet Connection (TS2060i Only)

Instrumentation Network Module

| PLC Selection on the Editor | CPU | Unit/Port | TCP/IP *1 | UDP/IP | Port No. | Lst File |
|-----------------------------|----------------------------|--------------------|-----------|--------|--------------------------------|----------------|
| NX (MODBUS TCP/IP) | NX-D15 NX-D25 NX-D35 | NX-CB1N NX-CB1R | ○ | × | 502: Default (Max. 2 units) | NX_Mod_Eth.Lst |
| | | NX-CR1 | ○ | × | | |

*1 Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

6.2.1 SDC10

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | 4800 / <u>9600</u> bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

Make the following settings.

When the [PARA] key is held down for three seconds or longer in the run mode, the parameter mode is selected. When the [PARA] key is held down for three seconds or longer again, the setup mode is selected.

(Underlined setting: default)

| Item | Indication | Setting | Remarks |
|-------------------------|------------|---|--|
| Communication address | C22 | 1 to 31 | Communication is disabled when "0" is set. |
| Communication condition | C23 | <u>0: 9600 bps, 8 bits, even parity, 1 stop bit</u> 1: 9600 bps, 8 bits, without parity, 2 stop bit 2: 4800 bps, 8 bits, even parity, 1 stop bit 3: 4800 bps, 8 bits, without parity, 2 stop bit | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|--|
| --- | 00H | Without "※": RAM With "※": RAM + EEPROM |

* The number of times EEPROM can be reprogrammed is limited (approx. 100,000 times). Accordingly, we recommend that you write such a parameter as to be reprogrammed frequently into RAM, where the number of reprogramming times is not limited. However, when the parameter has been written into RAM, and the power is turned off and back on again, data in EEPROM is transferred.

For more information, refer to the instruction manual for the controller issued by the manufacturer.

6.2.2 SDC15

Settings are the same as those described in "6.2.7 SDC35/36".

6.2.3 SDC20

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1 : 0</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / <u>9600</u> bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

Make the following settings.

(Underlined setting: default)

| Item | Indication | Setting | Remarks |
|-----------------------|------------|--|--|
| Communication address | C31 | 1 to 31 | Communication is disabled when "0" is set. |
| Baud rate | C32 | <u>0: 9600 bps</u> 1: 4800 bps | |
| Data type | C33 | <u>0: 8 bits, 1 stop bit, even parity</u> 1: 8 bits, 2 stop bit, without parity | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|--|
| --- | 00H | Without "x": RAM With "x": RAM + EEPROM |

* The number of times EEPROM can be reprogrammed is limited (approx. 100,000 times). Accordingly, we recommend that you write such a parameter as to be reprogrammed frequently into RAM, where the number of reprogramming times is not limited. However, when the parameter has been written into RAM, and the power is turned off and back on again, data in EEPROM is transferred.

For more information, refer to the instruction manual for the controller issued by the manufacturer.

6.2.4 SDC21

Settings are the same as those described in "6.2.3 SDC20".

6.2.5 SDC25/26

Settings are the same as those described in "6.2.7 SDC35/36".

6.2.6 SDC30/31

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | 4800 / <u>9600</u> bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

Make the following settings.

When the [PARA] key is held down for three seconds or longer in the run mode, the parameter mode is selected. When the [PARA] key is held down for three seconds or longer again, the setup mode is selected.

(Underlined setting: default)

| Item | Indication | Setting | Remarks |
|-----------------------|------------|---|--|
| Communication address | C31 | 1 to 31 | Communication is disabled when "0" is set. |
| Baud rate | C32 | <u>0</u> : 9600 bps 1: 4800 bps | |
| Data type | C33 | <u>0</u> : 8 bits, <u>1</u> stop bit, <u>even</u> parity 1: 8 bits, 2 stop bit, without parity | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|--|
| --- | 00H | Without "※": RAM With "※": RAM + EEPROM |

* The number of times EEPROM can be reprogrammed is limited (approx. 100,000 times). Accordingly, we recommend that you write such a parameter as to be reprogrammed frequently into RAM, where the number of reprogramming times is not limited. However, when the parameter has been written into RAM, and the power is turned off and back on again, data in EEPROM is transferred.

For more information, refer to the instruction manual for the controller issued by the manufacturer.

6.2.7 SDC35/36

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

CPL communication setting

(Underlined setting: default)

| Item (Bank) | Indication | Setting | Remarks |
|--|------------|---|--|
| Communication type (Setup bank) | C64 | <u>0: CPL</u> | See "20. MODBUS". |
| Device address (Setup bank) | C65 | 1 to 127 | Communication is disabled when "0" is set. |
| Baud rate (Setup bank) | C66 | 0: 4800 bps 1: 9600 bps 2: <u>19200 bps</u> 3: 38400 bps | |
| Data type: data length (Setup bank) | C67 | 0: 7 bits <u>1: 8 bits</u> | |
| Data type: parity (Setup bank) | C68 | <u>0: Even</u> 1: Odd 2: None | |
| Data type: stop bit (Setup bank) | C69 | <u>0: 1 bit</u> 1: 2 bits | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|--|
| --- | 00H | Without "*": RAM With "*": RAM + EEPROM |

* The number of times EEPROM can be reprogrammed is limited (approx. 100,000 times). Accordingly, we recommend that you write such a parameter as to be reprogrammed frequently into RAM, where the number of reprogramming times is not limited. However, when the parameter has been written into RAM, and the power is turned off and back on again, data in EEPROM is transferred.

For more information, refer to the instruction manual for the controller issued by the manufacturer.

6.2.8 SDC45/46

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 127 | |

Controller

CPL communication setting

(Underlined setting: default)

| Item (Bank) | Indication | Setting | Remarks |
|---|------------|---|--|
| Communication type (RS-485 communication bank) | Com.01 | <u>0: CPL</u> | When establishing a connection in "2: Modbus RTU" format, refer to "28. MODBUS" in book 3 of the TS2060 Connection Manual. |
| Device address (RS-485 communication bank) | Com.02 | 1 to 127 | Communication is disabled when "0" is set. |
| Baud Rate (RS-485 communication bank) | Com.03 | 0: 4800 bps 1: 9600 bps <u>2: 19200 bps</u> 3: 38400 bps | |
| Data type: data length (RS-485 communication bank) | Com.04 | 0: 7 bits <u>1: 8 bits</u> | |
| Data type: parity (RS-485 communication bank) | Com.05 | <u>0: Even</u> 1: Odd 2: None | |
| Data type: stop bit (RS-485 communication bank) | Com.06 | <u>0: 1 bit</u> 1 or 2 bits | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available with the device to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|--|
| --- | 00H | Without asterisk: RAM With asterisk: RAM and EEPROM |

* The number of times EEPROM can be reprogrammed is limited (approx. 100,000 times). Accordingly, we recommend that frequently reprogrammed parameters be written to RAM, where the number of reprogramming times is not limited. However, when the parameter is written into RAM, and the power is turned off and back on again, data in EEPROM is transferred.

For more information, refer to the instruction manual for the controller issued by the manufacturer.

6.2.9 SDC40A

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1 : 0</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / <u>9600</u> bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

Make the following settings.

(Underlined setting: default)

| Item | Indication | Setting | Remarks |
|-----------------------|------------|---|--|
| Communication address | C84 | 1 to 31 | Communication is disabled when "0" is set. |
| Baud rate | C85 | <u>0</u> : 9600 bps, even parity, <u>1</u> stop bit 1: 9600 bps, without parity, 2 stop bit 2: 4800 bps, even parity, 1 stop bit 3: 4800 bps, without parity, 2 stop bit | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|--|
| --- | 00H | Without "※": RAM With "※": RAM + EEPROM |

* The number of times EEPROM can be reprogrammed is limited (approx. 100,000 times). Accordingly, we recommend that you write such a parameter as to be reprogrammed frequently into RAM, where the number of reprogramming times is not limited. However, when the parameter has been written into RAM, and the power is turned off and back on again, data in EEPROM is transferred.

For more information, refer to the instruction manual for the controller issued by the manufacturer.

6.2.10 SDC40G

Settings are the same as those described in "6.2.9 SDC40A".

6.2.11 DMC10

Communication Setting

Editor


Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|------------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

Rotary switch for device address

| MODULE ADDRESS | Setting | Remarks |
|--|---------|--|
|  | 1 to F | Communication is disabled when "0" is set. |

CPL communication setting

Make the following settings on the PC loader. (Underlined setting: default)

| Setting Items | Setting | Remarks |
|---------------|--|-------------------|
| CPL/MODBUS | <u>0: CPL</u> | See "20. MODBUS". |
| Baud rate | 1: 4800 bps 2: 9600 bps 3: <u>19200 bps</u> | |
| Data type | <u>0: 8 bits / 1 bit / even</u> 1: 8 bits / 2 bits / none | |

Available Device Memory

The available setting range of device memory varies depending on the controller model. Be sure to set within the range available for the controller to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|--|
| --- | 00H | Without "※": RAM With "※": RAM + EEPROM |

* The number of times EEPROM can be reprogrammed is limited (approx. 100,000 times). Accordingly, we recommend that you write such a parameter as to be reprogrammed frequently into RAM, where the number of reprogramming times is not limited. However, when the parameter has been written into RAM, and the power is turned off and back on again, data in EEPROM is transferred.

For more information, refer to the instruction manual for the controller issued by the manufacturer.

6.2.12 DMC50 (COM)

Communication Setting

Editor


Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|---|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 / 38400 bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | <u>1</u> bit | |
| Parity | <u>Even</u> | |
| Target Port No. | <u>1</u> to 16 | When connecting to the COM module: Station number: COM module Sub-station number: CTRL module |
| Sub-station No. | <u>0</u> to 16 | When connecting to the CTRL module: Station number: CTRL module Sub-station number: 0 |

Controller

Rotary address for module address

| MODULE ADDRESS | Setting | Remarks |
|---|---------|--|
|  | 1 to F | Communication is disabled when "0" is set. |

COM module: RS-485 port 1

Make the following settings on the PC loader.

(Underlined setting: default)

| Setting Items | Contents | Remarks |
|--------------------|---|---------|
| Baud rate (port 1) | <u>9600 bps</u> 19200 bps 38400 bps | |
| Protocol (port 1) | <u>1: CPL communication</u> | |

CTRL module: Display communication port

Make the following settings on the PC loader.

(Underlined setting: default)

| Setting Items | Contents | Remarks |
|--|---|---------|
| Baud rate for display communication port | <u>9600 bps</u> 19200 bps 38400 bps | |

* The display communication port is a dedicated port for 1 : 1 communication.

Available Device Memory


The available setting range of device memory varies depending on the controller model. Be sure to set within the range available for the controller to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory (Parameter Type ID) | TYPE | Remarks |
|--|------|------------------------|
| 000 (NA area) | 00H | Double-word |
| 001 (H/W information) | 01H | Double-word, read only |
| 002 (calendar time setting) | 02H | Double-word |
| 021 (AI setting) high-resolution monitor: for standard input | 03H | Double-word |
| 022 (AI setting) special monitor | 04H | Double-word |
| 023 (AI setting) high-resolution monitor: for option input | 05H | Double-word |
| 041 (AUX-IN setting) | 06H | Double-word |
| 045 (AO setting) | 07H | Double-word |
| 061 (DO setting) | 08H | Double-word |
| 071 (TP setting) | 09H | Double-word |
| 074 (zener barrier adjustment value) | 0AH | Double-word |
| 0A1 (communication setting: for ME200) | 0BH | Double-word, read only |
| 0A2 (communication setting: for MR200) | 0CH | Double-word, read only |
| 0A3 (communication setting: front port) | 0DH | Double-word, read only |
| 0C1 (system status) | 0EH | Double-word, read only |
| 0C3 (calendar time display) | 0FH | Double-word, read only |
| 0C4 (log: system alarm) | 10H | Double-word |
| 0C5 (log: AI alarm) | 11H | Double-word |
| 0C6 (log: AUX-IN alarm) | 12H | Double-word |
| 0E1 (AI status) | 13H | Double-word, read only |
| 0E2 (AUX-IN setting) | 14H | Double-word, read only |
| 0E3 (AO status) | 15H | Double-word |
| 0E5 (DI status) | 16H | Double-word, read only |
| 0E6 (AO status) | 17H | Double-word |
| 0E7 (TP status) | 18H | Double-word |
| 0E8 (zener barrier adjustment count) | 19H | Double-word, read only |
| 0F1 (communication setting in use: for ME200) | 1AH | Double-word, read only |
| 0F2 (communication setting in use: for MR200) | 1BH | Double-word, read only |
| 0F3 (communication setting in use: front port) | 1CH | Double-word, read only |
| 201 (PID_A setting) | 1DH | Double-word |
| 202 (PID_A constant) | 1EH | Double-word |
| 203 (PID_A monitor) | 1FH | Double-word, read only |
| 211 (PID_CAS setting) | 20H | Double-word |
| 212 (PID_CAS constant: master side) | 21H | Double-word |
| 213 (PID_CAS constant: slave side) | 22H | Double-word |
| 214 (PID_CAS monitor) | 23H | Double-word, read only |
| 234 (Ra_PID setting) | 24H | Double-word |
| 235 (Ra_PID constant) | 25H | Double-word |
| 236 (Ra_PID monitor) | 26H | Double-word, read only |
| 241 (UP_PID setting) | 27H | Double-word |
| 242 (UP_PID constant) | 28H | Double-word |
| 243 (UP_PID monitor) | 29H | Double-word, read only |
| 301 (TBL/TBR setting) | 2AH | Double-word |
| 801 (user-defined parameter) | 2BH | Double-word |
| 802 (user-defined parameter) | 2CH | Double-word |
| 803 (user-defined parameter) | 2DH | Double-word |
| 804 (user-defined parameter) | 2EH | Double-word |
| 805 (user-defined parameter) | 2FH | Double-word |
| 806 (user-defined parameter) | 30H | Double-word |
| 80D (user-defined parameter) | 31H | Double-word |
| 80E (user-defined parameter) | 32H | Double-word |
| E01 (user-defined parameter) | 33H | Double-word |
| E02 (user-defined parameter) | 34H | Double-word |
| E04 (user-defined parameter) | 35H | Double-word |
| E05 (user-defined parameter) | 36H | Double-word |
| E06 (user-defined parameter) | 37H | Double-word |
| E07 (user-defined parameter) | 38H | Double-word |
| E08 (user-defined parameter) | 39H | Double-word |

| Device Memory (Parameter Type ID) | TYPE | Remarks |
|-----------------------------------|------|------------------------|
| E0A (user-defined parameter) | 3AH | Double-word |
| E12 (user-defined parameter) | 3BH | Double-word |
| E13 (user-defined parameter) | 3CH | Double-word |
| E14 (user-defined parameter) | 3DH | Double-word |
| E15 (user-defined parameter) | 3EH | Double-word |
| 610 (user-defined parameter) | 3FH | Double-word |
| C00 (pattern setup) | 40H | Double-word |
| CF1 (pattern FB monitor) | 41H | Double-word, read only |
| C01 (segment setup) | 42H | Double-word |
| C02 (segment setup) | 43H | Double-word |
| C03 (segment setup) | 44H | Double-word |
| C04 (segment setup) | 45H | Double-word |
| C05 (segment setup) | 46H | Double-word |
| C06 (segment setup) | 47H | Double-word |
| C07 (segment setup) | 48H | Double-word |
| C08 (segment setup) | 49H | Double-word |
| C09 (segment setup) | 4AH | Double-word |
| C0A (segment setup) | 4BH | Double-word |
| C0B (segment setup) | 4CH | Double-word |
| C0C (segment setup) | 4DH | Double-word |
| C0D (segment setup) | 4EH | Double-word |
| C0E (segment setup) | 4FH | Double-word |
| C0F (segment setup) | 50H | Double-word |
| C10 (segment setup) | 51H | Double-word |
| C11 (segment setup) | 52H | Double-word |
| C12 (segment setup) | 53H | Double-word |
| C13 (segment setup) | 54H | Double-word |
| C14 (segment setup) | 55H | Double-word |
| C15 (segment setup) | 56H | Double-word |
| C16 (segment setup) | 57H | Double-word |
| C17 (segment setup) | 58H | Double-word |
| C18 (segment setup) | 59H | Double-word |
| C19 (segment setup) | 5AH | Double-word |
| C1A (segment setup) | 5BH | Double-word |
| C1B (segment setup) | 5CH | Double-word |
| C1C (segment setup) | 5DH | Double-word |
| C1D (segment setup) | 5EH | Double-word |
| C1E (segment setup) | 5FH | Double-word |
| C1F (segment setup) | 60H | Double-word |

Address denotations

On the signal name reference list, every group ID is designated as "001". To access any group ID other than "001", input the desired ID via manual operation.




Indirect Device Memory Designation

- When the address (group ID) is 0 to FFH:

| | | | | |
|-------|------------------|---|---|-----------------|
| | 15 | 8 | 7 | 0 |
| n + 0 | Model | | | Device type |
| n + 1 | Group ID | | | Item ID |
| n + 2 | Expansion code * | | | Bit designation |
| n + 3 | 00 | | | Station number |




- * In the expansion code, specify the sub-station number, and set which word, higher or lower, is to be read when a 2-word address is specified (expansion bit designation).




- When the address (group ID) is 100 to FFFH:

| | | | | | | |
|-------|----------------------------|---|---|----------------------|---|---|
| | 15 | 8 | 7 | 4 | 3 | 0 |
| n + 0 | Model | | | Device type | | |
| n + 1 | Group ID (medium/lower) *1 | | | Item ID *1 | | |
| n + 2 | 000 | | | Group ID (higher) *1 | | |
| n + 3 | Expansion code *2 | | | Bit designation | | |
| n + 4 | 00 | | | Station number | | |

- *1 Set the address (group ID + item ID) for "n + 1" and "n + 2".



- *2 In the expansion code, specify the sub-station number, and set which word, higher or lower, is to be read when a 2-word address is specified (expansion bit designation).



6.2.13 AHC2001

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 9600 / <u>19200</u> / 38400 / 57600 bps | |
| Data Length | 7/ <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

CPU unit RS-232C setting

(Underlined setting: default)

| Parameter Type ID | Group ID | Item ID | Setting Items | Contents | Remarks |
|-------------------|----------|---------|--------------------|--|---------|
| 0D2 | 001 | 01 | Baud rate (port 1) | 9600 bps <u>19200 bps</u> 38400 bps 57600 bps | |
| | | 02 | Mode | 1: CPL | |
| | | 03 | CPL address | <u>1</u> to 31 | |

The following settings are fixed; parity: even, and stop bit: 1 bit.

SCU unit setting

(Underlined setting: default)

| Parameter Type ID | Group ID | Item ID | Setting Items | Contents | Remarks |
|-------------------|---------------|---------|---------------------------|---|---------|
| Exx *1 | 001 002 *2 | 01 | Baud rate | 9600 bps <u>19200 bps</u> 38400 bps | |
| | | 02 | Data bit length | 7: 7 bits <u>8: 8 bits</u> | |
| | | 03 | Parity | 0: None <u>1: Even</u> 2: Odd | |
| | | 04 | Stop bit | <u>1: 1 bit</u> 2: 2 bits | |
| | | 05 | Half duplex / full duplex | <u>0: Half duplex</u> 1: Full duplex | |
| | | 07 | Protocol selection | 2: CPL server | |

*1 xx: Unit position 01 to 10H

The unit position varies depending on the mounting position of the SCU unit.

| | | | | | | | | |
|--------------|-----|-----|-----|--|--|--|--|--|
| Power supply | CPU | SCU | SCU | | | | | |
|--------------|-----|-----|-----|--|--|--|--|--|

E01h E02h - - - -

E10h

← Unit position E01H - E10H

*2 Group ID of port 1 (RS-232C): 001, group ID of port 2 (RS-485): 002

Available Device Memory


The available setting range of device memory varies depending on the controller model. Be sure to set within the range available for the controller to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory (Parameter Type ID) | TYPE | Remarks |
|-------------------------------------|------|------------------------|
| 000 (NA area) | 00H | Double-word |
| 001 (H/W information) | 01H | Double-word, read only |
| 002 (calendar time setting) | 02H | Double-word |
| 0C3 (calendar time display) | 03H | Double-word, read only |
| 0D0 (system information data) | 04H | Double-word, read only |
| 0D1 (unit information data) | 05H | Double-word, read only |
| 0D2 (CPU unit RS-232C setting) | 06H | Double-word, read only |
| 0D3 (system operation setting) | 07H | Double-word, read only |
| 0D4 (system configuration setting) | 08H | Double-word, read only |
| 0D5 (analog cycle setting) | 09H | Double-word, read only |
| 0D6 (memory capacity monitor) | 0AH | Double-word, read only |
| 201 (PID_A setting) | 0BH | Double-word |
| 202 (PID_A constant) | 0CH | Double-word |
| 203 (PID_A monitor) | 0DH | Double-word, read only |
| 211 (PID_CAS setting) | 0EH | Double-word |
| 212 (PID_CAS constant: master side) | 0FH | Double-word |
| 213 (PID_CAS constant: slave side) | 10H | Double-word |
| 214 (PID_CAS monitor) | 11H | Double-word, read only |
| 234 (Ra_PID setting) | 12H | Double-word |
| 235 (Ra_PID constant) | 13H | Double-word |
| 236 (Ra_PID monitor) | 14H | Double-word, read only |
| 241 (UP_PID setting) | 15H | Double-word |
| 242 (UP_PID constant) | 16H | Double-word |
| 243 (UP_PID monitor) | 17H | Double-word, read only |
| 301 (TBL/TBR setting) | 18H | Double-word |
| 600 (PLC link basic setting) | 19H | Double-word, read only |
| 801 (user-defined area) | 1AH | Double-word |
| 802 (user-defined area) | 1BH | Double-word |
| 803 (user-defined area) | 1CH | Double-word |
| 804 (user-defined area) | 1DH | Double-word |
| 805 (user-defined area) | 1EH | Double-word |
| 806 (user-defined area) | 1FH | Double-word |
| 807 (user-defined area) | 20H | Double-word |
| 808 (user-defined area) | 21H | Double-word |
| 809 (user-defined area) | 22H | Double-word |
| 80A (user-defined area) | 23H | Double-word |
| 80B (user-defined area) | 24H | Double-word |
| 80C (user-defined area) | 25H | Double-word |
| 80D (user-defined area) | 26H | Double-word |
| 80E (user-defined area) | 27H | Double-word |
| 80F (user-defined area) | 28H | Double-word |
| 810 (user-defined area) | 29H | Double-word |
| 811 (user-defined area) | 2AH | Double-word |
| 812 (user-defined area) | 2BH | Double-word |
| 813 (user-defined area) | 2CH | Double-word |
| 814 (user-defined area) | 2DH | Double-word |
| 815 (user-defined area) | 2EH | Double-word |
| 816 (user-defined area) | 2FH | Double-word |
| 817 (user-defined area) | 30H | Double-word |
| 820 (user-defined area) | 31H | Double-word |
| E01 (user-defined area) | 32H | Double-word |
| E02 (user-defined area) | 33H | Double-word |
| E03 (user-defined area) | 34H | Double-word |
| E04 (user-defined area) | 35H | Double-word |
| F01 (user-defined area) | 36H | Double-word |
| F02 (user-defined area) | 37H | Double-word |
| F03 (user-defined area) | 38H | Double-word |
| F04 (user-defined area) | 39H | Double-word |

| Device Memory (Parameter Type ID) | TYPE | Remarks |
|-----------------------------------|------|-------------|
| F05 (user-defined area) | 3AH | Double-word |
| F06 (user-defined area) | 3BH | Double-word |

Address denotations

On the signal name reference list, every group ID is designated as "001". To access any group ID other than "001", manually input the desired ID.



PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---------------------------------------|---------------------|--------------|---------------------|----|
| ISaGRAF application Start/stop | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 0 | |
| | | n + 2 | 0: Stop 1: Start | |
| ISaGRAF application Current status | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 1 | |
| | | n + 2 | 0: Stop 1: Run | |
| Reserve for parameter backup | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 2 | |

Return data: Data stored from temperature controller to TS2060

6.2.14 AHC2001+DCP31/32

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|------------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 / 38400 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

AHC2001 SCU unit setting

(Underlined setting: default)

| Parameter Type ID | Group ID | Item ID | Setting Items | Contents | Remarks |
|-------------------|----------|---------|---------------------------|---|--|
| Exx *1 | 002 | 01 | Baud rate | 9600 bps <u>19200 bps</u> 38400 bps | |
| | | 02 | Data bit length | 7: 7 bits <u>8: 8 bits</u> | |
| | | 03 | Parity | 0: None <u>1: Even</u> 2: Odd | |
| | | 04 | Stop bit | <u>1: 1 bit</u> 2: 2 bits | |
| | | 05 | Half duplex / full duplex | <u>0: Half duplex</u> 1: Full duplex | Half duplex: 2-wire connection Full duplex: 4-wire connection |
| | | 07 | Protocol selection | 2: CPL server | |

*1 xx: Unit position 01 to 10H

The unit position varies depending on the mounting position of the SCU unit.

| | | | | | | | | |
|--------------|-----|-----|-----|--|--|--|--|--|
| Power supply | CPU | SCU | SCU | | | | | |
|--------------|-----|-----|-----|--|--|--|--|--|

E01h

E02h

- - - -

E10h

← Unit position E01H - E10H

DCP31/32

Setting group: Make the following setting on the setup data.

(Underlined setting: default)

| Item | Indication | Setting | Remarks |
|-----------------------|------------|---|--|
| Communication address | C84 | 1 to 31 | Communication is disabled when "0" is set. |
| Baud rate | C85 | <u>0: 9600 bps, even parity, 1 stop bit</u> 1: 9600 bps, without parity, 2 stop bit 2: 4800 bps, even parity, 1 stop bit 3: 4800 bps, without parity, 2 stop bit | |
| Data type | C93 | <u>0: Additional terminal</u> | |

IBS (air-fuel ratio controller)

Set the baud rate by the jumper setting (J2) on the CPU board.

(Underlined setting: default)

| Item | Setting | Remarks |
|------|-----------------------------|---|
| J2 | RS-485 Baud rate setting | <u>9600 bps: short-circuited between 1 and 2, 3 and 4,</u> <u>open between 5 and 6</u> 4800 bps: open between 1 and 2, short-circuited between 3 and 4, open between 5 and 6 |

Available Device Memory

The available setting range of device memory varies depending on the controller model. Be sure to set within the range available for the controller to be used. Use [TYPE] when assigning indirect device memory for macro programs.


| Device Memory (Parameter Type ID) | TYPE | Remarks |
|-------------------------------------|------|---------------------------------|
| 000 (NA area) | 00H | AHC2001, double-word |
| 001 (H/W information) | 01H | AHC2001, double-word, read only |
| 002 (calendar time setting) | 02H | AHC2001, double-word |
| 0C3 (calendar time display) | 03H | AHC2001, double-word, read only |
| 0D0 (system information data) | 04H | AHC2001, double-word, read only |
| 0D1 (unit information data) | 05H | AHC2001, double-word, read only |
| 0D2 (CPU unit RS-232C setting) | 06H | AHC2001, double-word, read only |
| 0D3 (system operation setting) | 07H | AHC2001, double-word, read only |
| 0D4 (system configuration setting) | 08H | AHC2001, double-word, read only |
| 0D5 (analog cycle setting) | 09H | AHC2001, double-word, read only |
| 0D6 (memory capacity monitor) | 0AH | AHC2001, double-word, read only |
| 201 (PID_A setting) | 0BH | AHC2001, double-word |
| 202 (PID_A constant) | 0CH | AHC2001, double-word |
| 203 (PID_A monitor) | 0DH | AHC2001, double-word, read only |
| 211 (PID_CAS setting) | 0EH | AHC2001, double-word |
| 212 (PID_CAS constant: master side) | 0FH | AHC2001, double-word |
| 213 (PID_CAS constant: slave side) | 10H | AHC2001, double-word |
| 214 (PID_CAS monitor) | 11H | AHC2001, double-word, read only |
| 234 (Ra_PID setting) | 12H | AHC2001, double-word |
| 235 (Ra_PID constant) | 13H | AHC2001, double-word |
| 236 (Ra_PID monitor) | 14H | AHC2001, double-word, read only |
| 241 (UP_PID setting) | 15H | AHC2001, double-word |
| 242 (UP_PID constant) | 16H | AHC2001, double-word |
| 243 (UP_PID monitor) | 17H | AHC2001, double-word, read only |
| 301 (TBL/TBR setting) | 18H | AHC2001, double-word |
| 600 (PLC link basic setting) | 19H | AHC2001, double-word, read only |
| 801 (user-defined area) | 1AH | AHC2001, double-word |
| 802 (user-defined area) | 1BH | AHC2001, double-word |
| 803 (user-defined area) | 1CH | AHC2001, double-word |
| 804 (user-defined area) | 1DH | AHC2001, double-word |
| 805 (user-defined area) | 1EH | AHC2001, double-word |
| 806 (user-defined area) | 1FH | AHC2001, double-word |
| 807 (user-defined area) | 20H | AHC2001, double-word |
| 808 (user-defined area) | 21H | AHC2001, double-word |
| 809 (user-defined area) | 22H | AHC2001, double-word |
| 80A (user-defined area) | 23H | AHC2001, double-word |
| 80B (user-defined area) | 24H | AHC2001, double-word |
| 80C (user-defined area) | 25H | AHC2001, double-word |
| 80D (user-defined area) | 26H | AHC2001, double-word |
| 80E (user-defined area) | 27H | AHC2001, double-word |
| 80F (user-defined area) | 28H | AHC2001, double-word |
| 810 (user-defined area) | 29H | AHC2001, double-word |
| 811 (user-defined area) | 2AH | AHC2001, double-word |
| 812 (user-defined area) | 2BH | AHC2001, double-word |
| 813 (user-defined area) | 2CH | AHC2001, double-word |
| 814 (user-defined area) | 2DH | AHC2001, double-word |
| 815 (user-defined area) | 2EH | AHC2001, double-word |
| 816 (user-defined area) | 2FH | AHC2001, double-word |
| 817 (user-defined area) | 30H | AHC2001, double-word |

| Device Memory (Parameter Type ID) | | TYPE | Remarks |
|-----------------------------------|---------------------|------|----------------------|
| 820 | (user-defined area) | 31H | AHC2001, double-word |
| E01 | (user-defined area) | 32H | AHC2001, double-word |
| E02 | (user-defined area) | 33H | AHC2001, double-word |
| E03 | (user-defined area) | 34H | AHC2001, double-word |
| E04 | (user-defined area) | 35H | AHC2001, double-word |
| F01 | (user-defined area) | 36H | AHC2001, double-word |
| F02 | (user-defined area) | 37H | AHC2001, double-word |
| F03 | (user-defined area) | 38H | AHC2001, double-word |
| F04 | (user-defined area) | 39H | AHC2001, double-word |
| F05 | (user-defined area) | 3AH | AHC2001, double-word |
| F06 | (user-defined area) | 3BH | AHC2001, double-word |
| --- | (DCP) | 3CH | DCP31/32 |

Address denotations


- AHC2001

On the signal name reference list, every group ID is designated as "001". To access any group ID other than "001", manually input the desired ID.



- DCP31/32

The address for DCP31/32 is not provided in the signal name reference list. Manually set the address by referring to the instruction manual for DCP31/32.



PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---------------------------------------|---------------------|--------------|---------------------|----|
| ISaGRAF application Start/stop | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 0 | |
| | | n + 2 | 0: Stop 1: Start | |
| ISaGRAF application Current status | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 1 | |
| | | n + 2 | 0: Stop 1: Run | |
| Reserve for parameter backup | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 2 | |

Return data: Data stored from temperature controller to TS2060

6.2.15 DCP31/32

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | 4800 / <u>9600</u> bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

Controller

Setting group: Make the following setting on the setup data.

(Underlined setting: default)

| Item | Indication | Setting | Remarks |
|-----------------------|------------|---|--|
| Communication address | C84 | 1 to 31 | Communication is disabled when "0" is set. |
| Baud rate | C85 | <u>0</u> : 9600 bps, even parity, <u>1</u> stop bit 1: 9600 bps, without parity, 2 stop bit 2: 4800 bps, even parity, 1 stop bit 3: 4800 bps, without parity, 2 stop bit | |
| Data type | C93 | <u>0</u> : <u>Additional terminal</u> | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| --- | 00H | |

6.2.16 NX (CPL)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115K bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | 1 to <u>127</u> | |

Controller

Make the following settings on [Actual Module Configuration] in the [SLP-NX] software.

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------------|---|--|
| RS-485 Address | 1 to <u>127</u> | Communication is disabled when "0" is set. |
| RS-485 Protocol | CPL | |
| RS-485 Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115200 bps | |
| RS-485 Bit Length | 7 / <u>8</u> bits | |
| RS-485 Parity Setting | None / Odd / <u>Even</u> | |
| RS-485 Stop Bit | <u>1</u> / 2 bits | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| --- | 00H | |

6.2.17 NX (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115K bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | 1 to <u>127</u> | |

Controller

Make the following settings on [Actual Module Configuration] in the [SLP-NX] software.

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------------|---|--|
| RS-485 Address | 1 to <u>127</u> | Communication is disabled when "0" is set. |
| RS-485 Protocol | MODBUS (RTU) | |
| RS-485 Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115200 bps | |
| RS-485 Bit Length | 8 bits | |
| RS-485 Parity Setting | None / Odd / <u>Even</u> | |
| RS-485 Stop Bit | <u>1</u> / 2 bits | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| --- | 02H | |


6.2.18 NX (MODBUS TCP/IP)

Communication Setting


Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".


- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]



- IP address, port number, and maximum read value of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].



Valid only for 1 : 1 connection
Select the PLC for connection from those registered on the PLC table.



Set the IP address, port number and maximum read value of the controller.

Maximum read value:
Set a value according to the controller specification.
32 or 64 words

Controller

Make the following settings on [Actual Module Configuration] in the [SLP-NX] software.

| Item | | Remarks |
|--------------|----------------------------------|--------------|
| IP Address | - | |
| IP Setting | Net mask | |
| | Default gateway | |
| Port Setting | MODBUS communication port number | Default: 502 |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| --- | 02H | |

6.2.19 Wiring Diagrams


When Connected at CN1:




- The CN1 port is available only when the TS2060i is attached the optional “DUR-00”.
- The “DUR-00” cannot be attached to the TS2060 (model name without “i”). Use the MJ1 and MJ2 ports for connection.

RS-232C

Wiring diagram 1 - C2




Wiring diagram 2 - C2




RS-422/RS-485


Wiring diagram 1 - C4




Wiring diagram 2 - C4



Wiring diagram 3 - C4




Wiring diagram 4 - C4




When Connected at MJ1/MJ2:

RS-232C

Wiring diagram 1 - M2




Wiring diagram 2 - M2




RS-422/RS-485


Wiring diagram 1 - M4




Wiring diagram 2 - M4




Wiring diagram 3 - M4




Wiring diagram 4 - M4



Wiring diagram 5 - M4




Wiring diagram 6 - M4



MEMO

MONITOUCH



7. Banner

7.1 Temperature Controller/Servo/Inverter Connection

7.1 Temperature Controller/Servo/Inverter Connection

Ethernet Connection (TS2060i Only)

Vision Sensor

| PLC Selection on the Editor | CPU | Port | TCP/IP ^{*1} | UDP/IP | Port No. | Keep Alive ^{*2} | Lst File |
|--|-------------------------------------|----------|----------------------|--------|----------|--------------------------|---------------|
| PresencePLUS (Ethernet/IP (TCP/IP)) | PresencePLUS P4 PresencePLUS Pro | Ethernet | ○ | × | 44818 | × | BPPVS_Eth.Lst |

^{*1} Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

^{*2} For KeepAlive functions, see "1.3.2 Ethernet Communication (TS2060i Only)".

7.1.1 PresencePLUS (Ethernet/IP (TCP/IP))

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 44818) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].


Network camera display settings must be configured to display images from the sensor on the TS2060i series.
For more information, refer to "1.3 Network Camera" in the TS2060i Series Reference Manual 2.

Vision Sensor

Make settings using Banner's dedicated software "Presence PLUS". For more information, refer to the manual of the vision sensor.

System setup

Click [Change Sensor IP Address] to display the [Set Sensor IP Address] window and configure the IP address and subnet mask settings.



Sensor IP address settings

| Item | Setting | Remarks |
|--------------------|---|---------|
| New Sensor Name | Set a name for the sensor. | |
| New IP Address | Set the IP address of the sensor. | |
| New Subnet Mask | Set the subnet mask of the sensor. | |
| New Gateway | Specify according to the environment. | |
| Sensor MAC Address | The MAC address of the sensor is displayed. | |
| Host PC IP Address | The IP address of the computer to which the sensor is connected is displayed. | |

Available Device Memory


The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used.

Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--------------------|------|-----------|
| PI1 (PPVS_INPUT) | 00H | |
| PO1 (PPVS_OUTPUT1) | 01H | Read only |
| PO2 (PPVS_OUTPUT2) | 02H | Read only |
| PO3 (PPVS_OUTPUT3) | 03H | Read only |
| PO4 (PPVS_OUTPUT4) | 04H | Read only |
| PO5 (PPVS_OUTPUT5) | 05H | Read only |

MEMO

MONITOUCH



8. Baumuller

8.1 PLC Connection

8.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*3} |
|--------------------------------|-----------|--------------|-----------------|-----------------------|-----------------------|----------------------------|----------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | |
| BMx-x-PLC | BMx-x-PLC | RS-232C port | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | RS-422 port | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*3} For the ladder transfer function, see the TS2060 Reference Manual 2.

8.1.1 BMx-x-PLC

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1:1</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1 bit</u> | |
| Parity | <u>Even</u> | |

PLC

No particular setting is necessary on the PLC.


Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|-----------------|------|---------|
| DB (Data Block) | 00H | |

* The assigned device memory is expressed as shown on the right when editing the screen.

Example: DB xxx yyy


 0 to 255 (decimal)
 0 to 255 (decimal)

8.1.2 Wiring Diagrams


When Connected at CN1:



- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.


RS-232C

Wiring diagram 1 - C2



RS-422/RS-485


Wiring diagram 1 - C4



When Connected at MJ1/MJ2:


RS-232C

Wiring diagram 1 - M2



RS-422/RS-485

Wiring diagram 1 - M4



9. BECKHOFF

9.1 PLC Connection

9.1 PLC Connection

Ethernet Connection (TS2060i Only)

| PLC Selection on the Editor | CPU | Unit | LAN port | TCP/IP ^{*1} | UDP/IP | Port No. | Ladder Transfer ^{*2} |
|-----------------------------|----------------------------|----------------------|----------------|----------------------|--------|-------------|-------------------------------|
| ADS protocol (Ethernet) | BC9000 BC9100 BX9000 | KLxxxx ^{*3} | CPU (built-in) | ○ | × | 48898 fixed | × |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.
^{*3} Use the same voltage (24 V) as for the CPU.

9.1.1 ADS Protocol (Ethernet)

Communication Setting

Editor

Communication settings

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

IP address setting

1. Set the DIP switches 9 and 10 to OFF.
2. Connect the PLC with the computer.
3. Launch "Command Prompt" on the computer.
4. Enter "Arp -a" and execute it.
The IP address (xxx.xxx.xxx.xxx) and the MAC address (zzz.zzz.zzz.zzz) of the PLC previously set are displayed.
(Check whether you can ping the IP address of the PLC ("ping xxx.xxx.xxx.xxx") successfully.)
5. Enter "Arp -d xxx.xxx.xxx.xxx" (IP address displayed in step 4.) and execute.
6. Enter "Arp -s yyy.yyy.yyy.yyy zzz.zzz.zzz.zzz" (new IP address and MAC address) and execute.
7. Enter "ping -l 123 yyy.yyy.yyy.yyy" (new IP address) and execute it. The new IP address becomes valid.

Port No.

TCP/IP port No. 48898 (fixed)

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|--------------------------|------|--------------------------|
| P100-0 | Port 100 - Index group 0 | 00H | |
| P300-I | Port 300 - Inputs | 01H | Read only ^{*1} |
| P300-O | Port 300 - Outputs | 02H | Write only ^{*1} |
| P800-I | Port 800 - Inputs | 03H | ^{*1} |
| P800-O | Port 800 - Outputs | 04H | ^{*1} |
| P800-F | Port 800 - Flags | 05H | ^{*1} |
| P801-I | Port 801 - Inputs | 06H | ^{*1} |
| P801-O | Port 801 - Outputs | 07H | ^{*1} |
| P801-F | Port 801 - Flags | 08H | ^{*1} |
| P811-I | Port 811 - Inputs | 09H | ^{*1} |
| P811-O | Port 811 - Outputs | 0AH | ^{*1} |
| P811-F | Port 811 - Flags | 0BH | ^{*1} |
| P821-I | Port 821 - Inputs | 0CH | ^{*1} |
| P821-O | Port 821 - Outputs | 0DH | ^{*1} |
| P821-F | Port 821 - Flags | 0EH | ^{*1} |
| P831-I | Port 831 - Inputs | 0FH | ^{*1} |
| P831-O | Port 831 - Outputs | 10H | ^{*1} |
| P831-F | Port 831 - Flags | 11H | ^{*1} |
| P350-I | Port 350 - Inputs | 12H | Read only ^{*1} |
| P350-O | Port 350 - Outputs | 13H | Write only ^{*1} |
| P851-I | Port 851 - Inputs | 14H | ^{*1} |
| P851-O | Port 851 - Outputs | 15H | ^{*1} |
| P851-F | Port 851 - Flags | 16H | ^{*1} |
| P852-I | Port 852 - Inputs | 17H | ^{*1} |
| P852-O | Port 852 - Outputs | 18H | ^{*1} |
| P852-F | Port 852 - Flags | 19H | ^{*1} |
| P853-I | Port 853 - Inputs | 1AH | ^{*1} |
| P853-O | Port 853 - Outputs | 1BH | ^{*1} |
| P853-F | Port 853 - Flags | 1CH | ^{*1} |
| P854-I | Port 854 - Inputs | 1DH | ^{*1} |
| P854-O | Port 854 - Outputs | 1EH | ^{*1} |
| P854-F | Port 854 - Flags | 1FH | ^{*1} |

* Access to the device memory area is not allowed if a password is set for the area.

^{*1} The addresses are expressed in "bytes". For word designation, specify an even-numbered address.

Address denotations

The assigned device memory is expressed as shown below when editing the screen.

Example: P800 - F00000001



Indirect Device Memory Designation

For P300 / P800 / P801 device memory:


Specify a value obtained by dividing the address by 2. (Discard the fraction.)

Example: With indirect device memory designation, "9" is assigned for "P300-I00000013".
 $13 \text{ (HEX)} = 19 \text{ (DEC)}$
 $19 \div 2 = 9.5$

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|----------------|---------------------|--------------|-----------------------------|----|
| Access Inputs | 1 - 8 (PLC1 - 8) | n | Station number | 7 |
| | | n + 1 | Command: 0001H | |
| | | n + 2 | Port * ¹ | |
| | | n + 3 | Index Group * ² | |
| | | n + 4 | | |
| | | n + 5 | Index Offset * ² | |
| | | n + 6 | | |
| | | n + 7 | Data | |
| Access Outputs | 1 - 8 (PLC1 - 8) | n | Station number | 8 |
| | | n + 1 | Command: 0002H | |
| | | n + 2 | Port * ¹ | |
| | | n + 3 | Index Group * ² | |
| | | n + 4 | | |
| | | n + 5 | Index Offset * ² | |
| | | n + 6 | | |
| | | n + 7 | Data | |

 Return data: Data stored from temperature controller to TS2060i

*1 Port setting values

| Port | Name |
|-----------|------------------------|
| 100 | Logger (only NT - Log) |
| 110 | Eventlogger |
| 300 | IO |
| 301 | Additional Task 1 |
| 302 | Additional Task 2 |
| 500 | NC |
| 801 / 851 | PLC Run-time System 1 |
| 811 / 852 | PLC Run-time System 2 |
| 821 / 853 | PLC Run-time System 3 |
| 831 / 854 | PLC Run-time System 4 |
| 900 | Camshaft Controller |
| 10000 | System Service |
| 14000 | Scope |

*2 Setting values for "Index Group" and "Index Offset"

| Access | | Index Group | Index Offset | Description |
|----------------------------------|----------------------------------|-------------|----------------|---|
| Input | Output | | | |
| <input type="radio"/> | <input type="radio"/> | 00004020H | 0 - 65535 | READ_M / WRITE_M |
| <input type="radio"/> | <input checked="" type="radio"/> | 00004025H | 0 | PLCADS_IJR_RMSIZE |
| <input type="radio"/> | <input type="radio"/> | 0000F003H | 0 | GET_SYMHANDLE_BYNAME |
| <input type="radio"/> | <input type="radio"/> | 0000F005H | 0 - 4294967295 | READ_SYMVAL_BYHANDLE WRITE_SYMVAL_BYHANDLE |
| <input checked="" type="radio"/> | <input type="radio"/> | 0000F006H | 0 | RELEASE_SYMHANDLE |
| <input type="radio"/> | <input type="radio"/> | 0000F020H | 0 - 4294967295 | READ_I / WRITE_I |
| <input type="radio"/> | <input checked="" type="radio"/> | 0000F025H | 0 | ADSIGRP_IOIMAGE_RISIZE |
| <input type="radio"/> | <input type="radio"/> | 0000F030H | 0 - 4294967295 | READ_Q / WRITE_Q |
| <input type="radio"/> | <input checked="" type="radio"/> | 0000F035H | 0 | ADSIGRP_IOIMAGE_ROSIZE |

10. Bosch Rexroth

10.1 Temperature Controller/Servo/Inverter Connection

10.1 Temperature Controller/Servo/Inverter Connection

Serial Connection

Servo

| PLC Selection on the Editor | Model | | Port | Signal Level | Wiring Diagram | | | Lst File |
|--------------------------------|--------------|---|--------------|-----------------|-----------------------|-----------------------|--------------|----------|
| | | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| IndraDrive | IndraDrive C | HCS02 HCS03 HCS02.1 HCS03.1 | RS-232C Port | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | None |
| | IndraDrive M | HMD01 HMS01 HMS02 HMOV1 HMOV2 | | | | | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

10.1.1 IndraDrive

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1: n | |
| Signal Level | <u>RS-232C</u> / RS-422 / 485 | |
| Baud Rate | <u>9600</u> / 19200 / 38400 / 57600 / 115K bps | |
| Parity | <u>None</u> / Odd / Even | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |

Servo

| Item | Setting | Remarks |
|--------|--------------------------|---------|
| Parity | <u>None</u> / Odd / Even | |

Baud rate, data length, and stop bit settings are not required.

Available Device Memory

There are no device memory.

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|-------------------------|-----------------------|--------------|--|----|
| SIS version acquisition | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 1H | |
| | | n + 2 | Execution result 0: Successful completion Other than 0: Abnormal termination | |
| | | n + 3 | mmVnn: SIS version (character string) | |
| | | : | | |
| | | n + 7 | | |
| FWA number acquisition | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 2H | |
| | | n + 2 | Execution result 0: Successful completion Other than 0: Abnormal termination | |
| | | n + 3 | FWA number (character string) (Max. 20 words) | |
| | | : | | |
| | | n + 22 | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|------------------------------------|-----------------------|--------------|---|----|
| Unit type code acquisition | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 3H | |
| | | n + 2 | Execution result 0: Successful completion Other than 0: Abnormal termination | |
| | | n + 3 | Unit type code (character string) (Max. 20 words) | |
| | | : | | |
| | | n+22 | | |
| Acquisition of supported baud rate | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 4H | |
| | | n + 2 | Execution result 0: Successful completion Other than 0: Abnormal termination | |
| | | n + 3 | Supported baud rate 0: 9600 bps 1: 19200 bps 2: 38400 bps 4: 57600 bps 8: 115.2 kbps | |
| Shutdown | 1 to 8 (PLC1 to 8) | n | Target Port No. | 5 |
| | | n + 1 | Command: 290H | |
| | | n + 2 | Shutdown target 0: Firmware 1: Load routine | |
| | | n + 3 | Starting address (lower) | |
| | | n + 4 | Starting address (higher) | |
| | | n + 5 | Execution result 0H: Normal termination 9002H: Firmware deleted 9003H: Shutdown phase 3 not permitted 9004H: Shutdown phase 4 not permitted | |
| Reboot | 1 to 8 (PLC1 to 8) | n | Target Port No. | 4 |
| | | n + 1 | Command: 291H | |
| | | n + 2 | Starting address (lower) | |
| | | n + 3 | Starting address (higher) | |
| | | n + 4 | Execution result 0H: Normal termination 9102H: Firmware deleted 9103H: Reboot phase 3 not permitted 9104H: Reboot phase 4 not permitted | |
| Data reading | 1 to 8 (PLC1 to 8) | n | Target Port No. | 5 |
| | | n + 1 | Command: 292H | |
| | | n + 2 | Starting address (lower) | |
| | | n + 3 | Starting address (higher) | |
| | | n + 4 | Reading size (Max. 244 bytes) | |
| | | n + 5 | Execution result 0H: Normal termination 9200H: Reading range error | |
| | | n + 6 | Data to read (Max. 122 words) | |
| | | : | | |
| | | n + 127 | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|--------------------------------|---|--------------|---|---------|
| Header top address acquisition | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 293H | |
| | | n + 2 | Execution result 0: Successful completion Other than 0: Abnormal termination | |
| | | n + 3 | Header top address (lower) | |
| | | n + 4 | Header top address (higher) | |
| Memory initialization | 1 to 8 (PLC1 to 8) | n | Target Port No. | 6 |
| | | n + 1 | Command: 294H | |
| | | n + 2 | Starting address (lower) | |
| | | n + 3 | Starting address (higher) | |
| | | n + 4 | Block length (lower) | |
| | | n + 5 | Block length (higher) | |
| n + 6 | Execution result 0H: Normal termination 9400H: Initialization timeout 940A: Initialization of only loader possible | | | |
| Data writing | 1 to 8 (PLC1 to 8) | n | Target Port No. | 7 ~ 126 |
| | | n + 1 | Command: 296H | |
| | | n + 2 | Starting address (lower) | |
| | | n + 3 | Starting address (higher) | |
| | | n + 4 | Device memory type 2: MEM_RAM 3: MEM_DPR 4: MEM_FLASH | |
| | | n + 5 | Writing data length (unit: bytes) m: 1 to 240 | |
| | | n + 6 | Data to write (m/2 words) | |
| | | : | | |
| | | n+(6+m/2) *1 | Execution result 0H: Normal termination 96FFH: Range error (other than RAM specified) 96E0H: Programming error of Flash 96E1H: Programming timeout of Flash | |
| Checksum setting | 1 to 8 (PLC1 to 8) | n | Target Port No. | 6 |
| | | n + 1 | Command: 297H | |
| | | n + 2 | Starting address (lower) | |
| | | n + 3 | Starting address (higher) | |
| | | n + 4 | Module size (lower) | |
| | | n + 5 | Module size (higher) | |
| n + 6 | Execution result 0H: Normal termination 9701H: Checksum setting error 9702H: CRC32 checksum error | | | |
| Error reset | 1 to 8 (PLC1 to 8) | n | Target Port No. | 2 |
| | | n + 1 | Command: 29FH | |
| | | n + 2 | Execution result 0: Successful completion Other than 0: Abnormal termination | |

| Contents | F0 | F1 (=\$u n) | | F2 |
|-----------------|-----------------------|-------------|--|----|
| Timeout setting | 1 to 8 (PLC1 to 8) | n | Target Port No. | 3 |
| | | n + 1 | Command: 301H | |
| | | n + 2 | Specified timeout time | |
| | | n + 3 | Execution result 0: Successful completion Other than 0: Abnormal termination | |

*1 "m/2" is rounded up to the nearest integer.


Return data: Data stored from servo to TS2060

10.1.2 Wiring Diagrams

When Connected at CN1:

RS-232C


Wiring diagram 1 - C2



When Connected at MJ1/MJ2:

RS-232C

Wiring diagram 1 - M2



11. CHINO

11.1 Temperature Controller/Servo/Inverter Connection

11.1 Temperature Controller/Servo/Inverter Connection

Digital Temperature Controller

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|--|----------------|--------------|-----------------------|-----------------------|-----------------------|-------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| DP1000 | DP1xxxBRxx | Terminal block | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | DP1000.Lst |
| | DP1xxxBAxx | Terminal block | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 4 - M4 | |
| | DP10xxGRxx-x xx | Terminal block | COM1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | |
| | DP10xxGSxx-x xx | Terminal block | COM1 | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | |
| | DP10xxGAxx-x xx | Terminal block | COM1 | RS-422 | × | Wiring diagram 4 - M4 | |
| | DP10xxGBxx-x xx | Terminal block | COM1 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | |
| | | | COM2 | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | |
| | DP10xxGCxx-x xx | Terminal block | COM1 | RS-485 | Wiring diagram 3 - C4 | Wiring diagram 2 - M4 | |
| | | | COM2 | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | |
| | DP10xxGDxx-x xx | Terminal block | COM1 | RS-422 | × | Wiring diagram 5 - M4 | |
| | | | COM2 | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | |
| | DP10xxGExx-x xx | Terminal block | COM1 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | |
| | | | COM2 | RS-485 | Wiring diagram 5 - C4 | Wiring diagram 3 - M4 | |
| | DP10xxGFxx-x xx | Terminal block | COM1 | RS-485 | Wiring diagram 3 - C4 | Wiring diagram 2 - M4 | |
| | | | COM2 | Wiring diagram 5 - C4 | Wiring diagram 3 - M4 | | |
| | DP10xxGGxx-x xx | Terminal block | COM1 | RS-422 | × | Wiring diagram 5 - M4 | |
| | | | COM2 | RS-485 | Wiring diagram 5 - C4 | Wiring diagram 3 - M4 | |
| DB1000B (MODBUS RTU) | DB1xxxBRxx-x xx | Terminal block | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | DB1000B.Lst |
| | DB1xxxBAxx-x xx | | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 4 - M4 | |
| | DB1xxxBSxx-x xx | | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | | |
| LT230 (MODBUS RTU) | LT23xxxS00-xx LT23xxx200-xx | Terminal block | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | | LT230.Lst |
| LT300 (MODBUS RTU) | LT35xxxRx0-xx x LT37xxxRx0-xx x | Terminal block | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | LT300.Lst |
| | LT35xxxAx0-xx x LT37xxxAx0-xx x | | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 4 - M4 | |
| | LT35xxxSx0-xx x LT37xxxSx0-xx x | | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | | |
| LT400 Series (MODBUS RTU) | LT45xxxRxx-xx x LT47xxxRxx-xx x | Terminal block | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | LT400.Lst |
| | LT45xxxAxx-xx x LT47xxxAxx-xx x | | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 4 - M4 | |
| | LT45xxxSxx-xx x | | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | | |
| LT830 (MODBUS RTU) | LT830xx000-2 xx | Terminal block | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | | LT830.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Graphic Recorder

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|--------------------------------|------------|----------------|--------------|-----------------------|-----------------------|--------------|----------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| KR2000 (MODBUS RTU) | KR21xxxRxA | Terminal block | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | KR2000 .Lst |
| | | | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | | |
| | KR21xxxQxA | Terminal block | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

11.1.1 DP1000

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Data Length | <u>Z</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 99 | |

Digital Program Controller

DP1000

The communication parameters can be set using keys attached to the digital program controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Mode No. | Item | Setting | Remarks |
|--|--|---|--|
| Mode 1 (Operation status selection) | Program start method * | MASTER COM.: Start by communication | |
| | Pattern selection method * | COM: Selection by communication | |
| Mode 8 (Communication setting) | Communication function, type | COM: Host communication | |
| | Device No. | 01 to 99 | Invalid during RS-232C communication 00: Communication not possible |
| | Baud rate | 4800 / 9600 bps | |
| | Communication characters (Data length, parity, stop bit) | Data length: <u>Z</u> / 8 bits Parity: <u>Even</u> / Odd / None Stop bit: <u>1</u> / 2 bits | |

* To start program operation from the TS2060, select "MASTER COM." for program start method. To select a pattern number from the TS2060, select "COM" for pattern selection method.

DP1000G

The communication parameters can be set using keys attached to the digital program controller.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Mode No. | Item | Setting | | Remarks |
|--|---|---|--------------|---|
| | | COM1 | COM2 | |
| Mode 1 (Operation status selection) | Program start method * | COM: Start by communication | | |
| | Pattern selection method * | COM: Selection by communication | | |
| Mode 8 (Communication setting) | Communication type | Fixed according to communication specification | PORT2 | |
| | Protocol | PRIVATE: CHINO's conventional protocol | | When establishing a connection by using MODBUS RTU format, refer to "30. MODBUS". |
| | Communication function, type | COMM: Host communication | | |
| | Device No. | 01 to 99 | | Invalid during RS-232C communication 00: Communication not possible |
| | Baud rate | 4800 / 9600 / <u>19200</u> / 38400 bps | | |
| | Communication characters (Data length, parity, stop bit) | 7N1: data length 7 bits, without parity, stop bit 1 7N2: data length 7 bits, without parity, stop bit 2 7E1: data length 7 bits, even parity, stop bit 1 7E2: data length 7 bits, even parity, stop bit 2 7O1: data length 7 bits, odd parity, stop bit 1 7O2: data length 7 bits, odd parity, stop bit 2 <u>8N1: data length 8 bits, without parity, stop bit 1</u> 8N2: data length 8 bits, without parity, stop bit 2 8E1: data length 8 bits, even parity, stop bit 1 8E2: data length 8 bits, even parity, stop bit 2 8O1: data length 8 bits, odd parity, stop bit 1 8O2: data length 8 bits, odd parity, stop bit 2 | | |

* To start program operation from the TS2060, select "COM" for program start method. To select a pattern number from the TS2060, select "COM" for pattern selection method.

Notes on parameter change from the TS2060

Before changing parameters from the TS2060, function keys and the related mode in the setting menu must be locked using keys on the digital program controller.

For more information, refer to the instruction manual for the controller issued by the manufacturer.


Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|-------------|
| D (data) | 00H | Double-word |
| DN (individual data) | 01H | Double-word |
| PG (program) | 02H | Double-word |

Address denotations

The assigned device memory is expressed as shown below when editing the screen.



Note on device memory setting

Do not access addresses that are not assigned in the device memory map.

D (Data)

| Address Denotations | | | Name | Decimal Place | Command | |
|---------------------|-------------------|-------------------|--|---------------|----------|----------|
| Address (BIN) | Parameter 1 (BCD) | Parameter 2 (BCD) | | | Read | Write |
| 00 | 0 | 0 | Pattern No. | - | △ 1, △ 1 | - |
| 01 | 0 | 0 | Step No. | - | △ 1, △ 1 | - |
| 02 | 0 | 0 | PV status | - | △ 1, △ 1 | - |
| 03 | 0 | 0 | PV (measurement value) | 4 | △ 1, △ 1 | - |
| 04 | 0 | 0 | SV (setting value) | 4 | △ 1, △ 1 | - |
| 05 | 0 | 0 | Time display method | - | △ 1, △ 1 | △ 2, △ 8 |
| 06 | 0 | 0 | Time unit 1 | - | △ 1, △ 1 | - |
| 07 | 0 | 0 | Time | 2 | △ 1, △ 1 | - |
| 08 | 0 | 0 | MV1 status | - | △ 1, △ 1 | - |
| 09 | 0 | 0 | MV1 | 2 | △ 1, △ 1 | △ 2, △ 3 |
| 0a | 0 | 0 | MV2 status | - | △ 1, △ 1 | - |
| 0b | 0 | 0 | MV2 | 2 | △ 1, △ 1 | △ 2, △ 3 |
| 0e | 0 | 0 | Execution target SV | 4 | △ 1, △ 2 | - |
| 0f | 0 | 0 | Execution P | 1 | △ 1, △ 2 | △ 2, △ 2 |
| 10 | 0 | 0 | Execution I | - | △ 1, △ 2 | △ 2, △ 2 |
| 11 | 0 | 0 | Execution D | - | △ 1, △ 2 | △ 2, △ 2 |
| 12 | 0 | 0 | Execution AL1 | 4 | △ 1, △ 2 | △ 2, △ 2 |
| 13 | 0 | 0 | Execution AL2 | 4 | △ 1, △ 2 | △ 2, △ 2 |
| 14 | 0 | 0 | Execution AL3 | 4 | △ 1, △ 2 | △ 2, △ 2 |
| 15 | 0 | 0 | Execution AL4 | 4 | △ 1, △ 2 | △ 2, △ 2 |
| 16 | 0 | 0 | Execution OL | 1 | △ 1, △ 2 | △ 2, △ 2 |
| 17 | 0 | 0 | Execution OH | 1 | △ 1, △ 2 | △ 2, △ 2 |
| 18 | 0 | 0 | Execution change amount (OSL) | 1 | △ 1, △ 2 | △ 2, △ 2 |
| 19 | 0 | 0 | Execution sensor offset | 4 | △ 1, △ 2 | △ 2, △ 2 |
| 1a | 0 | 0 | SV value offset | 4 | △ 1, △ 2 | △ 2, △ 2 |
| 1b | 0 | 0 | 2nd P | 1 | △ 1, △ 2 | - |
| 1c | 0 | 0 | 2nd I | - | △ 1, △ 2 | - |
| 1d | 0 | 0 | 2nd D | - | △ 1, △ 2 | - |
| 20 | 0 | 0 | Controller / setting device | - | △ 1, △ 6 | - |
| 21 | 0 | 0 | Setting device / thermoelectric type / resistance type | - | △ 1, △ 6 | - |
| 22 | 0 | 0 | 1st output | - | △ 1, △ 6 | - |
| 23 | 0 | 0 | 2nd output | - | △ 1, △ 6 | - |
| 24 | 0 | 0 | Transmission | - | △ 1, △ 6 | - |
| 25 | 0 | 0 | Time signal | - | △ 1, △ 6 | - |
| 26 | 0 | 0 | External drive | - | △ 1, △ 6 | - |
| 27 | 0 | 0 | Pattern select | - | △ 1, △ 6 | - |
| 28 | 0 | 0 | Time unit 2 | - | △ 1, △ 6 | - |
| 2b | 0 | 0 | FNC key (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 2c | 0 | 0 | Mode 0 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 2d | 0 | 0 | Lock 1 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 2e | 0 | 0 | Lock 2 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 2f | 0 | 0 | Lock 3 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 30 | 0 | 0 | Lock 4 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 31 | 0 | 0 | Lock 5 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 32 | 0 | 0 | Lock 6 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 33 | 0 | 0 | Lock 7 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 34 | 0 | 0 | Lock 8 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 35 | 0 | 0 | Lock 9 (lock / non-lock) | - | △ 1, △ 7 | △ 2, △ 7 |
| 38 | 0 | 0 | AL1 (ON/OFF) | - | △ 1, △ 8 | - |
| 39 | 0 | 0 | AL2 (ON/OFF) | - | △ 1, △ 8 | - |
| 3a | 0 | 0 | AL3 (ON/OFF) | - | △ 1, △ 8 | - |
| 3b | 0 | 0 | AL4 (ON/OFF) | - | △ 1, △ 8 | - |
| 3c | 0 | 0 | Wait time alert | - | △ 1, △ 8 | - |
| 3d | 0 | 0 | Error | - | △ 1, △ 8 | - |

| Address Denotations | | | Name | Decimal Place | Command | |
|---------------------|-------------------|-------------------|---------------|---------------|----------|----------|
| Address (BIN) | Parameter 1 (BCD) | Parameter 2 (BCD) | | | Read | Write |
| 3e | 0 | 0 | TS1 (ON/OFF) | - | △ 1, △ 8 | - |
| 3f | 0 | 0 | TS2 (ON/OFF) | - | △ 1, △ 8 | - |
| 40 | 0 | 0 | TS3 (ON/OFF) | - | △ 1, △ 8 | - |
| 41 | 0 | 0 | TS4 (ON/OFF) | - | △ 1, △ 8 | - |
| 42 | 0 | 0 | TS5 (ON/OFF) | - | △ 1, △ 8 | - |
| 43 | 0 | 0 | TS6 (ON/OFF) | - | △ 1, △ 8 | - |
| 44 | 0 | 0 | TS7 (ON/OFF) | - | △ 1, △ 8 | - |
| 45 | 0 | 0 | TS8 (ON/OFF) | - | △ 1, △ 8 | - |
| 46 | 0 | 0 | TS9 (ON/OFF) | - | △ 1, △ 8 | - |
| 47 | 0 | 0 | TS10 (ON/OFF) | - | △ 1, △ 8 | - |
| 4a | Pattern No. | 0 | RUN | - | △ 1, △ 9 | △ 2, △ 1 |
| 4b | 0 | 0 | STOP | - | △ 1, △ 9 | △ 2, △ 1 |
| 4c | 0 | 0 | RESET | - | △ 1, △ 9 | △ 2, △ 1 |
| 4d | 0 | 0 | END | - | △ 1, △ 9 | - |
| 4e | 0 | 0 | ADV | - | △ 1, △ 9 | △ 2, △ 1 |
| 4f | 0 | 0 | CONST | - | △ 1, △ 9 | △ 2, △ 4 |
| 50 | 0 | 0 | MAN1 | - | △ 1, △ 9 | △ 2, △ 3 |
| 51 | 0 | 0 | MAN2 | - | △ 1, △ 9 | △ 2, △ 3 |
| 52 | 0 | 0 | WAIT | - | △ 1, △ 9 | - |
| 53 | 0 | 0 | AT | - | △ 1, △ 9 | △ 2, △ 6 |
| 54 | 0 | 0 | FNC key LOCK | - | △ 1, △ 9 | - |
| 55 | 0 | 0 | M/S | - | △ 1, △ 9 | - |
| 56 | 0 | 0 | FAST | - | △ 1, △ 9 | - |
| 57 | 0 | 0 | SV Up | - | △ 1, △ 9 | - |
| 58 | 0 | 0 | SV Down | - | △ 1, △ 9 | - |
| 5b | 0 | 0 | Constant SV | 4 | △ 1, △ 1 | △ 2, △ 4 |

DN (Individual Data)

| Address Denotations | | | Name | Decimal Place | Command | |
|---------------------|-------------------------------|-------------------|---------------------------------|---------------|----------|-------|
| Address (BIN) | Parameter 1 (BCD) | Parameter 2 (BCD) | | | Read | Write |
| 00 | Alarm No. (1 to 8) | 0 | AL1 | 4 | △ 1, △ 4 | △ 12 |
| 01 | Alarm No. (1 to 8) | 0 | AL2 | 4 | △ 1, △ 4 | △ 12 |
| 02 | Alarm No. (1 to 8) | 0 | AL3 | 4 | △ 1, △ 4 | △ 12 |
| 03 | Alarm No. (1 to 8) | 0 | AL4 | 4 | △ 1, △ 4 | △ 12 |
| 06 | PID No. (1 to 8, 91 to 98) | 0 | P | 1 | △ 1, △ 4 | △ 13 |
| 07 | PID No. (1 to 8, 91 to 98) | 0 | I | - | △ 1, △ 4 | △ 13 |
| 08 | PID No. (1 to 8, 91 to 98) | 0 | D | - | △ 1, △ 4 | △ 13 |
| 0b | Parameter No. (1 to 8) | 0 | Output change amount limit | 1 | △ 1, △ 4 | △ 14 |
| 0e | Parameter No. (1 to 8) | 0 | Output lower limit | 1 | △ 1, △ 4 | △ 15 |
| 0f | Parameter No. (1 to 8) | 0 | Output upper limit | 1 | △ 1, △ 4 | △ 15 |
| 12 | Parameter No. (1 to 8) | 0 | Sensor offset | 4 | △ 1, △ 4 | △ 16 |
| 15 | Parameter No. (1 to 8) | 0 | Actual temperature compensation | 4 | △ 1, △ 4 | △ 17 |
| 18 | Parameter No. (1 to 8) | 0 | Wait time alert | 2 | △ 1, △ 4 | △ 18 |
| 1b | Parameter No. (1 to 8) | 0 | Time signal ON time | 2 | △ 1, △ 4 | △ 19 |
| 1c | Parameter No. (1 to 8) | 0 | Time signal OFF time | 2 | △ 1, △ 4 | △ 19 |
| 1f | 1 | 0 | Digital filter | 1 | △ 1, △ 4 | △ 20 |

| Address Denotations | | | Name | Decimal Place | Command | |
|---------------------|---------------------------|-------------------|---|---------------|----------|-------|
| Address (BIN) | Parameter 1 (BCD) | Parameter 2 (BCD) | | | Read | Write |
| 22 | 1 | 0 | Transmission type | - | △ 1, △ 4 | △ 21 |
| 23 | 1 | 0 | Scale (min.) | 4 | △ 1, △ 4 | △ 21 |
| 24 | 1 | 0 | Scale (max.) | 4 | △ 1, △ 4 | △ 21 |
| 27 | 1 | 0 | 2nd output gap | 1 | △ 1, △ 4 | △ 22 |
| 2a | 1 | 0 | 2nd output P | 1 | △ 1, △ 4 | △ 23 |
| 2b | 1 | 0 | 2nd output I | - | △ 1, △ 4 | △ 23 |
| 2c | 1 | 0 | 2nd output D | - | △ 1, △ 4 | △ 23 |
| 2f | 1 | 0 | 2nd output change amount limit | 1 | △ 1, △ 4 | △ 24 |
| 32 | 1 | 0 | 2nd OL | 1 | △ 1, △ 4 | △ 25 |
| 33 | 1 | 0 | 2nd OH | 1 | △ 1, △ 4 | △ 25 |
| 36 | 1 | 0 | 2nd deadband | 1 | △ 1, △ 4 | △ 26 |
| 39 | 1 | 0 | 2nd PV output error | 1 | △ 1, △ 4 | △ 27 |
| 3c | 1 | 0 | 2nd output normal/reverse | - | △ 1, △ 4 | △ 28 |
| 3f | 1 | 0 | 2nd pulse cycle | - | △ 1, △ 4 | △ 29 |
| 42 | 1 | 0 | Measurement input unit (input type No.) | - | △ 1, △ 4 | △ 30 |
| 43 | 1 | 0 | Measurement input unit (unit) | - | △ 1, △ 4 | △ 30 |
| 46 | 1 | 0 | CJ INT/EXT | - | △ 1, △ 4 | △ 31 |
| 49 | 1 | 0 | SV decimal place | - | △ 1, △ 4 | △ 32 |
| 4c | 1 | 0 | PV decimal place | - | △ 1, △ 4 | △ 33 |
| 4f | 1 | 0 | Alarm filter | - | △ 1, △ 4 | △ 34 |
| 52 | Alarm No. (1 to 4) | 0 | Alarm mode | - | △ 1, △ 4 | △ 35 |
| 53 | 1 | 0 | Alarm deadband | 4 | △ 1, △ 4 | △ 35 |
| 56 | 1 | 0 | Deadband | 1 | △ 1, △ 4 | △ 36 |
| 59 | 1 | 0 | Pulse cycle | - | △ 1, △ 4 | △ 37 |
| 5c | 1 | 0 | Zero | 1 | △ 1, △ 4 | △ 38 |
| 5d | 1 | 0 | Span | 1 | △ 1, △ 4 | △ 38 |
| 5e | 1 | 0 | Deadband | 1 | △ 1, △ 4 | △ 38 |
| 61 | 1 | 0 | Output preset | 1 | △ 1, △ 4 | △ 39 |
| 64 | 1 | 0 | Output in PV error | 1 | △ 1, △ 4 | △ 40 |
| 67 | 1 | 0 | Output normal/reverse | - | △ 1, △ 4 | △ 41 |
| 6a | 1 | 0 | Linear range (zero) | 4 | △ 1, △ 4 | △ 42 |
| 6b | 1 | 0 | Linear range (span) | 4 | △ 1, △ 4 | △ 42 |
| 6e | 1 | 0 | Linear scale (min.) | 4 | △ 1, △ 4 | △ 43 |
| 6f | 1 | 0 | Linear scale (max.) | 4 | △ 1, △ 4 | △ 43 |
| 72 | 1 | 0 | ARW (lower limit) | 1 | △ 1, △ 4 | △ 44 |
| 73 | 1 | 0 | ARW (upper limit) | 1 | △ 1, △ 4 | △ 44 |
| 76 | Parameter No. (1 to 8) | 0 | AT2SV (ON/OFF) | - | △ 1, △ 4 | △ 45 |
| 77 | Parameter No. (1 to 8) | 0 | AT2SV | 4 | △ 1, △ 4 | △ 45 |
| 7a | Parameter No. (1 to 7) | 0 | Break SV | 4 | △ 1, △ 4 | △ 46 |
| 7d | Parameter No. (1 to 8) | 0 | AT3SV (ON/OFF) | - | △ 1, △ 4 | △ 47 |
| 7e | Parameter No. (1 to 8) | 0 | AT3SV | 4 | △ 1, △ 4 | △ 47 |
| 81 | 1 | 0 | AT start direction | - | △ 1, △ 4 | △ 48 |
| 84 | 1 | 0 | SV at reset | 4 | △ 1, △ 4 | △ 49 |
| 87 | 1 | 0 | SV display scale (min.) | 4 | △ 1, △ 4 | △ 50 |
| 88 | 1 | 0 | SV display scale (max.) | 4 | △ 1, △ 4 | △ 50 |
| 8b | 1 | 0 | Thermocouple type (thermocouple No.) | - | △ 1, △ 4 | △ 51 |
| 8c | 1 | 0 | Thermocouple type (unit) | - | △ 1, △ 4 | △ 51 |
| 8f | 1 | 0 | SV scale (min.) | 4 | △ 1, △ 4 | △ 52 |
| 90 | 1 | 0 | SV scale (max.) | 4 | △ 1, △ 4 | △ 52 |

PG (Program)

| Address Denotations | | | Name | Decimal Place | Command | |
|---------------------|-------------------|-------------------|-------------------------------------|---------------|----------|----------|
| Address (BIN) | Parameter 1 (BCD) | Parameter 2 (BCD) | | | Read | Write |
| 00 | Pattern No. | 0 | Start SV | 4 | △ 1, △ 3 | △ 3, △ 1 |
| 01 | Pattern No. | 0 | SV/PV start | - | △ 1, △ 3 | △ 3, △ 1 |
| 04 | Pattern No. | Step No. | Program setting SV | 4 | △ 1, △ 3 | △ 3, △ 2 |
| 05 | Pattern No. | Step No. | Program setting time | 2 | △ 1, △ 3 | △ 3, △ 2 |
| 06 | Pattern No. | Step No. | Step repeat times | - | △ 1, △ 3 | - |
| 07 | Pattern No. | Step No. | PID No. | - | △ 1, △ 3 | △ 3, △ 4 |
| 08 | Pattern No. | Step No. | ALM No. | - | △ 1, △ 3 | △ 3, △ 4 |
| 09 | Pattern No. | Step No. | OPL No. | - | △ 1, △ 3 | △ 3, △ 4 |
| 0a | Pattern No. | Step No. | OSL No. | - | △ 1, △ 3 | △ 3, △ 4 |
| 0b | Pattern No. | Step No. | Sensor offset No. | - | △ 1, △ 3 | △ 3, △ 4 |
| 0c | Pattern No. | Step No. | Actual temperature compensation No. | - | △ 1, △ 3 | △ 3, △ 4 |
| 0d | Pattern No. | Step No. | Wait time No. | - | △ 1, △ 3 | △ 3, △ 4 |
| 0e | Pattern No. | Step No. | TS1 | - | △ 1, △ 3 | △ 3, △ 4 |
| 0f | Pattern No. | Step No. | TS2 | - | △ 1, △ 3 | △ 3, △ 4 |
| 10 | Pattern No. | Step No. | TS3 | - | △ 1, △ 3 | △ 3, △ 4 |
| 11 | Pattern No. | Step No. | TS4 | - | △ 1, △ 3 | △ 3, △ 4 |
| 12 | Pattern No. | Step No. | TS5 | - | △ 1, △ 3 | △ 3, △ 4 |
| 13 | Pattern No. | Step No. | TS6 | - | △ 1, △ 3 | △ 3, △ 4 |
| 14 | Pattern No. | Step No. | TS7 | - | △ 1, △ 3 | △ 3, △ 4 |
| 15 | Pattern No. | Step No. | TS8 | - | △ 1, △ 3 | △ 3, △ 4 |
| 16 | Pattern No. | Step No. | TS9 | - | △ 1, △ 3 | △ 3, △ 4 |
| 17 | Pattern No. | Step No. | TS10 | - | △ 1, △ 3 | △ 3, △ 4 |
| 1a | Pattern No. | Step No. | Link target pattern No. | - | △ 1, △ 3 | △ 3, △ 3 |
| 1b | Pattern No. | Step No. | Output at 1st end | - | △ 1, △ 3 | △ 3, △ 3 |
| 1c | Pattern No. | Step No. | Output at 2nd end | - | △ 1, △ 3 | △ 3, △ 3 |
| 1f | 0 | 0 | Pattern repeat times | - | △ 1, △ 3 | △ 3, △ 6 |
| 22 | Pattern No. | 0 | Set number of steps | - | △ 1, △ 5 | - |
| 23 | Pattern No. | 0 | Remaining number of steps | - | △ 1, △ 5 | - |

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|----------------|---------------------|--------------|--|----|
| Alarm reset | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0000H | |
| Pattern select | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 0001H | |
| | | n + 2 | Pattern No. | |
| Step repeat | 1 - 8 (PLC1 - 8) | n | Station number | 6 |
| | | n + 1 | Command: 0002H | |
| | | n + 2 | Pattern No. | |
| | | n + 3 | Start step | |
| | | n + 4 | End step | |
| | | n + 5 | Repeat times Reset: 0000H Times: 0001H to 0099H | |
| Pattern copy | 1 - 8 (PLC1 - 8) | n | Station number | 4 |
| | | n + 1 | Command: 0003H | |
| | | n + 2 | Copy source pattern No. | |
| | | n + 3 | Copy target pattern No. | |
| Pattern clear | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 0004H | |
| | | n + 2 | Pattern No. Clear all patterns: 0000H Clear individual pattern: 0001H to 0030H | |

11.1.2 DB1000B (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 99 | |

Digital Indicating Controller

The communication parameters can be set using keys attached to the digital indicating controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Mode No. | Item | Setting | Remarks |
|-----------------------------------|---|--|---------|
| Mode 7 (Communication setting) | Baud rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| | Device No. | <u>01</u> to 99 | |
| | Communication function | <u>COM: Host communication</u> | |
| | Communication protocol | <u>MODBUS (RTU)</u> | |
| | Communication characters (Data length, parity, stop bit) | 8 bits / without parity / <u>1 bit</u> 8 bits / without parity / 2 bits 8 bits / even parity / 1 bit 8 bits / even parity / 2 bits 8 bits / odd parity / 1 bit 8 bits / odd parity / 2 bits | |

Notes on parameter change from the TS2060

Before changing parameters from the TS2060, all modes on the setting screen must be locked using keys on the digital indicating controller. For more information, refer to the instruction manual for the controller issued by the manufacturer.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------|------|-----------|
| 4 (analog setting value) | 00H | |
| 3 (analog input data) | 01H | Read only |
| 0 (digital setting value) | 02H | |
| 1 (digital input data) | 03H | Read only |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

11.1.3 LT230 (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 99 | |

Digital Indicating Controller

The communication parameters can be set using keys attached to the digital indicating controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Mode | Indication | Item | Setting |
|---------------------------------------|------------|---|---|
| Mode 1 eng (engineering) | LoCK | Key lock | 4: All items prohibited * |
| Mode 7 com (communication setting) | PtCL | Communication protocol | <u>rtU: MODBUS (RTU)</u> |
| | FUnC | Communication function | <u>Com: Host communication</u> |
| | AdrS | Device No. | <u>1</u> to 99 |
| | rAtE | Baud rate | <u>9600</u> / 19200 bps |
| | CHAr | Character (Data length, parity, stop bit) | <u>5: 8 bits / without parity / 1 bit</u> 6: 8 bits / without parity / 2 bits 7: 8 bits / even parity / 1 bit 8: 8 bits / even parity / 2 bits 9: 8 bits / odd parity / 1 bit 10: 8 bits / odd parity / 2 bits |

* When changing parameters from the TS2060, set "LoCK (key lock): 4".

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------|------|-----------|
| 4 (analog setting value) | 00H | |
| 3 (analog input data) | 01H | Read only |
| 0 (digital setting value) | 02H | |
| 1 (digital input data) | 03H | Read only |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

11.1.4 LT300 (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 99 | |

Digital Indicating Controller

The communication parameters can be set using keys attached to the digital indicating controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Mode | Indication | Item | Setting |
|---------------------------------------|------------|---|---|
| Mode 1 eng (engineering) | LoCK | Key lock | 4: All items prohibited * |
| Mode 7 com (communication setting) | PtCL | Communication protocol | <u>rtU: MODBUS (RTU)</u> |
| | FUnC | Communication function | <u>Com: Host communication</u> |
| | AdrS | Device No. | <u>01</u> to 99 |
| | rAtE | Baud rate | <u>9600</u> / 19200 bps |
| | CHAr | Character (Data length, parity, stop bit) | <u>5: 8 bits / without parity / 1 bit</u> 6: 8 bits / without parity / 2 bits 7: 8 bits / even parity / 1 bit 8: 8 bits / even parity / 2 bits 9: 8 bits / odd parity / 1 bit 10: 8 bits / odd parity / 2 bits |

* When changing parameters from the TS2060, set "LoCK (key lock): 4".

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------|------|-----------|
| 4 (analog setting value) | 00H | |
| 3 (analog input data) | 01H | Read only |
| 0 (digital setting value) | 02H | |
| 1 (digital input data) | 03H | Read only |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

11.1.5 LT400 Series (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 99 | |

Digital Indicating Controller

The communication parameters can be set using keys attached to the digital indicating controller.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Mode | Display | Item | Setting |
|--|---------|---|--|
| Mode 1 eng (engineering) | LoCK | Key lock | 4: All items prohibited * |
| Mode 7 commu (communication setting) | PrtCL | Communication protocol | <u>rtU: MODBUS (RTU)</u> |
| | FUnC | Communication function | <u>Com: Host communication</u> |
| | AdrS | Device No. | <u>01</u> to 99 |
| | rAtE | Baud rate | <u>9600</u> / 19200 bps |
| | CHArA | Character (Data length, parity, stop bit) | <u>8N1: 8 bits / without parity / 1 bit</u> 8N2: 8 bits / without parity / 2 bits 8E1: 8 bits / even parity / 1 bit 8E2: 8 bits / even parity / 2 bits 8O1: 8 bits / odd parity / 1 bit 8O2: 8 bits / odd parity / 2 bits |

* When changing parameters from the TS2060, set "LoCK (key lock): 4".

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------|------|-----------|
| 4 (analog setting value) | 00H | |
| 3 (analog input data) | 01H | Read only |
| 0 (digital setting value) | 02H | |
| 1 (digital input data) | 03H | Read only |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

11.1.6 LT830 (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 99 | |

Digital Indicating Controller

The communication parameters can be set using keys attached to the digital indicating controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Mode | Indication | Item | Setting | Remarks |
|--|------------|--|--|---------|
| Mode 5 tyPE (type) | LoCK | Lock function | 3: All items prohibited * | |
| Mode 6 com (communication setting) | PtCL | Communication protocol | <u>rtU: MODBUS (RTU)</u> | |
| | FUnC | Communication function | <u>Com: Host communication</u> | |
| | AdrS | Device No. | <u>1</u> to 99 | |
| | rAtE | Baud rate | <u>9600</u> / 19200 bps | |
| | CHAr | Character (Data length, parity, stop bit) | <u>8n1: 8 bits / without parity / 1 bit</u> 8n2: 8 bits / without parity / 2 bits 8E1: 8 bits / even parity / 1 bit 8E2: 8 bits / even parity / 2 bits 8o1: 8 bits / odd parity / 1 bit 8o2: 8 bits / odd parity / 2 bits | |

* When changing parameters from the TS2060, set "LoCK (lock function): 3".

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------|------|-----------|
| 4 (analog setting value) | 00H | |
| 3 (analog input data) | 01H | Read only |
| 0 (digital setting value) | 02H | |
| 1 (digital input data) | 03H | Read only |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

11.1.7 KR2000 (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

Graphic Recorder

Selector switch

When establishing a communication with a graphic recorder, set the selector switch at the top of the unit.

(Underlined setting: default)

| Selector switch | Setting | Remarks |
|--|---|---|
| <div style="display: flex; align-items: center; gap: 10px;"> 485 <div style="border: 1px solid black; width: 20px; height: 20px; position: relative;"> <div style="position: absolute; top: 0; left: 0; width: 100%; height: 100%; background-color: white;"></div> </div> 232C </div> | 232C: RS-232C connection <u>485: RS-485 connection</u> | Switch the signal with the power to the recorder OFF. |

Communication setting

The communication parameters can be set using MENU keys attached to the graphic recorder. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Setting Menu | Menu | Item | Setting | Remarks |
|----------------|--------------------|---|--|---------|
| System setting | Host communication | Communication mode | <u>RTU: MODBUS (RTU)</u> | |
| | | Device address | <u>01</u> to 31 | |
| | | Bit rate | <u>9600</u> / 19200 bps | |
| | | Communication characters (Data length, parity, stop bit) | <u>8N1: 8 bits / without parity / 1 bit</u> 8N2: 8 bits / without parity / 2 bits 8E1: 8 bits / even parity / 1 bit 8E2: 8 bits / even parity / 2 bits 8O1: 8 bits / odd parity / 1 bit 8O2: 8 bits / odd parity / 2 bits | |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------|------|-----------|
| 4 (analog setting value) | 00H | |
| 3 (analog input data) | 01H | Read only |
| 0 (digital setting value) | 02H | |
| 1 (digital input data) | 03H | Read only |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

11.1.8 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C


Wiring diagram 1 - C2



Wiring diagram 2 - C2




Wiring diagram 3 - C2




RS-422/RS-485


Wiring diagram 1 - C4




Wiring diagram 2 - C4




Wiring diagram 3 - C4



Wiring diagram 4 - C4




Wiring diagram 5 - C4




When Connected at MJ1/MJ2:

RS-232C


Wiring diagram 1 - M2



Wiring diagram 2 - M2








Wiring diagram 3 - M2



RS-422/RS-485


Wiring diagram 1 - M4



Wiring diagram 2 - M4**Wiring diagram 3 - M4****Wiring diagram 4 - M4****Wiring diagram 5 - M4**

MEMO

MONITOUCH



12. CIMON

12.1 PLC Connection

12.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | | Signal Level | Connection | | | Ladder Transfer *3 |
|--------------------------------|---|----------------------------|------------|--------------------------|---------------------------|---------------------------|---------------------------|-----------------------|
| | | | | | CN1 TS2060i+ DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| BP series | CM2-BPxxMDxx-R CM2-BPxxMDxx-T CM2-BPxxMDxx-S CM2-BPxxMDxx-U | LOADER port | | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | CM2-BPxxMDxx-R | Comm port | | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | |
| | CM2-BPxxMDxx-T | CH1 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | | |
| | | CH2 | RS-422/485 | Wiring diagram 3 - C4 | Wiring diagram 1 - M4 | Wiring diagram 7 - M4 | | |
| | CM2-BPxxMDxx-S | Comm port | | RS-422/485 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 5 - M4 | |
| | CM2-BPxxMDxx-U | CH1 | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 6 - M4 | | |
| | | CH2 | RS-422/485 | Wiring diagram 3 - C4 | Wiring diagram 1 - M4 | Wiring diagram 7 - M4 | | |
| CP series | CM1-CPxx | LOADER port | | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | CM1-CP4C | Comm port | | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 4 - M2 | | |
| | CM1-CP4D | Comm port | | RS-422/485 | Wiring diagram 4 - C4 | Wiring diagram 3 - M4 | Wiring diagram 8 - M4 | |
| | CM1-CPxx | CM1-SC01A | CH1 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | | CM1-SC01B | CH1 | RS-422 | Wiring diagram 5 - C4 | × | Wiring diagram 9 - M4 | |
| | | | CH2 | RS-422/485 | Wiring diagram 5 - C4 | Wiring diagram 4 - M4 | Wiring diagram 9 - M4 | |
| | | CM1-SC02A | CH1 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | | | CH2 | RS-422/485 | Wiring diagram 5 - C4 | Wiring diagram 4 - M4 | Wiring diagram 9 - M4 | |
| S series | CM3-SP32MDT CM3-SP32MDT-SD CM3-SP32MDTV CM3-SP32MDTV-SD CM3-SP32MDTE CM3-SP32MDTE-SD CM3-SP32MDTF CM3-SP32MDTF-SD CM3-SP16MDR CM3-SP16MDRV CM3-SP16MDRE CM3-SP16MDRF | Channel1 | | RS-232C | Wiring diagram 5 - C2 | Wiring diagram 5 - M2 | | |
| | | Channel2 | | RS-422/485 | Wiring diagram 6 - C4 | Wiring diagram 10 - M4 | | |
| | | CM3-SP02ERS CM3-SP02ERR | CH1 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | | | CH2 | RS-422/485 | Wiring diagram 7 - C4 | Wiring diagram 11 - M4 | Wiring diagram 12 - M4 | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*3 For the ladder transfer function, see the TS2060 Reference Manual 2.

Ethernet Connection (TS2060i Only)

| PLC Selection on the Editor | CPU | Unit | TCP/IP ^{*1} | UDP/IP | Port No. | Keep Alive ^{*2} | Ladder Transfer ^{*3} |
|-----------------------------|--|--------------------|----------------------|--------|-----------------------|--------------------------|-------------------------------|
| S series (Ethernet) | CM3-SP32MDTE CM3-SP32MDTE-SD CM3-SP32MDTF CM3-SP32MDTF-SD CM3-SP16MDRE CM3-SP16MDRF | LAN built into CPU | ○ | ○ | TCP/IP: 10260 (fixed) | ○ | × |
| | | CM3-SP01EET | ○ | ○ | UDP/IP: 10262 (fixed) | | |

*1 Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

*2 For KeepAlive functions, see "1.3.2 Ethernet Communication (TS2060i Only)".

*3 For the ladder transfer function, see the TS2060i Reference Manual 2.

12.1.1 BP Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1-1</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 9600 / 19200 / <u>38400</u> bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |

PLC


CM2-BPxxMDxx-R, T, S, U (LOADER Port)

No particular setting is necessary on the PLC.

The communication parameters are fixed; signal level: RS-232C, baud rate: 38400 bps, data length: 8 bits, stop bit: 1 bit, parity: none.

CM2-BPxxMDxx-T, U (CH1)


Make communication settings using the application software "CICON". For more information, refer to the instruction manual issued by CIMON.



| Item | Setting | Remarks |
|-----------|-------------------------------|---------|
| Protocol | CICON(Loader) Protocol | |
| Baud Rate | 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

CM2-BPxxMDxx-T, U (CH2)


Make communication settings using the application software "CICON". For more information, refer to the instruction manual issued by CIMON.



| Item | Setting | Remarks |
|-----------|-------------------------------|----------------------------------|
| Comm Type | RS422 / RS485 | RS-422: 4-wire RS-485: 2-wire |
| Protocol | CICON(Loader) Protocol | |
| Baud Rate | 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

CM2-BPxxMDxx-R, S

Make communication settings using the application software "CICON". For more information, refer to the instruction manual issued by CIMON.



| Item | Setting | Remarks |
|-----------|-------------------------------|--|
| Type | Null / RS-422, Modem / RS-485 | RS-232C connection: Null / RS-422 RS-422 (4-wire) connection: Null / RS-422 RS-485 (2-wire) connection: Modem / RS-485 |
| Baud Rate | 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|----------------------|------|-----------|
| D | (Data Memory) | 00H | |
| X | (External Input) | 01H | |
| Y | (External Output) | 02H | |
| M | (Internal Relay) | 03H | |
| L | (Internal Relay) | 04H | |
| K | (Latch Relay) | 05H | |
| F | (Flags) | 06H | Read only |
| T | (Timer Output) | 07H | |
| TS | (Timer SV) | 08H | |
| TC | (Timer PV) | 09H | |
| C | (Counter Output) | 0AH | |
| CS | (Counter SV) | 0BH | |
| CC | (Counter PV) | 0CH | |
| S | (Step Control Relay) | 0DH | *1 |

*1 The addresses are expressed in "bytes". For word designation, specify an even-numbered address.

12.1.2 CP Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 9600 / 19200 / <u>38400</u> bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |

PLC


LOADER Port

No particular setting is necessary on the PLC.

The communication parameters are fixed; signal level: RS-232C, baud rate: 38400 bps, data length: 8 bits, stop bit: 1 bit, parity: none.

CM1-CP4C/CM1-CP4D

Make communication settings using the application software "CICON". For more information, refer to the instruction manual issued by CIMON.



| Item | Setting | Remarks |
|-----------|-------------------------------|--|
| Type | Null / RS-422, Modem / RS-485 | RS-232C connection: Null / RS-422 RS-422 (4-wire) connection: Null / RS-422 RS-485 (2-wire) connection: Modem / RS-485 |
| Baud Rate | 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

CM1-SC01A, CM1-SC01B, CM1-SC02A (CH1)

Make communication settings using the application software "CICON". For more information, refer to the instruction manual issued by CIMON.

| Item | Setting | Remarks |
|-----------|-------------------------------|---------|
| Protocol | CICON(Loader) Protocol | |
| Baud Rate | 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

CM1-SC01B, CM1-SC02A (CH2)

Make communication settings using the application software "CICON". For more information, refer to the instruction manual issued by CIMON.

| Item | Setting | Remarks |
|-----------|-------------------------------|----------------------------------|
| Comm Type | RS422 / RS485 | RS-422: 4-wire RS-485: 2-wire |
| Protocol | CICON(Loader) Protocol | |
| Baud Rate | 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|----------------------|------|-----------|
| D | (Data Memory) | 00H | |
| X | (External Input) | 01H | |
| Y | (External Output) | 02H | |
| M | (Internal Relay) | 03H | |
| L | (Internal Relay) | 04H | |
| K | (Latch Relay) | 05H | |
| F | (Flags) | 06H | Read only |
| T | (Timer Output) | 07H | |
| TS | (Timer SV) | 08H | |
| TC | (Timer PV) | 09H | |
| C | (Counter Output) | 0AH | |
| CS | (Counter SV) | 0BH | |
| CC | (Counter PV) | 0CH | |
| S | (Step Control Relay) | 0DH | *1 |

*1 The addresses are expressed in "bytes". For word designation, specify an even-numbered address.

12.1.3 S Series

Communication Setting

Editor

Communication setting


(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1</u> : <u>1</u> / 1 : n / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>0</u> to 255 | |

PLC

CPU Port: Channel1 (RS-232C) / Channel2 (RS-422/485)

Make communication settings using the application software "CICON". For more information, refer to the instruction manual issued by CIMON.



| Item | Setting | Remarks |
|-------------|---------------------------------|---------|
| Station No. | 0 | |
| Baud Rate | 4800 / 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

CM3-SP02ERS/CM3-SP02ERR

Make communication settings using the application software "CICON". For more information, refer to the instruction manual issued by CIMON.

CH1

| Item | Setting | Remarks |
|-------------|---------------------------------|---------|
| Protocol | HMI Protocol | |
| Station No. | 0 | |
| Baud Rate | 4800 / 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

CH2

| Item | Setting | Remarks |
|-------------|---------------------------------|---------|
| Comm Type | RS-422, RS-485 | |
| Protocol | HMI Protocol | |
| Station No. | 0 | |
| Baud Rate | 4800 / 9600 / 19200 / 38400 bps | |
| Parity | Even / Odd / None | |
| Data Bit | 7 / 8 bits | |
| Stop Bit | 1 / 2 bits | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|------------------------|------|-----------|
| D (Data Memory) | 00H | |
| X (External Input) | 01H | |
| Y (External Output) | 02H | |
| M (Internal Relay) | 03H | |
| L (Internal Relay) | 04H | |
| K (Latch Relay) | 05H | |
| F (Flags) | 06H | Read only |
| T (Timer Output) | 07H | |
| TS (Timer PV) | 08H | |
| TC (Timer SV) | 09H | |
| C (Counter Output) | 0AH | |
| CS (Counter PV) | 0BH | |
| CC (Counter SV) | 0CH | |
| S (Step Control Relay) | 0DH | *1 |
| Z | 0EH | |

*1 The addresses are expressed in "bytes". For word designation, specify an even-numbered address.

Indirect Device Memory Designation

| | | | |
|-----|----------------|--------------------|---|
| | 15 | 8 7 | 0 |
| n+0 | Model | Device type | |
| n+1 | Address No. *1 | | |
| n+2 | Expansion code | Bit designation *2 | |
| n+3 | 00 | Station number | |

*1 For designation of byte device memory S:
Specify an address number divided by "2" as the address number.

*2 For bit designation of byte device memory S:

- An even address number
Specify a byte address number divided by "2" as the address number.
- An odd address number
Specify a byte address number minus "1", divided by "2", as the address number. Specify a bit number plus "8" for the bit designation.

Example: Indirect device memory designation of S11-07

$$n + 1 = (11 - 1) / 2 = 5 \text{ (DEC)}$$

$$n + 2 = 7 + 8 = 15 \text{ (DEC)}$$

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | F2 |
|-------------|-----------------------|--------------|---|
| Mode change | 1 to 8 (PLC1 to 8) | n | Station number |
| | | n+1 | Command: 0000H |
| | | n+2 | Mode 0: Run 1: Program 2: Pause/Remote |
| | | | 3 |

12.1.4 S Series (Ethernet)

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 10260 for TCP/IP or No. 10262 for UDP/IP) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

LAN port built into CPU

The screenshot shows the 'PLC Parameter' dialog box with the 'Ethernet' tab selected. The 'IP Setting' section contains three input fields: 'IP Address' (100.100.100.100), 'Subnet Mask Address' (255.255.255.0), and 'Gateway IP Address' (100.100.100.1). The 'Option' section has a 'Use DHCP' checkbox. The 'Cicon Relay Use' section has checkboxes for 'Ch1. (RS232C)' and 'Ch2. (RS485 Relay)'. The 'DDNS Setting' section includes fields for 'DDNS 1 Address', 'DDNS 1 Port', 'DDNS 2 Address', and 'DDNS 2 Port', each with a 'Use' checkbox. The 'Site Name' field is labeled '(Maximum 17.)' and the 'DDNS Retry' field is labeled '(0-255 Sec)'. At the bottom are 'Default', 'Help', 'OK', and 'Cancel' buttons.

| Item | Setting | Remarks |
|---------------------|---------------------------------------|---|
| IP Address | Set the IP address of the PLC. | For more information, refer to the manual of the PLC. |
| Subnet Mask Address | Set the subnet mask of the PLC. | |
| Gateway IP Address | Specify according to the environment. | |

* The port numbers are 10260 for TCP/IP and 10262 for UDP/IP (both fixed). For details, refer to the PLC manual issued by the manufacturer.

CM3-SP01EET

Setup Ethernet Module

Base: Local Slot: Slot 1 Help

Basic Setup DHCP Setup

Network Setup

IP Address : 192 168 0 196

Subnet Mask: 255 255 255 0

Gateway: 192 168 0 1

MODBUS Unit ID: 1

MAC Address

0004A3 - 167283

Modify

Comm. Check

Enable: 1000 msec

IP Address #0: 0 0 0 0

IP Address #1: 0 0 0 0

IP Address #2: 0 0 0 0

IP Address #3: 0 0 0 0

IP Address #4: 0 0 0 0

IP Address #5: 0 0 0 0

IP Address #6: 0 0 0 0

IP Address #7: 0 0 0 0

Write Read Status Close

| Item | Setting | Remarks |
|-------------|---------------------------------------|---|
| IP Address | Set the IP address of the PLC. | For more information, refer to the manual of the PLC. |
| Subnet Mask | Set the subnet mask of the PLC. | |
| Gateway | Specify according to the environment. | |

* The port numbers are 10260 for TCP/IP and 10262 for UDP/IP (both fixed). For details, refer to the PLC manual issued by the manufacturer.

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060i.

Available Device Memory

Settings are the same as those described in "12.1.3 S Series".

12.1.5 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C


Wiring diagram 1 - C2




Wiring diagram 2 - C2




Wiring diagram 3 - C2



Wiring diagram 4 - C2




Wiring diagram 5 - C2




RS-422/RS-485


Wiring diagram 1 - C4




Wiring diagram 2 - C4






Wiring diagram 3 - C4



Wiring diagram 4 - C4




Wiring diagram 5 - C4**Wiring diagram 6 - C4****Wiring diagram 7 - C4**


When Connected at MJ1/MJ2:

RS-232C


Wiring diagram 1 - M2




Wiring diagram 2 - M2




Wiring diagram 3 - M2



Wiring diagram 4 - M2




Wiring diagram 5 - M2




RS-422/RS-485


Wiring diagram 1 - M4




Wiring diagram 2 - M4







Wiring diagram 3 - M4




Wiring diagram 4 - M4




Wiring diagram 5 - M4**Wiring diagram 6 - M4****Wiring diagram 7 - M4****Wiring diagram 8 - M4**


Wiring diagram 9 - M4




Wiring diagram 10 - M4



Wiring diagram 11 - M4




Wiring diagram 12 - M4



MEMO

MONITOUCH



13. DELTA

13.1 PLC Connection

13.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*2} |
|-----------------------------|---|----------------------------|--------------|-----------------------|-----------------------|--------------|-------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| DVP series | DVP-EH2 DVP-ES DVP-EX DVP-SS DVP-SA DVP-SX DVP-SC DVP-SV DVP-PM | RS-232C communication port | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | RS-485 communication port | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | |
| DVP-SE (MODBUS ASCII) | DVP-SE | RS-485 communication port | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | × |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

Ethernet Connection (TS2060i Only)

| PLC Selection on the Editor | CPU | Unit | TCP/IP ^{*1} | UDP/IP ^{*1} | Port No. | Keep Alive ^{*2} | Ladder Transfer ^{*3} |
|-----------------------------|--------|------------------------|----------------------|----------------------|-------------|--------------------------|-------------------------------|
| DVP-SE (MODBUS TCP/IP) | DVP-SE | Built-in Ethernet port | ○ | × | 502 (fixed) | ○ | × |

^{*1} Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

^{*2} For KeepAlive functions, see "1.3.2 Ethernet Communication".

^{*3} For the ladder transfer function, see the TS2060 Reference Manual 2.

13.1.1 DVP Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1</u> :1 / 1 : n / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 / 38400 / 57600 / 115200 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

PLC

(Underlined setting: default)

| Item | Setting | Remarks |
|----------------|-------------|---|
| Baud rate | 9600 | For more information, refer to the PLC manual issued by the manufacturer. |
| Station number | <u>1</u> | |
| Data length | <u>7</u> | |
| Stop bit | <u>1</u> | |
| Parity | <u>Even</u> | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--------------------------|------|-------------|
| D (Data register) | 00H | |
| X (Input relay) | 01H | Read only |
| Y (Output relay) | 02H | |
| M (Auxiliary relay) | 03H | |
| S (Step relay) | 04H | |
| T (Timer) | 05H | |
| C (Counter) | 06H | |
| 32C (High-speed counter) | 07H | Double-word |

13.1.2 DVP-SE (MODBUS ASCII)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|--------------|
| Connection Mode | <u>1</u> : <u>1</u> / 1 : n / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>9600</u> / 19200 / 38400 / 57600 / 115200 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | 0: Broadcast |

PLC

| Item | Setting | Remarks |
|-----------------|---------------------------------------|---|
| Baud Rate | 9600 / 19200 / 38400 / 57600 / 115200 | For more information, refer to the PLC manual issued by the manufacturer. |
| Target Port No. | 1 to 31 | |
| Data Length | 7 / 8 | |
| Stop Bit | 1 / 2 | |
| Parity | None / Odd / Even | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--------------------------|------|-------------|
| D (Data register) | 00H | |
| X (Input relay) | 01H | Read only |
| Y (Output relay) | 02H | |
| M (Auxiliary relay) | 03H | |
| S (Step relay) | 04H | |
| T (Timer) | 05H | |
| C (Counter) | 06H | |
| 32C (High-speed counter) | 07H | Double-word |


13.1.3 DVP-SE (MODBUS TCP/IP)

Communication Setting


Editor

Make the following settings on the editor. For more information, see “1.3.2 Ethernet Communication”.

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 502) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].




Valid only for 1 : 1 connection
Select the PLC for connection from those registered on the PLC table.



Set the IP address, port number and whether or not to use the KeepAlive function for the PLC.

PLC

Make settings using the application software “DCISoft”. For more information, refer to the PLC manual issued by the manufacturer.



| Item | Setting | Remarks |
|------------------|---------------------------------------|---|
| IP Configuration | Static | For more information, refer to the PLC manual issued by the manufacturer. |
| IP Address | Set the IP address of the PLC. | |
| Netmask | Set the subnet mask of the PLC. | |
| Gateway | Specify according to the environment. | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060i.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|----------------------|------|-------------|
| D | (Data register) | 00H | |
| X | (Input relay) | 01H | Read only |
| Y | (Output relay) | 02H | |
| M | (Auxiliary relay) | 03H | |
| S | (Step relay) | 04H | |
| T | (Timer) | 05H | |
| C | (Counter) | 06H | |
| 32C | (High-speed counter) | 07H | Double-word |

13.1.4 Wiring Diagrams


When Connected at CN1:



- The CN1 port is available only when the TS2060i is attached the optional “DUR-00”.
- The “DUR-00” cannot be attached to the TS2060 (model name without “i”). Use the MJ1 and MJ2 ports for connection.


RS-232C

Wiring diagram 1 - C2



RS-422/RS-485


Wiring diagram 1 - C4



When Connected at MJ1/MJ2:


RS-232C

Wiring diagram 1 - M2




RS-422/RS-485

Wiring diagram 1 - M4



MEMO

MONITOUCH



14. DELTA TAU DATA SYSTEMS

14.1 Temperature Controller/Servo/Inverter Connection

14.1 Temperature Controller/Servo/Inverter Connection

Serial Connection

Motion Controller

| PLC Selection on the Editor | Model | Port | | Signal Level | Connection | | | Lst File |
|-----------------------------|-----------------|-----------------|----|--------------|-----------------------|-----------------------|--------------|----------|
| | | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| PMAC | PMAC PCI | Serial port | J4 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | PMAC.Lst |
| | Turbo PMAC PCI | Option-9T | J8 | | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | PMAC2 PCI | Serial port | J5 | | | | | |
| | Turbo PMAC2 PCI | Option-9T | J8 | | | | | |
| | UMAC Turbo CPU | Serial port | J7 | | | | | |
| | | Sub-serial port | J8 | | | | | |
| | 3U Turbo PMAC2 | Serial port | J7 | | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | Option-9T | J8 | | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Ethernet Connection (TS2060i Only)

Motion Controller

| PLC Selection on the Editor | Model | Unit | TCP/IP *1 | UDP/IP | Port No. | Lst File |
|-----------------------------|----------------|----------------------------|-----------|--------|------------------------|--------------|
| PMAC (Ethernet TCP/IP) | UMAC Turbo CPU | CPU with built-in Ethernet | ○ | × | 1025 (max. 4 units) | PMAC_Eth.Lst |

*1 Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

14.1.1 PMAC

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C | |
| Baud Rate | 4800 / 9600 / 19200 / <u>38400</u> / 57600 / 76800 / 115K bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | None | |
| Target Port No. | <u>0</u> to 31 | |

PMAC

Make PMAC settings by using the software "PEWIN32PRO2". For more information, refer to the PMAC instruction manual issued by the manufacturer.

Values after change are saved in FROM and determined when the power is turned off and back on again.

I-Variables by number

| Address | Contents | Setting |
|---------|----------------------------------|--|
| I0 | Serial card number | 0: 1:1 connection |
| I1 | Serial port mode | 0: CTS signal used |
| I3 | Handshake I/O control | 2 |
| I4 | Communication sum check mode | 0: Without sum check |
| I6 | Error notification mode | 1 |
| I43 | Protocol selection ^{*1} | 0: Standard protocol |
| I53 | Sub port ^{*2} | Baud rate 6: 4800, 8: 9600, 10: 19200, 12: 38400, 13: 57600, 14: 78600, 15: 115K ^{*3} bps |
| I54 | Main port | Baud rate 6: 4800, 8: 9600, 10: 19200, 12: 38400, 13: 57600, 14: 78600, 15: 115K ^{*3} bps |
| I63 | Echo back selection | 1: Valid |



*1 Set when Turbo PMAC PCI, Turbo PMAC2 CPCI, UMAC Turbo CPU or 3U Turbo PMAC2 is used.

*2 Valid when "Option-9T" is used with Turbo PMAC PCI, Turbo PMAC2 CPCI / 3U Turbo PMAC2 or the sub port of UMAC Turbo CPU is used.


*3 When "115K bps" is set, set the multiples of 30 MHz for "I52" (CPU frequency).

PMAC PCI



MAIN BOARD E-POINT

| E-POINT | Contents | Setting |
|---|--|---|
|  | E49 Parity control for serial communication | No parity: Install a jumper between pins 1 and 2. |
|  | E110 Serial port setting | RS-232C: Install a jumper between pins 1 and 2. |


PMAC2 PCI**BASE BOARD E-POINT**

| E-POINT | | Contents | Setting |
|---|------------|----------------------------|---|
|  | E17 E18 | Serial port type selection | RS-232C: Install a jumper between pins 1 and 2. |


Turbo PMAC PCI**MAIN BOARD E-POINT**

| E-POINT | | Contents | Setting |
|---|------|---|---|
|  | E49 | Parity control for serial communication | No parity: Install a jumper between pins 1 and 2. |
|  | E110 | Serial port setting | RS-232C: Install a jumper between pins 1 and 2. |


Turbo PMAC2 PCI**BASE BOARD E-POINT**

| E-POINT | | Contents | Setting |
|---|------------|----------------------------|---|
|  | E17 E18 | Serial port type selection | RS-232C: Install a jumper between pins 1 and 2. |

UMAC Turbo CPU**TURBO CPU BOARD E-POINT**

| E-POINT | | Contents | Setting |
|---|------|----------------------|---|
|  | E17A | PHASE+ valid/invalid | Invalid: Install a jumper between pins 1 and 2. |
| | E17B | PHASE- valid/invalid | Invalid: Install a jumper between pins 1 and 2. |
| | E18A | SERVO+ valid/invalid | Invalid: Install a jumper between pins 1 and 2. |
| | E18B | SERVO- valid/invalid | Invalid: Install a jumper between pins 1 and 2. |

3U Turbo MPMAC2**TURBO CPU BOARD E-POINT**

| E-POINT | | Contents | Setting |
|---|------------|-----------------------|---|
|  | E17 E18 | Serial port selection | RS-232C: Install a jumper between pins 1 and 2. |

Available Device Memory


The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|------------------------|------|-------------|
| P | (variable P) | 00H | Real number |
| Q | (variable Q) | 01H | Real number |
| M | (variable M) | 02H | Real number |
| I | (variable I) | 03H | Real number |
| M_INT | (variable M (integer)) | 04H | Double-word |
| I_INT | (variable I (integer)) | 05H | Double-word |
| P_INT | (variable P (integer)) | 06H | Double-word |

Indirect Device Memory Designation

| | | | | |
|-------|------------------|---|---|-----------------|
| | 15 | 8 | 7 | 0 |
| n + 0 | Model | | | Device type |
| n + 1 | Address No. | | | |
| n + 2 | Expansion code * | | | Bit designation |
| n + 3 | 00 | | | Station number |

* In the expansion code, set which word, higher or lower, is to be read when a double-word address is specified (expansion bit designation).



PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---------------|---------------------|--------------|---|----|
| Write of data | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 0000H | |
| | | n + 2 | Timeout time: 1 to 300 sec. (0: Time set on the editor*) | |
| Control-X | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0001H | |

* Depends on the time set for [Time-out Time] under [Communication Setting] in the [PLC Properties] window ([System Setting] → [Hardware Setting]).

14.1.2 PMAC (Ethernet TCP/IP)

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]

PLC1 Properties DELTA TAU DATA SYSTEMS PMAC(Ethernet TCP/IP)

| | |
|----------------------------------|--------------------|
| Communication Setting | |
| Connection Mode | 1:1 |
| Retrials | 3 |
| Time-out Time(*10msec) | 50 |
| Send Delay Time(*msec) | 0 |
| Start Time(*sec) | 1 |
| Port No. | 10001 |
| Code | DEC |
| Text Process | LSB→MSB |
| Comm. Error Handling | Stop |
| Detail | |
| Priority | 1 |
| System memory(\$s) V7 Compatible | None |
| Target Settings | |
| Connect To | 1:192.168.1.1(PLC) |
| PLC Table | Setting... |
| Use Connection Check Device | None |

- IP address and port number of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

| | |
|----------------------------------|--------------------|
| System memory(\$s) V7 Compatible | None |
| Target Settings | |
| Connect To | 1:192.168.1.1(PLC) |
| PLC Table | Setting... |
| Use Connection Check Device | None |

Valid only for 1 : 1 connection
Select the PLC for connection from those registered on the PLC table.

PLC Table

| No. | Port Name | IP Address | Port No. |
|-----|-----------|-------------|----------|
| 0 | | | |
| 1 | PLC | 192.168.1.1 | 1025 |
| 2 | | | |
| 3 | | | |
| 4 | | | |
| 5 | | | |
| 6 | | | |
| 7 | | | |
| 8 | | | |
| 9 | | | |
| 10 | | | |
| 11 | | | |
| 12 | | | |
| 13 | | | |
| 14 | | | |

Close


Set the IP address, port number 1025 and whether or not to use the KeepAlive function of the PLC.

UMAC

Make UMAC settings by using the software "PEWIN32PRO2 *". For more information, refer to the UMAC manual issued by the manufacturer.

* For Ethernet communication, PEWIN32PRO service pack 2.0 and later is necessary.


Ethernet configuration




| Item | Setting | Remarks |
|------------|---------------------|---|
| Protocol | TCP | For more information, refer to the UMAC instruction manual. |
| Port No. | 1025 (fixed) | |
| IP Address | IP address of UMAC | |

Procedure for changing the IP address


1. Change the IP address on the [Ethernet Configuration] dialog.
2. Click [Store IP] on the [Ethernet Configuration] dialog.




3. The [Ethernet Configure] dialog is displayed. Click [Yes].




4. The [Dialog] dialog is displayed. Set "0" for [Card Instance] and click [OK].



5. The [ETHUSBConfigure] dialog is displayed.
Click [OK].



6. The [Ethernet Configuration] dialog is displayed again.
Click [Done] in the dialog.



7. Turn the power off and back on again.

- * UMAC settings must be made via USB communication.
Before performing Ethernet communication with MONITOUCH, turn the power to UMAC off and remove the USB cable. Then, insert the Ethernet cable and turn the power on again.


I-Variables by number

| Address | Contents | Setting |
|---------|--------------------------------|----------|
| I3 | Handshake I/O control | 2 |
| I6 | Error notification mode | 1 |
| I63 | <Control-X> Echo valid/invalid | 1: Valid |

- * Values after change are saved in FROM and determined when the power is turned off and back on again.

UMAC Turbo CPU

TURBO CPU BOARD E-POINT

| E-POINT | Contents | Setting |
|---|---|--|
|  | E6 Reloading the micro controller firmware | Normal operation: Install a jumper between pins 1 and 2. |

Available Device Memory


The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|------------------------|------|-------------|
| P | (variable P) | 00H | Real number |
| Q | (variable Q) | 01H | Real number |
| M | (variable M) | 02H | Real number |
| I | (variable I) | 03H | Real number |
| M_INT | (variable M (integer)) | 04H | Double-word |
| I_INT | (variable I (integer)) | 05H | Double-word |
| P_INT | (variable P (integer)) | 06H | Double-word |

Indirect Device Memory Designation

| | | | | |
|-------|------------------|---|-----------------|---|
| | 15 | 8 | 7 | 0 |
| n + 0 | Model | | Device type | |
| n + 1 | Address No. | | | |
| n + 2 | Expansion code * | | Bit designation | |
| n + 3 | 00 | | Station number | |

* In the expansion code, set which word, higher or lower, is to be read when a double-word address is specified (expansion bit designation).



PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---------------|---------------------|--------------|---|----|
| Write of data | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 0000H | |
| | | n + 2 | Timeout time: 1 to 300 sec. (0: Time set on the editor*) | |
| Control-X | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0001H | |

* Depends on the time set for [Time-out Time] under [Communication Setting] in the [PLC Properties] window ([System Setting] → [Hardware Setting]).

14.1.3 Wiring Diagrams


When Connected at CN1:




- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C

Wiring diagram 1 - C2




Wiring diagram 2 - C2




When Connected at MJ1/MJ2:

RS-232C

Wiring diagram 1 - M2



Wiring diagram 2 - M2



15. EATON Cutler-Hammer

15.1 PLC Connection

15.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*2} |
|--------------------------------|--|---|-----------------|-----------------------|-----------------------|--------------|----------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| ELC | ELC-PA10 ELC-PC12 ELC-PH12 ELC-PB14 | Programming port on the CPU unit (COM1) | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | Communication port on the CPU unit (COM2) | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

15.1.1 ELC

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1</u> :1 / 1 : n / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 / 57600 / 115200 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

PLC

Make the PLC setting using device memory "D" (data register). For more information, refer to the PLC manual issued by the manufacturer.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--------------------------|------|-------------|
| D (data register) | 00H | |
| X (input) | 01H | Read only |
| Y (output) | 02H | |
| M (auxiliary relay) | 03H | |
| S (step point) | 04H | |
| T (timer) | 05H | |
| C (counter) | 06H | |
| 32C (high-speed counter) | 07H | Double-word |

15.1.2 Wiring Diagrams

When Connected at CN1:




CAUTION

- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.


RS-232C

Wiring diagram 1 - C2



RS-422


Wiring diagram 1 - C4



When Connected at MJ1/MJ2:


RS-232C

Wiring diagram 1 - M2



RS-422

Wiring diagram 1 - M4



16. EMERSON

16.1 PLC Connection

16.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*2} |
|---------------------------------|------|---------------------|--------------|-----------------------|-----------------------|--------------|-------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| EC10/EC20/EC20H (MODBUS RTU) | EC10 | Port1 ^{*3} | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | |
| | EC20 | COM2 ^{*3} | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

^{*3} The concurrent use of RS-232C and RS-485 terminals is not allowed for connection.

16.1.1 EC10/EC20/EC20H (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / 1 : n / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | Odd / <u>Even</u> / None | |
| Target Port No. | <u>1</u> to 247 | |

PLC

Be sure to match the settings to those made under [Communication Setting] of the editor.

Calendar

This model is equipped with a calendar function; however, the calendar data cannot be written from the TS2060. Thus, time correction must be performed on the controller side.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--------------------------------|------|-------------|
| D (Data register) | 00H | |
| SD (Special data register) | 01H | |
| Y (Output I/O) | 02H | |
| X (Input I/O) | 03H | |
| M (Auxiliary relay) | 04H | |
| SM (Special auxiliary relay) | 05H | |
| S (State relay) | 06H | |
| T (Timer) | 07H | |
| C (Counter) | 08H | |
| Z (Offset addressing register) | 09H | |
| TW (Timer) | 0AH | |
| CW (Counter) | 0BH | |
| CDW (Counter) | 0CH | Double-word |
| R (R) | 0DH | |

Indirect Device Memory Designation

| | | | |
|-----|------------------|-----------------|---|
| | 15 | 8 7 | 0 |
| n+0 | Model | Device type | |
| n+1 | Address No. | | |
| n+2 | Expansion code * | Bit designation | |
| n+3 | 00 | Station number | |

- * For bit designation, an expansion code setting is required.
 00H: when designating bit 0 to 15
 01H: when designating bit 16 to 31

16.1.2 Wiring Diagrams

When Connected at CN1:




CAUTION

- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.


RS-232C

Wiring diagram 1 - C2



RS-422/RS-485


Wiring diagram 1 - C4



When Connected at MJ1/MJ2:


RS-232C

Wiring diagram 1 - M2



RS-422/RS-485

Wiring diagram 1 - M4



17. FANUC

17.1 PLC Connection

17.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Port | Signal Level | Connection | | | Ladder Transfer ^{*3} | | |
|--------------------------------|--|-------|-----------------------|-----------------------|-----------------------|----------------------------|----------------------------------|-----------------------|--|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | | | |
| Power Mate | Power Mate Model H/D | JD14 | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | × | | |
| | Power Mate i Model H/D | JD40 | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | | | |
| | | JD42 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | | | |
| | 16-Model C | JD5B | RS-232C | | | | | | |
| | 16i-Model A 16i-Model B 18i-Model A 18i-Model B 18-Model C 21i-Model A 21i-Model B | JD36B | RS-232C | | | Wiring diagram 2 - C2 | | Wiring diagram 2 - M2 | |
| | | | | | | | | | |
| | | | | | | | | | |
| | 30i-Model A 31i-Model A 32i-Model A | JD36A | | | | | | | |
| | JD54 | | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | | | | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*3} For the ladder transfer function, see the TS2060 Reference Manual 2.

17.1.1 Power Mate

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|-----------------------------|---------|
| Connection Mode | <u>1-1</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 19200 bps (fixed) | |
| Data Length | 8 bits (fixed) | |
| Stop Bit | 1 bit (fixed) | |
| Parity | Even (fixed) | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|-----------------------|------|---|
| D (data table) | 00H | |
| X (input relay) | 01H | WX as word device |
| Y (output relay) | 02H | WY as word device |
| R (internal relay) | 03H | WR as word device |
| K (keep relay) | 04H | WK as word device |
| T (timer) | 05H | |
| C (counter) | 06H | |
| E (extensional relay) | 07H | WE as word device, available only with 30i/31i/32i-ModelA |

17.1.2 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C


Wiring diagram 1 - C2



Wiring diagram 2 - C2




Wiring diagram 3 - C2




RS-422

Wiring diagram 1 - C4




Wiring diagram 2 - C4




When Connected at MJ1/MJ2:

RS-232C


Wiring diagram 1 - M2



Wiring diagram 2 - M2




Wiring diagram 3 - M2




RS-422/485

Wiring diagram 1 - M4



Wiring diagram 2 - M4



18. Fatek Automation

18.1 PLC Connection

18.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | | Signal Level | Connection | | | Ladder Transfer ^{*2} |
|-----------------------------|----------------------------------|---------------------------------|---------------------------|--------------|-----------------------|-----------------------|--------------|-------------------------------|
| | | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| FACON FB series | FBE-20MC FBE-28MC FBE-40MC | CPU unit Programming port | Port1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | | Port2 | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | |
| | | FB-DTBR | Port1 (D-sub 15) | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | Port1 (D-sub 9) | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | | | Port2 (terminal block) | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | | |
| | | | | | | | | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

18.1.1 FACON FB Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|-----------------------------------|---------|
| Connection Mode | <u>1</u> :1 / 1 : n / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | <u>9600</u> / 19200 / 38400 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

PLC

Make the PLC setting using the configuration tool "PRO_LADDER". For more information, refer to the PLC manual issued by the manufacturer.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|------------------------------------|------|-------------------|
| HR (data register) | 00H | |
| DR (data register) | 01H | |
| X (input relay) | 02H | WX as word device |
| Y (output relay) | 03H | WY as word device |
| M (internal relay) | 04H | WM as word device |
| S (step relay) | 05H | WS as word device |
| T (timer/contact) | 06H | WT as word device |
| C (counter/contact) | 07H | WC as word device |
| RT (timer/current value) | 08H | |
| RC (counter/current value) | 09H | |
| DRC (32-bit counter/current value) | 0AH | *1 |

- *1 For items where double-words can be used (Num. Display, Graph, Sampling), data is processed as double-words.
 For those where bits or words can be used, data is processed as words consisting of lower 16 bits.
 For input: Upper 16 bits are ignored.
 For output: "0" is written for upper 16 bits.

18.1.2 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C

Wiring diagram 1 - C2




Wiring diagram 2 - C2




RS-422

Wiring diagram 1 - C4




Wiring diagram 2 - C4




When Connected at MJ1/MJ2:

RS-232C

Wiring diagram 1 - M2




Wiring diagram 2 - M2




RS-422

Wiring diagram 1 - M4




Wiring diagram 2 - M4



MEMO

MONITOUCH



19. FESTO

19.1 PLC Connection

19.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | | Port | Signal Level | Wiring Diagram | | | Ladder Transfer ^{*2} |
|--------------------------------|-------------|--|------|--------------|-----------------------|-----------------------|--------------|----------------------------------|
| | | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| FEC | FEC Compact | FC20-FST FC21-FST FC22-FST FC23-FST FC30-FST FC34-FST | EXT | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

19.1.1 FEC

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1 : 1</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Parity | None | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |

PLC

No particular setting is necessary on the PLC.

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used.

Use [TYPE] when assigning indirect device memory for macro programs.


| Device Memory | TYPE | Remarks |
|------------------------------|------|---------|
| FW (flag word) | 00H | |
| IW (input) | 01H | |
| OW (output) | 02H | |
| R (register) | 03H | |
| T (pulse timer) | 04H | |
| TP (timer [preset value]) | 05H | |
| TW (timer [current value]) | 06H | |
| C (counter) | 07H | |
| CP (counter [preset value]) | 08H | |
| CW (counter [current value]) | 09H | |

19.1.2 Wiring Diagrams

When Connected at CN1:

RS-232C


Wiring diagram 1 - C2



When Connected at MJ1/MJ2:


RS-232C

Wiring diagram 1 - M2



MEMO

MONITOUCH



20. FUFENG

20.1 PLC Connection

20.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*2} |
|--------------------------------|--------|-----------|--------------|-----------------------|-----------------------|--------------|----------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| APC Series Controller | APB-50 | COM1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | | RS-422/485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | |
| | | COM2 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

20.1.1 APC Series Controller

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1:1</u> / 1 : n / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / 19200 / 38400 / <u>115K</u> bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1 bit</u> | |
| Parity | <u>None</u> | |
| Target Port No. | <u>0</u> to 98 | |

PLC

COM1

Communication setting

Make PLC settings using the application software "APC Pro". For more information, refer to the PLC manual issued by the manufacturer.

| Item | Setting | Remarks |
|------------|---------------------|--------------------------------------|
| APC system | APC number setup | 0 to 98 |
| | APC baud rate setup | 115200 / 38400 / 19200 / 9600 / 4800 |

Parity: none, data length: 8 bits, stop bit: 1 bit (fixed)

Signal level selection

| Item | Setting | Remarks |
|--------|---------|--|
| Jumper | RS-232C | J1-1: Jumper across pins 2 and 3 J1-2: Jumper across pins 2 and 3 J1-3: Jumper across pins 2 and 3 |
| | RS-485 | J1-1: Jumper across pins 1 and 2 J1-2: Jumper across pins 1 and 2 J1-3: Jumper across pins 1 and 2 |

COM2

Station number: 0, parity: none, data length: 8 bits, stop bit: 1 bit, baud rate: 115200 bps (fixed)

Calendar

This model is not equipped with the calendar function. Use the calendar function of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--|------|------------------------------------|
| D (Data area) | 00H | |
| T (Timer relay area) | 01H | Read only |
| C (Counter relay area) | 02H | Read only |
| R (Accessory relay area) | 03H | Common to D0 to D15 ^{*1} |
| X (Input channel) | 04H | Common to D16 to D30 ^{*1} |
| Y (Output channel) | 05H | Common to D31 to D40 ^{*1} |
| S (System relay area) | 06H | Common to D41 to D55 ^{*1} |
| K (Thermal control relay area) | 07H | Common to D56 to D63 ^{*1} |
| TSW (Timer setting area) | 08H | Common to D208 to D335 |
| TP (Present timer setting area) | 09H | Read only, common to D336 to D463 |
| CSW (Counter setting area) | 0AH | Common to D464 to D591 |
| CP (Present counter setting area) | 0BH | Read only, common to D592 to D719 |
| KJS (Thermal control temperature setting) | 0CH | Common to D80 to D95 |
| KP (Present thermal control temperature setting) | 0DH | Read only, common to D96 to D111 |
| KJL (Thermal control low-temperature alarm setting) | 0EH | Common to D112 to D127 |
| KJH (Thermal control high-temperature alarm setting) | 0FH | Common to D128 to D143 |
| KI (Present thermal control current setting) | 10H | Read only, common to D144 to D159 |
| KJC (Insufficient thermal control) | 11H | Common to D160 to D175 |
| KJR (Thermal control cycle setting) | 12H | Common to D192 to D207 |

^{*1} When using consecutive bit devices, select device memory "D" for improved performance.

20.1.2 Wiring Diagrams


When Connected at CN1:




- The CN1 port is available only when the TS2060i is attached the optional “DUR-00”.
- The “DUR-00” cannot be attached to the TS2060 (model name without “i”). Use the MJ1 and MJ2 ports for connection.

RS-232C

Wiring diagram 1 - C2




Wiring diagram 2 - C2



RS-422/RS-485


Wiring diagram 1 - C4




When Connected at MJ1/MJ2:

RS-232C

Wiring diagram 1 - M2




Wiring diagram 2 - M2



RS-422/RS-485

Wiring diagram 1 - M4



MEMO

MONITOUCH



21. Fuji Electric

21.1 PLC Connection

21.2 Temperature Controller/Servo/Inverter Connection

21.1 PLC Connection

Serial Connection

MICREX-F Series

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*3} |
|-----------------------------|--|-----------|--------------|-----------------------|-----------------------|----------------------------|-------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | |
| MICREX-F series | NV1P-x (F55) | NV1L-RS2 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | NC1P-E (F70) | NC1L-RS2 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | NC1P-S (F70S) | NC1L-RS4 | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | Wiring diagram 2 - M4 | |
| | FPU080H (F80H) FPU120H (F120H) FPU120S (F120S) FPU140S (F140S) FPU15xS (F15xS) | FFU120B | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | FFK120A | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | Wiring diagram 2 - M4 | |
| | | | | | | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*3 For the ladder transfer function, see the TS2060 Reference Manual 2.

SPB (N Mode), FLEX-PC

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*3} |
|-------------------------------|--|--------------|-----------------|--|-----------------------|---|-------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | |
| SPB (N mode) & FLEX-PC series | NS-CPU-xx | NS-RS1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | | RS-485 | Wiring diagram 1 - C4 | × | Wiring diagram 2 - M4 | |
| | NJ-CPU-xx | NJ-RS2 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | NJ-RS4 | RS-485 | Wiring diagram 1 - C4 | × | Wiring diagram 2 - M4 | |
| | NBxx | NB-RS1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | RS-485 | Wiring diagram 1 - C4 | × | Wiring diagram 2 - M4 | |
| | NW0Pxx (SPB) | NW0LA-RS2 | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | |
| | | NW0LA-RS4 | RS-485 (4-wire) | Wiring diagram 1 - C4 | × | Wiring diagram 2 - M4 | |
| | | | RS-485 (2-wire) | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | | |
| | | | | | | | |
| SPB (N Mode) & FLEX-PC CPU | NS-CPU-xx NJ-CPU-xx NBxx NW0Pxx (SPB) | CPU port | RS-485 | Hakko Electronics' cable "D9-FU-SPBCPU" ^{*4} | × | Hakko Electronics' cable "MJ2-FU-SPBCPU" ^{*4} | ○ |
| | NJ-CPU-B16 | RS-232C port | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*3 For the ladder transfer function, see the TS2060 Reference Manual 2.

*4 Cable length: XXX-FU-SPBCPU-□M (□ = 2, 3, 5 m)

MICREX-SX, SPB (IEC Mode)

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*3} |
|---|------------------------|----------------------|--------------|--|--|---|-------------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | |
| MICREX-SX SPH/SPB/ SPM/SPE/ SPF series | NP1Px-xx (SPH) | NP1L-RS1 | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 4 - M2 | | × |
| | | | RS-485 | Wiring diagram 3 - C4 | × | Wiring diagram 3 - M4 | |
| | | NP1L-RS2 NP1L-RS3 | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 4 - M2 | | |
| | | | RS-485 | Wiring diagram 3 - C4 | × | Wiring diagram 3 - M4 | |
| | | NP1L-RS5 | RS-485 | Wiring diagram 1 - C4 | × | Wiring diagram 2 - M4 | |
| | NW0Pxx (SPB) | NW0LA-RS2 | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | |
| | | NW0LA-RS4 | RS-485 | Wiring diagram 1 - C4 | × | Wiring diagram 2 - M4 | |
| | NA0PAxxx- xxx (SPF) | NA3LA-RS1 | RS-232C | Wiring diagram 5 - C2 | Wiring diagram 5 - M2 | | |
| | | | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | |
| | | NA0LA-RS3 | RS-232C | Wiring diagram 5 - C2 | Wiring diagram 5 - M2 | | |
| | | NA0LA-RS5 | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | |
| MICREX-SX SPH/SPB/ SPM/SPE/ SPF CPU | NP1Px-xx (SPH) | CPU port | RS-485 | Hakko Electronics' cable ^{*4} ^{*5} | × | Hakko Electronics' cable ^{*4} ^{*5} | ○ |
| | NW0Pxx (SPB) | CPU port | RS-485 | Hakko Electronics' cable "D9-FU-SPBCPU" ^{*5} | × | Hakko Electronics' cable "MJ2-FU-SPBCPU" ^{*5} | |
| | NA0PAxxx- xxx (SPF) | CPU port | RS-232C | Hakko Electronics' cable "D9-FU-SPFCPU" ^{*5} | Hakko Electronics' cable "MJ-FU-SPFCPU" ^{*5} | | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*3} For the ladder transfer function, see the TS2060 Reference Manual 2.

^{*4} The cable for connection varies depending on the model and hardware version of the CPU.

| CPU Model: Hardware Version | | Connector Shape | CN1 | MJ2 (4-wire) |
|--|--|-------------------------|--|---|
| NP1PH-08/16: NP1PS-32: NP1PS-32R/74R/117R: NP1PS-245R: NP1PM-48R/48E/256E/256H: NP1PU-048E/128E/256E: | Before V22 Before V26 Before V26 Before V23 Before V25 Before V22 | Small-type connector | Hakko Electronics' cable "D9-FU-SPHCPU" ^{*5} | Hakko Electronics' cable "MJ2-FU-SPHCPU" ^{*5} |
| NP1PH-08/16: NP1PS-32: NP1PS-32R/74R/117R: NP1PS-245R: NP1PM-48R/48E/256E/256H: NP1PU-048E/128E/256E: | V22 or later V26 or later V26 or later V23 or later V25 or later V22 or later | RJ-45 | Hakko Electronics' cable "D9-FU-SPBCPU" ^{*5} | Hakko Electronics' cable "MJ2-FU-SPBCPU" ^{*5} |

^{*5} Cable length: xxx-FU-SPHCPU-□M, xxx-FU-SPBCPU-□M, xx-FU-SPFCPU-□M (□ = 2, 3, 5 m)

Ethernet Connection (TS2060i Only)

MICREX-SX Series

| PLC Selection on the Editor | CPU | Unit | TCP/IP ^{*1} | UDP/IP | Port No. | Ladder Transfer ^{*2} |
|-----------------------------|---|----------------------------|----------------------|--------|---------------------------------|-------------------------------|
| MICREX-SX (Ethernet) | NP1PH-xx (SPH200) NP1PS-xx (SPH300) NP1PM-xx (SPH2000) NP1PU-xx (SPH3000) NP1PU2-xx (SPH3000MM) | NP1L-ET1 | ○ | × | Self port standard No. + 251 | × |
| | NP1PM-xx (SPH2000) NP1PU-xx (SPH3000) NP1PU2-xx (SPH3000MM) | CPU with built-in Ethernet | | | | |
| | NA0PAxxx-xxx (SPF) | NA3LA-ET1 NA0LA-ET1 | ○ | × | | |

^{*1} Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

Network Connection (TS2060i Only)

T-Link

| PLC Selection on the Editor | CPU | Unit on PLC | Unit on TS2060i | Ladder Transfer |
|-----------------------------|--|-----------------------------|-----------------|-----------------|
| MICREX-F (T-Link) | NV1P-x (F55) | NV1L-TL1 | CUR-01 | × |
| | NC1P-E (F70) | Standard T-Link | | |
| | NC1P-S (F70S) | Standard T-Link NC1H-TL1 | | |
| | FPU080H (F80H) FPU120H (F120H) FPU120S (F120S) FPU140S (F140S) FPU15xS (F15xS) | Standard T-Link FPC120T | | |
| MICREX-SX (T-Link) | NP1Px-xx (SPH) | NP1L-TL1 | | |

For more information on T-Link connection, refer to the Specifications for Communication Unit T-LINK manual.

OPCN-1

| PLC Selection on the Editor | CPU | Unit on PLC | Unit on TS2060i | Ladder Transfer |
|-----------------------------|----------------|-------------|-----------------|-----------------|
| MICREX-SX (OPCN-1) | NP1Px-xx (SPH) | NP1L-JP1 | CUR-00 | × |

For more information on OPCN-1 connection, refer to the Specifications for Communication Unit OPCN-1 manual.

SX BUS

| PLC Selection on the Editor | CPU | Unit on PLC | Unit on TS2060i | Ladder Transfer |
|-----------------------------|----------------|-------------|-----------------|-----------------|
| MICREX-SX (SX BUS) | NP1Px-xx (SPH) | — | CUR-06 | × |

MICREX-SX Model Selection


When the MICREX-SX SPH or SPB series is connected, a mode selection may be required on the TS2060 editor depending on the programming tool used on the PLC or the setting on the programming tool.

| PLC | PLC Programming Tool | | Setting on the TS2060 Editor | |
|------------|-------------------------------------|--------------------|---|-------------------|
| | | Address Expression | PLC Selection | Mode Selection *2 |
| SPH series | SX-Programmer Expert (D300win) | | MICREX-SX SPH/SPB/SPM/SPE/SPF series MICREX-SX SPH/SPB/SPM/SPE/SPF CPU MICREX-SX (Ethernet) MICREX-SX (T-Link) MICREX-SX (OPCN-1) MICREX-SX (SX BUS) | IEC Mode |
| | SX-Programmer Standard (Ver. 1 / 2) | Unchecked *1 | | N Mode |
| | | Checked *1 | | F Mode |
| | SX-Programmer Standard (Ver. 3) | FLEX-PC *1 | | N Mode |
| | | MICREX-F *1 | | F Mode |
| SPF series | SX-Programmer Expert (D300win) | | MICREX-SX SPH/SPB/SPM/SPE/SPF series MICREX-SX SPH/SPB/SPM/SPE/SPF CPU | IEC Mode |
| | SX-Programmer Standard (Ver. 1 / 2) | SX-MODE | | N Mode |
| | | Checked *1 | | F Mode |
| | SX-Programmer Standard (Ver. 3) | FLEX-PC *1 | | N Mode |
| | | MICREX-F *1 | | F Mode |
| | SX-Programmer Standard (Ver. 1 / 2) | N-MODE | SPB (N mode) & FLEX-PC series | - |
| | FLEX-PC Programmer | - | SPB (N mode) & FLEX-PC CPU | - |

*1 The setting procedure differs depending on the version of the SX-Programmer Standard tool.


- Ver. 1 or 2:

Check or uncheck the box for [Express address in MICREX-F address type] on the [Editor Options] tab window in the [Environment Options for MICREX-SX] dialog ([Options] → [MICREX-SX Environment]).




- Ver. 3:

Select "MICREX-F" from [Address display mode] ([Tool] → [Options] → [Category: General]).



*2 [Mode Select] dialog on the TS2060 editor



- [IEC Mode]: Variable name cooperation function

- [N Mode]: Address denotation "hexadecimal" *

- [F Mode]: Address denotation "decimal" *

* Except bit addresses

21.1.1 MICREX-F Series

Communication Setting

Editor

Communication setting


(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1</u> :1 / 1:n / Multi-link / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>0</u> to 31 | |

PLC



Be sure to match the settings to those made under [Communication Setting] of the editor.

Mode setting

| MODE | Setting | Contents | |
|--|---------|----------|--|
|  | 1 | RS-232C | Command-defined asynchronous communication (non-procedure) |
| | 3 | RS-485 | Command-defined asynchronous communication (non-procedure) |

* The mode setting switch is common to NV1L-RS2, NC1L-RS2, NC1L-RS4, FFU120B and FFK120A.


Station number setting

| ADDRESS | Setting | Contents |
|--|---------|---|
|   | 0 to 31 | Station number ×10: the tens place ×1: the ones place |

* The station number setting switch is common to NC1L-RS4, FFU120B and FFK120A.
It is not provided on NV1L-RS2 nor NC1L-RS2.


Transmission setting

NV1L-RS2, NC1L-RS2, NC1L-RS4, FFU120B


| Switch | Contents | ON | OFF | E.g.) Editor Default Setting |
|--------|---------------------|----------|--------------|---|
| 8 | Initializing method | Switch | Initial file |  |
| 7 | Parity | Provided | Not provided | |
| 6 | Parity bit | Even | Odd | |
| 5 | Data bit length | 7 bits | 8 bits | |
| 4 | Stop bit length | 1 bit | 2 bits | |
| | Baud rate | 19200 | 9600 | |
| 3 | | ON | ON | |
| 2 | | ON | OFF | |
| 1 | | OFF | ON | |

FFK120A

- Character switches

| Switch | Contents | ON | OFF | E.g.) Editor Default Setting |
|--------|---------------------|----------|--------------|--|
| 8 | Initializing method | Switch | Initial file |  |
| 7 | Parity | Provided | Not provided | |
| 6 | Parity bit | Even | Odd | |
| 5 | Data bit length | 7 bits | 8 bits | |
| 4 | Stop bit length | 2 bits | 1 bit | |
| 3 | Not used | - | OFF | |
| 2 | | - | OFF | |
| 1 | | - | OFF | |

- Baud rate setting switches
Set a switch to the ON position.

| Switch | Contents | Example: 19,200 bps |
|--------|------------|---|
| 8 | Not used |  |
| 7 | 19,200 bps | |
| 6 | 9,600 bps | |
| 5 | 4,800 bps | |
| 4 | 2,400 bps | |
| 3 | 1,200 bps | |
| 2 | 600 bps | |
| 1 | 300 bps | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------------|------|-------------------|
| M (auxiliary relay) | 00H | WM as word device |
| K (keep relay) | 01H | WK as word device |
| B (input/output relay) | 02H | WB as word device |
| L (link relay) | 09H | WL as word device |
| F (special relay) | 0AH | WF as word device |
| TS (timer/set value) | 0BH | *1 |
| TR (timer/current value) | 0CH | *1 |
| W9 (0.1-sec timer/current value) | 0DH | *1 |
| CS (counter/set value) | 0EH | *1 |
| CR (counter/current value) | 0FH | *1 |
| BD (data memory) | 10H | *1 |
| WS (step relay) | 11H | *2 |
| Wn (file memory) | 12H | *3, *4 |

*1 For items where double-words can be used (Num. Display, Graph, Sampling), data is processed as double-words. For those where bits or words can be used, data is processed as words consisting of lower 16 bits.

For input: Upper 16 bits are ignored.

For output: "0" is written for upper 16 bits.


*2 WS (step relay) is a byte device processed as described below.

For input: Upper 8 bits are "0".

For output: Lower 8 bits are written.

*3 To set up the file memory on the editor, enter "file number" + ":" (colon) + "address" in order.

Example: W30 : 00002



*4 Define the file area as "**ST**".

21.1.2 SPB (N Mode) & FLEX-PC Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)


| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | <u>1</u> : 1 / 1 : n / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>0</u> to 31 | |

PLC


Be sure to match the settings to those made under [Communication Setting] of the editor.

NS-RS1, NJ-RS2, NJ-RS4, NB-RS1

Mode setting


| MODE | Setting | Contents | |
|---|---------|----------|--|
|  | 1 | RS-232C | Command-defined asynchronous communication (non-procedure) |
| | 3 | RS-485 | Command-defined asynchronous communication (non-procedure) |

Station number setting

| ADDRESS | Setting | Contents |
|---|---------|---|
|  | 0 to 31 | Station number ×10: the tens place ×1: the ones place |

* The station number setting switch is not provided on NJ-RS2.


Transmission setting

| Switch | Contents | ON | OFF | E.g.) Editor Default Setting |
|--------|---------------------|----------|--------------|---|
| 8 | Initializing method | Switch | Initial file |  |
| 7 | Parity | Provided | Not provided | |
| 6 | Parity bit | Even | Odd | |
| 5 | Data bit length | 7 bits | 8 bits | |
| 4 | Stop bit length | 1 bit | 2 bits | |
| | Baud rate | 19200 | 9600 | |
| 3 | | ON | ON | |
| 2 | | ON | OFF | |
| 1 | | OFF | ON | |

NW0LA-RS2, NW0LA-RS4 (parameter setting)

On the PLC loader, set parameters for general communications.

Be sure to match the settings to those made under [Communication Setting] of the editor.



| Item | Setting | Remarks |
|-------------------|-----------------------------|---|
| Mode | General (Command asyn) | These settings can also be specified for the parameter area. For more information, refer to the MICREX-SX SPB Series User's Manual <Communication Adapter> (FEH405). |
| Station No. | RS-232C: 0, RS-485: 0 to 31 | |
| Initialize method | Set parameters | |
| Baud rate | 4800 / 9600 / 19200 / 38400 | |
| Parity | Odd / Even / None | |
| Data bits | 8 / 7 | |
| Stop bits | 1 / 2 | |

Notes on use of 2-wire connection with NW0LA-RS4

The settings show above are not enough to establish a 2-wire connection with NW0LA-RS4.

To establish a connection, select [Initial file transfer] for [Initial Setting Mode] on the PLC loader, and select 2-wire connection for [485 mode] in the initial setting file.

For more information, refer to the MICREX-SX SPB Series User's Manual <Communication Adapter> (FEH405).

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Standard Device Memory | TYPE | Remarks |
|----------------------------|------|-------------------|
| D (data register) | 00H | |
| W (link register) | 01H | |
| M (internal relay) | 02H | WM as word device |
| L (latch relay) | 03H | WL as word device |
| X (input relay) | 04H | WX as word device |
| Y (output relay) | 05H | WY as word device |
| R (file register) | 06H | |
| TN (timer/current value) | 07H | |
| CN (counter/current value) | 08H | |
| T (timer/contact) | 09H | |
| C (counter/contact) | 0AH | |
| WS (step relay) | 0BH | |

21.1.3 SPB (N Mode) & FLEX-PC CPU

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|-----------------------------|---|
| Connection Mode | <u>1:1</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | When connecting MONITOUCH to the RS-232C port on NJ-CPU-B16, select [RS-232C]. In other cases, select [RS-422/485]. |
| Baud Rate | <u>19200</u> bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | <u>1</u> bit | |
| Parity | <u>Odd</u> | |
| Target Port No. | <u>0</u> | |

PLC


SPB, FLEX-PC CPU port

No particular setting is necessary on the PLC.

Built-in RS-232C port on NJ-CPU-B16

On the PLC loader, set parameters for the built-in RS-232C port.

Be sure to match the settings to those made under [Communication Setting] of the editor.



Available Device Memory

The available device memory is the same as the one described in "21.1.2 SPB (N Mode) & FLEX-PC Series".

21.1.4 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (IEC Mode)

Communication Setting

Editor

Communication setting


(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|-----------------------------|---|
| Connection Mode | <u>1:1</u> / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 38400 bps | For the SPH series: Do not change the default setting. |
| Data Length | 8 bits | |
| Stop Bit | 1 bits | |
| Parity | Even | |
| Target Port No. | <u>0</u> to 31 | |

PLC

NP1L-RS1, NP1L-RS2, NP1L-RS3, NP1L-RS4, NP1L-RS5

Mode setting

| MODE | Setting | RS1, 2, 4 | RS-232C Port | RS-485 Port | Remarks |
|---|---------|-----------|-------------------------|-------------------------|-------------------------|
| | | RS3, 5 | CH1 | CH2 | |
|  | 0 | | General equipment | General equipment | |
| | 1 | | Loader | General equipment | |
| | 2 | | General equipment | Loader | |
| | 3 | | Loader | Loader | |
| | 4 | | General equipment | General equipment | RS3 and 5 are not used. |
| | 5 | | Not used | | |
| | 6 | | Modem loader 19200 bps | General equipment | |
| | 7 | | Self-diagnosis mode 1 | | |
| | 8 | | Self-diagnosis mode 2 | | |
| | 9 | | Modem loader 19200 bps | Loader | |
| | A | | Modem loader 9600 bps | General equipment | |
| | B | | Modem loader 9600 bps | Loader | |
| | C | | Modem loader 38400 bps | General equipment | |
| | D | | Modem loader 38400 bps | Loader | |
| | E | | Modem loader 76800 bps | General equipment | |
| | F | | Modem loader 115200 bps | Modem loader 115200 bps | |


* Set the port (or CH No.) where the TS2060 is connected to "loader".
Communication parameters are fixed to 38400 bps (baud rate), 8 bits (data length), 1 bit (stop bit), and even (parity).

* When the PLC is connected with the TS2060, the station number setting switch for RS-485 is not used.

NW0LA-RS2, NW0LA-RS4 (parameter setting)

On the PLC loader, set parameters for general communications.

Be sure to match the settings to those made under [Communication Setting] of the editor.



| Item | Setting | Remarks |
|-----------|-----------------------------|---------|
| Mode | Loader | |
| Baud rate | 4800 / 9600 / 19200 / 38400 | |
| Parity | Odd / Even / None | |
| Data bits | 8 | |
| Stop bits | 1 / 2 | |

Available Device Memory

Variable name cooperation function

The variable name cooperation function can be used only for PLC1. For device memory assignment, basically use the variable name cooperation function. **It is recommended that you specify a device memory address in the [AT] field to define the area (variable) that is used for communications with the TS2060.**

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|-------------------------|------|---|
| %IX (input memory) *1 | - | %IW as word device, %ID as double-word device *3 |
| %QX (output memory) *1 | - | %QW as word device, %QD as double-word device *3 |
| %MX1. (standard memory) | 02H | %MW1. as word device, %MD1. as double-word device *2 *3 |
| %MX3. (retain memory) | 04H | %MW3. as word device, %MD3. as double-word device *2 *3 |
| %MX10. (system memory) | 08H | %MW10. as word device, %MD10. as double-word device *2 *3 |

*1 For the input/output memory, the variable name cooperation function of the PLC1 must be used. Indirect designation is not available with the input/output memory.

*2 Double-word addresses (%MD1., %MD3., %MD10.) can be specified only for PLC1.


In the case with PLC2 to PLC8, access to the above addresses is possible when the data length is set to 2 words in the word address (%MW1., %MW3., %MW10.).

Example: When accessing the address in %MD1.100:


Set the data length to 2 words for %MW1.100.

*3 The assigned device memory is expressed as shown below when editing the screen.

- For %IX or %QX:




Example: %IX1 . 1 . 0



- For %MX1., %MX3., or %MX10:



Example: %MX1 . 1 . 1 . 0



Indirect Device Memory Designation

Specify the CPU number in the expansion code.

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---------------------------------|---------------------|--------------|---|----|
| All start | 1 - 8 (PLC1 - 8) | n | Station number: 0000H | 2 |
| | | n + 1 | Command: 0400H | |
| All stop | 1 - 8 (PLC1 - 8) | n | Station number: 0000H | 2 |
| | | n + 1 | Command: 0402H | |
| Operation / standby switching * | 1 - 8 (PLC1 - 8) | n | Station number: 0000H | 3 |
| | | n + 1 | Command: 040BH | |
| | | n + 2 | CPU No. operated by default: m (0, 2, 4, 6) | |

* Valid only for the redundant system.

21.1.5 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (N Mode / F Mode)

Communication Setting


The communication setting is the same as the one described in "21.1.4 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (IEC Mode)".

Available Device Memory


The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|---|
| X (input memory) *1 | - | WX as word device, DX as double-word device *3 |
| Y (output memory) *1 | - | WY as word device, DY as double-word device *3 |
| M (standard memory) | 02H | WM as word device, DM as double-word device *2 *3 |
| L (retain memory) | 04H | WL as word device, DL as double-word device *2 *3 |
| SM (system memory) | 08H | WSM as word device, DSM as double-word device *2 *3 |
| WFL (user file) | 0FH | DFL as double-word device *4 |

- *1 Input/output memory does not operate normally unless you import the "*.ini" file created using [Export Device Information] in the PLC programming tool.
Can be used only for PLC1. Indirect designation is not available.
- *2 Double-word addresses (DM, DL, DSM) can be specified only for PLC1.
In the case with PLC2 to PLC8, access to the above addresses is possible when the data length is set to 2 words in the word address (WM, WL, WSM).
Example: When accessing the address in DM100:
Set the data length to 2 words for WM100.
- *3 The assigned device memory is expressed as shown below when editing the screen.
 - For X or Y:



- For M, L or SM



Example: X 1 . 00000001 0

Example: M 1 . 00000001 0

- *4 Can be used only in F mode. Bit designation is not available.

Indirect Device Memory Designation

Specify the CPU number in the expansion code.

PLC_CTL

The macro command is the same as the one described in "21.1.4 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (IEC Mode)".

21.1.6 MICREX-SX SPH/SPB/SPM/SPE/SPF CPU (IEC Mode)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--------------------------|---|
| Connection Mode | <u>1-1</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 38400 bps | Do not change the setting from default. |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | Even | |
| Target Port No. | <u>0</u> to 31 | |

PLC

No particular setting is necessary on the PLC.

Communication parameters are fixed to 38400 bps (baud rate), RS-422 (signal level), 8 bits (data length), 1 bit (stop bit), and even (parity).

Available Device Memory

The available device memory is the same as the one described in "21.1.4 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (IEC Mode)".

PLC_CTL

The macro command is the same as the one described in "21.1.4 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (IEC Mode)".

21.1.7 MICREX-SX SPH/SPB/SPM/SPF CPU (N Mode / F Mode)

Communication Setting

The communication setting is the same as the one described in "21.1.6 MICREX-SX SPH/SPB/SPM/SPE/SPF CPU (IEC Mode)".

Available Device Memory

The available device memory is the same as the one described in "21.1.5 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (N Mode / F Mode)".

PLC_CTL

The macro command is the same as the one described in "21.1.4 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (IEC Mode)".

21.1.8 MICREX-SX (Ethernet) (IEC Mode)

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].
The PLC port number is "Self port standard No." plus 251 set on the PLC.

PLC (Ethernet Parameter Setting)

The table below shows settings required for communication with the TS2060i.


(Underlined setting: default)

| Item | Setting | Remarks |
|------------------------|----------------------|---------|
| IP Address | <u>192.168.0.1</u> | |
| Subnet Mask | <u>255.255.255.0</u> | |
| Self-port Standard No. | <u>256</u> | |


For more information on other setting items, refer to the PLC manual issued by the manufacturer.

Setting Example

The following example shows the setting for communication between MICREX-SX ET1 module and the TS2060i unit via Ethernet.




Setting on the PLC loader




When the Ethernet module is used, the module driver must be transferred to the PLC.
To transfer it to the PLC, check [Module driver] on the relevant PLC transfer setting dialog.


- SX Programmer Standard Ver. 2



- SX Programmer Standard Ver. 3




- D300win




Settings on the editor

- IP address setting for the TS2060i unit (on the editor)
[System Setting] → [Hardware Setting] → [Local Port IP Address]



- PLC Table

[System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings] → [PLC Table]



Available Device Memory

The available device memory is the same as the one described in "21.1.4 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (IEC Mode)".

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---|---------------------|--------------|---|----|
| All start | 1 - 8 (PLC1 - 8) | n | Station number: 00H to FFH ^{*1} | 2 |
| | | n + 1 | Command: 0400H | |
| All stop | 1 - 8 (PLC1 - 8) | n | Station number: 00H to FFH ^{*1} | 2 |
| | | n + 1 | Command: 0402H | |
| Operation / standby switching ^{*2} | 1 - 8 (PLC1 - 8) | n | Station number: 00H to FFH ^{*1} | 3 |
| | | n + 1 | Command: 040BH | |
| | | n + 2 | CPU No. operated by default: m (0, 2, 4, 6) | |

^{*1} Valid only when "1 : n" connection mode is selected under [Communication Setting] in the [PLC Properties] window ([System Setting] → [Hardware Setting]).
For the station number, set the PLC table number under [Target Settings] in the [PLC Properties] window ([System Setting] → [Hardware Setting]).

^{*2} Valid only for a redundant system.

21.1.9 MICREX-SX (Ethernet) (N Mode / F Mode)

Communication Setting

The communication setting is the same as the one described in "21.1.8 MICREX-SX (Ethernet) (IEC Mode)".

Available Device Memory

The available device memory is the same as the one described in "21.1.5 MICREX-SX SPH/SPB/SPM/SPE/SPF Series (N Mode / F Mode)".

PLC_CTL

The macro command is the same as the one described in "21.1.8 MICREX-SX (Ethernet) (IEC Mode)".

21.1.10 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C


Wiring diagram 1 - C2




Wiring diagram 2 - C2




Wiring diagram 3 - C2



Wiring diagram 4 - C2




Wiring diagram 5 - C2







RS-422/RS-485





Wiring diagram 1 - C4



Wiring diagram 2 - C4




Wiring diagram 3 - C4**Wiring diagram 4 - C4****When Connected at MJ1/MJ2:****RS-232C****Wiring diagram 1 - M2**


Wiring diagram 2 - M2**Wiring diagram 3 - M2****Wiring diagram 4 - M2****Wiring diagram 5 - M2**

RS-422/RS-485


Wiring diagram 1 - M4




Wiring diagram 2 - M4



Wiring diagram 3 - M4



Wiring diagram 4 - M4



21.2 Temperature Controller/Servo/Inverter Connection

Serial Connection

Temperature Controller

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|--------------------------------|--|-----------------------|-----------------|-----------------------|-----------------------|--------------|----------------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| PYX (MODBUS RTU) | PYX4xx PYX5xx PYX9xx ^{*2} | Terminal block | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | PYX.Lst |
| PXR (MODBUS RTU) | PXR3xx PXR4xx PXR5xx PXR7xx PXR9xx ^{*2} | Terminal block | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | PXR.Lst |
| PXF (MODBUS RTU) | PXF4xx PXF5xx PXF9xx ^{*2} | Terminal block | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | PXF.Lst |
| PXG (MODBUS RTU) | PXG4xx PXG5xx PXG9xx ^{*2} | Terminal block | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | F_PXG.Lst |
| PXH (MODBUS RTU) | PXH9xx ^{*2} | Terminal block | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | | F_PXH.Lst |
| PUM (MODBUS RTU) | PUMxx | Terminal block (base) | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | | F_PUMA_B.Lst F_PUME.Lst |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} Select a model on which Modbus communication is available.

Power Monitor Unit

| PLC Selection on the Editor | Series Name | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|-------------|----------------------------------|------------------|--------------|-----------------------|-----------------------|--------------|-------------------|
| | | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| F-MPC04P (loader) | F-MPC04P | UM02-AR2 UM02-AR3 UM02-AR4 | RS-485 connector | RS-485 | Wiring diagram 3 - C4 | Wiring diagram 3 - M4 | | F-MPC04P.Lst |
| F-MPC series / FePSU | F-MPC04 | UM01-ARxx | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | UM01_ARA4.Lst |
| | F-MPC04P | UM02-AR2 | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | UM02_AR2.Lst |
| | | UM02-AR3 | | | | | | UM02_AR3.Lst |
| | | UM02-AR4 | | | | | | UM02_AR4.Lst |
| | F-MPC04S | UM03-AR3x | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | UM03_ARA3G.Lst |
| | F-MPC30 | UM5ACxx | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | UM5A.Lst |
| | | UM45xx | | | | | | |
| | F-MPC50 | UM50xx | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | UM50.Lst |
| | F-MPC55 | UM55V | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | UM55V.Lst |
| | F-MPC60B | UM4Bxx | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | UM4_UM42_UM43.Lst |
| | | UM42Cxx | | | | | | |
| | | UM42Fxx | | | | | | |
| | | UM43FDxx | | | | | | |
| | | UM43FGxx | | | | | | |
| | | UM44Bxx | | | | | | |
| | | UM44CDxx | | | | | | UM44.Lst |
| | | UM44FGxx | | | | | | |
| | FePSU | EAXx EGxx SAXx SGxx | Terminal block | RS-485 | Wiring diagram 5 - C4 | Wiring diagram 5 - M4 | | FePSU.Lst |
| | | BWxxxxxx EWxxxxxx | Terminal block | RS-485 | Wiring diagram 5 - C4 | Wiring diagram 5 - M4 | | FePSUBk.Lst |
| | F*JF-R | F1JF-R F2JF-R F3JF-R | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | FJF-R.Lst |
| | F-MPC04E | UM05-AR3 | Terminal block | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | | UM05_AR3.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Select a model on which RS-485 communication is available.

Inverter

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|------------------------------------|--------------------------------|-----------------------------------|--------------|---------------------------|---------------------------|---------------------------|----------------------------------|
| | | | | CN1 TS2060i+ DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| FVR-E11S | FVRxxE11S-x | Touch panel connector | RS-485 | Wiring diagram 6 - C4 | Wiring diagram 6 - M4 | | FVR-E11S.Lst |
| FVR-E11S (MODBUS RTU) | | | | | | | FVR-E11S (Modbus).Lst |
| FVR-C11S (MODBUS RTU) | FVRxxC11S-x | OPC-C11S-RSx | RS-485 | Wiring diagram 7 - C4 | Wiring diagram 7 - M4 | | FVR-C11S (Modbus).Lst |
| FRENIC5000G11S / P11S | FRNxxG11S-x FRNxxP11S-x | Terminal block | RS-485 | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | F-G11S.Lst |
| FRENIC5000G11S / P11S (MODBUS RTU) | | | | | | | FRENIC5000G11S_P11S (Modbus).Lst |
| FRENIC5000VG7 (MODBUS RTU) | FRNxxVG7S-x | RS-485 connector | RS-485 | Wiring diagram 9 - C4 | Wiring diagram 9 - M4 | Wiring diagram 19 - M4 | FRENIC5000VG7S (Modbus).Lst |
| | | OPC-VG7-RS (communication board) | | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | |
| FRENIC-Mini (MODBUS RTU) | FRNxxC1S-x | OPC-C1-RS (communication board) | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | F-Mini.Lst |
| | FRNxxC2x-xx | RS-485 communication port | | | | | |
| FRENIC-Eco (MODBUS RTU) | FRNxxF1S-x | Touch panel connector | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | F-Eco (Modbus).Lst |
| | | OPC-F1-RS (communication board) | | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | |
| FRENIC-Multi (MODBUS RTU) | FRNxxE1S-x | Touch panel connector | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | F-Multi.Lst |
| | | OPC-E1-RS (communication board) | | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | |
| FRENIC-MEGA (MODBUS RTU) | FRNxxxG1x-xx | Touch panel connector | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | FRENIC-MEGA (Modbus).Lst |
| | | Terminal block on control circuit | | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | |
| FRENIC-MEGA SERVO (MODBUS RTU) | FRNxxxG1x-xxxQ | Touch panel connector | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | FRENIC-MEGA SERVO (Modbus).Lst |
| | | Control circuit terminal block | | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | |
| FRENIC-HVAC/AQUA (MODBUS RTU) | FRNxxxAR1x-4x FRNxxxAQ1x-4x | Touch panel connector | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | FRENIC-HVAC (Modbus).Lst |
| | | Control circuit terminal block | | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | FRENIC-AQUA (Modbus).Lst |
| FRENIC-VG1 (MODBUS RTU) | FRNxxVG1S-xx | Control circuit terminal block | RS-485 | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | FRENIC-VG1 (MODBUS RTU).Lst |
| FRENIC-Ace (MODBUS RTU) | FRNxEx-xJ | RS-485 communication port 1 | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | FRENIC-Ace (MODBUS RTU).Lst |
| | | RS-485 communication port 2 | RS-485 | Wiring diagram 20 - C4 | Wiring diagram 24 - M4 | | |

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|---|-------------------------------------|--------------|---------------------------|---------------------------|-----------------------------|----------|
| | | | | CN1 TS2060i+ DUR-00 | MJ1/MJ2 * ¹ | MJ2 (4-wire) * ² | |
| FRENIC series (loader) | FRENIC5000VG7S | RS-485 connector | RS-485 | Wiring diagram 9 - C4 | Wiring diagram 9 - M4 | Wiring diagram 19 - M4 | - |
| | | OPC-VG7-RS (communication board) | RS-485 | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | |
| | FRENIC-Mini | OPC-C1-RS (communication board) | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | |
| | | RS-485 communication port | | | | | |
| | FRENIC-Eco FRENIC-Multi FRENIC-MEGA FRENIC-MEGA SERVO FRENIC-HF FRENIC-Lift | Touch panel connector | | | | | |
| | FRENIC-HVAC/ AQUA | Touch panel connector | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | |
| | | Control circuit Terminal block | RS-485 | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | |
| | FRENIC-VG1 | Control circuit Terminal block | RS-485 | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | |
| | FRENIC-Ace | RS-485 communication port 1 | RS-485 | Wiring diagram 10 - C4 | Wiring diagram 10 - M4 | | |
| | | RS-485 communication port 2 | RS-485 | Wiring diagram 20 - C4 | Wiring diagram 24 - M4 | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

IH Inverter

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|--|---------------------------------|--------------|------------------------|------------------------|--------------|--------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| HFR-C9K | HFR030C9Kxx HFR050C9Kxx | HFR-OPC01 (communication board) | RS-485 | Wiring diagram 13 - C4 | Wiring diagram 13 - M4 | | F_HFR.Lst |
| HFR-C11K | HFR3.0C11Kxx HFR5.0C11Kxx HFR7.0C11Kxx | Terminal block | RS-485 | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | HFR-C11K.Lst |
| HFR-K1K | HFR2.5K1K-2 HFR3.0K1K-2 HFR5.0K1K-2 HFR6.0K1K-2 | CN3 | RS-485 | Wiring diagram 19 - C4 | Wiring diagram 23 - M4 | | HFR-K1K.Lst |
| | | I/O PCB (option) *2 | RS-485 | Wiring diagram 8 - C4 | Wiring diagram 8 - M4 | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 This port is available only with models equipped with the option.

AC Power Monitor

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|-----------|----------------|--------------|-----------------------|-----------------------|--------------|------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| PPMC (MODBUS RTU) | PPMCxx *2 | Terminal block | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | F-PPMC.Lst |
| | | | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Select a model on which RS-485 or RS-232C communication is available.

Servo Amplifier

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|----------------|----------------|--------------|------------------------|------------------------|------------------------|------------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| FALDIC-α series | RYSxx *3 | CN3 | RS-485 | Wiring diagram 12 - C4 | Wiring diagram 12 - M4 | Wiring diagram 20 - M4 | F_FAL-A.Lst |
| FALDIC-W series | RYCxxx x3-VVT2 | CN3A (UP port) | RS-485 | Wiring diagram 17 - C4 | Wiring diagram 17 - M4 | Wiring diagram 22 - M4 | F_Fal-W.Lst |
| ALPHA5 (MODBUS RTU) | RYTxxx5-VVx | CN3A | RS-485 | Wiring diagram 14 - C4 | Wiring diagram 14 - M4 | | ALPHA5.Lst |
| ALPHA5 Smart (MODBUS RTU) | RYHxxx5-VV2 | CN3A | RS-485 | Wiring diagram 14 - C4 | Wiring diagram 14 - M4 | | ALPHA5 Smart.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*3 Select a model on which host interface: universal communication (RS-485) is available.

Controller

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|--------------------------------|----------|--------------|-----------------------|------------------------|------------------------|----------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| WSZ series | WSZ-24MCT2-AC | PORT0 | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | WSZ.Lst |
| | WSZ-32MCT2-AC | WSZ-CB25 | PORT1 | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 4 - M2 | |
| | WSZ-40MCT2-AC WSZ-60MCT2-AC | | PORT2 | RS-485 | Wiring diagram 18 - C4 | Wiring diagram 18 - M4 | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Recorder

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|--------------------------------|----------------|--------------|------------------------|------------------------|--------------|-----------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| PH series | PHAxxx4-xxxRY PHCxxx3-xxxRY | Terminal block | RS-485 | Wiring diagram 16 - C4 | Wiring diagram 16 - M4 | | F_PHC.Lst |
| PHR (MODBUS RTU) | PHRxx | Terminal block | RS-485 | Wiring diagram 2 - C4 | Wiring diagram 2 - M4 | | F_PHR.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Digital Panel Meter

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|--|--------------|--------------|------------------------|------------------------|--------------|------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| WA5000 | WA5xx3-yy WA5xx4-yy WA5xx6-yy WA5xx7-yy | Modular Jack | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | WA5000.Lst |
| | | | RS-485 | Wiring diagram 11 - C4 | Wiring diagram 11 - M4 | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Specify an input unit (-yy: 01 to 12, or 18) when selecting the model.

AC Power Regulator

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|-----------------------------|----------------------|---------------------------------|--------------|-----------------------|-----------------------|------------------------|-------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| APR-N (MODBUS RTU) | RPNExxx-xx-ZAM-xx/xx | RPN003-AM (communication board) | RS-485 | Wiring diagram 4 - C4 | Wiring diagram 4 - M4 | Wiring diagram 21 - M4 | F_APR-N.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

Electronic Multimeter

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|--------------------------------|-----------------|----------------|--------------|------------------------|------------------------|--------------|--|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 * ¹ | MJ2 (4-wire) | |
| WE1MA (Ver. A) (MODBUS RTU) | WE1MA-AFxxx-Mxx | Terminal block | RS-485 | Wiring diagram 15 - C4 | Wiring diagram 15 - M4 | | F_WE1MA.Lst |
| | WE1MA-AGxxx-Mxx | | | | | | F_WE1MA_1P.Lst * ² |
| | WE1MA-A1xxx-Mxx | | | | | | F_WE1MA_1P3L.Lst * ² |
| | WE1MA-A5xxx-Mxx | | | | | | F_WE1MA_3P3L.Lst * ² |
| | WE1MA-A2xxx-Mxx | | | | | | F_WE1MA_3P4L.Lst * ² |
| | WE1MA-A6xxx-Mxx | | | | | | |
| | WE1MA-A7xxx-Mxx | | | | | | |
| WE1MA (Ver. B) (MODBUS RTU) | WE1MA-AFxxx-Mxx | Terminal block | RS-485 | Wiring diagram 15 - C4 | Wiring diagram 15 - M4 | | F_WE1MA (Ver. B).Lst |
| | WE1MA-AGxxx-Mxx | | | | | | F_WE1MA_1P (Ver. B).Lst * ² |
| | WE1MA-A1xxx-Mxx | | | | | | F_WE1MA_1P3L (Ver. B).Lst * ² |
| | WE1MA-A5xxx-Mxx | | | | | | F_WE1MA_3P3L (Ver. B).Lst * ² |
| | WE1MA-A2xxx-Mxx | | | | | | F_WE1MA_3P4L (Ver. B).Lst * ² |
| | WE1MA-A6xxx-Mxx | | | | | | |
| | WE1MA-A7xxx-Mxx | | | | | | |
| | WE1MA-A4xxx-Mxx | | | | | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 List files "F_WE1MA.Lst" and "F_WE1MA(Ver. B).Lst" can be browsed as default through the [Refer] button. These files can be used for device memory settings.

Ethernet Connection (TS2060i Only)

Controller

| PLC Selection on the Editor | CPU | Unit/Port | TCP/IP * ¹ | UDP/IP | Port No. | Keep Alive * ² | Lst File |
|-----------------------------|--|-----------|-----------------------|--------|---|---------------------------|-------------|
| WSZ series (Ethernet) | WSZ-xxMAR2-D24 WSZ-xxMCT2-D24 WSZ-xxMCT2-AC | WSZ-CBE | ○ | ○ | 500: Default (Max. 8 units for TCP/IP) | ○ | WSZ_Eth.Lst |
| | FBs-xxMNxxx-x FBs-xxMCxxx-x-XY FBs-xxMAxxx-x | FBs-CBE | ○ | ○ | | | |

*1 Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

*2 For KeepAlive functions, see 1.3.2 Ethernet Communication (TS2060i Only).

21.2.1 PYX (MODBUS RTU)

Communication Setting

Editor

Communication setting


(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | Do not change the default settings because these settings on the temperature controller cannot be changed. |
| Signal Level | RS-422/485 | |
| Baud Rate | 9600 bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | Odd | |
| Target Port No. | 1 to 31 | |

Temperature Controller

The communication parameter can be set using keys attached to the front of the temperature controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | Item | Setting | Example |
|--|--|----------------|---------|
|  | Digital transmission function (station number) | <u>1</u> to 31 | 1 |

- * The communication function of the temperature controller can be selected from Fuji protocol or Modbus protocol at the time of purchase. For communication with a TS2060, select a model on which the Modbus protocol is available.
- * The following communication parameters are fixed; baud rate: 9600 bps, data length: 8 bits, stop bit: 1 bit, and parity: odd.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|-----------|
| 0 | 00H | |
| 1 | 01H | Read only |
| 4 | 02H | |
| 3 | 03H | Read only |

21.2.2 PXR (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|------------------------------------|--|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | Do not change the default settings because these settings on the temperature controller cannot be changed. |
| Baud Rate | 9600 bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | None / Even / <u>Odd</u> | |
| Target Port No. | 1 to 31 | |

Temperature Controller

The communication parameter can be set using keys attached to the front of the temperature controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | Display | Item | Setting | Example |
|-----------------------|-------------|------|------------------------|--|
| Third block parameter | STno | STno | Station number | <u>1</u> - 31 |
| | CoM | CoM | Parity | <u>0</u> : Odd 1: Even 2: None |
| | PCoL | PCoL | Communication protocol | 1: Modbus ^{*1} 2: Z-ASCII |

*1 The communication function of the temperature controller can be selected at the time of purchase. Select a model on which RS-485 (Modbus) communication is available.

*2 The following communication parameters are fixed; baud rate: 9600 bps, data length: 8 bits, and stop bit: 1 bit.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|-----------|
| 0 | 00H | |
| 1 | 01H | Read only |
| 4 | 02H | |
| 3 | 03H | Read only |

21.2.3 PXF (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-422/485 | Do not change the default settings of the signal level, data length and stop bit because these settings on the temperature controller cannot be changed. |
| Baud Rate | <u>9600</u> / 19200 / 38400 / 115200 bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | None / <u>Odd</u> / Even | |
| Target Port No. | <u>1</u> to 255 | |

Temperature Controller

The communication parameters can be set using keys attached to the front of the temperature controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter Channel | Display | Parameter Name | Setting | Example |
|-------------------|---------|------------------------------|--|---------|
| Ch9 COM | CtyP | Communication type selection | <u>0: Modbus RTU</u> | 0 |
| | STno | ST No. setting | 1 to 255 | 1 |
| | SPEd | RS-485 baud rate | <u>96</u> : <u>9600 bps</u> 192: 19200 bps 384: 38400 bps 115K:115K bps | 96 |
| | PrTy | RS-485 Parity | NoNe <u>odd</u> EVEN | odd |

*1 The communication function of the temperature controller can be selected at the time of purchase. Select a model on which RS-485 (Modbus) communication is available as an option.

*2 The following communication parameters are fixed; data length: 8 bits and stop bit: 1 bit.

Available Device Memory

The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|-----------|
| 4 | 02H | |
| 3 | 03H | Read only |

21.2.4 PXG (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | <u>9600</u> / 19200 bps | Do not change the default settings of the signal level, data length and stop bit because these settings on the temperature controller cannot be changed. |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | None / Even / <u>Odd</u> | |
| Target Port No. | 1 to 31 | |

Temperature Controller

The communication parameter can be set using keys attached to the front of the temperature controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Channel | Parameter Display | Item | Setting | Example |
|----------------------------------|-------------------|-------------------------|--|---------|
| "CoM Ch9" Communication (Ch9) | "STno" STno | Station number | <u>1</u> to 31 | 1 |
| | "CoM" CoM | Parity | 96od (9600 bps / odd parity) 96Ev (9600 bps / even parity) 96no (9600 bps / without parity) 19od (19200 bps / odd parity) 19Ev (19200 bps / even parity) 196no (19200 bps / without parity) | 96od |
| | "SCC" SCC | Communication authority | r (Read only) <u>rW</u> (Read/write allowed) | rW |

* The communication function of the temperature controller can be selected at the time of purchase. Select a model on which RS-485 (Modbus) communication is available.

* The following communication parameters are fixed; data length: 8 bits and stop bit: 1 bit.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|---------|
| 1 (input relay) | 01H | |
| 4 (holding register) | 02H | |
| 3 (input register) | 03H | |

21.2.5 PXH (MODBUS RTU)

Communication Setting

Editor

Communication setting


(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---------------------------------|--|
| Connection Mode | 1: 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 9600 / 19200 / <u>38400</u> bps | Do not change the default settings of the signal level, data length and stop bit because these settings on the temperature controller cannot be changed. |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | None / Even / <u>Odd</u> | |
| Target Port No. | 1 to 31 | |

Temperature Controller

The communication parameter can be set using keys attached to the front of the temperature controller. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Channel | Parameter Display | Item | Setting | Example |
|--|-------------------|--------------------|--|---------|
|  Communication (Ch B) | STn4 | RS-485 station No. | <u>1</u> to 31 | 1 |
| | SPd4 | RS-485 baud rate | 96: 9600 bps 192: 19200 bps <u>384: 38400 bps</u> | 384 |
| | biT4 | RS-485 bit format | 8n: Data length 8 bits, without parity <u>8o: Data length 8 bits, odd parity</u> 8E: Data length 8 bits, even parity | 8o |

* The communication function of the temperature controller can be selected at the time of purchase. Select a model on which RS-485 (Modbus) communication is available.

* The following communication parameters are fixed; data length: 8 bits and stop bit: 1 bit.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|---------|
| 4 (holding register) | 02H | |
| 3 (input register) | 03H | |

21.2.6 PUM (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)


| Item | Setting | Remarks |
|-----------------|--|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | Do not change the default settings of the signal level, data length and stop bit because these settings on the temperature controller cannot be changed. |
| Baud Rate | 9600 / <u>19200</u> / 38400 / 115200 bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | <u>None</u> / Even / Odd | |
| Target Port No. | 1 to 15 [DEC] | |

Temperature Controller

Be sure to match the settings to those made under [Communication Setting] of the editor.

Station number setting

(Underlined setting: default)

| STATION | Setting | Example |
|---|---------------------|---|
|  | <u>Q</u> to F [HEX] | 0: Station number 1 F: Station number 16 |

Communication setting

On the temperature controller loader, set communication parameters.

(Underlined setting: default)

| Item | Setting | Example | Remarks |
|--|--|---------|---|
| RS-485 parity setting | <u>0: None</u> 1: Odd 2: Even | 0 | |
| RS-485 baud rate setting | 0: 9600 <u>1: 19200</u> 2: 38400 4: 115200 kbps | 1 | |
| RS-485 communication authority setting | 0: Read only <u>1: Read/write allowed</u> | 1 | |
| RS-485 response interval setting | 0 to 25 (default: <u>1</u>) | 1 | Response interval = setting value × 20 ms |
| Extensional communication module (PUMC) connection | <u>0: Without PUMC (RS-485 valid)</u> 1: With PUMC (RS-485 invalid) | 0 | When using RS-485 communication, set "0". |

* The following communication parameters are fixed; data length: 8 bits and stop bit: 1 bit.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|--------------------|------|---------|
| 4 | (holding register) | 02H | |
| 3 | (input register) | 03H | |

Note on Setting the Device Memory

In accordance with the connected PUM model, set the "List" file name to be browsed by pressing the [Refer] button.

| Model | | List File Name |
|-------|---------------------------|----------------|
| PUMAx | Control module (4 ch) | F_PUMA_B.Lst |
| PUMBx | Control module (2 ch) | |
| PUMEx | Event input/output module | F_PUME.Lst |

"F_PUMA_B.Lst" is set as default.

21.2.7 F-MPC04P (Loader)

Communication Setting

Editor

Communication setting

(Underlined setting: default)


| Item | Setting | Remarks |
|-----------------|----------------------------------|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | 1 bit | Do not change the default setting because the setting on the power monitor unit cannot be changed. |
| Parity | None / <u>Odd</u> / Even | |
| Target Port No. | 1 to 99*1 | |

*1 To use port No. 32 to 99, use the station number table.

Power Monitor Unit

Be sure to match the settings to those made under [Communication Setting] of the editor.

Station number setting

| Station | Setting | Example | Remarks |
|---|-------------------------------------|---------|---------|
|  | 01 to 99 [DEC] (default: <u>0</u>) | 1 | |

Communication setting

The communication parameter can be set using keys attached to the front of the power monitor unit.

(Underlined setting: default)

| Circuit No. | Setting Code | Item | Setting | Example |
|-------------|--------------|-------------|--|---------|
| C | L1-□□ | Baud rate | 00: 4800 bps 01: 9600 bps <u>02: 19200 bps</u> | 02 |
| | L2-□□ | Parity | 00: None 01: Even <u>02: Odd</u> | 02 |
| | L3-□□ | Data length | <u>00: 7 bits</u> 01: 8 bits | 00 |

* The communication parameter (stop bit) is fixed to 1 bit.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.


| Device Memory | TYPE | Remarks |
|---------------|------|-------------|
| --- | 00H | Double-word |

Station Number Table


- A maximum of 31 units can be connected via serial communication. Port numbers from 0 to 31 can be set on the [Device Setting] dialog of the editor; however, depending on the controller, port numbers exceeding 32 may be available. In such a case, use the station number table to enable communications with devices of port No. 32 or greater.
- It is easier to specify port numbers for each network in the field by making the screen for setting the port number when creating the screen program. In this case, it is not necessary to transfer the screen program again.

Setting the Station Number Table

1. Select [Yes] for [Use Port No. Table] under [Communication Setting] on the [PLC Properties] window ([System Setting] → [Hardware Setting]).



2. Click "Setting..." next to [Port No. Table]. The [Port No. Table Setting] dialog is displayed.
3. Specify port numbers of the temperature controllers for "Table 0" to "31".



Macro

To rewrite the station number table on the TS2060 screen, use macro commands [FROM_WR] and [RESTART].

FROM_WR

FROM_WR F0 F1

- Function: Writing to FROM
As many words as specified for F1 from the device memory address set for F0 is written in the FP-ROM.
- Available device memory

| | Internal Device Memory | PLC n Device Memory | Memory Card | Constant |
|----|------------------------|---------------------|-------------|----------|
| F0 | ⊙ | ⊙ | ⊙ | |
| F1 | | | | ○ |

○: Setting enabled (indirect designation disabled)
⊙: Setting enabled (indirect designation enabled)

- Data range

| | Setting | Remarks |
|----|---|---|
| F0 | Top device memory address of the source | 32 words from the top address of the specified device memory are used. Set port numbers from 0 to 31 for each address. For the station number table not used, set [-1]. |
| F1 | Number of transmission words: 32 | If any other value than "32" is set, the write error (\$s728 = 1) occurs. |

- Notes
 - The maximum possible number of write operations to the FP-ROM is 100,000 times. This is not related to the number of words that are written.
 - Do not include the FROM_WR command in a cycle macro or an event timer macro.
 - Writing to FP-ROM takes a longer time.
 - When the station number table has been rewritten using the [FROM_WR] command, be sure to execute the [RESTART] command.
 - When the station number table is used, it is not possible to set ☐ Use Internal Flash ROM as Back-up Area on the [General Settings] tab window that is displayed by selecting [System Setting] → [Unit Setting] → [General Settings]. Be sure to leave this box unchecked.

RESTART

When the station number table has been rewritten using the [FROM_WR] command, be sure to execute this command.

SYS (RESTART) F0

- Function: Reconnection
This macro command reconnects the controller when the time specified for F1 has elapsed.
- Available device memory


| | Internal Device Memory | PLC n Device Memory | Memory Card | Constant |
|----|------------------------|---------------------|-------------|----------|
| F1 | ⊙ | | | |

○: Setting enabled (indirect designation disabled)
⊙: Setting enabled (indirect designation enabled)

- Data range

| | Setting |
|----|-----------------|
| F0 | RESTART |
| F1 | Time: 0 to 60 s |

Example of Procedure for Rewriting the Station Number Table



System Device Memory

The result of [FROM_WR] macro execution is stored in \$s728.

[0]: Normal

[1]: Error

21.2.8 F-MPC Series / FePSU

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | 38400 bps is available for F-MPC04E only. |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | 1 bit | Do not change the default setting because the setting on the power monitor unit cannot be changed. |
| Parity | None / <u>Odd</u> / Even | |
| Target Port No. | 1 to 99*1 | |

*1 To use port numbers 32 to 99, use the station number table. For the station number table, see "Station Number Table" (page 21-37).

F-MPC04

Communication setting

The communication parameters can be set using keys attached to the front of the power monitor unit.
Be sure to match the settings to those made under [Communication Setting] of the editor.


(Underlined setting: default)

| Circuit No. | Setting Code | Item | Setting | Example |
|-------------|--------------|--------------------------|--|---------|
| C | 4-0 | RS-485 address | <u>Loc: Communication not used</u> 01 to 99 | 01 |
| | 4-1 | RS-485 baud rate setting | 4.8: 4800 bps 9.6: 9600 bps <u>19.2: 19200 bps</u> | 19.2 |
| | 4-2 | RS-485 data length | <u>7: 7 bits</u> 8: 8 bits | 7 |
| | 4-3 | RS-485 parity | 00: None 01: Even <u>02: Odd</u> | 02 |

F-MPC04P

Be sure to match the settings to those made under [Communication Setting] of the editor.

Station number setting

| Station | Setting | Example | Remarks |
|---|-----------------------------|---------|---------|
|  | 01 to 99 [DEC] (default: 0) | 1 | |

Communication setting

The communication parameters can be set using keys attached to the front of the power monitor unit.

(Underlined setting: default)

| Circuit No. | Setting Code | Item | Setting | Example |
|-------------|--------------|-------------|--|---------|
| C | L1-□□ | Baud rate | 00: 4800 bps 01: 9600 bps <u>02: 19200 bps</u> | 02 |
| | L2-□□ | Parity | 00: None 01: Even <u>02: Odd</u> | 02 |
| | L3-□□ | Data length | <u>00: 7 bits</u> 01: 8 bits | 00 |

* The communication parameter (stop bit) is fixed to 1 bit.

F-MPC04S

Communication setting

The communication parameters can be set using keys attached to the front of the power monitor unit.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Setting Code | Item | Setting | Example |
|--------------|--|---|---------|
| L-□□ | Baud rate | 4.8: 4800 bps 9.6: 9600 bps <u>19.2: 19200 bps</u> | 19.2 |
| L2-□□ | Data length and parity | 8n: Data length 8 bits, without parity 8E: Data length 8 bits, even parity 8o: Data length 8 bits, odd parity 7n: Data length 7 bits, without parity 7E: Data length 7 bits, even parity <u>7o: Data length 7 bits, odd parity</u> | 7o |
| LA-□□ | Address (Transmission station number) | <u>Loc: Station number not set</u> 01 to 99 | 01 |
| Lt-□□ | Communication model mode | 04: F-MPC04 mode *1 PP: PPM (B) mode | 04 |

*1 The communication function of F-MPC04 can be selected at the time of purchase. Select a model on which "F-MPC04 mode" is available.


*2 The communication parameter (stop bit) is fixed to 1 bit.

F-MPC30

Communication setting

The communication parameters can be set using keys attached to the front of the power monitor unit.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Setting Code | Item | Setting | Example |
|--------------|-----------------------------------|--|---------|
| 90 | RS-485 address setting | <u>Loc: Communication not used</u> 01 to 99 | 01 |
| 91 | RS-485 transmission specification | <p>7SEG LED</p>  <p>Parity n: None E: Even o: Odd</p> <p>Data length 7: 7 bits 8: 8 bits</p> <p>Baud rate 48: 4800 bps 96: 9600 bps 192: 19200 bps</p> <p>* "b192E" is set as default.</p> | 1927o |


* The communication parameter (stop bit) is fixed to 1 bit.

F-MPC50/F-MPC55/F-MPC60B (UM4Bx, UM42xx, UM43xx)

Communication setting

The communication parameters can be set using keys attached to the front of the power monitor unit.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Setting Code | Item | Setting | Example |
|--------------|-----------------------------------|---|---------|
| 90 | RS-485 address setting | <u>Loc: communication not used</u> 01 to 99 | 01 |
| 91 | RS-485 transmission specification | 7SEG LED  <p>Parity n: None E: Even <u>o: Odd</u></p> <p>Data length <u>7: 7 bits</u> 8: 8 bits</p> <p>Baud rate 48: 4800 bps 96: 9600 bps <u>192: 19200 bps</u></p> | 1927o |


* The communication parameter (stop bit) is fixed to 1 bit.

F-MPC60B (UM44xx)

Communication setting

The communication parameters can be set using keys attached to the front of the power monitor unit.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Setting Code | Item | Setting | Example |
|--------------|-----------------------------------|---|---------|
| 90 | RS-485 address setting | <u>Loc: communication not used</u> 01 to 99 | 01 |
| 91 | RS-485 transmission specification | 7SEG LED  <p>Parity <u>n: None</u> E: Even o: Odd</p> <p>Data length <u>7: 7 bits</u> 8: 8 bits</p> <p>Baud rate 48: 4800 bps <u>96: 9600 bps</u> 192: 19200 bps</p> | 1927o |

* The communication parameter (stop bit) is fixed to 1 bit.

FePSU

Communication setting

The communication parameters can be set using keys attached to the front of the power monitor unit.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Type | Parameter Display | Item | Setting | Example |
|-------|-------------------|------------------------------|---|---------|
| SEL-c | Adr. □ □ | Communicating station number | <u>Loc: Communication not used</u> 01 to 99 | 01 |
| | bud □ □ | Baud rate | 4.8: 4800 bps 9.6: 9600 bps <u>19.2: 19200 bps</u> | 19.2 |
| | cbit. □ □ | Data length, parity | 8n: Data length 8 bits, without parity 8E: Data length 8 bits, even parity 8o: Data length 8 bits, odd parity 7n: Data length 7 bits, without parity 7E: Data length 7 bits, even parity <u>7o: Data length 7 bits, odd parity</u> | 7o |
| | LtY. □ □ | Communication Mode | <u>Psu: FePSU mode</u> *1 _PP: PPM(B) mode | Psu |

*1 The communication function of FePSU can be selected at the time of purchase. Select a model on which "FePSU mode" is available.

*2 The communication parameter (stop bit) is fixed to 1 bit.

F*JF-R**Communication setting**

The communication parameters can be set using keys attached to the front of the digital regular electricity meter.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)


| Type | Item | Setting | Example |
|-----------------------|-------------|--|-----------|
| Communication setting | Address | 01 - 99 | 01 |
| | Baud Rate | 4800 bps / 9600 bps / <u>19.2k bps</u> | 19.2k bps |
| | Data Length | <u>7</u> / 8 bits | 7 bits |
| | Parity Bit | None / Even / <u>Odd</u> | Odd |

* The communication parameter (stop bit) is fixed to 1 bit.

F-MPC04E

Be sure to match the settings to those made under [Communication Setting] of the editor.

Station number

| Station | Setting | Example | Remarks |
|---|------------------------------|---------|--|
|  | 01 to 99 [DEC] (default: 00) | 1 | Communication is not possible with "00". |

Communication setting

The communication parameters can be set using keys attached to the front of the digital regular electricity meter.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Type | Item | Setting | Example |
|-----------------------|---------------------|--|-----------|
| Communication setting | Baud rate | 4800 bps / 9600 bps / <u>19200 bps</u> / 38400 bps | 19200 bps |
| | Data length, parity | 8E / 8o / 8n / 7E / <u>7o</u> / 7n | 7o |

* The communication parameter (stop bit) is fixed to 1 bit.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--|------|------------------------|
| 00 (data request of circuit No. 1 to 4) *1 | 00H | Double-word, read only |
| 01 (data request of circuit No. 5 to 8) *1 | 01H | Double-word, read only |
| 02 (data request of circuit No. 9, 10 or E) *1 | 02H | Double-word, read only |
| 03 (Data request of the minimum/maximum voltage, power factor of circuit 1 to 10, and invalid power) *1 *2 | 03H | Double-word, read only |
| 09 (model code) | 09H | Read only |
| 10 (operation status) | 0AH | Read only |
| 11 (pre-alarm value) *1 | 0BH | Double-word, read only |
| 12 (current value measurement data) *1 *2 | 0CH | Double-word, read only |
| 13 (integrated value data) *1 *2 | 0DH | Double-word, read only |
| 14 (demand measurement data) *1 *2 | 0EH | Double-word, read only |
| 15 (data of a maximum value of demand measurement) *1 *2 | 0FH | Double-word, read only |
| 16 (historical data 1) *1 *2 | 10H | Double-word, read only |
| 17 (historical data 2) | 11H | Double-word, read only |
| 18 (setting data) *3 | 12H | Double-word |
| 50 (9-digit power request) | 32H | Read only, double-word |

*1 When a device memory other than status is used, set the decimal point of the numerical display part to "3".

*2 "0" is stored in the address for which "(Blank)" is indicated in the table below.

*3 For setting data, see "18 (Setting Data)" described below.

18 (Setting Data)

| Address | F-MPC04/F-MPC04P/F-MPC04S | FePSU | F-MPC30/F-MPC50/F-MPC55V/F-MPC60B | F-MPC04E |
|---------|--|--|--|----------------------------|
| 00zz | Wiring method (voltage measured) | (Blank) | CT primary rated current | (Blank) |
| 01zz | Ratio of VT 1 (primary voltage) * ¹ | (Blank) | Ratio of VT (primary voltage) | Ratio of VT * ³ |
| 02zz | Ratio of VT 1 (secondary voltage) * ¹ | (Blank) | Ratio of VT (secondary voltage) | (Blank) |
| 03zz | Demand average time | Demand average time | Rated frequency | (Blank) |
| 04zz | Frequency | (Blank) | Protective INST (current setting)* ² | (Blank) |
| 05zz | Number of applicable circuits | (Blank) | Protective INST (output setting) | (Blank) |
| 06zz | Pulse multiplying factor | (Blank) | Protective DT (current setting)* ² | Pulse multiplying factor |
| 07zz | Ratio of VT 2 (primary voltage) * ¹ | (Blank) | Protective DT (operation time)* ² | (Blank) |
| 08zz | Ratio of VT 2 (secondary voltage) * ¹ | (Blank) | Protective DT (output setting)* ² | (Blank) |
| 09zz | Number of turns for CT2 secondary line | (Blank) | Protective OC (current setting) | (Blank) |
| 10zz | CT primary current * ¹ | (Blank) | Protective OC (characteristic) | CT primary current |
| 11zz | OCG sensitivity current | (Blank) | Protective OC (time magnification)* ² | (Blank) |
| 12zz | OCG operation time * ² | (Blank) | Protective OC (output setting) | (Blank) |
| 13zz | Load pre-alarm sensitivity current | (Blank) | Protective OCA overcurrent pre-alarm (current setting) | (Blank) |
| 14zz | Load pre-alarm operation time | (Blank) | Protective OCA overcurrent pre-alarm (operation time) | (Blank) |
| 15zz | Automatic display circuit register | (Blank) | Protective OCA overcurrent pre-alarm (output setting) | (Blank) |
| 16zz | ZCT select | (Blank) | Protective OCG (51G) (current setting) * ³ | (Blank) |
| 17zz | VT select | (Blank) | Protective OCG (51G) (characteristic) | (Blank) |
| 18zz | (Blank) | (Blank) | Protective OCG (51G) (time magnification) * ² | (Blank) |
| 19zz | (Blank) | (Blank) | Protective OCG (51G) (output setting) | (Blank) |
| 20zz | Phase selection | (Blank) | Protective OCG (50G) (current setting) * ² | (Blank) |
| 21zz | Power alarm upper limit | Power alarm upper limit | Protective OCG (50G) (operation time) * ² | (Blank) |
| 22zz | Integral power pulse multiplying factor * ⁴ | Pulse multiplying factor * ⁴ | Protective OCG (50G) (output setting) | (Blank) |
| 23zz | Load pre-alarm operation value | Load pre-alarm operation value | Protective DG (DG/OCG) (current setting) * ³ | (Blank) |
| 24zz | Load pre-alarm operation time | (Blank) | Protective DG (DG/OCG) (operation time) * ³ | (Blank) |
| 25zz | Leak pre-alarm sensitivity current | Leak pre-alarm sensitivity current | Protect DG (DG/OCG) (output setting) | (Blank) |
| 26zz | Leak pre-alarm operation time * ² | Leak pre-alarm operation time * ² | Protective DG (DG/OCG) (maximum sensitivity phase angle) | (Blank) |
| 27zz | OCG sensitivity current | Leak alarm sensitivity current | Protective DG (DG/OCG) (voltage setting) * ² | (Blank) |
| 28zz | OCG operation time * ² | Leak alarm operation time * ² | Protective DG (DG/OCG) (selected from DG or OCG) | (Blank) |
| 29zz | Operation type for power | Operation type for power | Protective 0 V (voltage setting) | (Blank) |
| 30zz | (Blank) | Phase R input position | Protective 0 V (operation time)* ² | (Blank) |

| Address | F-MPC04/F-MPC04P/F-MPC04S | FePSU | F-MPC30/F-MPC50/F-MPC55V/F-MPC60B | F-MPC04E |
|---------|---------------------------|--|--|----------|
| 31zz | (Blank) | History of turning breaker ON | Protective 0 V (output setting) | (Blank) |
| 32zz | (Blank) | Show/hide cause of trouble | Protective UV (voltage setting) | (Blank) |
| 33zz | (Blank) | Phase interruption alarm of neutral line | Protective UV (operation time)* ² | (Blank) |
| 34zz | (Blank) | Alarm output 1 | Protective UV (output setting) | (Blank) |
| 35zz | (Blank) | Alarm output 2 | Protective UV2 (voltage setting) | (Blank) |
| 36zz | (Blank) | Contact input 1 | Protective UV2 (operation time)* ² | (Blank) |
| 37zz | (Blank) | Contact input 2 | Protective UV2 (output setting) | (Blank) |
| 38zz | (Blank) | (Blank) | Protective UV operation setting | (Blank) |
| 39zz | (Blank) | Rated current (IN) | Voltage establishment VR (voltage setting) | (Blank) |
| 40zz | (Blank) | Current demand time | Voltage establishment VR (operation time) * ² | (Blank) |
| 41zz | (Blank) | Voltage demand time | Voltage establishment VR (output setting) | (Blank) |
| 42zz | (Blank) | Power demand time | Protective OVG (voltage setting)* ² | (Blank) |
| 43zz | (Blank) | Leak demand time | Protective OVG (operation time) | (Blank) |
| 44zz | (Blank) | (Blank) | Protective OVG (output setting) | (Blank) |
| 45zz | (Blank) | (Blank) | ZPD/EVT selection | (Blank) |
| 46zz | (Blank) | (Blank) | Phase interruption relay | (Blank) |
| 47zz | (Blank) | (Blank) | Reverse phase relay | (Blank) |
| 48zz | (Blank) | (Blank) | Demand average time | (Blank) |
| 49zz | (Blank) | Year setting | CB opening jam monitoring time * ³ | (Blank) |
| 50zz | (Blank) | Month setting | CB closing jam monitoring time * ³ | (Blank) |
| 51zz | (Blank) | Date setting | Monitoring trip coil TC disconnection, OFF expedited, function application setting | (Blank) |
| 52zz | (Blank) | Hour setting | kWh pulse constant * ⁵ | (Blank) |
| 53zz | (Blank) | Minute setting | kvarh pulse constant * ⁵ | (Blank) |
| 54zz | (Blank) | (Blank) | Selective input 1 function setting | (Blank) |
| 55zz | (Blank) | (Blank) | Selective input 2 function setting | (Blank) |
| 56zz | (Blank) | (Blank) | Selective input 3 function setting | (Blank) |
| 57zz | (Blank) | (Blank) | Selective input 4 function setting | (Blank) |
| 58zz | (Blank) | (Blank) | Selective input 5 function setting | (Blank) |
| 59zz | (Blank) | (Blank) | Selective input 6 function setting | (Blank) |
| 60zz | (Blank) | (Blank) | Selective input 7 function setting | (Blank) |
| 61zz | (Blank) | (Blank) | Selective input 8 function setting | (Blank) |
| 62zz | (Blank) | (Blank) | Device fault detection function setting | (Blank) |
| 63zz | (Blank) | (Blank) | Fault pick-up output setting | (Blank) |
| 64zz | (Blank) | (Blank) | Transmission component 1 output setting | (Blank) |
| 65zz | (Blank) | (Blank) | Transmission component 2 output setting | (Blank) |
| 66zz | (Blank) | (Blank) | Distant/direct state output setting | (Blank) |
| 67zz | (Blank) | (Blank) | Transducer output current phase setting | (Blank) |
| 68zz | (Blank) | (Blank) | Transducer output voltage phase setting | (Blank) |

| Address | F-MPC04/F-MPC04P/F-MPC04S | FePSU | F-MPC30/F-MPC50/F-MPC55V/F-MPC60B | F-MPC04E |
|---------|---------------------------|---------|--|----------|
| 69zz | (Blank) | (Blank) | Residue/CT 3rd selection (zero-phase current) | (Blank) |
| 70zz | (Blank) | (Blank) | Protective INST (phase N) (current setting)* ² | (Blank) |
| 71zz | (Blank) | (Blank) | Protective INST (phase N) (output setting) | (Blank) |
| 72zz | (Blank) | (Blank) | Protective OC (phase N) (current setting) | (Blank) |
| 73zz | (Blank) | (Blank) | Protective OC (phase N) (characteristic) | (Blank) |
| 74zz | (Blank) | (Blank) | Protective OC (phase N) (time magnification)* ² | (Blank) |
| 75zz | (Blank) | (Blank) | Protective OC (phase N) (output setting) | (Blank) |
| 76zz | (Blank) | (Blank) | Protective OCA overcurrent pre-alarm (phase N) (current setting) | (Blank) |
| 77zz | (Blank) | (Blank) | Protective OCA overcurrent pre-alarm (phase N) (operation time) | (Blank) |
| 78zz | (Blank) | (Blank) | Protective OCA overcurrent pre-alarm (phase N) (output setting) | (Blank) |
| 79zz | (Blank) | (Blank) | Protective OCGA pre-alarm (current setting) | (Blank) |
| 80zz | (Blank) | (Blank) | Protective OCGA pre-alarm (operation time) | (Blank) |
| 81zz | (Blank) | (Blank) | Protective OCGA pre-alarm (output setting) | (Blank) |
| 82zz | (Blank) | (Blank) | Protective DT2 (current setting) | (Blank) |
| 83zz | (Blank) | (Blank) | Protective DT2 (operation time) * ² | (Blank) |
| 84zz | (Blank) | (Blank) | Protective DT2 (output setting) | (Blank) |
| 85zz | (Blank) | (Blank) | Transducer output CH1 setting | (Blank) |
| 86zz | (Blank) | (Blank) | Transducer output CH2 setting | (Blank) |
| 87zz | (Blank) | (Blank) | Transducer output CH3 setting | (Blank) |
| 88zz | (Blank) | (Blank) | Transducer output CH4 setting | (Blank) |
| 89zz | (Blank) | (Blank) | Transducer output CH5 setting | (Blank) |
| 90zz | (Blank) | (Blank) | Transducer output CH6 setting | (Blank) |
| 91zz | (Blank) | (Blank) | External change-over function setting of transducer output | (Blank) |
| 92zz | (Blank) | (Blank) | Display mode selection | (Blank) |

*1 When using a direct value, set [DEC (with sign)] for [Display Format] on the [Num. Display] window.

*2 Specify "1" for [Decimal Point] on the [Num. Display] window.


*3 Specify "2" for [Decimal Point] on the [Num. Display] window.

*4 Specify the multiplying factor in the range of -3 to 2.

*5 Specify the pulse constant in the range of -2 to 4 or F.


Address denotations:

- For the device memory for which the circuit number is set (00 to 02, 12 to 18, 50):



* For circuit No. E, specify "11" for the circuit number.

- For the device memory for which the circuit number is not set (03, 09 to 11):



Note on Setting the Device Memory

Only the "List" file of "F-MPC04S" can be browsed by pressing the [Refer] button by default.

If any power monitor unit other than above is used, refer to each "List" file by pressing the [Refer] button and set the device memory.

PLC_CTL

| Content | F0 | F1 (= \$u n) | | F2 |
|--|---------------------|--------------|---|--|
| kWh integrated value reset ^{*1} | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0 | |
| Max. kW (amount of power) reset | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 1 | |
| Operation control ^{*2} | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 2 | |
| | | n + 2 | 0: Turning ON the input/output 1: Turning ON the output of Power OFF 2: Turning OFF the output of power ON/OFF | |
| Reset all of the demand maximum values ^{*3} | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 3 | |
| Alarm reset ^{*3} | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 4 | |
| Time setting ^{*3} | 1 - 8 (PLC1 - 8) | n | Station number ^{*4} | 8 (9 when broadcast is specified) |
| | | n + 1 | Command: 5 | |
| | | n + 2 | 0: Specific station number 1: Broadcast | |
| | | n + 3 | Year | |
| | | n + 4 | Month | |
| | | n + 5 | Day | |
| | | n + 6 | Hour | |
| | | n + 7 | Minute | |
| | | n + 8 | Second ^{*5} | |
| Reset the maximum and minimum voltage values ^{*6} | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 6 | |
| Entering test mode ^{*6} | 1 - 8 (PLC1 - 8) | n | Station number ^{*4} | 3 |
| | | n + 1 | Command: 7 | |
| | | n + 2 | 0: Specific station number 1: Broadcast | |
| Exiting test mode ^{*6} | 1 - 8 (PLC1 - 8) | n | Station number ^{*4} | 3 |
| | | n + 1 | Command: 8 | |
| | | n + 2 | 0: Specific station number 1: Broadcast | |

^{*1} Not available with F*JF-R.

^{*2} Available only with F-MPC60B.

^{*3} Available only with FePSU.

^{*4} Select station No. 0 for broadcast commands.

^{*5} Can be set only for a broadcast command.

^{*6} Available only with F*JF-R.

21.2.9 FVR-E11S

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

Inverter

Set communication parameters. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example | | | | | | | | | | | | | | | | | | | | |
|---------------|---------------------------|---|-------------------|---------|-----------|-------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| H30 | Link function *1 | <table border="1"> <thead> <tr> <th></th><th>Monitor</th><th>Frequency</th><th>Operation Command</th></tr> </thead> <tbody> <tr> <td>0</td><td>○</td><td>X</td><td>X</td></tr> <tr> <td>1</td><td>○</td><td>○</td><td>X</td></tr> <tr> <td>2</td><td>○</td><td>X</td><td>○</td></tr> <tr> <td>3</td><td>○</td><td>○</td><td>○</td></tr> </tbody> </table> | | Monitor | Frequency | Operation Command | 0 | ○ | X | X | 1 | ○ | ○ | X | 2 | ○ | X | ○ | 3 | ○ | ○ | ○ | 3 |
| | Monitor | Frequency | Operation Command | | | | | | | | | | | | | | | | | | | | |
| 0 | ○ | X | X | | | | | | | | | | | | | | | | | | | | |
| 1 | ○ | ○ | X | | | | | | | | | | | | | | | | | | | | |
| 2 | ○ | X | ○ | | | | | | | | | | | | | | | | | | | | |
| 3 | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | |
| H31 | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | | | | | | |
| H34 | Baud rate | 0: 19200 bps <u>1: 9600 bps</u> 2: 4800 bps | 1 | | | | | | | | | | | | | | | | | | | | |
| H35 | Data length | <u>0: 8 bits</u> 1: 7 bits | 0 | | | | | | | | | | | | | | | | | | | | |
| H36 | Parity bit | <u>0: None</u> 1: Even 2: Odd | 0 | | | | | | | | | | | | | | | | | | | | |
| H37 | Stop bit | <u>0: 1 bits</u> 1: 2 bits | 0 | | | | | | | | | | | | | | | | | | | | |
| - | Communication protocol *2 | "FGI-bus" is set as default. | - | | | | | | | | | | | | | | | | | | | | |

*1 Available when the communication is enabled by digital input.

Example: To make the communication enabled when digital input terminal X1 is turned ON;

Set "18 (link operation)" for function code E01 and turn on the digital input terminal X1 externally.

Terminals from X2 to X5 can also be used. Set the function code corresponding to the digital input terminal to use.

*2 When "FVR-E11S" is selected for model selection on the editor, use "FGI-bus" for the communication protocol on the inverter.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|-------------------------|------|-------------|
| S (command data) | 00H | |
| M (monitor data) | 01H | Double-word |
| F (basic function) | 02H | |
| E (terminal function) | 03H | |
| C (control function) | 04H | |
| P (motor 1) | 05H | |
| H (high level function) | 06H | |
| A (motor 2) | 07H | |
| o (optional function) | 08H | |

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---------------|---------------------|--------------|----------------|----|
| Reset command | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0 | |

21.2.10 FVR-E11S (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|------------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

Inverter

Be sure to match the communication settings of the inverter to those made on the editor.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.11 FVR-C11S (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 / <u>2</u> bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

Inverter

Be sure to match the communication settings of the inverter to those made on the editor.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.12 FRENIC5000 G11S / P11S

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | 1 / <u>2</u> bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | | | | Example |
|---------------|--------------------------|--|----------------------------------|-------------------|-------------------|---------|
| H30 | Link function *1 | | | | | 3 |
| | | | Writing of Monitor/function Data | Frequency Setting | Operation Command | |
| | | 0 | ○ | X | X | |
| | | 1 | ○ | ○ | X | |
| | | 2 | ○ | X | ○ | |
| | | 3 | ○ | ○ | ○ | |
| H31 | Station address | 1 to 31 | | | | 1 |
| H34 | Baud rate | 0: 19200 bps 1: 9600 bps 2: 4800 bps | | | | 1 |
| H35 | Data length | 0: 8 bits 1: 7 bits | | | | 0 |
| H36 | Parity bit | 0: None 1: Even 2: Odd | | | | 0 |
| H37 | Stop bit | 0: 2 bits 1: 1 bit | | | | 0 |
| U49 | Communication protocol*2 | 0: FGI-bus 1: Modbus RTU | | | | 1 |

*1 Available when the communication is enabled by digital input.

Example: To make the communication enabled when digital input terminal X1 is turned ON;

Set "24 (link operation)" for function code E01 and turn on the digital input terminal X1 externally.

Terminals from X2 to X9 can also be used. Set the function code corresponding to the digital input terminal to use.

*2 When "FRENIC5000G11S/P11S" is selected for model selection on the editor, select "FGI-bus" for the communication protocol on the inverter.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|-------------------------|------|------------------------|
| S (command data) | 00H | |
| M (monitor data) | 01H | Double-word, read only |
| F (basic function) | 02H | |
| E (terminal function) | 03H | |
| C (control function) | 04H | |
| P (motor 1) | 05H | |
| H (high level function) | 06H | |
| A (motor 2) | 07H | |
| o (optional function) | 08H | |
| U (user function) | 0AH | |

Indirect Device Memory Designation

- When "S" (command data) or "M" (monitor data) is used:
For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---------------|---------------------|--------------|----------------|----|
| Reset command | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0 | |

21.2.13 FRENIC5000 G11S / P11S (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Data Length | <u>8</u> bits | |
| Stop Bit | 1 / <u>2</u> bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | | | | Example |
|---------------|--------------------------|--|----------------------------------|-------------------|-------------------|---------|
| H30 | Link function *1 | | Writing of Monitor/function Data | Frequency Setting | Operation Command | 3 |
| | | 0 | ○ | X | X | |
| | | 1 | ○ | ○ | X | |
| | | 2 | ○ | X | ○ | |
| | | 3 | ○ | ○ | ○ | |
| H31 | Station address | 1 to 31 | | | | 1 |
| H34 | Baud rate | 0: 19200 bps 1: 9600 bps 2: 4800 bps | | | | 1 |
| H35 | Data length | 0: 8 bits 1: 7 bits | | | | 0 |
| H36 | Parity bit | 0: None 1: Even 2: Odd | | | | 0 |
| H37 | Stop bit | 0: 2 bits 1: 1 bit | | | | 0 |
| U49 | Communication protocol*2 | 0: FGI-bus 1: Modbus RTU | | | | 1 |

*1 Available when the communication is enabled by digital input.

Example: To make the communication enabled when digital input terminal X1 is turned ON;

Set "24 (link operation)" for function code E01 and turn on the digital input terminal X1 externally.

Terminals from X2 to X9 can also be used. Set the function code corresponding to the digital input terminal to use.

*2 When "FRENIC5000G11S/P11S (MODBUS RTU)" is selected for model selection on the editor, select "Modbus RTU" for the communication protocol on the inverter.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.14 FRENIC5000 VG7S (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / 9600 / 19200 / <u>38400</u> bps | |
| Data Length | 8 bits | Do not change the default setting because the setting on the inverter cannot be changed. |
| Stop Bit | <u>1</u> / 2 bits* ¹ | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

*1 When no parity setting is made, set "2 bits" for stop bit.
When a parity setting (even or odd) is made, set "1 bit" for stop bit.

When Connecting to the Built-in RS-485 Port on the Inverter:

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example | | | | | | | | | | | | | | | | | | | | |
|---------------|--------------------------------------|---|-------------------|----------------------------------|-------------------|-------------------|----------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| H30 | Link function * ¹ | <table><tr><td></td><td>Writing of Monitor/function Data</td><td>Frequency Setting</td><td>Operation Command</td></tr><tr><td><u>0</u></td><td>○</td><td>X</td><td>X</td></tr><tr><td>1</td><td>○</td><td>○</td><td>X</td></tr><tr><td>2</td><td>○</td><td>X</td><td>○</td></tr><tr><td>3</td><td>○</td><td>○</td><td>○</td></tr></table> | | Writing of Monitor/function Data | Frequency Setting | Operation Command | <u>0</u> | ○ | X | X | 1 | ○ | ○ | X | 2 | ○ | X | ○ | 3 | ○ | ○ | ○ | 3 |
| | Writing of Monitor/function Data | Frequency Setting | Operation Command | | | | | | | | | | | | | | | | | | | | |
| <u>0</u> | ○ | X | X | | | | | | | | | | | | | | | | | | | | |
| 1 | ○ | ○ | X | | | | | | | | | | | | | | | | | | | | |
| 2 | ○ | X | ○ | | | | | | | | | | | | | | | | | | | | |
| 3 | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | |
| H31 | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | | | | | | |
| H34 | Baud rate | <u>0: 38400 bps</u> 1: 19200 bps 2: 9600 bps 3: 4800 bps | 0 | | | | | | | | | | | | | | | | | | | | |
| H36 | Parity bit | 0: None <u>1: Even</u> 2: Odd | 1 | | | | | | | | | | | | | | | | | | | | |
| H37 | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When no parity setting is made, “2 bits” is set for stop bit. When a parity setting (even or odd) is made, “1 bit” is set for stop bit. | 1 | | | | | | | | | | | | | | | | | | | | |
| H40 | Communication protocol* ² | 0: FGI-bus <u>1: SX (loader) protocol</u> 2: Modbus RTU | 2 | | | | | | | | | | | | | | | | | | | | |

* The communication parameter (data length) is fixed to 8 bits.

When Connecting to the Terminal Block on "OPC-VG7-RS" (Optional Communication Board):

Communication setting

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example | | | | | | | | | | | | | | | | | | | | |
|---------------|----------------------------------|---|-------------------|----------------------------------|-------------------|-------------------|----------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| H30 | Link function *1 | <table border="1"> <thead> <tr> <th></th><th>Writing of Monitor/function Data</th><th>Frequency Setting</th><th>Operation Command</th></tr> </thead> <tbody> <tr> <td><u>0</u></td><td>○</td><td>X</td><td>X</td></tr> <tr> <td>1</td><td>○</td><td>○</td><td>X</td></tr> <tr> <td>2</td><td>○</td><td>X</td><td>○</td></tr> <tr> <td>3</td><td>○</td><td>○</td><td>○</td></tr> </tbody> </table> | | Writing of Monitor/function Data | Frequency Setting | Operation Command | <u>0</u> | ○ | X | X | 1 | ○ | ○ | X | 2 | ○ | X | ○ | 3 | ○ | ○ | ○ | 3 |
| | Writing of Monitor/function Data | Frequency Setting | Operation Command | | | | | | | | | | | | | | | | | | | | |
| <u>0</u> | ○ | X | X | | | | | | | | | | | | | | | | | | | | |
| 1 | ○ | ○ | X | | | | | | | | | | | | | | | | | | | | |
| 2 | ○ | X | ○ | | | | | | | | | | | | | | | | | | | | |
| 3 | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | |
| H31 | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | | | | | | |
| o37 | Communication definition setting | | 10 | | | | | | | | | | | | | | | | | | | | |
| H40 | Communication protocol*2 | 0: FGI-bus <u>1: SX (loader) protocol</u> 2: Modbus RTU | 2 | | | | | | | | | | | | | | | | | | | | |

*1 Available when the communication is enabled by digital input.

Example: To make the communication enabled when digital input terminal X1 is turned ON;

Set "24 (link operation)" for function code E01 and turn on the digital input terminal X1 externally.

*2 When "FRENIC5000G11S/P11S (MODBUS RTU)" is selected for model selection on the editor, select "Modbus RTU" for the communication protocol on the inverter.

*3 The communication parameter (data length) is fixed to 8 bits.

Notes on Using "OPC-VG7-RS" (Optional Communication Board)

Set the DIPSW2 on the optional communication board "OPC-VG7-RS" as shown below when connecting the TS2060 and the terminal block of the board.

The underlined settings are set as default.

| SW2 | SW2-1 Setting | SW2-2 Setting | Function | Remarks |
|-----|---------------|---------------|--------------------------------------|--|
| | OFF | OFF | - | - |
| | ON | OFF | - | - |
| | <u>OFF</u> | <u>ON</u> | Optional communication board enabled | Do not change the default setting when connecting with the TS2060. |
| | ON | ON | - | - |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.15 FRENIC-Mini (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> bps | |
| Data Length | 8 bits | Do not change the default setting because the setting on the inverter cannot be changed. |
| Stop bit | 1 / <u>2</u> bits*1 | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

- *1 When no parity setting is made, "2 bits" is set for stop bit.
When a parity setting (even or odd) is made, "1 bit" is set for stop bit.

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example | | | | | | | | | | | | | | | |
|---------------|--------------------------------------|--|---------|-----------|-------------------|----------|-------------------|-------------------|---|-----------------------|-------------------|---|-------------------|-----------------------|---|-----------------------|-----------------------|---|
| y01 | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | |
| y04 | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> | 3 | | | | | | | | | | | | | | | |
| y06 | Parity bit | <u>0: None</u> 1: Even 2: Odd | 0 | | | | | | | | | | | | | | | |
| y07 | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When no parity setting is made, "2 bits" is set for stop bit. When a parity setting (even or odd) is made, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y10 | Communication protocol* ¹ | 0: Modbus RTU <u>1: SX (loader) protocol</u> 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y99 | Support link function | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td><u>0</u></td><td>Function code H30</td><td>Function code H30</td></tr><tr><td>1</td><td>Commanded from RS-485</td><td>Function code H30</td></tr><tr><td>2</td><td>Function code H30</td><td>Commanded from RS-485</td></tr><tr><td>3</td><td>Commanded from RS-485</td><td>Commanded from RS-485</td></tr></table> | | Frequency | Operation Command | <u>0</u> | Function code H30 | Function code H30 | 1 | Commanded from RS-485 | Function code H30 | 2 | Function code H30 | Commanded from RS-485 | 3 | Commanded from RS-485 | Commanded from RS-485 | 0 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | |
| <u>0</u> | Function code H30 | Function code H30 | | | | | | | | | | | | | | | | |
| 1 | Commanded from RS-485 | Function code H30 | | | | | | | | | | | | | | | | |
| 2 | Function code H30 | Commanded from RS-485 | | | | | | | | | | | | | | | | |
| 3 | Commanded from RS-485 | Commanded from RS-485 | | | | | | | | | | | | | | | | |
| H30 | Link function * ² | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td><u>0</u></td><td>Inverter</td><td>Inverter</td></tr><tr><td>1</td><td>RS-485 communication</td><td>Inverter</td></tr><tr><td>2</td><td>Inverter</td><td>RS-485 communication</td></tr><tr><td>3</td><td>RS-485 communication</td><td>RS-485 communication</td></tr></table> | | Frequency | Operation Command | <u>0</u> | Inverter | Inverter | 1 | RS-485 communication | Inverter | 2 | Inverter | RS-485 communication | 3 | RS-485 communication | RS-485 communication | 3 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | |
| <u>0</u> | Inverter | Inverter | | | | | | | | | | | | | | | | |
| 1 | RS-485 communication | Inverter | | | | | | | | | | | | | | | | |
| 2 | Inverter | RS-485 communication | | | | | | | | | | | | | | | | |
| 3 | RS-485 communication | RS-485 communication | | | | | | | | | | | | | | | | |

- *1 Select "Modbus RTU" for the communication protocol on the inverter when connecting with the TS2060.

- *2 When "0" is specified for y99 (support link function), command from function code H30 is valid for the frequency setting and operation command.

- *3 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| --- | 02H | |

Address denotations XYYY

Function code identification number
 Function code group

| Group | Code | Name |
|-------|------|-----------------------|
| F | 00H | Basic function |
| E | 01H | Terminal function |
| C | 02H | Control function |
| P | 03H | Motor parameter |
| H | 04H | High level function |
| S | 07H | Command/function data |
| M | 08H | Monitor data |
| J | 0DH | Application function |
| y | 0EH | Link function |
| W | 0FH | Monitor 2 |
| X | 10H | Alarm 1 |
| Z | 11H | Alarm 2 |

21.2.16 FRENIC-Eco (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | 8 bits | Do not change the default setting because the setting on the inverter cannot be changed. |
| Stop Bit | 1 / <u>2</u> bits | When no parity setting is made, "2 bits" is set for stop bit. |
| Parity | <u>None</u> / Odd / Even | When a parity setting is made, "1 bit" is set for stop bit. |
| Target Port No. | <u>1</u> to 31 | |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | | Setting | Example | | | | | | | | | | | | | | | |
|---------------|-----------------------------------|--------------------------------------|--|---------|-----------|-------------------|----------|------------------------|------------------------|---|-----------------------------|------------------------|---|------------------------|-----------------------------|---|-----------------------------|-----------------------------|---|
| y01 | RS-485 setting (touch panel) | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | |
| y04 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y06 | | Parity bit | <u>0: None</u> 1: Even 2: Odd | 0 | | | | | | | | | | | | | | | |
| y07 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When no parity setting is made, "2 bits" is set for stop bit. When a parity setting (even or odd) is made, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y10 | | Communication protocol* ¹ | 0: Modbus RTU <u>1: SX (loader) protocol</u> 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y11 | RS-485 setting 2 (optional board) | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | |
| y14 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y16 | | Parity bit | <u>0: None</u> 1: Even 2: Odd | 0 | | | | | | | | | | | | | | | |
| y17 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When no parity setting is made, "2 bits" is set for stop bit. When a parity setting (even or odd) is made, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y20 | | Communication protocol* ¹ | 0: Modbus RTU 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y98 | Bus function | | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td><u>0</u></td><td>Function code H30</td><td>Function code H30</td></tr><tr><td>1</td><td>Commanded from the fieldbus</td><td>Function code H30</td></tr><tr><td>2</td><td>Function code H30</td><td>Commanded from the fieldbus</td></tr><tr><td>3</td><td>Commanded from the fieldbus</td><td>Commanded from the fieldbus</td></tr></table> | | Frequency | Operation Command | <u>0</u> | Function code H30 | Function code H30 | 1 | Commanded from the fieldbus | Function code H30 | 2 | Function code H30 | Commanded from the fieldbus | 3 | Commanded from the fieldbus | Commanded from the fieldbus | 0 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | |
| <u>0</u> | Function code H30 | Function code H30 | | | | | | | | | | | | | | | | | |
| 1 | Commanded from the fieldbus | Function code H30 | | | | | | | | | | | | | | | | | |
| 2 | Function code H30 | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |
| 3 | Commanded from the fieldbus | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |
| y99 | Support link function | | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td><u>0</u></td><td>Function code H30, y98</td><td>Function code H30, y98</td></tr><tr><td>1</td><td>Commanded from RS-485</td><td>Function code H30, y98</td></tr><tr><td>2</td><td>Function code H30, y98</td><td>Commanded from RS-485</td></tr><tr><td>3</td><td>Commanded from RS-485</td><td>Commanded from RS-485</td></tr></table> | | Frequency | Operation Command | <u>0</u> | Function code H30, y98 | Function code H30, y98 | 1 | Commanded from RS-485 | Function code H30, y98 | 2 | Function code H30, y98 | Commanded from RS-485 | 3 | Commanded from RS-485 | Commanded from RS-485 | 0 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | |
| <u>0</u> | Function code H30, y98 | Function code H30, y98 | | | | | | | | | | | | | | | | | |
| 1 | Commanded from RS-485 | Function code H30, y98 | | | | | | | | | | | | | | | | | |
| 2 | Function code H30, y98 | Commanded from RS-485 | | | | | | | | | | | | | | | | | |
| 3 | Commanded from RS-485 | Commanded from RS-485 | | | | | | | | | | | | | | | | | |

| Function Code | Item | Setting | | Example |
|---------------|-----------------------------|---------|--|---------|
| H30 | Link function ^{*2} | | | 3 |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

*1 Select "Modbus RTU" for the communication protocol on the inverter when connecting with the TS2060.

*2 When "0" is specified for y98 (bus function) as well as y99 (support link function), the frequency and operation command can be set on the TS2060.
When making the frequency and operation command settings on the TS2060 connected to the connector for the touch panel, specify "3" for function code H30. When making those settings on the TS2060 connected to the optional communication board, specify "8" for function code H30.

*3 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.17 FRENIC-Multi (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | 8 bits | Do not change the default setting because the setting on the inverter cannot be changed. |
| Stop Bit | 1 / <u>2</u> bits | On the inverter: 2 bits when "0" is specified for y06 or y16 1 bit when "1", "2" or "3" is specified for y06 or y16 |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | | Setting | Example | | | | | | | | | | | | | | | |
|---------------|-----------------------------------|--------------------------------------|--|---------|-----------|-------------------|----------|-------------------|-------------------|---|-----------------------------|-------------------|---|-------------------|-----------------------------|---|-----------------------------|-----------------------------|---|
| y01 | RS-485 setting (touch panel) | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | |
| y04 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y06 | | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 | | | | | | | | | | | | | | | |
| y07 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y06, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y06, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y10 | | Communication protocol ^{*1} | 0: Modbus RTU <u>1: SX (loader) protocol</u> 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y11 | RS-485 setting 2 (optional board) | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | |
| y14 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y16 | | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 | | | | | | | | | | | | | | | |
| y17 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y16, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y16, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y20 | | Communication protocol ^{*1} | 0: Modbus RTU 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y98 | Bus function | | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td><u>0</u></td><td>Function code H30</td><td>Function code H30</td></tr><tr><td>1</td><td>Commanded from the fieldbus</td><td>Function code H30</td></tr><tr><td>2</td><td>Function code H30</td><td>Commanded from the fieldbus</td></tr><tr><td>3</td><td>Commanded from the fieldbus</td><td>Commanded from the fieldbus</td></tr></table> | | Frequency | Operation Command | <u>0</u> | Function code H30 | Function code H30 | 1 | Commanded from the fieldbus | Function code H30 | 2 | Function code H30 | Commanded from the fieldbus | 3 | Commanded from the fieldbus | Commanded from the fieldbus | 0 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | |
| <u>0</u> | Function code H30 | Function code H30 | | | | | | | | | | | | | | | | | |
| 1 | Commanded from the fieldbus | Function code H30 | | | | | | | | | | | | | | | | | |
| 2 | Function code H30 | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |
| 3 | Commanded from the fieldbus | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |

| Function Code | Item | Setting | | | Example |
|---------------|-----------------------|---------|---------------------------------|---------------------------------|---------|
| y99 | Support link function | | Frequency | Operation Command | 0 |
| | | 0 | Function code H30, y98 | Function code H30, y98 | |
| | | 1 | Commanded from RS-485 | Function code H30, y98 | |
| | | 2 | Function code H30, y98 | Commanded from RS-485 | |
| | | 3 | Commanded from RS-485 | Commanded from RS-485 | |
| H30 | Link function *2 | | Frequency | Operation Command | 3 |
| | | 0 | Inverter | Inverter | |
| | | 1 | RS-485 communication | Inverter | |
| | | 2 | Inverter | RS-485 communication | |
| | | 3 | RS-485 communication | RS-485 communication | |
| | | 4 | RS-485 communication (optional) | Inverter | |
| | | 5 | RS-485 communication (optional) | RS-485 communication | |
| | | 6 | Inverter | RS-485 communication (optional) | |
| | | 7 | RS-485 communication | RS-485 communication (optional) | |
| | | 8 | RS-485 communication (optional) | RS-485 communication (optional) | |

*1 Select "Modbus RTU" for the communication protocol on the inverter when connecting with the TS2060.

*2 When "0" is specified for y98 (bus function) as well as y99 (support link function), the frequency and operation command can be set on the TS2060.
When making the frequency and operation command settings on the TS2060 connected to the connector for the touch panel, specify "3" for function code H30. When making those settings on the TS2060 connected to the optional communication board, specify "8" for function code H30.

*3 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.18 FRENIC-MEGA (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | 8 bits | Do not change the default setting because the setting on the inverter cannot be changed. |
| Stop Bit | 1 / <u>2</u> bits | On the inverter: 2 bits when "0" is specified for y06 or y16 1 bit when "1", "2" or "3" is specified for y06 or y16 |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 31 | |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | | Setting | Example | | | | | | | | | | | | | | | |
|---------------|------------------------------------|--------------------------------------|--|---------|-----------|-------------------|----------|-------------------|-------------------|---|-----------------------------|-------------------|---|-------------------|-----------------------------|---|-----------------------------|-----------------------------|---|
| y01 | RS-485 setting (touch panel) | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | |
| y04 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y06 | | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 | | | | | | | | | | | | | | | |
| y07 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y06, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y06, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y10 | | Communication protocol ^{*1} | 0: Modbus RTU <u>1: SX (loader) protocol</u> 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y11 | RS-485 setting 2 (control circuit) | Station address | <u>1</u> to 31 | 1 | | | | | | | | | | | | | | | |
| y14 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y16 | | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 | | | | | | | | | | | | | | | |
| y17 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y16, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y16, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y20 | | Communication protocol ^{*1} | 0: Modbus RTU 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y98 | Bus function | | <table><tr><td></td><th>Frequency</th><th>Operation Command</th></tr><tr><td><u>0</u></td><td>Function code H30</td><td>Function code H30</td></tr><tr><td>1</td><td>Commanded from the fieldbus</td><td>Function code H30</td></tr><tr><td>2</td><td>Function code H30</td><td>Commanded from the fieldbus</td></tr><tr><td>3</td><td>Commanded from the fieldbus</td><td>Commanded from the fieldbus</td></tr></table> | | Frequency | Operation Command | <u>0</u> | Function code H30 | Function code H30 | 1 | Commanded from the fieldbus | Function code H30 | 2 | Function code H30 | Commanded from the fieldbus | 3 | Commanded from the fieldbus | Commanded from the fieldbus | 0 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | |
| <u>0</u> | Function code H30 | Function code H30 | | | | | | | | | | | | | | | | | |
| 1 | Commanded from the fieldbus | Function code H30 | | | | | | | | | | | | | | | | | |
| 2 | Function code H30 | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |
| 3 | Commanded from the fieldbus | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |

| Function Code | Item | Setting | | | Example |
|---------------|-----------------------|---------|--|--|---------|
| y99 | Support link function | | Frequency | Operation Command | 0 |
| | | 0 | Function code H30, y98 | Function code H30, y98 | |
| | | 1 | Commanded from the loader | Function code H30, y98 | |
| | | 2 | Function code H30, y98 | Commanded from the loader | |
| | | 3 | Commanded from the loader | Commanded from the loader | |
| H30 | Link function *2 | | Frequency | Operation Command | 3 |
| | | 0 | Inverter | Inverter | |
| | | 1 | RS-485 communication | Inverter | |
| | | 2 | Inverter | RS-485 communication | |
| | | 3 | RS-485 communication | RS-485 communication | |
| | | 4 | RS-485 communication (control circuit) | Inverter | |
| | | 5 | RS-485 communication (control circuit) | RS-485 communication | |
| | | 6 | Inverter | RS-485 communication (control circuit) | |
| | | 7 | RS-485 communication | RS-485 communication (control circuit) | |
| | | 8 | RS-485 communication (control circuit) | RS-485 communication (control circuit) | |

*1 Select "Modbus RTU" for the communication protocol on the inverter when connecting with the TS2060.

*2 When "0" is specified for y98 (bus function) as well as y99 (support link function), the frequency and operation command can be set on the TS2060.
When making the frequency and operation command settings on the TS2060 connected to the connector for the touch panel, specify "3" for function code H30. When making those settings on the TS2060 connected to the terminal block on control circuit, specify "8" for function code H30.

*3 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.19 FRENIC-MEGA SERVO (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | 1 / <u>2</u> bits | On the inverter: 2 bits when "0" is specified for y06 or y16 1 bit when "1", "2" or "3" is specified for y06 or y16 |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | 0 to 247 | 0: Broadcast |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | | Item | Setting | Example | | | | | | | | | | | | | | | |
|---------------|---------------------------------------|---|---|---------|-----------|-------------------|---|-------------------|-------------------|---|-----------------------------|-------------------|---|-------------------|-----------------------------|---|-----------------------------|-----------------------------|---|
| y01 | RS-485 setting 1 (Touch panel) | Station address | <u>1</u> to 247 | 1 | | | | | | | | | | | | | | | |
| y04 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y06 | | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 | | | | | | | | | | | | | | | |
| y07 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y06, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y06, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y10 | | Communication protocol *1 | 0: Modbus RTU <u>1: SX (loader) protocol</u> 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y11 | RS-485 setting 2 (Control circuit) | Station address | <u>1</u> to 247 | 1 | | | | | | | | | | | | | | | |
| y14 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y16 | | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 | | | | | | | | | | | | | | | |
| y17 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y16, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y16, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y20 | | Communication protocol *1 | 0: Modbus RTU 2: FGI-bus | 0 | | | | | | | | | | | | | | | |
| y98 | Bus function | <table><tr><td></td><td>Frequency</td><td>Operation Command</td></tr><tr><td>Q</td><td>Function code H30</td><td>Function code H30</td></tr><tr><td>1</td><td>Commanded from the fieldbus</td><td>Function code H30</td></tr><tr><td>2</td><td>Function code H30</td><td>Commanded from the fieldbus</td></tr><tr><td>3</td><td>Commanded from the fieldbus</td><td>Commanded from the fieldbus</td></tr></table> | | | Frequency | Operation Command | Q | Function code H30 | Function code H30 | 1 | Commanded from the fieldbus | Function code H30 | 2 | Function code H30 | Commanded from the fieldbus | 3 | Commanded from the fieldbus | Commanded from the fieldbus | 0 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | |
| Q | Function code H30 | Function code H30 | | | | | | | | | | | | | | | | | |
| 1 | Commanded from the fieldbus | Function code H30 | | | | | | | | | | | | | | | | | |
| 2 | Function code H30 | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |
| 3 | Commanded from the fieldbus | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |

| Function Code | Item | Setting | | | Example |
|---------------|-----------------------|---------|--|--|---------|
| y99 | Support link function | | Frequency | Operation Command | 0 |
| | | 0 | Function code H30, y98 | Function code H30, y98 | |
| | | 1 | Commanded from FRENIC loader | Function code H30, y98 | |
| | | 2 | Function code H30, y98 | Commanded from FRENIC loader | |
| | | 3 | Commanded from FRENIC loader | Commanded from FRENIC loader | |
| H30 | Link function *2 | | Frequency | Operation Command | 3 |
| | | 0 | Inverter | Inverter | |
| | | 1 | RS-485 communication | Inverter | |
| | | 2 | Inverter | RS-485 communication | |
| | | 3 | RS-485 communication | RS-485 communication | |
| | | 4 | RS-485 communication (Control circuit) | Inverter | |
| | | 5 | RS-485 communication (Control circuit) | RS-485 communication | |
| | | 6 | Inverter | RS-485 communication (Control circuit) | |
| | | 7 | RS-485 communication | RS-485 communication (Control circuit) | |
| | | 8 | RS-485 communication (Control circuit) | RS-485 communication (Control circuit) | |

*1 Select "Modbus RTU" for the communication protocol on the inverter when connecting with the TS2060.

*2 When "0" is specified for y98 (bus function) as well as y99 (support link function), the frequency and operation command can be set on the TS2060.

When making frequency and operation command settings on the TS2060 connected to the connector for the touch panel, specify "3" for function code H30. When making the settings on the TS2060 connected to the control circuit terminal block, specify "8" for H30.

*3 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.20 FRENIC-HVAC/AQUA (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | 1 / <u>2</u> bits | On the inverter: 2 bits when "0" is specified for y06 or y16 1 bit when "1", "2" or "3" is specified for y06 or y16 |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | 0 to 247 | 0: Broadcast |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | | Item | Setting | Example | | | | | | | | | | | | | | | |
|---------------|--------------------------------------|---|---|---------|-----------|-------------------|---|-------------------|-------------------|---|-----------------------------|-------------------|---|-------------------|-----------------------------|---|-----------------------------|-----------------------------|---|
| y01 | RS-485 setting 1 (Touch panel) | Station address | <u>1</u> to 247 | 1 | | | | | | | | | | | | | | | |
| y04 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y06 | | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 | | | | | | | | | | | | | | | |
| y07 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y06, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y06, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y10 | | Communication protocol *1 | 0: Modbus RTU | 0 | | | | | | | | | | | | | | | |
| y11 | RS-485 setting 2 (terminal block) | Station address | <u>1</u> to 247 | 1 | | | | | | | | | | | | | | | |
| y14 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | | | | | | | | | | | | | | |
| y16 | | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 | | | | | | | | | | | | | | | |
| y17 | | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y16, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y16, "1 bit" is set for stop bit. | - | | | | | | | | | | | | | | | |
| y20 | | Communication protocol *1 | 0: Modbus RTU | 0 | | | | | | | | | | | | | | | |
| y98 | Bus function | <table><tr><td></td><td>Frequency</td><td>Operation Command</td></tr><tr><td>0</td><td>Function code H30</td><td>Function code H30</td></tr><tr><td>1</td><td>Commanded from the fieldbus</td><td>Function code H30</td></tr><tr><td>2</td><td>Function code H30</td><td>Commanded from the fieldbus</td></tr><tr><td>3</td><td>Commanded from the fieldbus</td><td>Commanded from the fieldbus</td></tr></table> | | | Frequency | Operation Command | 0 | Function code H30 | Function code H30 | 1 | Commanded from the fieldbus | Function code H30 | 2 | Function code H30 | Commanded from the fieldbus | 3 | Commanded from the fieldbus | Commanded from the fieldbus | 0 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | |
| 0 | Function code H30 | Function code H30 | | | | | | | | | | | | | | | | | |
| 1 | Commanded from the fieldbus | Function code H30 | | | | | | | | | | | | | | | | | |
| 2 | Function code H30 | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |
| 3 | Commanded from the fieldbus | Commanded from the fieldbus | | | | | | | | | | | | | | | | | |

| Function Code | Item | Setting | Example | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|--|--|---------|-----------|-------------------|---|------------------------|------------------------|---|------------------------------|------------------------|---|------------------------|----------------------------|---|----------------------------|----------------------------|---|--|----------|---|--|----------------------|---|----------|--|---|----------------------|--|---|--|--|---|
| y99 | Support link function | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td>0</td><td>Function code H30, y98</td><td>Function code H30, y98</td></tr><tr><td>1</td><td>Commanded from FRENIC loader</td><td>Function code H30, y98</td></tr><tr><td>2</td><td>Function code H30, y98</td><td>Command from FRENIC loader</td></tr><tr><td>3</td><td>Command from FRENIC loader</td><td>Command from FRENIC loader</td></tr></table> | | Frequency | Operation Command | 0 | Function code H30, y98 | Function code H30, y98 | 1 | Commanded from FRENIC loader | Function code H30, y98 | 2 | Function code H30, y98 | Command from FRENIC loader | 3 | Command from FRENIC loader | Command from FRENIC loader | 0 | | | | | | | | | | | | | | | |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Function code H30, y98 | Function code H30, y98 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Commanded from FRENIC loader | Function code H30, y98 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Function code H30, y98 | Command from FRENIC loader | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Command from FRENIC loader | Command from FRENIC loader | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H30 | Link function *2 | <table><tr><th></th><th>Frequency</th><th>Operation command</th></tr><tr><td>0</td><td>Inverter</td><td>Inverter</td></tr><tr><td>1</td><td>RS-485 communication</td><td>Inverter</td></tr><tr><td>2</td><td>Inverter</td><td>RS-485 communication</td></tr><tr><td>3</td><td>RS-485 communication</td><td>RS-485 communication</td></tr><tr><td>4</td><td>RS-485 communication (Control circuit)</td><td>Inverter</td></tr><tr><td>5</td><td>RS-485 communication (Control circuit)</td><td>RS-485 communication</td></tr><tr><td>6</td><td>Inverter</td><td>RS-485 communication (Control circuit)</td></tr><tr><td>7</td><td>RS-485 communication</td><td>RS-485 communication (Control circuit)</td></tr><tr><td>8</td><td>RS-485 communication (Control circuit)</td><td>RS-485 communication (Control circuit)</td></tr></table> | | Frequency | Operation command | 0 | Inverter | Inverter | 1 | RS-485 communication | Inverter | 2 | Inverter | RS-485 communication | 3 | RS-485 communication | RS-485 communication | 4 | RS-485 communication (Control circuit) | Inverter | 5 | RS-485 communication (Control circuit) | RS-485 communication | 6 | Inverter | RS-485 communication (Control circuit) | 7 | RS-485 communication | RS-485 communication (Control circuit) | 8 | RS-485 communication (Control circuit) | RS-485 communication (Control circuit) | 3 |
| | Frequency | Operation command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Inverter | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | RS-485 communication | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Inverter | RS-485 communication | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | RS-485 communication | RS-485 communication | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | RS-485 communication (Control circuit) | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | RS-485 communication (Control circuit) | RS-485 communication | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Inverter | RS-485 communication (Control circuit) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | RS-485 communication | RS-485 communication (Control circuit) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | RS-485 communication (Control circuit) | RS-485 communication (Control circuit) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

*1 Select "Modbus RTU" for the communication protocol on the inverter when connecting with the TS2060.

*2 When "0" is specified for y98 (bus function) as well as y99 (support link function), the frequency and operation command can be set on the TS2060.

When making frequency and operation command settings on the TS2060 connected to the connector for the touch panel, specify "3" for function code H30. When making the settings on the TS2060 connected to the control circuit terminal block, specify "8" for H30.

*3 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.21 FRENIC-VG1 (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--------------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / 19200 / <u>38400</u> bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | 0 to 247 | 0: Broadcast |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example |
|---------------|--------------------|---|---------|
| H31 | Station address | 1 to 247 | 1 |
| H34 | Baud rate | <u>0: 38400 bps</u> 1: 19200 bps 2: 9600 bps 3: 4800 bps | 0 |
| H35 | Data length | <u>0: 8 bits</u> | 0 |
| H36 | Parity bit | 0: None <u>1: Even parity</u> 2: Odd parity | 1 |
| H37 | Stop bit | 0: 2 bits <u>1: 1 bit</u> | 1 |
| H40 | Protocol selection | <u>2: Modbus-RTU protocol</u> | 2 |

Available Device Memory

The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.22 FRENIC-Ace (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--------------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | 1 / <u>2</u> bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | 0 to 247 | 0: Broadcast |

Inverter

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example |
|---------------|---------------------------|---|---------|
| y01 | Station address | 1 to 247 | 1 |
| y04 | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 |
| y05 | Data length | <u>0: 8 bits</u> 1: 7 bits | 0 |
| y06 | Parity bit | <u>0: None</u> 1: Even parity 2: Odd 3: None | 0 |
| y07 | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y06, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y06 "1 bit" is set for stop bit. | - |
| y10 | Communication protocol *1 | 0: Modbus RTU | 0 |
| y11 | Station address | 1 to 247 | 1 |
| y14 | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 |
| y15 | Data length | <u>0: 8 bits</u> 1: 7 bits | 0 |
| y16 | Parity bit | <u>0: None</u> 1: Even 2: Odd 3: None | 0 |
| y17 | Stop bit | For Modbus RTU communication, the stop bit setting is automatically made according to the parity bit setting. When "0" is specified for y16, "2 bits" is set for stop bit. When "1", "2", or "3" is specified for y16, "1 bit" is set for stop bit. | - |
| y20 | Communication protocol *1 | 0: Modbus RTU | 0 |

| Function Code | Item | Setting | Example | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|-------------------------------|--|---------|-----------|-------------------|---|------------------------|------------------------|---|-------------------------------|------------------------|---|------------------------|-------------------------------|---|-------------------------------|-------------------------------|---|-------------------------------|----------|---|-------------------------------|-------------------------------|---|----------|-------------------------------|---|-------------------------------|-------------------------------|---|-------------------------------|-------------------------------|---|
| y98 | Bus function | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td>0</td><td>Function code H30</td><td>Function code H30</td></tr><tr><td>1</td><td>Commanded from the fieldbus</td><td>Function code H30</td></tr><tr><td>2</td><td>Function code H30</td><td>Commanded from the fieldbus</td></tr><tr><td>3</td><td>Commanded from the fieldbus</td><td>Commanded from the fieldbus</td></tr></table> | | Frequency | Operation Command | 0 | Function code H30 | Function code H30 | 1 | Commanded from the fieldbus | Function code H30 | 2 | Function code H30 | Commanded from the fieldbus | 3 | Commanded from the fieldbus | Commanded from the fieldbus | 0 | | | | | | | | | | | | | | | |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Function code H30 | Function code H30 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Commanded from the fieldbus | Function code H30 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Function code H30 | Commanded from the fieldbus | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Commanded from the fieldbus | Commanded from the fieldbus | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| y99 | Support link function | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td>0</td><td>Function code H30, y98</td><td>Function code H30, y98</td></tr><tr><td>1</td><td>Command from FRENIC loader</td><td>Function code H30, y98</td></tr><tr><td>2</td><td>Function code H30, y98</td><td>Command from FRENIC loader</td></tr><tr><td>3</td><td>Command from FRENIC loader</td><td>Command from FRENIC loader</td></tr></table> | | Frequency | Operation Command | 0 | Function code H30, y98 | Function code H30, y98 | 1 | Command from FRENIC loader | Function code H30, y98 | 2 | Function code H30, y98 | Command from FRENIC loader | 3 | Command from FRENIC loader | Command from FRENIC loader | 0 | | | | | | | | | | | | | | | |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Function code H30, y98 | Function code H30, y98 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Command from FRENIC loader | Function code H30, y98 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Function code H30, y98 | Command from FRENIC loader | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Command from FRENIC loader | Command from FRENIC loader | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H30 | Link function *2 | <table><tr><th></th><th>Frequency</th><th>Operation Command</th></tr><tr><td>0</td><td>Inverter</td><td>Inverter</td></tr><tr><td>1</td><td>RS-485 communication (port 1)</td><td>Inverter</td></tr><tr><td>2</td><td>Inverter</td><td>RS-485 communication (port 1)</td></tr><tr><td>3</td><td>RS-485 communication (port 1)</td><td>RS-485 communication (port 1)</td></tr><tr><td>4</td><td>RS-485 communication (port 2)</td><td>Inverter</td></tr><tr><td>5</td><td>RS-485 communication (port 2)</td><td>RS-485 communication (port 1)</td></tr><tr><td>6</td><td>Inverter</td><td>RS-485 communication (port 2)</td></tr><tr><td>7</td><td>RS-485 communication (port 1)</td><td>RS-485 communication (port 2)</td></tr><tr><td>8</td><td>RS-485 communication (port 2)</td><td>RS-485 communication (port 2)</td></tr></table> | | Frequency | Operation Command | 0 | Inverter | Inverter | 1 | RS-485 communication (port 1) | Inverter | 2 | Inverter | RS-485 communication (port 1) | 3 | RS-485 communication (port 1) | RS-485 communication (port 1) | 4 | RS-485 communication (port 2) | Inverter | 5 | RS-485 communication (port 2) | RS-485 communication (port 1) | 6 | Inverter | RS-485 communication (port 2) | 7 | RS-485 communication (port 1) | RS-485 communication (port 2) | 8 | RS-485 communication (port 2) | RS-485 communication (port 2) | 3 |
| | Frequency | Operation Command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Inverter | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | RS-485 communication (port 1) | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Inverter | RS-485 communication (port 1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | RS-485 communication (port 1) | RS-485 communication (port 1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | RS-485 communication (port 2) | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | RS-485 communication (port 2) | RS-485 communication (port 1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Inverter | RS-485 communication (port 2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | RS-485 communication (port 1) | RS-485 communication (port 2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | RS-485 communication (port 2) | RS-485 communication (port 2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

*1 Select "Modbus RTU" for the communication protocol on the inverter when connecting with the TS2060.

*2 When "0" is specified for y98 (bus function) as well as y99 (support link function), the frequency and operation command can be set on the TS2060.

When making frequency and operation command settings on the TS2060 connected to communication port 1, specify "3" for function code H30. When making the settings on the TS2060 connected to communication port 2, specify "8" for H30.

*3 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| 4 | 02H | |

21.2.23 FRENIC Series (Loader)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1 bit</u> | |
| Parity | <u>Even</u> | |
| Target Port No. | <u>1</u> to 255 | |

Inverter

Set communication parameters. Be sure to match the settings to those made under [Communication Setting] of the editor.

FRENIC5000VG7S

Built-in RS-485 port


(Underlined setting: default)

| Function Code | Item | Setting | Example | | | | | | | | | | | | | | | | | | | | |
|---------------|----------------------------------|--|-------------------|----------------------------------|-------------------|-------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| H30 | Link function ^{*1} | <table border="1"> <thead> <tr> <th></th><th>Writing of Monitor/Function Data</th><th>Frequency Setting</th><th>Operation Command</th></tr> </thead> <tbody> <tr> <td>0</td><td>○</td><td>×</td><td>×</td></tr> <tr> <td>1</td><td>○</td><td>○</td><td>×</td></tr> <tr> <td>2</td><td>○</td><td>×</td><td>○</td></tr> <tr> <td>3</td><td>○</td><td>○</td><td>○</td></tr> </tbody> </table> | | Writing of Monitor/Function Data | Frequency Setting | Operation Command | 0 | ○ | × | × | 1 | ○ | ○ | × | 2 | ○ | × | ○ | 3 | ○ | ○ | ○ | 3 |
| | Writing of Monitor/Function Data | Frequency Setting | Operation Command | | | | | | | | | | | | | | | | | | | | |
| 0 | ○ | × | × | | | | | | | | | | | | | | | | | | | | |
| 1 | ○ | ○ | × | | | | | | | | | | | | | | | | | | | | |
| 2 | ○ | × | ○ | | | | | | | | | | | | | | | | | | | | |
| 3 | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | |
| H31 | Station address | <u>1</u> to 255 | 1 | | | | | | | | | | | | | | | | | | | | |
| H34 | Baud rate | <u>0: 38400 bps</u> 1: 19200 bps 2: 9600 bps 3: 4800 bps | 1 | | | | | | | | | | | | | | | | | | | | |
| H40 | Communication protocol | 0: FGI-bus <u>1: SX (loader) protocol</u> 2: Modbus RTU | 1 | | | | | | | | | | | | | | | | | | | | |

Connecting to terminal block of "OPC-VG7-RS" optional communication board

(Underlined setting: default)

| Function Code | Item | Setting | Example | | | | | | | | | | | | | | | | | | | | |
|---------------|----------------------------------|--|-------------------|----------------------------------|-------------------|-------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| H30 | Link function ^{*1} | <table border="1"> <thead> <tr> <th></th><th>Writing of Monitor/Function Data</th><th>Frequency Setting</th><th>Operation Command</th></tr> </thead> <tbody> <tr> <td>0</td><td>○</td><td>×</td><td>×</td></tr> <tr> <td>1</td><td>○</td><td>○</td><td>×</td></tr> <tr> <td>2</td><td>○</td><td>×</td><td>○</td></tr> <tr> <td>3</td><td>○</td><td>○</td><td>○</td></tr> </tbody> </table> | | Writing of Monitor/Function Data | Frequency Setting | Operation Command | 0 | ○ | × | × | 1 | ○ | ○ | × | 2 | ○ | × | ○ | 3 | ○ | ○ | ○ | 3 |
| | Writing of Monitor/Function Data | Frequency Setting | Operation Command | | | | | | | | | | | | | | | | | | | | |
| 0 | ○ | × | × | | | | | | | | | | | | | | | | | | | | |
| 1 | ○ | ○ | × | | | | | | | | | | | | | | | | | | | | |
| 2 | ○ | × | ○ | | | | | | | | | | | | | | | | | | | | |
| 3 | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | |
| H31 | Station address | <u>1</u> to 255 | 1 | | | | | | | | | | | | | | | | | | | | |

| Function Code | Item | Setting | Example |
|---------------|----------------------------------|---|---------|
| o37 | Communication definition setting |  <p>Baud rate <u>0: 38400 bps</u> 1: 19200 bps 2: 9600 bps 3: 4800 bps</p> <p>Parity 0: None (stop bit: 2 bits) <u>1: Even (stop bit: 1 bit)</u> 2: Odd (stop bit: 1 bit)</p> | 11 |
| H40 | Communication protocol | 0: FGI-bus <u>1: SX (loader) protocol</u> 2: Modbus RTU | 1 |

*1 Available when the communication is enabled by digital input.

Example: To make the communication enabled when digital input terminal X1 is turned ON:


Set "24 (link operation)" for function code E01 and turn on the digital input terminal X1 externally.

Terminals from X2 to X9 can also be used. Set the function code corresponding to the digital input terminal to use.

Notes on Using the "OPC-VG7-RS" (Optional Communication Board)

Set the DIPSW2 on the optional communication board "OPC-VG7-RS" as shown below when connecting the TS2060 and the terminal block of the board.

The underlined settings are set as default.

| SW2 | SW2-1 Setting | SW2-2 Setting | Function | Remarks |
|--|---------------|---------------|--------------------------------------|--|
|  | OFF | OFF | - | - |
| | ON | OFF | - | - |
| | <u>OFF</u> | <u>ON</u> | Optional communication board enabled | Do not change the default setting when connecting with the TS2060. |
| | ON | ON | - | - |

FRENIC-Mini/Eco/Multi/MEGA/MEGA SERVO/HVAC/AQUA/Ace/HF/Lift

(Underlined setting: default)

| Function Code | Name | | Setting | Example | Remarks | |
|---------------|---|---------------------------|--|---------|--|--|
| y01 | RS-485 setting 1 (touch panel / communication port 1) | Station address | <u>1</u> to 255 | 1 | | |
| y04 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | |
| y10 | | Communication protocol *1 | 0: Modbus RTU <u>1: SX (loader) protocol</u> 2: FGI-bus | 1 | | |
| y11 | RS-485 setting 2 (control circuit terminal block / communication port 2) | Station address | <u>1</u> to 255 | 1 | The control circuit terminal block / communication port 2 is available only with FRENIC-HVAC/AQUA/Ace. | |
| y14 | | Baud rate | 1: 4800 bps 2: 9600 bps <u>3: 19200 bps</u> 4: 38400 bps | 3 | | |
| y20 | | Communication protocol | 0: Modbus RTU <u>1: SX (loader) protocol</u> 2: FGI-bus | 1 | | |
| y98 | Bus function | | | 0 | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

| Function Code | Name | Setting | Example | Remarks | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|---------------------------------|---|----------------------|-------------------|-------------------|---|------------------------|------------------------|---|-------------------------------|------------------------|---|------------------------|-------------------------------|---|-------------------------------|-------------------------------|---|---------------------------------|----------|---|---------------------------------|-------------------------------|---|----------|---------------------------------|---|-------------------------------|---------------------------------|---|---------------------------------|---------------------------------|--|-------------------|-------------------|---------------------|---|----------|----------------|-----|---|----------------------|----------------|-----|---|----------|----------------------|-----|---|----------------------|----------------------|-----|---|-----|----------------|-----|---|----------|-----|-----|---|-----|-----|-----|---|----------|----------------|----------------------|---|----------------------|----------------|----------------------|---|----------|----------------------|----------------------|----|----------------------|----------------------|----------------------|----|----------|----------------|-----|----|-----|----------------|-----|----|----------|-----|-----|----|-----|-----|-----|---|--|
| y99 | Support link function | <table><tr><th></th><th>Frequency Setting</th><th>Operation Command</th></tr><tr><td>0</td><td>Function code H30, y98</td><td>Function code H30, y98</td></tr><tr><td>1</td><td>Command from FRENIC loader</td><td>Function code H30, y98</td></tr><tr><td>2</td><td>Function code H30, y98</td><td>Command from FRENIC loader</td></tr><tr><td>3</td><td>Command from FRENIC loader</td><td>Command from FRENIC loader</td></tr></table> | | Frequency Setting | Operation Command | 0 | Function code H30, y98 | Function code H30, y98 | 1 | Command from FRENIC loader | Function code H30, y98 | 2 | Function code H30, y98 | Command from FRENIC loader | 3 | Command from FRENIC loader | Command from FRENIC loader | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Frequency Setting | Operation Command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Function code H30, y98 | Function code H30, y98 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Command from FRENIC loader | Function code H30, y98 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Function code H30, y98 | Command from FRENIC loader | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Command from FRENIC loader | Command from FRENIC loader | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H30 | Link function ^{*1} | <div><div><ul style="list-style-type: none">FRENIC-Mini/Eco/Multi/MEGA/MEGA SERVO/HVAC/AQUA/Ace/HF<table><tr><th></th><th>Frequency Setting</th><th>Operation Command</th></tr><tr><td>0</td><td>Inverter</td><td>Inverter</td></tr><tr><td>1</td><td>RS-485 communication (port 1)</td><td>Inverter</td></tr><tr><td>2</td><td>Inverter</td><td>RS-485 communication (port 1)</td></tr><tr><td>3</td><td>RS-485 communication (port 1)</td><td>RS-485 communication (port 1)</td></tr><tr><td>4</td><td>RS-485 communication (port 2) *</td><td>Inverter</td></tr><tr><td>5</td><td>RS-485 communication (port 2) *</td><td>RS-485 communication (port 1)</td></tr><tr><td>6</td><td>Inverter</td><td>RS-485 communication (port 2) *</td></tr><tr><td>7</td><td>RS-485 communication (port 1)</td><td>RS-485 communication (port 2) *</td></tr><tr><td>8</td><td>RS-485 communication (port 2) *</td><td>RS-485 communication (port 2) *</td></tr></table></div><div><ul style="list-style-type: none">FRENIC-Lift<table><tr><th></th><th>Frequency Setting</th><th>Operation Command</th><th>Torque Bias Command</th></tr><tr><td>0</td><td>Inverter</td><td>Terminal block</td><td>L54</td></tr><tr><td>1</td><td>RS-485 communication</td><td>Terminal block</td><td>L54</td></tr><tr><td>2</td><td>Inverter</td><td>RS-485 communication</td><td>L54</td></tr><tr><td>3</td><td>RS-485 communication</td><td>RS-485 communication</td><td>L54</td></tr><tr><td>4</td><td>CAN</td><td>Terminal block</td><td>L54</td></tr><tr><td>5</td><td>Inverter</td><td>CAN</td><td>L54</td></tr><tr><td>6</td><td>CAN</td><td>CAN</td><td>L54</td></tr><tr><td>7</td><td>Inverter</td><td>Terminal block</td><td>RS-485 communication</td></tr><tr><td>8</td><td>RS-485 communication</td><td>Terminal block</td><td>RS-485 communication</td></tr><tr><td>9</td><td>Inverter</td><td>RS-485 communication</td><td>RS-485 communication</td></tr><tr><td>10</td><td>RS-485 communication</td><td>RS-485 communication</td><td>RS-485 communication</td></tr><tr><td>11</td><td>Inverter</td><td>Terminal block</td><td>CAN</td></tr><tr><td>12</td><td>CAN</td><td>Terminal block</td><td>CAN</td></tr><tr><td>13</td><td>Inverter</td><td>CAN</td><td>CAN</td></tr><tr><td>14</td><td>CAN</td><td>CAN</td><td>CAN</td></tr></table></div></div> | | Frequency Setting | Operation Command | 0 | Inverter | Inverter | 1 | RS-485 communication (port 1) | Inverter | 2 | Inverter | RS-485 communication (port 1) | 3 | RS-485 communication (port 1) | RS-485 communication (port 1) | 4 | RS-485 communication (port 2) * | Inverter | 5 | RS-485 communication (port 2) * | RS-485 communication (port 1) | 6 | Inverter | RS-485 communication (port 2) * | 7 | RS-485 communication (port 1) | RS-485 communication (port 2) * | 8 | RS-485 communication (port 2) * | RS-485 communication (port 2) * | | Frequency Setting | Operation Command | Torque Bias Command | 0 | Inverter | Terminal block | L54 | 1 | RS-485 communication | Terminal block | L54 | 2 | Inverter | RS-485 communication | L54 | 3 | RS-485 communication | RS-485 communication | L54 | 4 | CAN | Terminal block | L54 | 5 | Inverter | CAN | L54 | 6 | CAN | CAN | L54 | 7 | Inverter | Terminal block | RS-485 communication | 8 | RS-485 communication | Terminal block | RS-485 communication | 9 | Inverter | RS-485 communication | RS-485 communication | 10 | RS-485 communication | RS-485 communication | RS-485 communication | 11 | Inverter | Terminal block | CAN | 12 | CAN | Terminal block | CAN | 13 | Inverter | CAN | CAN | 14 | CAN | CAN | CAN | 3 | <div>* The communication port 2 is available only with FRENIC-HVAC/AQUA/Ace.</div> |
| | Frequency Setting | Operation Command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Inverter | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | RS-485 communication (port 1) | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Inverter | RS-485 communication (port 1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | RS-485 communication (port 1) | RS-485 communication (port 1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | RS-485 communication (port 2) * | Inverter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | RS-485 communication (port 2) * | RS-485 communication (port 1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Inverter | RS-485 communication (port 2) * | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | RS-485 communication (port 1) | RS-485 communication (port 2) * | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | RS-485 communication (port 2) * | RS-485 communication (port 2) * | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Frequency Setting | Operation Command | Torque Bias Command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Inverter | Terminal block | L54 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | RS-485 communication | Terminal block | L54 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Inverter | RS-485 communication | L54 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | RS-485 communication | RS-485 communication | L54 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | CAN | Terminal block | L54 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Inverter | CAN | L54 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | CAN | CAN | L54 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Inverter | Terminal block | RS-485 communication | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | RS-485 communication | Terminal block | RS-485 communication | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Inverter | RS-485 communication | RS-485 communication | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | RS-485 communication | RS-485 communication | RS-485 communication | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Inverter | Terminal block | CAN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | CAN | Terminal block | CAN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Inverter | CAN | CAN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | CAN | CAN | CAN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

*1 When "0" is specified for y98 (bus function) and "3" is specified for y99 (support link function), the frequency and operation command can be set on the TS2060.
When making frequency and operation command settings on the TS2060 connected to communication port 1, specify "3" for function code H30. When making the settings on the TS2060 connected to communication port 2, specify "8" for H30.

FRENIC-VG1

(Underlined setting: default)

| Function Code | Name | Setting | Example |
|---------------|--------------------|---|---------|
| H31 | Station address | <u>1</u> to 255 | 1 |
| H34 | Baud rate | <u>0: 38400 bps</u> 1: 19200 bps 2: 9600 bps 3: 4800 bps | 1 |
| H40 | Protocol selection | 0: FGI-bus <u>1: SX (loader) protocol</u> 2: Modbus RTU | 1 |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--|------|---------|
| F (basic function) | 00H | |
| E (terminal function) | 01H | |
| C (control function) | 02H | |
| P (motor parameter function M1) | 03H | |
| H (high performance function) | 04H | |
| A (motor parameter function M2, 3) | 05H | |
| o (optional function) | 06H | |
| S (communication command function) | 07H | |
| M (monitor data function) | 08H | |
| L (lift function) | 09H | |
| r (VG7, UPAC RAS function) | 0AH | |
| U (user function) | 0BH | |
| J (application function) | 0DH | |
| y (communication function) | 0EH | |
| W (extensional monitor) | 0FH | |
| X (alarm information 1) | 10H | |
| Z (alarm information 2) | 11H | |
| b (ASR/torque) | 12H | |
| d (soft relay) | 13H | |
| E1 (terminal function 1) | 14H | |
| H1 (high level function 1) | 15H | |
| H2 (high level function 2) | 16H | |
| H3 (high level function 3) | 17H | |
| H4 (high level function 4) | 18H | |
| H5 (high level function 5) | 19H | |
| A1 (motor 3 function) | 1AH | |
| o1 (optional function 1) | 1BH | |
| o2 (optional function 2) | 1CH | |
| U1 (user function 1) | 1DH | |
| M1 (monitor data function 1) | 1EH | |
| M2 (monitor data function 2) | 1FH | |
| q (for validation by manufacturer) | 21H | |
| i (model-specific adjustment value) | 22H | |
| u (back 1 function code) | 23H | |
| n (back 2 function code) | 24H | |
| K (touch panel / loader communication (K)) | 26H | |

21.2.24 HFR-C9K

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Data Length | 7 / <u>8</u> bits | |
| Stop Bit | 1 / <u>2</u> bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

IH Inverter

Be sure to match the settings to those made under [Communication Setting] of the editor.

SW1 setting (station address / optional selection)

| Switch | Contents | | | | | Example: Station Address: 1 Optional Selection: Selection for Communication Operation (Start from LSB) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|-------------------------------|--|-----|-----|-----|---|-------------------|-----|-----|-----|-----|---|---|-----|-----|-----|-----|-----|---|----|-----|-----|-----|-----|---|-----|----|-----|-----|-----|---|----|----|-----|-----|-----|---|---|---|---|---|---|----|-----|-----|----|----|----|----|----|-----|----|----|----|----|-----|----|----|----|----|----|----|----|----|----|----|
| 1 | Station Address* ¹ | <table><tr><th>Switch Address</th><th>1</th><th>2</th><th>3</th><th>4</th><th>5</th></tr><tr><td>0</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>1</td><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>2</td><td>OFF</td><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>3</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>:</td><td>:</td><td>:</td><td>:</td><td>:</td><td>:</td></tr><tr><td>28</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td></tr><tr><td>29</td><td>ON</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td></tr><tr><td>30</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td></tr><tr><td>31</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td></tr></table> | | | | | Switch Address | 1 | 2 | 3 | 4 | 5 | 0 | OFF | OFF | OFF | OFF | OFF | 1 | ON | OFF | OFF | OFF | OFF | 2 | OFF | ON | OFF | OFF | OFF | 3 | ON | ON | OFF | OFF | OFF | : | : | : | : | : | : | 28 | OFF | OFF | ON | ON | ON | 29 | ON | OFF | ON | ON | ON | 30 | OFF | ON | ON | ON | ON | 31 | ON | ON | ON | ON | ON |
| Switch Address | | | | | | | 1 | 2 | 3 | 4 | 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | | | | | | | OFF | OFF | OFF | OFF | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | | | | | | | ON | OFF | OFF | OFF | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | | | | | | | OFF | ON | OFF | OFF | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | | | | | | | ON | ON | OFF | OFF | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| : | | | | | | | : | : | : | : | : | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 28 | | | | | | | OFF | OFF | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 29 | | | | | | | ON | OFF | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30 | | | | | | | OFF | ON | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31 | ON | ON | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Optional Selection | Contents | | | LSB | MSB | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Selection for Communication Operation (Start from LSB) | | | ON | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Selection for Communication Operation (Start from MSB) | | | OFF | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

OFF(0)

ON(1)

1

2

4

8

16

MSB

LSB

*1 For connection to a TS2060, be sure to set the station address other than 0.

Communication setting

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example |
|---------------|-------------|---|---------|
| F16 | Baud rate | 4: 4800 bps <u>5: 9600 bps</u> 6: 19200 bps | 5 |
| F17 | Data length | 0: 7 bit <u>1: 8 bits</u> | 1 |
| F18 | Parity bit | 0: None <u>1: Even</u> 2: Odd | 1 |
| F19 | Stop bit | 0: 1 bit <u>1: 2 bits</u> | 1 |

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|---------|
| --- | 00H | |

21.2.25 HFR-C11K

Communication Setting

Editor

Communication setting

(Underlined setting: default)


| Item | Setting | Remarks |
|-----------------|----------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

IH Inverter

Be sure to match the settings to those made under [Communication Setting] of the editor. (Underlined setting: default)

SW3 setting (station address / terminating resistance)

| Switch | Contents | | | | | Example: Station Address: 1 Terminating Resistance: None | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------------------|-------------------------------|--|------------------|-----|-----|--|------|----------|---|-----|-----|-----|-----|-----|---|----|-----|-----|-----|-----|---|-----|----|-----|-----|-----|---|----|----|-----|-----|-----|---|---|---|---|---|---|----|-----|-----|----|----|----|----|----|-----|----|----|----|----|-----|----|----|----|----|----|----|----|----|----|----|--|--|--|--|--|
| 1 | Station Address ^{*1} | <table><tr><th>Switch Address \</th><th>1</th><th>2</th><th>3</th><th>4</th><th>5</th></tr><tr><td>0</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>1</td><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>2</td><td>OFF</td><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>3</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>:</td><td>:</td><td>:</td><td>:</td><td>:</td><td>:</td></tr><tr><td>28</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td></tr><tr><td>29</td><td>ON</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td></tr><tr><td>30</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td></tr><tr><td>31</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td></tr></table> | Switch Address \ | 1 | 2 | 3 | 4 | 5 | 0 | OFF | OFF | OFF | OFF | OFF | 1 | ON | OFF | OFF | OFF | OFF | 2 | OFF | ON | OFF | OFF | OFF | 3 | ON | ON | OFF | OFF | OFF | : | : | : | : | : | : | 28 | OFF | OFF | ON | ON | ON | 29 | ON | OFF | ON | ON | ON | 30 | OFF | ON | ON | ON | ON | 31 | ON | ON | ON | ON | ON | | | | | |
| Switch Address \ | | | 1 | 2 | 3 | 4 | 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | | | OFF | OFF | OFF | OFF | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | | | ON | OFF | OFF | OFF | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | | | OFF | ON | OFF | OFF | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | | | ON | ON | OFF | OFF | OFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| : | | | : | : | : | : | : | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 28 | | | OFF | OFF | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 29 | | | ON | OFF | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30 | | | OFF | ON | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31 | ON | ON | ON | ON | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminating Resistance | | <table><tr><th>Contents</th><th>OFF</th><th>ON</th></tr><tr><td>Terminating resistance</td><td>None</td><td>Provided</td></tr></table> | Contents | OFF | ON | Terminating resistance | None | Provided | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Contents | OFF | ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminating resistance | None | Provided | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



*1 For connection to a TS2060, be sure to set the station address other than 0.

Communication setting

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example |
|---------------|-------------------------|---|---------|
| r 04 | Baud rate | 2: 4800 bps <u>3: 9600 bps</u> 4: 19200 bps | 3 |
| r 05 | Data length | 0: 8 bit <u>1: 7 bits</u> | 1 |
| r 06 | Parity bit | 0: None <u>1: Even</u> 2: Odd | 1 |
| r 07 | Stop bit | 0: 2 bit <u>1: 1 bits</u> | 1 |
| r 10 | Communication protocol* | <u>0: FGI-bus</u> 1: C9K mode | 0 |

* RS-485 communication is available when the communication is enabled by digital input.

Example: To make the communication enabled when digital input terminal X1 is turned ON;

Set "11 (RS485 communication selection (RS))" for function code i01 and turn on the digital input terminal X1 externally. Terminals from X2 to X5 can also be used. Set the function code corresponding to the digital input terminal to use.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|--|------|---------|
| S (command data) | 00H | |
| M (monitor data) | 01H | |
| F (basic function) | 02H | |
| E (error display function) | 03H | |
| C (control function) | 04H | |
| P (optional function) | 05H | |
| H (high level function) | 06H | |
| o (output terminal function) | 08H | |
| i (input terminal function) | 0BH | |
| t (control function in the event of trip (alarm) occurrence) | 0CH | |
| r (RS communication function) | 0DH | |
| Pn (touch panel function) | 0EH | |

PLC_CTL

| Content | F0 | F1 (= \$u n) | | F2 |
|---------------|---------------------|--------------|----------------|----|
| Reset command | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0 | |

21.2.26 HFR-K1K

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1:1</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 9600 / 19200 / <u>38400</u> bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Odd / <u>Even</u> | |
| Target Port No. | <u>1</u> to 31 | |

IH Inverter

Be sure to match the settings to those made under [Communication Setting] of the editor.

Control PCB internal switch

| Internal Switch | | Description |
|-----------------|-----|--------------------------|
| SW3 | SW4 | |
| RS | RS | For RS-485 communication |

Communication setting

Set communication parameters.

(Underlined setting: default)

| Function Code | Item | Setting | Example |
|---------------|---|--|--|
| R00 | Communication host setting | <u>0: Touch panel connection terminal</u> 1: I/O PCB (option) | 0 |
| R01 | RS-485 setting (touch panel connection terminal) | Station address | 1 to 31 |
| R04 | | Baud Rate | 3: 9600 bps 4: 19200 bps <u>5: 38400 bps</u> |
| R05 | | Data length | 0: 8 bits <u>1: 7 bits</u> |
| R06 | | Parity bit | 0: None <u>1: Even parity</u> 2: Odd parity 3: None |
| R07 | | Stop bit | 0: 2 bits <u>1: 1 bit</u> |
| R10 | | Protocol selection | <u>0: FGI-bus</u> |
| R12 | RS-485 setting (I/O PCB (option)) | Station address | 1 to 31 |
| R15 | | Baud Rate | 3: 9600 bps 4: 19200 bps <u>5: 38400 bps</u> |
| R16 | | Data length | 0: 8 bits <u>1: 7 bits</u> |
| R17 | | Parity bit | 0: None <u>1: Even parity</u> 2: Odd parity 3: None |
| R18 | | Stop bit | 0: 2 bits <u>1: 1 bit</u> |
| R21 | | Protocol selection | <u>0: FGI-bus</u> |

Available Device Memory

The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|-----------------------------------|------|---------|
| S (command data) | 00H | |
| d (monitor data) | 01H | |
| F (basic function) | 02H | |
| E (error display function) | 03H | |
| C (control function) | 04H | |
| P (optional function) | 05H | |
| H (advanced function) | 06H | |
| o (output terminal function) | 08H | |
| I (input terminal function) | 0BH | |
| t (trip (alarm) control function) | 0CH | |
| r (RS communication function) | 0DH | |
| Pn (touch panel function) | 0EH | |

PLC_CTL

| Description | F0 | F1 (= \$u n) | | F2 |
|---------------|-----------------------|--------------|----------------|----|
| Reset command | 1 to 8 (PLC1 to 8) | n | Station number | 2 |
| | | n+1 | Command: 0 | |

21.2.27 PPMC (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | <u>9600</u> / 19200 bps | |
| Data Length | 8 bits | Do not change the default setting because the setting on the AC power monitor cannot be changed. |
| Stop Bit | 1 bit | |
| Parity | <u>None</u> / Even / Odd | |
| Target Port No. | 1 to 31 | |

AC Power Monitor

The communication parameters can be set using keys attached to the front of the AC power monitor. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | Item | Setting | Example |
|---------------------|---------------|----------------------------------|--|
| Setting condition 2 | Item number 2 | ID number | 1 to 31 (default: unit number ^{*1}) |
| | Item number 3 | Communication protocol selection | <u>nor: Dedicated protocol</u> rtu: Modbus RTU protocol ^{*2} |
| | Item number 7 | Baud rate | <u>9.6: 9600 bps</u> 19.2: 19200 bps 4.8: 4800 bps |
| | Item number 8 | Data length, parity | <u>8n: Data length 8 bits, without parity</u> 8o: Data length 8 bits, odd parity 8E: Data length 8 bits, even parity |

^{*1} The unit number is set for the ID number upon delivery. The unit number is indicated on the instruction plate attached to the side of the case.

^{*2} Select "rtu (Modbus RTU)" for the communication protocol when communicating with the TS2060.

^{*3} The communication parameter (stop bit) is fixed to 1 bit.

^{*4} The communication function of the AC power monitor can be selected at the time of purchase. Select a model on which RS-485/RS-232C communication is available.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|-----------|
| 4 (holding register) | 02H | |
| 3 (input register) | 03H | Read only |

* Remarks on data format for the following device memory:

40022 (fixed voltage), 40028 (Ip fixed power factor): 6-byte character string

40046 (calendar): 14-byte character string

Measurement data: real type (Float)

40060 (alarm clear), 40062 (amount of power clear), 40064 (cumulative value of invalid power clear): write only

21.2.28 FALDIC- α Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | Do not change the default setting other than baud rate because the setting on the servo amplifier cannot be changed. |
| Signal Level | RS-422/485 | |
| Baud Rate | <u>9600</u> / 19200 / 38400 bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | Even | |
| Target Port No. | 1 to 31 | |

Servo Amplifier

Set the communication parameters using the touch panel mounted on the servo amplifier.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | | | Item | Setting | Example |
|----------------------------------|--------------|----------|----------------|---|---------|
| <i>Pn002</i> System parameter | <i>PP096</i> | (No. 96) | Station number | 1 to 31 | 1 |
| | <i>PP097</i> | (No. 97) | Baud rate | <u>0</u> : 9600 bps 1: 19200 bps 2: 38400 bps | 0 |

*1 The communication function of the servo amplifier can be selected at the time of purchase. Select a model on which host interface: universal communication (RS-485) is available.

*2 The following communication parameters are fixed; data length: 8 bits, stop bit: 1 bit, and parity: even.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---|------|-------------------------|
| 00 (monitor data) | 00H | Double-word, read only |
| 01 (data on positioning being executed) | 01H | Double-word, read only |
| 10 (sequence mode) | 02H | Read only |
| 11 (control input/output signal) | 03H | Read only |
| 12 (alarm detection log) | 04H | Read only |
| 13 (detected alarm contents) | 05H | Read only |
| 20 (standard parameter) | 06H | Double-word*1 |
| 21 (system parameter) | 07H | Double-word*1 |
| 30 (positioning data) | 08H | Double-word*2 |
| 40 (control command) | 09H | Double-word, write only |

*1 Input a parameter number by manual operation.

*2 Address denotations XXYY

└─ Address
└─ Positioning data number (01H - 63H)

PLC_CTL

| Contents | F0 | F1 (= \$u n) | | F2 |
|--|---------------------|----------------|-----------------|----|
| Positioning data (immediate) setting | 1 - 8 (PLC1 - 8) | n | Station number | 6 |
| | | n + 1 | Command: 9 | |
| | | n + 2 | ABS/INC | |
| | | n + 3 | Speed selection | |
| | | n + 4 to n + 5 | Position data | |
| Automatic start (immediate) | 1 - 8 (PLC1 - 8) | n | Station number | 6 |
| | | n + 1 | Command: 11 | |
| | | n + 2 | ABS/INC | |
| | | n + 3 | Speed selection | |
| | | n + 4 to n + 5 | Position data | |
| Automatic start (positioning data number) | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 12 | |
| | | n + 2 | Start number | |
| Override setting | 1 - 8 (PLC1 - 8) | n | Station number | 4 |
| | | n + 1 | Command: 33 | |
| | | n + 2 | Data type | |
| | | n + 3 | Setting | |

21.2.29 FALDIC-W Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-422/485 | Do not change the default setting other than baud rate because the setting on the servo amplifier cannot be changed. |
| Baud Rate | 9600 / 19200 / <u>38400</u> bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | Even | |
| Target Port No. | 1 to 31 | |

* When changing the time-out time, note the following points. (Default: 500 (msec))

- When the baud rate is 19200 bps or 38400 bps, set 200 (msec) or greater.
- When the baud rate is 9600 bps, set 500 (msec) or greater.

Servo Amplifier

Set the communication parameters using the touch panel mounted on the servo amplifier.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | | | Item | Setting | Example | Remarks |
|---------------------------------------|--------------|----------|----------------|--|---------|--|
| Pn01 Parameter editing mode | no.82 | (No. 82) | Station number | <u>1</u> to 31 | 1 | The setting takes effect when the power is turned off and back on again. |
| | no.83 | (No. 83) | Baud rate | <u>0: 38400 bps</u> 1: 19200 bps 2: 9600 bps | 0 | |

* The following communication parameters are fixed; data length: 8 bits, stop bit: 1 bit, and parity: even.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------|------|------------------------|
| 01 (monitor data) | 00H | Double-word, read only |
| 02 (sequence mode) | 01H | Read only |
| 03 (sequence I/O signal) | 02H | Read only |
| 04 (alarm history) | 03H | Read only |
| 06 (current alarm readout) | 04H | Read only |
| 07 (parameter) | 05H | Double-word |
| 09 (alarm reset) | 06H | Write only |

Indirect Device Memory Designation

| | | | | |
|-------|------------------|---|--------------------|---|
| | 15 | 8 | 7 | 0 |
| n + 0 | Model | | Device Memory type | |
| n + 1 | Address No. | | | |
| n + 2 | Expansion code * | | Bit designation | |
| n + 3 | 00 | | Station number | |

* In the expansion code, set which word, higher or lower, is to be read when a double-word address is specified (expansion bit designation).

| | | | | | | | | | | | | | | | | | | |
|----|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 15 | | | | | | | | | | | | | | | | | | 8 |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |

└ Expansion bit designation
0: 0 to 15 bits
1: 16 to 31 bits

PLC_CTL

| Contents | F0 | F1 (= \$u n) | | F2 |
|-----------------------|---------------------|----------------|-----------------------------------|----|
| System status readout | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0 | |
| | | n + 2 | System 1 | |
| | | n + 3 | System 2 | |
| | | n + 4 | Model | |
| | | n + 5 | Occupied by maker, Zno | |
| | | n + 6 - n + 10 | Occupied by maker (max. 10 bytes) | |

Return data: Data stored from the servo amplifier to the TS2060

21.2.30 PH Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> bps | |
| Data Length | 8 bits | Do not change the default setting because the setting on the recorder cannot be changed. |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Odd</u> / Even | |
| Target Port No. | <u>1</u> to 31 | |

Recorder

The communication parameters can be set using keys attached to the front of the recorder.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | Setting | Example | Remarks |
|-------------|--------------------------------|-----------|---------|
| Station No. | <u>1</u> to 31 | 1 | |
| Baud rate | 4800 / 9600 / <u>19200</u> bps | 19200 bps | |
| Stop bit | <u>1</u> / 2 bits | 1 | |
| Parity | None / Even / <u>Odd</u> | Odd | |

- * The communication function of the recorder can be selected at the time of purchase. Select a model on which RS-485 transmission mode is available.
- * The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------------------|------|------------|
| F00 (setting value file) | 00H | |
| F01 (range file CH1) | 01H | |
| F02 (range file CH2) | 02H | |
| F03 (range file CH3) | 03H | |
| F04 (range file CH4) | 04H | |
| F05 (range file CH5) | 05H | |
| F06 (range file CH6) | 06H | |
| F07 (range file CH7) | 07H | |
| F08 (range file CH8) | 08H | |
| F09 (range file CH9) | 09H | |
| F10 (range file CH10) | 0AH | |
| F11 (range file CH11) | 0BH | |
| F12 (range file CH12) | 0CH | |
| F13 (warning setting file) | 0DH | |
| F14 (system file) | 0EH | |
| F15 (command file) | 0FH | |
| F16 (abnormal input information file) | 10H | Read only |
| F17 (input data file) | 11H | Read only |
| F19 (alarm output file) | 13H | Read only |
| F21 (transmission input data file) | 15H | Write only |
| F22 (message file) | 16H | |
| F33 (daily report file 1) | 21H | Read only |
| F34 (daily report file 2) | 22H | Read only |
| F35 (daily report file 3) | 23H | Read only |
| F37 (integral file 1) | 25H | Read only |
| F38 (integral file 2) | 26H | Read only |
| F51 (status information control file) | 33H | |

21.2.31 PHR (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|----------------------------------|--|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 9600 / <u>19200</u> bps | Do not change the default settings of the signal level, data length and stop bit because these settings on the recorder cannot be changed. |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | None / Even / <u>Odd</u> | |
| Target Port No. | 1 to 31 | |

Recorder

The communication parameters can be set using keys attached to the front of the recorder.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | Setting | Example | Remarks |
|------------------------------|--------------------------|-----------|-------------------------|
| Modbus station No. | <u>1</u> to 31 | 1 | |
| Modbus baud rate | 9600 / <u>19200</u> bps | 19200 bps | |
| Modbus parity | None / Even / <u>Odd</u> | Odd | |
| Front communication function | ON / OFF | ON | Be sure to set to "ON". |

*1 The communication function of the recorder can be selected at the time of purchase. Select a model on which RS-485 communication is available.

*2 The following communication parameters are fixed; data length: 8 bits and stop bit: 1 bit.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|---------|
| 4 (holding register) | 02H | |
| 3 (input register) | 03H | |

21.2.32 WA5000

Communication Setting

Editor

Communication setting

(Underlined setting: default)







| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | 1 / <u>2</u> bits | |
| Parity | None / <u>Even</u> / Odd | |
| CR / LF | <u>CR</u> / CR/LF | |
| Target Port No. | <u>1</u> to 31 | |
| Send Delay Time | 0 to 255 msec | *1 |

*1 If the send delay time is too short, "Communication Error "Format"" may occur. If this error occurs, set the send delay time to 5 msec or longer.

Digital Panel Meter

The communication parameters can be set using keys attached to the front of the digital panel meter.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | Item | Setting | Example | Remarks |
|---|-------|---------------------|---|---|
|  | BAUD | Baud rate setting | 4800: 4800 <u>9600: 9600</u> 192: 19200 384: 38400 | 9600 |
|  | DATA | Data length setting | <u>7: 7 bits</u> 8: 8 bits | 7 bits |
|  | P.BIT | Parity bit setting | <u>E: Even</u> o: Odd n: None | E: Even |
|  | S.BIT | Stop bit setting | <u>2: 2 bits</u> 1: 1 bit | 2: 2 bits |
|  | T- | Delimiter setting | <u>cr.LF: CR/LF</u> cr: CR | cr.LF: CR/LF |
|  | ADR | Unit ID setting | 01 to 31 (default: <u>00</u>) | 01 Specify a value when using RS-485 connection. |

* The communication function of the temperature controller can be selected with the output unit specified at the time of purchase. Select a model on which RS-485/RS-232C communication is available.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|------------------------|------|---------|
| DSP (display) | 00H | |
| CMP (comparator) | 01H | |
| SCL (scaling) | 02H | |
| CAL1 (calibration 1)*1 | 03H | |
| CAL2 (calibration 2) | 04H | |

*1 To perform zero calibration (0000), specify a value other than 0.

PLC_CTL

| Contents | F0 | F1 (= \$u n) | | F2 |
|--------------------------------------|---------------------|--------------|---|----|
| Hold remote control response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 0 | |
| | | n + 2 | Hold status 0: OFF, 1: ON | |
| Hold terminal response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 1 | |
| | | n + 2 | Hold status 0: OFF, 1: ON | |
| Hold remote control | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 2 | |
| | | n + 2 | Hold status 0: OFF, 1: ON | |
| Trigger input | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 3 | |
| | | n + 2 | Display type 0: Normal display 1: Over display 2: Peak hold display 3: Valley hold display 4: Peak valley hold display | |
| | | n + 3 | Measurement value | |
| | | n + 4 | Comparison result 0: OFF 1: HI 2: GO 3: LO | |
| Hold remote control cancel | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 4 | |
| Peak hold remote control response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 5 | |
| | | n + 2 | Peak hold type 0: Peak hold 1: Valley hold 2: Peak valley hold | |
| | | n + 3 | Peak hold status 0: OFF, 1: ON | |
| Peak hold terminal response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 6 | |
| | | n + 2 | Peak hold status 0: OFF, 1: ON | |
| Peak hold type setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 7 | |
| | | n + 2 | Peak hold type 0: Peak hold 1: Valley hold 2: Peak valley hold | |
| Peak hold remote control | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 8 | |
| | | n + 2 | Peak hold remote 0: OFF, 1: ON | |
| Peak hold value response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 9 | |
| | | n + 2 | Peak hold value | |
| | | n + 3 | Valley hold value | |
| Peak hold value clear | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 10 | |
| | | n + 2 | Peak hold type 0: Peak hold 1: Valley hold 2: Peak valley hold | |
| Peak hold remote control cancel | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 11 | |
| Digital zero remote control response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 12 | |
| | | n + 2 | Digital zero 0: OFF, 1: ON | |
| | | n + 3 | Displayed value | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|--|---------------------|--------------|--|----|
| Digital zero terminal response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 13 | |
| | | n + 2 | Digital zero 0: OFF, 1: ON | |
| Digital zero remote control | 1 - 8 (PLC1 - 8) | n | Station number | 4 |
| | | n + 1 | Command: 14 | |
| | | n + 2 | Digital zero 0: OFF, 1: ON, 2: ON when the value reaches the set value | |
| | | n + 3 | Setting value | |
| Digital zero remote control cancel | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 15 | |
| Comparison output remote control response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 16 | |
| | | n + 2 | Status 0: OFF 1: Set (ON) HI 2: Set (ON) GO 3: Set (ON) LO | |
| Comparison output remote control | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 17 | |
| | | n + 2 | Status 0: OFF 1: Set (ON) HI 2: Set (ON) GO 3: Set (ON) LO | |
| Comparison output remote control cancel | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 18 | |
| Remote control response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 19 | |
| | | n + 2 | Remote control status <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">Bit</div> <div style="border: 1px solid black; padding: 2px; text-align: center;"> <div style="display: flex; justify-content: space-between; width: 100px;"> -3210 </div> <div style="display: flex; justify-content: space-between; width: 100px;"> <div style="width: 20px; height: 20px;"></div> <div style="width: 20px; height: 20px;"></div> <div style="width: 20px; height: 20px;"></div> <div style="width: 20px; height: 20px;"></div> <div style="width: 20px; height: 20px;"></div> </div> </div> <div style="margin-left: 10px;"> <div style="margin-bottom: 5px;">Hold function</div> <div style="margin-bottom: 5px;">Peak hold</div> <div style="margin-bottom: 5px;">Digital zero</div> <div style="margin-bottom: 5px;">Comparison output</div> </div> </div> <p>* No remote control is performed when all bits are reset (OFF).</p> | |
| Maximum / minimum / (maximum - minimum) response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 20 | |
| | | n + 2 | Maximum | |
| | | n + 3 | Minimum | |
| | | n + 4 | (Maximum - minimum) | |
| Maximum / minimum / (maximum - minimum) clear | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 21 | |
| | | n + 2 | Maximum / minimum / (maximum - minimum) clear 0: Maximum 1: Minimum 2: Maximum - minimum | |
| Range response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 22 | |
| | | n + 2 | Range <div style="display: flex; justify-content: space-between;"> <div> 0: No designation 1: Range 11 2: Range 12 3: Range 13 4: Range 14 5: Range 15 6: Range 23 7: Range 24 8: Range 25 9: Range 26 10: KA 11: KB </div> <div> 12: J 13: T 14: R 15: S 16: B 17: PA 18: Pb 19: JPA 20: JPb 21: 1V 22: 2A </div> </div> | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|--|---------------------|--------------|---|----|
| Range setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 23 | |
| | | n + 2 | Range 1: Range 11 12: J 2: Range 12 13: T 3: Range 13 14: R 4: Range 14 15: S 5: Range 15 16: B 6: Range 23 17: PA 7: Range 24 18: Pb 8: Range 25 19: JPA 9: Range 26 20: JPb 10: KA 21: 1V 11: KB 22: 2A | |
| | | | | |
| Average number of responses | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 24 | |
| | | n + 2 | Average number of times 1 / 2 / 4 / 8 / 10 / 20 / 40 / 80 (times) | |
| Setting for average number of times | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 25 | |
| | | n + 2 | Average number of times 1 / 2 / 4 / 8 / 10 / 20 / 40 / 80 (times) | |
| Average number of movement times | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 26 | |
| | | n + 2 | Average number of movement times 0 (OFF) / 2 / 4 / 8 / 16 / 32 (times) | |
| Setting for average number of movement times | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 27 | |
| | | n + 2 | Average number of movement times 0 (OFF) / 2 / 4 / 8 / 16 / 32 (times) | |
| Step-wide response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 28 | |
| | | n + 2 | Step wide 1:1, 2:2, 5:5, 0:10 (digit) | |
| Step-wide setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 29 | |
| | | n + 2 | Step wide 1:1, 2:2, 5:5, 0:10 (digit) | |
| Communication function parameter response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 30 | |
| | | n + 2 | Baud rate 0: 2400, 1: 4800, 2: 9600, 3: 19200, 4: 38400 | |
| | | n + 3 | Data length 0: 7 bits, 1: 8 bits | |
| | | n + 4 | Parity 0: none, 1: odd, 2: even | |
| | | n + 5 | Stop bit 0: 1 bit, 1: 2 bits | |
| | | n + 6 | Delimiter 0: CR/LF, 1: CR | |
| Communication function parameter setting | 1 - 8 (PLC1 - 8) | n | Station number | 7 |
| | | n + 1 | Command: 31 | |
| | | n + 2 | Baud rate 0: 2400, 1: 4800, 2: 9600, 3: 19200, 4: 38400 | |
| | | n + 3 | Data length 0: 7 bits, 1: 8 bits | |
| | | n + 4 | Parity 0: none, 1: odd, 2: even | |
| | | n + 5 | Stop bit 0: 1 bit, 1: 2 bits | |
| | | n + 6 | Delimiter 0: CR/LF, 1: CR | |
| Unit ID response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 32 | |
| | | n + 2 | Unit ID 1 to 99 | |
| Unit ID setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 33 | |
| | | n + 2 | Unit ID 1 to 99 | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|-------------------------------------|---------------------|--------------|--|----|
| Analog output type response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 34 | |
| | | n + 2 | Analog output type 0: Not provided 1: OFF 2: 0 - 1 (V) 3: 0 - 10 (V) 4: 1 - 5 (V) 5: 0 - 20 (mA) 6: 4 - 20 (mA) | |
| Analog output type setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 35 | |
| | | n + 2 | Analog output type 1: OFF 2: 0 - 1 (V) 3: 0 - 10 (V) 4: 1 - 5 (V) 5: 0 - 20 (mA) 6: 4 - 20 (mA) | |
| Digital zero backup status response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 36 | |
| | | n + 2 | Digital zero backup status 0: OFF 1: ON | |
| Digital zero backup control | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 37 | |
| | | n + 2 | Digital zero backup status 0: OFF 1: ON | |
| Digital zero data save command | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 38 | |
| Input change response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 39 | |
| | | n + 2 | Input change 0: Not provided 1: Open collector 2: Logic 3: Magnetic | |
| Input change setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 40 | |
| | | n + 2 | Input change 1: Open collector 2: Logic 3: Magnetic | |
| Tracking zero response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 41 | |
| | | n + 2 | Tracking zero time 0 (OFF) / 1 to 99 | |
| | | n + 3 | Tracking zero width 0 (OFF) / 1 to 99 | |
| Tracking zero time setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 42 | |
| | | n + 2 | Tracking zero time 0 (OFF) / 1 to 99 | |
| Tracking zero width setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 43 | |
| | | n + 2 | Tracking zero width 0 (OFF) / 1 to 99 | |
| Sensor power response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 44 | |
| | | n + 2 | Sensor power 0: 5 V 1: 10 V | |
| Sensor power setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 45 | |
| | | n + 2 | Sensor power 0: 5 V 1: 10 V | |
| Power-on delay time response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 46 | |
| | | n + 2 | Power-on delay time 0 (OFF) / 1 to 30 | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|---|---------------------|--------------|---|----|
| Power-on delay time setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 47 | |
| | | n + 2 | Power-on delay time 0 (OFF) / 1 to 30 | |
| Protection response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 48 | |
| | | n + 2 | Protect 0: OFF 1: ON | |
| Protection setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 49 | |
| | | n + 2 | Protect 0: OFF 1: ON | |
| Unit No. response | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 50 | |
| | | n + 2 | Input unit number 1 to 18 | |
| | | n + 3 | Output unit number 0 to 7 | |
| Response to prohibition of key operations | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 51 | |
| | | n + 2 | Prohibition of key operations 0: OFF 1: ON | |
| Prohibition of key operations setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 52 | |
| | | n + 2 | Prohibition of key operations 0: OFF 1: ON | |
| Response to linearizing function status | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 53 | |
| | | n + 2 | Linearizing function 0: OFF 1: ON 2: CLR | |
| Linearizing function status setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 54 | |
| | | n + 2 | Linearizing function 0: OFF 1: ON 2: CLR | |
| Response to the number of linearization correction data | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 55 | |
| | | n + 2 | Linearization correction data 0 (clear) to 16 | |
| The number of linearization correction data setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 56 | |
| | | n + 2 | Linearization correction data 1 to 16 | |

| Contents | F0 | F1 (= \$u n) | F2 |
|--------------------------------|---------------------|--------------|---|
| Response to linearization data | 1 - 8 (PLC1 - 8) | n | Station number |
| | | n + 1 | Command: 57 |
| | | n + 2 | Read start number 1 to 16 |
| | | n + 3 | The number of read data 1 to 16 |
| | | n + 4 | Linearization data input value (start number + 0) |
| | | n + 5 | Linearization data output value (start number + 0) |
| | | n + 6 | Linearization data input value (start number + 1) |
| | | n + 7 | Linearization data output value (start number + 1) |
| | | n + 8 | Linearization data input value (start number + 2) |
| | | n + 9 | Linearization data output value (start number + 2) |
| | | n + 10 | Linearization data input value (start number + 3) |
| | | n + 11 | Linearization data output value (start number + 3) |
| | | n + 12 | Linearization data input value (start number + 4) |
| | | n + 13 | Linearization data output value (start number + 4) |
| | | n + 14 | Linearization data input value (start number + 5) |
| | | n + 15 | Linearization data output value (start number + 5) |
| | | n + 16 | Linearization data input value (start number + 6) |
| | | n + 17 | Linearization data output value (start number + 6) |
| | | n + 18 | Linearization data input value (start number + 7) |
| | | n + 19 | Linearization data output value (start number + 7) |
| | | n + 20 | Linearization data input value (start number + 8) |
| | | n + 21 | Linearization data output value (start number + 8) |
| | | n + 22 | Linearization data input value (start number + 9) |
| | | n + 23 | Linearization data output value (start number + 9) |
| | | n + 24 | Linearization data input value (start number + 10) |
| | | n + 25 | Linearization data output value (start number + 10) |
| | | n + 26 | Linearization data input value (start number + 11) |
| | | n + 27 | Linearization data output value (start number + 11) |
| | | n + 28 | Linearization data input value (start number + 12) |
| | | n + 29 | Linearization data output value (start number + 12) |
| | | n + 30 | Linearization data input value (start number + 13) |
| | | n + 31 | Linearization data output value (start number + 13) |
| | | n + 32 | Linearization data input value (start number + 14) |
| | | n + 33 | Linearization data output value (start number + 14) |
| | | n + 34 | Linearization data input value (start number + 15) |
| | | n + 35 | Linearization data output value (start number + 15) |

| Contents | F0 | F1 (= \$u n) | | F2 |
|----------------------------|---------------------|--------------|---|--------------|
| Linearization data setting | 1 - 8 (PLC1 - 8) | n | Station number | 6 , 36 |
| | | n + 1 | Command: 58 | |
| | | n + 2 | Read start number 1 to 16 | |
| | | n + 3 | The number of read data 1 to 16 | |
| | | n + 4 | Linearization data input value (start number + 0) | |
| | | n + 5 | Linearization data output value (start number + 0) | |
| | | n + 6 | Linearization data input value (start number + 1) | |
| | | n + 7 | Linearization data output value (start number + 1) | |
| | | n + 8 | Linearization data input value (start number + 2) | |
| | | n + 9 | Linearization data output value (start number + 2) | |
| | | n + 10 | Linearization data input value (start number + 3) | |
| | | n + 11 | Linearization data output value (start number + 3) | |
| | | n + 12 | Linearization data input value (start number + 4) | |
| | | n + 13 | Linearization data output value (start number + 4) | |
| | | n + 14 | Linearization data input value (start number + 5) | |
| | | n + 15 | Linearization data output value (start number + 5) | |
| | | n + 16 | Linearization data input value (start number + 6) | |
| | | n + 17 | Linearization data output value (start number + 6) | |
| | | n + 18 | Linearization data input value (start number + 7) | |
| | | n + 19 | Linearization data output value (start number + 7) | |
| | | n + 20 | Linearization data input value (start number + 8) | |
| | | n + 21 | Linearization data output value (start number + 8) | |
| | | n + 22 | Linearization data input value (start number + 9) | |
| | | n + 23 | Linearization data output value (start number + 9) | |
| | | n + 24 | Linearization data input value (start number + 10) | |
| | | n + 25 | Linearization data output value (start number + 10) | |
| | | n + 26 | Linearization data input value (start number + 11) | |
| | | n + 27 | Linearization data output value (start number + 11) | |
| | | n + 28 | Linearization data input value (start number + 12) | |
| | | n + 29 | Linearization data output value (start number + 12) | |
| | | n + 30 | Linearization data input value (start number + 13) | |
| | | n + 31 | Linearization data output value (start number + 13) | |
| | | n + 32 | Linearization data input value (start number + 14) | |
| | | n + 33 | Linearization data output value (start number + 14) | |
| | | n + 34 | Linearization data input value (start number + 15) | |
| | | n + 35 | Linearization data output value (start number + 15) | |

Return data: Data stored from the panel meter to the TS2060

21.2.33 APR-N (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / Even / <u>Odd</u> | |
| Target Port No. | <u>1</u> to 31 | |

AC Power Regulator

The communication parameter can be set using keys attached to the front of the AC power regulator. Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Item | Setting | Example |
|---------------|-----------------------------------|--|---------|
| 6.o02 | Setting device selection* | <u>APd</u> : Setting indicator nEt: Network device APr: APR main unit | nEt |
| 7.n01 | Communication protocol selection* | <u>m-S</u> : Master / slave parallel operation nEt: MODBUS RTU | nEt |
| 7.n02 | Station address | A000: 0 , A031: 31 (default: A001: 1) | A001 |
| 7.n04 | Baud rate selection | 4800: 4800 bps <u>9600</u> : 9600 bps 1.920: 19200 bps 3.840: 38400 bps | 9600 |
| 7.n05 | Parity bit + Stop bit selection | P0: Without parity, Stop bit 2 bits P1: Even parity, Stop bit 1 bits <u>P2: Odd parity, Stop bit 1 bits</u> P3: Without parity, Stop bit 1 bits | P2 |

*1 For communication with TS2060, select "Network device" for the setting device selection and "MODBUS RTU" for the communication protocol selection on this regulator.

*2 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------|------|--------------|
| --- | 02H | Byte address |

Indirect Device Memory Designation

- For word designation, specify the device memory No. (address) in even address.
Example: To make the setting of "output setting" for the function code 1.b01;
Specify "2" in the device memory No. (address).
- For bit designation, it is possible to specify the device memory No. (address) in both even and odd address.
Specify "00H" for the extensional code because the setting range for the bit address is 0 to 7.
Example: To make the setting of "gradient setting selection" for the function code 1.b09;
Specify "1" in the device memory No. (address), "00H" for the extensional code, and "00" or "01" in the bit No..

21.2.34 ALPHA5 (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Signal Level | RS-422/485 | |
| Baud Rate | 9600 / 19200 / <u>38400</u> / 115200 bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Even</u> / Odd | |
| Target Port No. | <u>1</u> to 31 | |

Servo Amplifier

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | | | Item | Setting | Example |
|--|--------|----------|-----------------------------------|---|---------|
| PA2 Extensional Function Setting | PA2_72 | (No. 72) | Station number | <u>1</u> to 31 | 1 |
| | PA2_73 | (No. 73) | Baud rate | <u>0: 38400 bps</u> 1: 19200 bps 2: 9600 bps 3: 115200 bps | 0 |
| | PA2_93 | (No. 93) | Parity bit / Stop bit selection | <u>0: Even parity, Stop bit 1 bits</u> 1: Odd parity, Stop bit 1 bits 2: Without parity, Stop bit 1 bits 3: Even parity, Stop bit 2 bits 4: Odd parity, Stop bit 2 bits 5: Without parity, Stop bit 2 bits | 0 |
| | PA2_97 | (No. 97) | Communication protocol selection* | <u>0: PC Loader protocol</u> 1: MODBUS RTU | 1 |

*1 For communication with TS2060, select "MODBUS RTU" for the communication protocol selection on the servo amplifier.

*2 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|------------------------------------|------|------------------------|
| 00 | (communication CONT / OUT signals) | 00H | Double-word* |
| 01 | (monitor) | 01H | Double-word, read only |
| 02 | (sequence monitor) | 02H | Double-word, read only |
| 03 | (various commands) | 03H | Double-word |
| 04 | (parameter) | 04H | Double-word |
| 05 | (immediate value data) | 05H | Double-word |

* Communication OUT signal is read only.

PLC_CTL

| Contents | F0 | F1 (=\$u n) | | | F2 | | |
|--------------------------|--------------------------|--|--|-------------------------------|----|-------|--|
| Positioning data reading | 1 - 8 (PLC1 - 8) | n | Station number | | | 4 | |
| | | n+1 | Command: 03 (HEX) | | | | |
| | | n+2 | Reading device memory address | | | | |
| | | n+3 | Reading positioning data count: m (1 to 9) | | | | |
| | | n+4 | Positioning data m = 1 | Positioning status and M code | | | |
| | | <div>Bit<div>15 to 876543210</div><div>M code</div><div>Not used</div><div>M code output timing</div><div>Not used</div><div>Step mode</div><div>Command mode</div><div>M code valid/invalid</div></div> | | | | | |
| | | n+5 | | Stop timer | | | |
| | | n+6 to n+7 | | Stop position | | | |
| | | n+8 to n+9 | | Rotation speed | | | |
| | | n+10 to n+11 | | Acceleration time | | | |
| n+12 to n+13 | Deceleration time | | | | | | |
| n+14 to n+(3+10m) | Positioning data (m = 2) | | | | | | |
| Positioning data writing | 1 - 8 (PLC1 - 8) | n | Station number *1 | | | 4+10m | |
| | | n+1 | Command: 10 (HEX) | | | | |
| | | n+2 | Writing device memory address | | | | |
| | | n+3 | Writing positioning data count: m (1 to 9) | | | | |
| | | n+4 | Positioning data m = 1 | Positioning status and M code | | | |
| | | <div>Bit<div>15 to 876543210</div><div>M code</div><div>Not used</div><div>M code output timing</div><div>Not used</div><div>Step mode</div><div>Command mode</div><div>M code valid/invalid</div></div> | | | | | |
| | | n+5 | | Stop timer | | | |
| | | n+6 to n+7 | | Stop position | | | |
| | | n+8 to n+9 | | Rotation speed | | | |
| | | n+10 to n+11 | | Acceleration time | | | |
| n+12 to n+13 | Deceleration time | | | | | | |
| n+14 to n+(3+10m) | Positioning data (m = 2) | | | | | | |

*1 Select station No. 0 for broadcast commands.

Return data: Data stored from the servo amplifier to the TS2060

21.2.35 ALPHA5 Smart (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-422/485 | |
| Baud Rate | 9600 / 19200 / <u>38400</u> / 115K bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Even</u> / Odd | |
| Target Port No. | <u>1</u> to 31 | |

Servo Amplifier

Set communication parameters.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Parameter | Item | Setting | Example |
|-------------------------------------|-----------------|---------------------------------------|---|
| PA2 Extended function setting | PA2_72 (No. 72) | Station number | <u>1</u> to 31 |
| | PA2_73 (No. 73) | Baud rate | <u>0: 38400 bps</u> 1: 19200 bps 2: 9600 bps 3: 115200 bps |
| | PA2_93 (No. 93) | Parity bit and stop bit selection | <u>0: Even parity, stop bit 1</u> 1: Odd parity, stop bit 1 2: Without parity, stop bit 1 3: Even parity, stop bit 2 4: Odd parity, stop bit 2 5: Without parity, stop bit 2 |
| | PA2_97 (No. 97) | Communication protocol selection*1 | <u>0: PC loader protocol</u> 1: MODBUS RTU |

*1 For communication with a TS2060, select "MODBUS RTU" for the communication protocol.

*2 The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|------------------------------------|------|------------------------|
| 00 (communication CONT/OUT signal) | 00H | Double-word *1 |
| 01 (monitor) | 01H | Double-word, read only |
| 02 (sequence monitor) | 02H | Double-word, read only |
| 03 (various commands) | 03H | Double-word |
| 04 (parameter) | 04H | Double-word |
| 05 (immediate data) | 05H | Double-word |

*1 Communication OUT signal: Read only

PLC_CTL

| Contents | F0 | F1 (= \$u n) | | F2 | | | | | | | | | | | | | | | | | | | |
|-----------------------------|--------------------------|--------------|---|-------|--|--------|----------------------|---|----------|---|-----------------------------|---|---|---|--------|--|----------|--|----------------------|--|----------|--|-----------------------------|
| Reading of positioning data | 1 - 8 (PLC1 - 8) | n | Station number | 4 | | | | | | | | | | | | | | | | | | | |
| | | n+1 | Command: 03 (HEX) | | | | | | | | | | | | | | | | | | | | |
| | | n+2 | Reading address | | | | | | | | | | | | | | | | | | | | |
| | | n+3 | Number of positioning data to read: m (1 to 9) | | | | | | | | | | | | | | | | | | | | |
| | | n+4 | Positioning data m = 1 | | Positioning status & M code Bit <table><tr><td>15 - 8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td colspan="2">M code</td><td colspan="2">Not used</td><td colspan="2">M code output timing</td><td colspan="2">Not used</td><td>Command method Step mode</td></tr></table> | 15 - 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | M code | | Not used | | M code output timing | | Not used | | Command method Step mode |
| | | 15 - 8 | | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | |
| | | M code | | | Not used | | M code output timing | | Not used | | Command method Step mode | | | | | | | | | | | | |
| | | n+5 | | | Stop timer | | | | | | | | | | | | | | | | | | |
| | | n+6 to n+7 | | | Stop position | | | | | | | | | | | | | | | | | | |
| | | n+8 to n+9 | | | Rotation speed | | | | | | | | | | | | | | | | | | |
| n+10 to n+11 | Acceleration time | | | | | | | | | | | | | | | | | | | | | | |
| n+12 to n+13 | Deceleration time | | | | | | | | | | | | | | | | | | | | | | |
| n+14 to n+(3+10m) | Positioning data (m = 2) | | | | | | | | | | | | | | | | | | | | | | |
| Writing of positioning data | 1 - 8 (PLC1 - 8) | n | Station number *1 | 4+10m | | | | | | | | | | | | | | | | | | | |
| | | n+1 | Command: 10 (HEX) | | | | | | | | | | | | | | | | | | | | |
| | | n+2 | Writing address | | | | | | | | | | | | | | | | | | | | |
| | | n+3 | Number of positioning data to write: m (1 to 9) | | | | | | | | | | | | | | | | | | | | |
| | | n+4 | Positioning data m = 1 | | Positioning status & M code Bit <table><tr><td>15 - 8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td colspan="2">M code</td><td colspan="2">Not used</td><td colspan="2">M code output timing</td><td colspan="2">Not used</td><td>Command method Step mode</td></tr></table> | 15 - 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | M code | | Not used | | M code output timing | | Not used | | Command method Step mode |
| | | 15 - 8 | | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | |
| | | M code | | | Not used | | M code output timing | | Not used | | Command method Step mode | | | | | | | | | | | | |
| | | n+5 | | | Stop timer | | | | | | | | | | | | | | | | | | |
| | | n+6 to n+7 | | | Stop position | | | | | | | | | | | | | | | | | | |
| | | n+8 to n+9 | | | Rotation speed | | | | | | | | | | | | | | | | | | |
| n+10 to n+11 | Acceleration time | | | | | | | | | | | | | | | | | | | | | | |
| n+12 to n+13 | Deceleration time | | | | | | | | | | | | | | | | | | | | | | |
| n+14 to n+(3+10m) | Positioning data (m = 2) | | | | | | | | | | | | | | | | | | | | | | |

*1 Select station No. 0 for broadcast commands.

Return data: Data stored from servo amplifier to TS2060

21.2.36 WE1MA (Ver. A) (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|--------------|
| Connection Mode | 1 : 1/ <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Even</u> / Odd | |
| Target Port No. | 0 to 247 | 0: Broadcast |

Electronic Multimeter

The communication parameter can be set using keys attached to the front of the electronic multimeter.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Setting Component | Setting No. | Item | Setting | Example |
|-------------------|-------------|------------------|--|---------|
| Adr | 231C | Station address | <u>1</u> to 247 | 1 |
| bPS | 232C | Baud rate | 4800 / <u>9600</u> / 19200 / 38400 bps | 9600 |
| PAr | 233C | Parity bit | <u>E</u> : Even o: Odd -: None | E |
| StoP | 234C | Stop bit | <u>1</u> / 2 bits | 1 |
| WEr | 235C | Protocol version | A: Version A | A |

* The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|-----------|
| 1 (input relay) | 01H | Read only |
| 4 (holding register) | 02H | |
| 3 (input register) | 03H | Read only |

21.2.37 WE1MA (Ver. B) (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--------------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Even</u> / Odd | |
| Target Port No. | 0 to 247 | 0: Broadcast |

Electronic Multimeter

Communication parameters can be set by operating the front-mounted keys of the electronic multimeter.
Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Setting Component | Setting No. | Item | Setting | Example |
|-------------------|-------------|------------------|--|---------|
| Adr | 231C | Address | <u>1</u> to 247 | 1 |
| bPS | 232C | Baud rate | 4800 / <u>9600</u> / 19200 / 38400 bps | 9600 |
| PAr | 233C | Parity | <u>E</u> : Even o: Odd -: None | E |
| StoP | 234C | Stop bit | <u>1</u> / 2 bits | 1 |
| WEr | 235C | Protocol version | B : Version B | B |

* The communication parameter (data length) is fixed to 8 bits.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------|------|-----------|
| 4 (holding register) | 02H | |
| 3 (input register) | 03H | Read only |

21.2.38 WSZ Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1</u> : <u>1</u> / 1 : n / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 / 57600 / 76800 / 115k bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Even</u> / Odd | |
| Target Port No. | <u>1</u> to 254 | |

WSZ Series

Make settings for the controller by using the software "WinProladder". For more information, refer to the instruction manual of the controller issued by the manufacturer.

Station number

(Underlined setting: default)

| Setting Items | Setting | Remarks |
|----------------|-----------------|---------|
| Station Number | <u>1</u> to 254 | |

PORT 0

Comm. parameters setting - Port 0

(Underlined setting: default)

| Setting Items | Setting | Remarks |
|---------------|--|--|
| Baud Rate | <u>9600</u> / 19200 / 38400 / 57600 / 115200 | The baud rate can also be set by specifying a value for the designated address. For more information, refer to the instruction manual of the controller issued by the manufacturer. |

* The following settings are fixed; data length: 7, stop bit: 1, parity: even, and protocol: Fatek Communication protocol.


WSZ-CB25 (PORT 1 / PORT 2)

Comm. parameters setting - Port 1 / Port 2

(Underlined setting: default)

| Setting Items | Setting | Remarks |
|---------------|---|--|
| Baud Rate | 4800 / <u>9600</u> / 19200 / 38400 / 57600 / 76800 / 115200 | The baud rate can also be set by specifying a value for the designated address. For more information, refer to the instruction manual of the controller issued by the manufacturer. |
| Parity | None / <u>Even</u> / Odd | |
| Data Bit | <u>7</u> / 8 | |
| Stop Bit | <u>1</u> / 2 | |
| Protocol | <u>Fatek Communication protocol</u> | |

DIPSW

| Setting Items | Setting | Remarks |
|---|--|--|
| Terminating resistance  | ON: With terminating resistance OFF: Without terminating resistance | This setting must be the same for both switches. |

Calendar

This model is equipped with a calendar function; however, the calendar data cannot be written from the TS2060. Thus, time correction must be performed on the controller side.

Available Device Memory


The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|--------------------------------|------|-------------------|
| R | (data register) | 00H | |
| D | (data register) | 01H | |
| X | (input relay) | 02H | WX as word device |
| Y | (output relay) | 03H | WY as word device |
| M | (internal relay) | 04H | WM as word device |
| S | (step relay) | 05H | WS as word device |
| T | (timer/contact) | 06H | WT as word device |
| C | (counter/contact) | 07H | WC as word device |
| TR | (timer/current value) | 08H | |
| CR | (counter/current value) | 09H | |
| 32CR | (32-bit counter/current value) | 0AH | Double-word |

Indirect Device Memory Designation

| | | | | |
|-------|------------------|---|-----------------|---|
| | 15 | 8 | 7 | 0 |
| n + 0 | Model | | Device type | |
| n + 1 | Address No. | | | |
| n + 2 | Expansion code * | | Bit designation | |
| n + 3 | 00 | | Station number | |

* In the expansion code, set which word, higher or lower, is to be read when a double-word address is specified.



21.2.39 WSZ Series (Ethernet)

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]

| PLC1 Properties Fuji Electric WSZ series(Ethernet) | |
|--|--------------------|
| Reset to Default | |
| Communication Setting | |
| Connection Mode | 1:1 |
| Retrials | 3 |
| Time-out Time(*100msec) | 50 |
| Send Delay Time(*msec) | 0 |
| Start Time(*sec) | 0 |
| Port No. | 10001 |
| Code | DEC |
| Text Process | LSB->MSB |
| Comm. Error Handling | Stop |
| Detail | |
| Priority | 1 |
| System device(\$s) V7 Compatible | None |
| Target Settings | |
| Connect To | 1:192.168.1.3(WSZ) |
| PLC Table | Setting... |
| Use Connection Check Device | None |

- IP address, port number, and maximum read value of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].


Valid only for 1 : 1 connection
Select the PLC for connection from those registered on the PLC table.

Set the IP address, port number and whether or not to use the KeepAlive function for the controller.

| No. | Port Name | IP Address | Port No. | KeepAlive |
|-----|-----------|-------------|----------|-------------------------------------|
| 0 | | | | <input type="checkbox"/> |
| 1 | WSZ | 192.168.1.3 | 500 | <input checked="" type="checkbox"/> |
| 2 | | | | <input type="checkbox"/> |
| 3 | | | | <input type="checkbox"/> |
| 4 | | | | <input type="checkbox"/> |
| 5 | | | | <input type="checkbox"/> |
| 6 | | | | <input type="checkbox"/> |
| 7 | | | | <input type="checkbox"/> |
| 8 | | | | <input type="checkbox"/> |
| 9 | | | | <input type="checkbox"/> |
| 10 | | | | <input type="checkbox"/> |
| 11 | | | | <input type="checkbox"/> |
| 12 | | | | <input type="checkbox"/> |
| 13 | | | | <input type="checkbox"/> |

WSZ Series

Make settings for the controller using the software "Ethernet Module Configuration Tool Version. 3. 3" For more information, refer to the instruction manual of the controller issued by the manufacturer.



| Item | | Remarks |
|---------------|--------------|--------------|
| General | IP Address | |
| | Subnet Mask | |
| | GateWay | |
| Service Ports | WSZ Protocol | Major Port |
| | | Default: 500 |

Calendar

This model is equipped with a calendar function; however, the calendar data cannot be written from the TS2060i. Thus, time correction must be performed on the controller side.

Available Device Memory


The available setting range of device memory varies depending on the connected device. Be sure to set within the range available with the device to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|-------------------------------------|------|-------------------|
| R (data register) | 00H | |
| D (data register) | 01H | |
| X (input relay) | 02H | WX as word device |
| Y (output relay) | 03H | WY as word device |
| M (internal relay) | 04H | WM as word device |
| S (step relay) | 05H | WS as word device |
| T (timer/contact) | 06H | WT as word device |
| C (counter/contact) | 07H | WC as word device |
| TR (timer/current value) | 08H | |
| CR (counter/current value) | 09H | |
| 32CR (32-bit counter/current value) | 0AH | Double-word |
| F (file register) | 0BH | |

Indirect Device Memory Designation

| | | | | |
|-------|------------------|---|-----------------|-------------|
| | 15 | 8 | 7 | 0 |
| n + 0 | Model | | | Device type |
| n + 1 | Address No. | | | |
| n + 2 | Expansion code * | | Bit designation | |
| n + 3 | 00 | | Station number | |

* In the expansion code, set which word, higher or lower, is to be read when a double-word address is specified.



21.2.40 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C


Wiring diagram 1 - C2




Wiring diagram 2 - C2



Wiring diagram 3 - C2




Wiring diagram 4 - C2




RS-422/RS-485


Wiring diagram 1 - C4




Wiring diagram 2 - C4











Wiring diagram 3 - C4







Wiring diagram 4 - C4




Wiring diagram 5 - C4**Wiring diagram 6 - C4****Wiring diagram 7 - C4****Wiring diagram 8 - C4**


Wiring diagram 9 - C4**Wiring diagram 10 - C4****Wiring diagram 11 - C4****Wiring diagram 12 - C4**

Wiring diagram 13 - C4**Wiring diagram 14 - C4****Wiring diagram 15 - C4****With an electronic multimeter connected at the terminal**


Wiring diagram 16 - C4




Wiring diagram 17 - C4




Wiring diagram 18 - C4



Wiring diagram 19 - C4




Wiring diagram 20 - C4




When Connected at MJ1/MJ2:

RS-232C


Wiring diagram 1 - M2




Wiring diagram 2 - M2



Wiring diagram 3 - M2




Wiring diagram 4 - M2




RS-422/RS-485


Wiring diagram 1 - M4




Wiring diagram 2 - M4




Wiring diagram 3 - M4













Wiring diagram 4 - M4








Wiring diagram 5 - M4






Wiring diagram 6 - M4**Wiring diagram 7 - M4****Wiring diagram 8 - M4****Wiring diagram 9 - M4****Wiring diagram 10 - M4**


Wiring diagram 11 - M4**Wiring diagram 12 - M4****Wiring diagram 13 - M4****Wiring diagram 14 - M4****Wiring diagram 15 - M4**

With an electronic multimeter connected at the end**Wiring diagram 16 - M4****Wiring diagram 17 - M4****Wiring diagram 18 - M4****Wiring diagram 19 - M4**

* Slide switch: RS-422 (lower)


Wiring diagram 20 - M4**Wiring diagram 21 - M4****Wiring diagram 22 - M4**

Wiring diagram 23 - M4



* Use shielded twist-pair cables.

Wiring diagram 24 - M4



* Use shielded twist-pair cables.

22. Gammaflux

22.1 Temperature Controller / Servo / Inverter

22.1 Temperature Controller / Servo / Inverter

Serial Connection

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|--------------------------------|-------------------------------------|------|-----------------|-----------------------|-----------------------|--------------|-----------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| TTC2100 | TTC2100-1 TTC2100-2 TTC2200-1 | COM2 | RS-485 | Wiring diagram1 - C4 | Wiring diagram 1 - M4 | | TTC2100. Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

22.1.1 TTC2100

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|------------------------------------|---------|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 57600 bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | Not provided | |
| Target Port No. | 0 to 31 | |

Temperature Controller


Be sure to match the settings to those made under [Communication Setting] of the editor.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|-----------------------|------|---------------------|
| TD (temperature data) | 00H | Read only |
| ZC (zone commands) | 01H | Partially read only |
| ZD (zone commands2) | 02H | Partially read only |

Specify the storage device memory.



Address denotations are as follows.

- For the TD:
Example: 0 : #0 : TD0000A
 - Station number
 - Storage device memory
 - 0: Volatile
 - 1: Nonvolatile
 - ZONE No. 00 - 3FH (1 - 64)
 - Command No. (HEX)
- For ZC, ZD:
Example: 0 : #1 : ZC000A0
 - Station number
 - Storage device memory
 - 0: Volatile
 - 1: Nonvolatile
 - ZONE No. 00 - 3FH (1 - 64)
 - Command No. (HEX)
 - Data No. (HEX)

Indirect Device Memory Designation

| | | | | |
|-------|--------------------|---|-----------------|-------------|
| | 15 | 8 | 7 | 0 |
| n + 0 | Model | | | Device type |
| n + 1 | Lower address No. | | | |
| n + 2 | Higher address No. | | | |
| n + 3 | Expansion code * | | Bit designation | |
| n + 4 | 00 | | Station number | |

- Specify the ZONE number, command number, and the data number for the address number.

Example: When specifying TD1000A
 Store "1000A" as the address number.
 Lower address No. = 000A (HEX)
 Higher address No. = 0001 (HEX)

Example: When specifying ZC100A0
 Store "100A0" as the address number.
 Lower address No. = 00A0 (HEX)
 Higher address No. = 0001 (HEX)

- Specify the storage device memory address with the expansion code.
 00H: Volatile
 01H: Nonvolatile

PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | | | | | F2 | | | | | | | | | | | | |
|--|--|--------------|--|----|----|---|----|----|---|----|----|----|----|---|---|---|---|---|---|---|
| External Standby Group | 1 - 8 (PLC1 - 8) | n | Station number | | | | | | 7 | | | | | | | | | | | |
| | | n + 1 | ZONE No.: Fixed to 0 | | | | | | | | | | | | | | | | | |
| | | n + 2 | ZONE COMMAND 008CH (Storage device memory: Volatile) 808CH (Storage device memory: Nonvolatile) | | | | | | | | | | | | | | | | | |
| | | n + 3 | <div>Bit</div> <table><tr><td>15</td><td>14</td><td colspan="2">-</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Zone16Zone1</div> | | | | | | | 15 | 14 | - | | 2 | 1 | 0 | | | | |
| | | 15 | 14 | - | | 2 | 1 | 0 | | | | | | | | | | | | |
| | | n + 4 | <div>Bit</div> <table><tr><td>15</td><td>14</td><td colspan="2">-</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Zone32Zone17</div> | | | | | | | 15 | 14 | - | | 2 | 1 | 0 | | | | |
| | | 15 | 14 | - | | 2 | 1 | 0 | | | | | | | | | | | | |
| n + 5 | <div>Bit</div> <table><tr><td>15</td><td>14</td><td colspan="2">-</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Zone48Zone33</div> | | | | | | 15 | 14 | - | | 2 | 1 | 0 | | | | | | | |
| 15 | 14 | - | | 2 | 1 | 0 | | | | | | | | | | | | | | |
| n + 6 | <div>Bit</div> <table><tr><td>15</td><td>14</td><td colspan="2">-</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Zone64Zone49</div> | | | | | | 15 | 14 | - | | 2 | 1 | 0 | | | | | | | |
| 15 | 14 | - | | 2 | 1 | 0 | | | | | | | | | | | | | | |
| Data Concentrator Resettable Alarm Relays | 1 - 8 (PLC1 - 8) | n | Station number | | | | | | 4 | | | | | | | | | | | |
| | | n + 1 | ZONE No.: Fixed to 0 | | | | | | | | | | | | | | | | | |
| | | n + 2 | ZONE COMMAND: 91H | | | | | | | | | | | | | | | | | |
| | | n + 3 | <div>Bit</div> <table><tr><td>-</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>-</td><td>3</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Not usedSet Output1, Resettable Alarm</div> <div>Set Output2, Non-resettable Alarm</div> <div>Set Output3</div> <div>Set Output4 (Alarm Bar)</div> <div>Clear1, Resettable Alarm</div> <div>Clear2, Non-resettable Alarm</div> <div>Clear Output3</div> <div>Clear Output4 (Alarm Bar)</div> <div>Clear Overtemp Occurred</div> | | | | | | | - | 12 | 11 | 10 | 9 | 8 | - | 3 | 2 | 1 | 0 |
| | | - | 12 | 11 | 10 | 9 | 8 | - | | 3 | 2 | 1 | 0 | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |

| Contents | F0 | F1 (=\$u n) | | F2 |
|----------------------------|---------------------|-------------|---|----|
| Turn All Zones On/Off | 1 - 8 (PLC1 - 8) | n | Station number | 7 |
| | | n + 1 | ZONE No.: Fixed to 0 | |
| | | n + 2 | ZONE COMMAND 0099H (Storage device memory: Volatile) 8099H (Storage device memory: Nonvolatile) | |
| | | n + 3 | Bit <div> <div>15</div> <div>14</div> <div>-</div> <div>2</div> <div>1</div> <div>0</div> </div> <div>Zone16</div> <div>Zone1</div> | |
| | | n + 4 | Bit <div> <div>15</div> <div>14</div> <div>-</div> <div>2</div> <div>1</div> <div>0</div> </div> <div>Zone32</div> <div>Zone17</div> | |
| | | n + 5 | Bit <div> <div>15</div> <div>14</div> <div>-</div> <div>2</div> <div>1</div> <div>0</div> </div> <div>Zone48</div> <div>Zone33</div> | |
| | | n + 6 | Bit <div> <div>15</div> <div>14</div> <div>-</div> <div>2</div> <div>1</div> <div>0</div> </div> <div>Zone64</div> <div>Zone49</div> | |
| Zones Temporarily in Group | 1 - 8 (PLC1 - 8) | n | Station number | 7 |
| | | n + 1 | ZONE No.: Fixed to 0 | |
| | | n + 2 | ZONE COMMAND 009AH (Storage device memory: Volatile) 809AH (Storage device memory: Nonvolatile) | |
| | | n + 3 | Bit <div> <div>15</div> <div>14</div> <div>-</div> <div>2</div> <div>1</div> <div>0</div> </div> <div>Zone16</div> <div>Zone1</div> | |
| | | n + 4 | Bit <div> <div>15</div> <div>14</div> <div>-</div> <div>2</div> <div>1</div> <div>0</div> </div> <div>Zone32</div> <div>Zone17</div> | |
| | | n + 5 | Bit <div> <div>15</div> <div>14</div> <div>-</div> <div>2</div> <div>1</div> <div>0</div> </div> <div>Zone48</div> <div>Zone33</div> | |
| | | n + 6 | Bit <div> <div>15</div> <div>14</div> <div>-</div> <div>2</div> <div>1</div> <div>0</div> </div> <div>Zone64</div> <div>Zone49</div> | |

22.1.2 Wiring Diagrams

When Connected at CN1:




CAUTION

- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-422/RS-485


Wiring diagram1 - C4



When Connected at MJ1/MJ2:


RS-422/RS-485

Wiring diagram 1 - M4



MEMO

MONITOUCH



23. GE Fanuc

23.1 PLC Connection

23.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | | Unit/Port | | Signal Level | Connection | | | Ladder Transfer*3 | | |
|---|--|--|---|----------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|---|
| | | | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | | | |
| 90 series | IC693CPU331 IC693CPU340 IC693CPU341 IC693CPU350 IC693CPU351 IC693CPU352 IC693CPU360 IC693CPU363 IC693CPU364 IC693CPU366 IC693CPU367 IC693CPU370 IC693CPU372 IC693CPU374 | | IC693CMM 311 | Port 1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × | | |
| | | | | Port 2 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | | | |
| | | | RS-422 | | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | Wiring diagram 5 - M4 | | | | |
| | | | IC698CPE010 IC698CPE020 IC698CRE020 IC697CPU731 IC697CPX772 IC697CPX782 IC697CPX928 IC697CPX935 IC697CPU780 IC697CGR772 IC697CGR935 IC697CPU789 IC697CPM790 | | IC697CMM711 | | RS-422 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | Wiring diagram 5 - M4 | × |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| IC693CPU350 IC693CPU360 IC693CPU363 IC693CPU364 IC693CPU366 IC693CPU367 IC693CPU374 | | COM port of the CPU | | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 4 - M4 | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| 90 series (SNP) | 90-30 series | IC693CPU311 IC693CPU313 IC693CPU323 IC693CPU331 IC693CPU340 IC693CPU341 IC693CPU350 IC693CPU360 IC693CPU364 IC693CPU366 IC693CPU367 IC693CPU370 IC693CPU372 IC693CPU374 PLUS | | Serial port (power supply) | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 4 - M4 | × | |
| | | | | IC693CMM 311 | Port 1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | | |
| | | | | | | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | | |
| | | Port 2 | RS-422 | | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | Wiring diagram 5 - M4 | | | | |
| | | | Serial port (power supply) | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 4 - M4 | | | |
| | | | | | PORT1 | | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | |
| | | PORT2 | | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 4 - M4 | | | |
| | | IC693CPU351 IC693CPU352 IC693CPU363 | | IC693CMM 311 | Port 1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | | |
| | | | | | | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | | |
| | | | | | Port 2 | RS-422 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | Wiring diagram 5 - M4 | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |

| PLC Selection on the Editor | CPU | | Unit/Port | | Signal Level | Connection | | | Ladder Transfer *3 |
|-----------------------------|---|--|--|-------------------|---|---|-----------------------|-----------------------|--------------------|
| | | | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) *2 | |
| 90 series (SNP) | 90-70 series | IC697CPU731 IC697CPU780 IC697CPU789 IC697CPM790 | Serial Port | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 4 - M4 | × |
| | | | IC697CMM 711 | Port 1/ Port 2 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | | | RS-422 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | Wiring diagram 5 - M4 | |
| | | IC697CPX772 IC697CPX782 IC697CPX928 IC697CPX935 IC697CGR772 IC697CGR935 | Serial Port1 | | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | |
| | | | Serial Port2 Serial Port3 | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 4 - M4 | |
| | | | IC697CMM 711 | Port 1/ Port 2 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | | | | RS-422 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | Wiring diagram 5 - M4 | |
| | | | | | COM1 | | RS-232C | Wiring diagram 4 - C2 | |
| | | | IC695CPU310 IC695CPU315 IC695CPU320 IC695CMU310 IC695CRU320 IC695CPE310 | COM2 | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | |
| | COM1 | | | RS-232C | Wiring diagram 4 - C2 + GE Fanuc IC693CBL316 | Wiring diagram 4 - M2 + GE Fanuc IC693CBL316 | | | |
| | IC698CPE010 IC698CPE020 IC698CPE030 IC698CPE040 IC698CRE020 IC698CRE030 IC698CRE040 | COM1 | | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 4 - M2 | | | |
| | | COM2 | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 4 - M4 | | |
| | | IC697CMM 711 | Port 1/ Port 2 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | | |
| | | | | RS-422 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 | Wiring diagram 5 - M4 | | |
| | VersaMax | IC200CPU001 IC200CPU002 IC200CPU005 IC200CPUE05 | PORT1 | | RS-232C | Wiring diagram 4 - C2 | Wiring diagram 4 - M2 | | |
| | | | PORT2 | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 4 - M4 | |
| | VersaMax Micro & Nano | Nano 10 PLCs Micro 14 PLCs | Serial Port | | RS-232C | Wiring diagram 5 - C2 | Wiring diagram 5 - M2 | | |
| | | | Serial Port 1 | | RS-232C | Wiring diagram 5 - C2 | Wiring diagram 5 - M2 | | |
| | | Micro 23 PLCs Micro 28 PLCs | Serial Port 2 | | RS-422 | Wiring diagram 1 - C4 | Wiring diagram 2 - M4 | Wiring diagram 4 - M4 | |
| | | | Serial Port | | RS-232C | Wiring diagram 5 - C2 | Wiring diagram 5 - M2 | | |
| | | Micro 20 PLCs Micro 40 PLCs Micro 64 PLCs | IC200USB001 | | RS-232C | Wiring diagram 5 - C2 | Wiring diagram 5 - M2 | | |
| | | | IC200USB002 | | RS-422 | Wiring diagram 3 - C4 | Wiring diagram 3 - M4 | Wiring diagram 6 - M4 | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*3 For the ladder transfer function, see the TS2060 Reference Manual 2.

Ethernet Connection (TS2060i Only)

| PLC Selection on the Editor | CPU | | Unit | TCP/IP ^{*1} | UDP/IP | Port No. | Ladder Transfer ^{*2} |
|-----------------------------|-----------------|-------------|---------------------------------------|----------------------|--------|-------------|-------------------------------|
| 90 series (Ethernet TCP/IP) | Series 90-70 | | IC697CMM742 (Type 2) | ○ | × | 18245 fixed | × |
| | Series 90-30 | | IC693CMM321 CPU with built-in port | ○ | × | | |
| RX3i (Ethernet TCP/IP) | PACSystems RX3i | IC695CPU310 | ETM001 | ○ | × | 18245 fixed | × |

*1 Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

*2 For the ladder transfer function, see the TS2060 Reference Manual 2.

23.1.1 90 Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / 1:n / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | None / <u>Odd</u> | |
| Target Port No. | 1 to 31 | |

PLC

Be sure to match the settings to those made under [Communication Setting] of the editor.

PCM

(Underlined setting: default)

| Item | Setting | Remarks |
|--------------------|---------------------------------------|---------------------------------------|
| Configuration Mode | CCM ONLY, BAS/CCM, PROG/CCM, CCM/PROG | |
| Port 1 | CCM Enable | YES |
| | CCM Mode | SLAVE |
| | Interface | RS-232 |
| | Date Rate | 4800 / 9600 / <u>19200</u> bps |
| | Flow Control | NONE |
| | Parity | NONE / <u>ODD</u> |
| | Retry Count | <u>NORMAL</u> / SHORT |
| | Timeout | <u>LONG</u> / MEDIUM / SHORT / NONE |
| | Turnaround Delay | <u>NONE</u> / 10 ms / 100 ms / 500 ms |
| | CPU ID | 1 to 31 |
| Port 2 | CCM Enable | YES |
| | CCM Mode | SLAVE |
| | Interface | <u>RS-232</u> / RS-485 |
| | Date Rate | 4800 / 9600 / <u>19200</u> bps |
| | Flow Control | NONE |
| | Parity | NONE / <u>ODD</u> |
| | Retry Count | <u>NORMAL</u> / SHORT |
| | Timeout | <u>LONG</u> / MEDIUM / SHORT / NONE |
| | Turnaround Delay | <u>NONE</u> / 10 ms / 100 ms / 500 ms |
| | CPU ID | 1 to 31 |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

IC693CMM311

(Underlined setting: default)

| Item | | Setting | Remarks |
|--------------------|------------------|--|---------|
| Configuration Mode | | CCM ONLY, CCM/RTU, RTU/CCM, SNP/CCM, CCM/SNP | |
| Port 1 | CCM Enable | YES | |
| | CCM Mode | SLAVE | |
| | Interface | RS-232 | |
| | Date Rate | 4800 / 9600 / <u>19200</u> bps | |
| | Flow Control | NONE | |
| | Parity | NONE / <u>ODD</u> | |
| | Retry Count | <u>NORMAL</u> / SHORT | |
| | Timeout | <u>LONG</u> / MEDIUM / SHORT / NONE | |
| | Turnaround Delay | <u>NONE</u> / 10 ms / 100 ms / 500 ms | |
| | CCM CPU ID | 1 to 31 | |
| Port 2 | CCM Enable | YES | |
| | CCM Mode | SLAVE | |
| | Interface | <u>RS-232</u> / RS-485 | |
| | Date Rate | 4800 / 9600 / <u>19200</u> bps | |
| | Flow Control | NONE | |
| | Parity | NONE / <u>ODD</u> | |
| | Retry Count | <u>NORMAL</u> / SHORT | |
| | Timeout | <u>LONG</u> / MEDIUM / SHORT / NONE | |
| | Turnaround Delay | <u>NONE</u> / 10 ms / 100 ms / 500 ms | |
| | CCM CPU ID | 1 to 31 | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|------------|------|---------|
| R | (register) | 00H | |
| I | (input) | 01H | |
| Q | (output) | 02H | |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

23.1.2 90 Series (SNP-X)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--------------------------------|---------|
| Connection Mode | <u>1</u> :1 / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> bps | |
| Data Length | 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Odd</u> / Even | |

PLC

Be sure to match the settings to those made under [Communication Setting] of the editor.

90 series (SNP-X)

| Item | Setting | Remarks |
|-------------------|-------------|---------|
| Baud Rate | 19200 bps | |
| Parity | Odd | |
| Transmission code | Data Length | 8 bits |
| | Stop Bit | 1 bit |
| Function | SNP-X | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------|------|-----------|
| R (register) | 00H | |
| I (input) | 01H | |
| Q (output) | 02H | |
| M (internal relay) | 03H | |
| G (global relay) | 04H | |
| AI (analog input) | 05H | |
| AQ (analog output) | 06H | |
| T (temporary memory relay) | 07H | |
| S (system status) | 08H | Read only |
| SA (system status) | 09H | |
| SB (system status) | 0AH | |
| SC (system status) | 0BH | |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

23.1.3 90 Series (SNP)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115K bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | None / <u>Odd</u> / Even | |

PLC

Be sure to match the settings to those made under [Communication Setting] of the editor.

IC693CMM311 / IC697CMM711

(Underlined setting: default)

| Item | | Setting | Remarks |
|--------------------|------------------------|--|--------------------------------------|
| Configuration Mode | | SNP ONLY, SNP/CCM, CCM/SNP, SNP/RTU, RTU/SNP | |
| Port 1 | SNP Enable | YES | |
| | SNP Mode | SLAVE | |
| | Interface | <u>RS485</u> / RS232 | Only RS232C supported by IC693CMM311 |
| | Date Rate | 4800 / 9600 / <u>19200</u> bps | |
| | Flow Control | NONE | |
| | Parity | <u>ODD</u> / EVEN / NONE | |
| | Stop Bits | <u>1</u> / 2 | |
| | Timeout | <u>LONG</u> / MEDIUM / SHORT / NONE | |
| | Modem Turnaround Delay | <u>NONE</u> / 10 ms / 100 ms / 500 ms | |
| Port 2 | SNP Enable | YES | |
| | SNP Mode | SLAVE | |
| | Interface | <u>RS485</u> / RS232 | |
| | Date Rate | 4800 / 9600 / <u>19200</u> bps | |
| | Flow Control | NONE | |
| | Parity | <u>ODD</u> / EVEN / NONE | |
| | Stop Bits | <u>1</u> / 2 | |
| | Timeout | <u>LONG</u> / MEDIUM / SHORT / NONE | |
| | Modem Turnaround Delay | <u>NONE</u> / 10 ms / 100 ms / 500 ms | |

90-30 Series / 90-70 Series

(Underlined setting: default)

| Parameter | Setting | Remarks |
|--------------------|--------------------------------|----------------------|
| Port Mode | SNP Slave | |
| Data Rate | 4800 / 9600 / <u>19200</u> bps | |
| Parity | <u>ODD</u> / EVEN / NONE | |
| Stop Bits | <u>1</u> / 2 | |
| Physical Interface | 2-wire / <u>4-wire</u> | Both valid for RS232 |

PAC Systems

(Underlined setting: default)

| Parameter | Setting | Remarks |
|--------------------|---|----------------------|
| Port Mode | SNP Slave | |
| Data Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115200 bps | |
| Parity | <u>ODD</u> / EVEN / NONE | |
| Stop Bits | 1 | |
| Physical Interface | 2-wire / <u>4-wire</u> | Both valid for RS232 |

VersaMax / VersaMax Micro & Nano / IC200USB001 / IC200USB002

(Underlined setting: default)

| Parameter | Setting | Remarks |
|--------------------|--|----------------------|
| Port Mode | SNP | |
| Port Type | Slave | |
| Data Rate | 4800 / 9600 / <u>19200</u> / 38400 bps | |
| Parity | <u>ODD</u> / EVEN / NONE | |
| Stop Bits | <u>1</u> / 2 | |
| Physical Interface | 2-wire / <u>4-wire</u> | Both valid for RS232 |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------|------|-------------------|
| R (register) | 00H | |
| I (input) | 01H | |
| Q (output) | 02H | |
| M (internal relay) | 03H | |
| G (global relay) | 04H | |
| AI (analog input) | 05H | |
| AQ (analog output) | 06H | |
| T (temporary memory relay) | 07H | |
| S (system status) | 08H | Read only |
| SA (system status) | 09H | |
| SB (system status) | 0AH | |
| SC (system status) | 0BH | |
| P (local subblock data) | 0CH | 90-70 series only |
| L (program block data) | 0DH | 90-70 series only |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting "1" from the actual address.

23.1.4 90 Series (Ethernet TCP/IP)

Communication Setting


Editor

Make the following settings on the editor. For more information, see “1.3.2 Ethernet Communication (TS2060i Only)”.

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 18245) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

Parameters



| Parameters | Values |
|-------------------------------------|---------------|
| Configuration Mode: | TCP/IP |
| Adapter Name: | 0.1 |
| IP Address: | 10.91.131.229 |
| Subnet Mask: | 255.255.255.0 |
| Gateway IP Address: | 10.91.131.1 |
| Status Address: | %I00001 |
| Status Length: | 80 |
| Network Time Sync: | SNTP |
| Max number of Web Server Connection | 1 |
| Max number of FTP Server Connection | 2 |

| Item | Setting | Remarks |
|--------------------|---|---------|
| IP Address | Set the IP address of the PLC. | |
| Subnet Mask | Set the subnet mask of the PLC. | |
| Gateway IP Address | Make settings in accordance with the network environment. | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060i.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------|------|-----------|
| R (register) | 00H | |
| I (input) | 01H | |
| Q (output) | 02H | |
| M (internal relay) | 03H | |
| G (global relay) | 04H | |
| AI (analog input) | 05H | |
| AQ (analog output) | 06H | |
| T (temporary memory relay) | 07H | |
| S (system status) | 08H | Read only |
| SA (system status) | 09H | |
| SB (system status) | 0AH | |
| SC (system status) | 0BH | |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting “1” from the actual address.

23.1.5 RX3i (Ethernet TCP/IP)

Communication Setting

Editor

Make the following settings on the editor. For more information, see “1.3.2 Ethernet Communication (TS2060i Only)”.

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number (No. 18245) of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

Parameters

| Item | Setting | Remarks |
|--------------------|---------------------------------------|---------|
| IP Address | Set the IP address of the PLC. | |
| Subnet Mask | Set the subnet mask of the PLC. | |
| Gateway IP Address | Specify according to the environment. | |

Calendar

This model is not equipped with the calendar function. Use the built-in clock of the TS2060i.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------|------|-----------|
| R (register) | 00H | |
| I (input) | 01H | |
| Q (output) | 02H | |
| M (internal relay) | 03H | |
| G (global relay) | 04H | |
| AI (analog input) | 05H | |
| AQ (analog output) | 06H | |
| T (temporary memory relay) | 07H | |
| S (system status) | 08H | Read only |
| SA (system status) | 09H | |
| SB (system status) | 0AH | |
| SC (system status) | 0BH | |

Indirect Device Memory Designation

For the device memory address number, specify the value obtained by subtracting “1” from the actual address.

23.1.6 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C


Wiring diagram 1 - C2




Wiring diagram 2 - C2




Wiring diagram 3 - C2



Wiring diagram 4 - C2







Wiring diagram 5 - C2







RS-422/RS-485

Wiring diagram 1 - C4




Wiring diagram 2 - C4**Wiring diagram 3 - C4****When Connected at MJ1/MJ2:****RS-232C****Wiring diagram 1 - M2**


Wiring diagram 2 - M2**Wiring diagram 3 - M2****Wiring diagram 4 - M2****Wiring diagram 5 - M2**

RS-422/RS-485


Wiring diagram 1 - M4




Wiring diagram 2 - M4




Wiring diagram 3 - M4




Wiring diagram 4 - M4



Wiring diagram 5 - M4




Wiring diagram 6 - M4



MEMO

MONITOUCH



24. Hitachi

24.1 PLC Connection

24.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*3} | |
|-----------------------------------|--------------------------------------|--------------------------------------|-----------------|------------------------|-----------------------|----------------------------|----------------------------------|--|
| | | | | CN1 TS2060i+ DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | | |
| HIDIC-S10/2 α , S10mini | S10 2 α | Interface on the CPU unit | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | × | |
| | LQP000 LQP010 LQP011 LQP120 | RS-232C connector on the CPU unit | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | | |
| | | LQE060 (CN1, CN2) | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | | |
| | | LQE160 (CN1, CN2) | | | | | | |
| | | LQE560 (CN1, CN2) | | | | | | |
| | | LQE165 (CN1, CN2) | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | | |
| | | LQE565 (CN1, CN2) | | | | | | |
| HIDIC-S10/4 α | S10 4 α | LWE805 | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | | |
| HIDIC-S10V | LQP510 | UP LINK | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | | |
| | | LQE560 (CN1, CN2) | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | | |
| | | LQE565 (CN1, CN2) | RS-422 | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*3 For the ladder transfer function, see the TS2060 Reference Manual 2.

Ethernet Connection (TS2060i Only)

| PLC Selection on the Editor | CPU | Unit | TCP/IP ^{*1} | UDP/IP | Port No. | Ladder Transfer ^{*2} |
|---|---------|--------|----------------------|--------|-----------------------|-------------------------------|
| HIDIC-S10/2 α , S10mini (Ethernet) | S10mini | LQE020 | ○ | × | 4301 (max. 4 units) | × |
| | | LQE520 | | | | |
| HIDIC-S10V (Ethernet) | LQP510 | LQE520 | | | 4302 (max. 4 units) | |
| | | LQP520 | | | 4302 to 4305 (1 each) | |

*1 Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

*2 For the ladder transfer function, see the TS2060 Reference Manual 2.

Network Connection (TS2060i Only)

OPCN-1

The optional communication interface unit "CUR-00" is required. For more information, refer to the Specifications for Communication Unit OPCN-1 manual.

| PLC Selection on the Editor | CPU | Unit | Unit on TS2060 | Ladder Transfer ^{*1} |
|-----------------------------|---------------|--------------------------------------|----------------|-------------------------------|
| HIDIC-S10 (OPCN-1) | S10V (LQP510) | LQE540 LQE545 | CUR-00 | × |
| | S10-mini | LQE040 LQE540 LQE045 LQE545 | | |
| | S10 α | LWE580 | | |

*1 For the ladder transfer function, see the TS2060 Reference Manual 2.

24.1.1 HIDIC-S10/2 α , S10mini

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115k bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | Odd | |

PLC

All PLC parameters are fixed to the following settings:

Baud rate: 19200 bps, data length: 8 bits, stop bit: 1 bit, parity: odd

However, when the optional RS-232C/RS-422 module is used, the channel and the protocol must be set using the channel No./protocol setting switch.

Channel No./Protocol Setting Switch

A maximum of two RS-232C/RS-422 modules (four channels) can be attached to one CPU. When using multiple channels, set a unique channel number (#1 to #4) for each.

LQE060

| MODU NO | Communication Mode | Channel No. |
|---------|--------------------|-------------|
| 8 | H-7338 protocol | #0 |
| 9 | | #1 |

LQE160 / LQE165 / LQE560 / LQE565

| MODU NO | Communication Mode | Channel No. |
|---------|--------------------|-------------|
| 8 | H-7338 protocol | #0 |
| 9 | | #1 |
| A | | #2 |
| E | | #3 |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|------------------------------------|------|-------------------|
| FW | (work register) | 00H | |
| X | (input) | 01H | XW as word device |
| Y | (output) | 02H | YW as word device |
| R | (internal relay) | 03H | RW as word device |
| G | (global link relay) | 04H | GW as word device |
| K | (keep relay) | 05H | KW as word device |
| T | (on-delay timer/contact) | 06H | TW as word device |
| U | (one-shot timer/contact) | 07H | UW as word device |
| C | (up/down counter/contact) | 08H | CW as word device |
| TS | (on-delay timer/set value) | 09H | |
| TC | (on-delay timer/enumerated value) | 0AH | |
| US | (one-shot timer/set value) | 0BH | |
| UC | (one-shot timer/enumerated value) | 0CH | |
| CS | (up/down counter/set value) | 0DH | |
| CC | (up/down counter/enumerated value) | 0EH | |
| DW | (data register) | 0FH | |
| E | (event register) | 10H | EW as word device |
| S | (system register) | 11H | SW as word device |
| J | (transfer register) | 12H | JW as word device |
| Q | (receive register) | 13H | QW as word device |
| M | (extensional internal register) | 14H | MW as word device |

24.1.2 HIDIC-S10/2 α , S10mini (Ethernet)

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

LQE020

Module No. setting switch

| MODU NO | Contents | |
|---------|----------------------------|--|
| 0 | Communication via 10BASE-5 | |
| 2 | Communication via 10BASE-T | |

ET. NET system

Specify the IP address and the subnet mask.

LQE520

Module No. setting switch

| MODU NO | Contents | |
|---------|----------------------------|--|
| 0 | Communication via 10BASE-5 | |
| 2 | Communication via 10BASE-T | |

S10V ET.NET system

Specify the IP address and the subnet mask.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|------------------------------------|------|-------------------|
| FW | (work register) | 00H | |
| X | (input) | 01H | XW as word device |
| Y | (output) | 02H | YW as word device |
| R | (internal relay) | 03H | RW as word device |
| G | (global link relay) | 04H | GW as word device |
| K | (keep relay) | 05H | KW as word device |
| T | (on-delay timer/contact) | 06H | TW as word device |
| U | (one-shot timer/contact) | 07H | UW as word device |
| C | (up/down counter/contact) | 08H | CW as word device |
| TS | (on-delay timer/set value) | 09H | |
| TC | (on-delay timer/enumerated value) | 0AH | |
| US | (one-shot timer/set value) | 0BH | |
| UC | (one-shot timer/enumerated value) | 0CH | |
| CS | (up/down counter/set value) | 0DH | |
| CC | (up/down counter/enumerated value) | 0EH | |
| DW | (data register) | 0FH | |
| E | (event register) | 10H | EW as word device |
| S | (system register) | 11H | SW as word device |
| J | (transfer register) | 12H | JW as word device |
| Q | (receive register) | 13H | QW as word device |
| M | (extensional internal register) | 14H | MW as word device |

24.1.3 HIDIC-S10/4 α

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 19200 bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | Odd | |

PLC

All PLC parameters are fixed to the following settings:

Baud rate: 19200 bps, data length: 8 bits, stop bit: 1 bit, parity: odd

Only RS-422 (4-wire) connection can be used. For RS-232C or RS-485 (2-wire) connection, a commercially available converter must be used.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------------------|------|-------------------|
| FW (work register) | 00H | |
| X (input) | 01H | XW as word device |
| Y (output) | 02H | YW as word device |
| R (internal relay) | 03H | RW as word device |
| G (global link relay) | 04H | GW as word device |
| K (keep relay) | 05H | KW as word device |
| T (on-delay timer/contact) | 06H | TW as word device |
| U (one-shot timer/contact) | 07H | UW as word device |
| C (up/down counter/contact) | 08H | CW as word device |
| TS (on-delay timer/set value) | 09H | |
| TC (on-delay timer/enumerated value) | 0AH | |
| US (one-shot timer/set value) | 0BH | |
| UC (one-shot timer/enumerated value) | 0CH | |
| CS (up/down counter/set value) | 0DH | |
| CC (up/down counter/enumerated value) | 0EH | |
| DW (data register) | 0FH | |
| E (event register) | 10H | EW as word device |
| S (system register) | 11H | SW as word device |
| J (transfer register) | 12H | JW as word device |
| Q (receive register) | 13H | QW as word device |
| M (extensional internal register) | 14H | MW as word device |

24.1.4 HIDIC-S10V

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | <u>1:1</u> / Multi-link2 | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115K bps | |
| Data Length | 8 bits | |
| Stop Bit | 1 bit | |
| Parity | Odd | |

PLC

All PLC parameters are fixed to the following settings:

Baud rate: 19200 bps, data length: 8 bits, stop bit: 1 bit, parity: odd

However, when the optional RS-232C/RS-422 module is used, the channel and the protocol must be set using the channel No./protocol setting switch.

Channel No./Protocol Setting Switch

A maximum of two RS-232C/RS-422 modules (four channels) can be attached to one CPU. When using multiple channels, set a unique channel number (#1 to #4) for each.

LQE560 / LQE565

| MODU NO | Communication Mode | Channel No. |
|---------|--------------------|-------------|
| 8 | H-7338 protocol | #0 |
| 9 | | #1 |
| A | | #2 |
| E | | #3 |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|--|------|--------------------|
| FW | (work register) | 00H | |
| X | (input) | 01H | XW as word device |
| Y | (output) | 02H | YW as word device |
| R | (internal relay) | 03H | RW as word device |
| G | (global link relay) | 04H | GW as word device |
| K | (keep relay) | 05H | KW as word device |
| T | (on-delay timer/contact) | 06H | TW as word device |
| U | (one-shot timer/contact) | 07H | UW as word device |
| C | (up/down counter/contact) | 08H | CW as word device |
| TS | (on-delay timer/set value) | 09H | |
| TC | (on-delay timer/enumerated value) | 0AH | |
| US | (one-shot timer/set value) | 0BH | |
| UC | (one-shot timer/enumerated value) | 0CH | |
| CS | (up/down counter/set value) | 0DH | |
| CC | (up/down counter/enumerated value) | 0EH | |
| DW | (data register) | 0FH | |
| E | (event register) | 10H | EW as word device |
| S | (system register) | 11H | SW as word device |
| J | (transfer register) | 12H | JW as word device |
| Q | (receive register) | 13H | QW as word device |
| M | (extensional internal register) | 14H | MW as word device |
| LB | (work register) | 15H | LBW as word device |
| LR | (work register 1 for ladder converter) | 16H | LRW as word device |
| LV | (work register 2 for ladder converter) | 17H | LVW as word device |
| LLL | (long-word work register) | 18H | Double-word |
| LFF | (floating-point work register) | 19H | |
| LWW | (word work register) | 1AH | |
| LML | (long-word work register) backup area | 1BH | Double-word |
| LGF | (floating-point work register) backup area | 1CH | |
| LXW | (word work register) backup area | 1DH | |

24.1.5 HIDIC-S10V (Ethernet)

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

LQE520

Module No. setting switch

| MODU NO | Contents | Remarks |
|---------|----------------------------|---------|
| 0 | Communication via 10BASE-5 | |
| 2 | Communication via 10BASE-T | |

S10V ET.NET

Specify the IP address and the subnet mask.

LQP520

Station No. setting switch

| S/T NO | Setting | Contents |
|--------|---------|--------------------------|
| U L | 0 0 | Set IP address is valid. |
| | F F | 192.192.192.1 is valid. |

Standard system tool

Specify the IP address and the subnet mask.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|--|------|--------------------|
| FW | (work register) | 00H | |
| X | (input) | 01H | XW as word device |
| Y | (output) | 02H | YW as word device |
| R | (internal relay) | 03H | RW as word device |
| G | (global link relay) | 04H | GW as word device |
| K | (keep relay) | 05H | KW as word device |
| T | (on-delay timer/contact) | 06H | TW as word device |
| U | (one-shot timer/contact) | 07H | UW as word device |
| C | (up/down counter/contact) | 08H | CW as word device |
| TS | (on-delay timer/set value) | 09H | |
| TC | (on-delay timer/enumerated value) | 0AH | |
| US | (one-shot timer/set value) | 0BH | |
| UC | (one-shot timer/enumerated value) | 0CH | |
| CS | (up/down counter/set value) | 0DH | |
| CC | (up/down counter/enumerated value) | 0EH | |
| DW | (data register) | 0FH | |
| E | (event register) | 10H | EW as word device |
| S | (system register) | 11H | SW as word device |
| J | (transfer register) | 12H | JW as word device |
| Q | (receive register) | 13H | QW as word device |
| M | (extensional internal register) | 14H | MW as word device |
| LB | (work register) | 15H | LBW as word device |
| LR | (work register 1 for ladder converter) | 16H | LRW as word device |
| LV | (work register 2 for ladder converter) | 17H | LVW as word device |
| LLL | (long-word work register) | 18H | Double-word |
| LFF | (floating-point work register) | 19H | |
| LWW | (word work register) | 1AH | |
| LML | (long-word work register) backup area | 1BH | Double-word |
| LGF | (floating-point work register) backup area | 1CH | |
| LXW | (word work register) backup area | 1DH | |
| A | (extensional internal register) | 1EH | AW as word device |
| N | (nesting coil) | 1FH | NW as word device |
| P | (process coil) | 20H | PW as word device |
| V | (edge contact) | 21H | VW as word device |
| Z | (Z register) | 22H | ZW as word device |
| IW | (extensional input) | 23H | |
| OW | (extensional output) | 24H | |
| BD | (special internal register) | 25H | |

24.1.6 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C

Wiring diagram 1 - C2




Wiring diagram 2 - C2




RS-422/RS-485

Wiring diagram 1 - C4

When connecting to the S10xα series, place a resistor of 50Ω (1/2 W) as shown below.




Wiring diagram 2 - C4




When Connected at MJ1/MJ2:

RS-232C

Wiring diagram 1 - M2




Wiring diagram 2 - M2




RS-422/RS-485

Wiring diagram 1 - M4




Wiring diagram 2 - M4



MEMO

MONITOUCH



25. Hitachi Industrial Equipment Systems

25.1 PLC Connection

25.2 Temperature Controller/Servo/Inverter Connection

25.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | | Signal Level | Connection | | | Ladder Transfer ^{*3} |
|-----------------------------|----------------|----------------------|-------------|--------------|--|-------------------------------------|----------------------------|-------------------------------|
| | | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) ^{*2} | |
| HIDIC-H | H series | COMM-2H | | RS-232C | Hakko Electronics' cable "D9-HI2-H-5M" or Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | | | RS-422 | Wiring diagram 1 - C4 | × | Wiring diagram 6 - M4 | |
| | | PERIPHERAL on CPU | | RS-232C | Hakko Electronics' cable "D9-HI2-H-5M" or Wiring diagram 1 - C2 | × | | |
| | | | | RS-232C | Hakko Electronics' cable "D9-HI2-H-5M" or Wiring diagram 1 - C2 | × | | |
| | | H252C CPU | PERIPHERAL1 | RS-232C | Hakko Electronics' cable "D9-HI2-H-5M" or Wiring diagram 1 - C2 | × | | |
| | | | PERIPHERAL2 | RS-232C | Hakko Electronics' cable "D9-HI2-H-5M" + Hitachi's "CNCOM-05" or Wiring diagram 1 - C2 + Hitachi's "CNCOM-05" | × | | |
| | EH-150 | On CPU | PORT1 | RS-232C | Wiring diagram 2 - C2 ^{*5} | Wiring diagram 2 - M2 | | |
| | | | PORT2 | RS-422 | Wiring diagram 2 - C4 | Wiring diagram 1 - M4 ^{*6} | Wiring diagram 7 - M4 | |
| | | EH-SIO ^{*4} | PORT1 | RS-232C | Wiring diagram 2 - C2 ^{*5} | Wiring diagram 2 - M2 | | |
| | | | PORT2 | RS-232C | Wiring diagram 2 - C2 ^{*5} | Wiring diagram 2 - M2 | | |
| | | | PORT1 | RS-422 | Wiring diagram 3 - C4 | Wiring diagram 2 - M4 ^{*6} | Wiring diagram 8 - M4 | |
| | | | PORT2 | RS-422 | Wiring diagram 3 - C4 | Wiring diagram 2 - M4 ^{*6} | Wiring diagram 8 - M4 | |
| | MICRO-EH | On CPU | PORT1 | RS-232C | Wiring diagram 2 - C2 ^{*5} | Wiring diagram 2 - M2 | | |
| | | | PORT2 | RS-422 | Wiring diagram 4 - C4 | Wiring diagram 3 - M4 ^{*6} | Wiring diagram 9 - M4 | |
| | | EH-OB232 | PORT2 | RS-232C | Wiring diagram 2 - C2 ^{*5} | Wiring diagram 2 - M2 | | |
| | | | PORT2 | RS-422 | Wiring diagram 5 - C4 | Wiring diagram 4 - M4 ^{*6} | Wiring diagram 10 - M4 | |
| | Web controller | EH-WD10 DR | SERIAL | RS-232C | Wiring diagram 3 - C2 | Wiring diagram 3 - M2 | | |
| | | EH-WA23 DR | | RS-422 | Wiring diagram 6 - C4 | Wiring diagram 5 - M4 ^{*6} | Wiring diagram 11 - M4 | |
| HIDIC-EHV | EH-150 EHV | EHV-CPU 128 | SERIAL | RS-232C | Wiring diagram 2 - C2 ^{*5} | Wiring diagram 2 - M2 | | × |
| | | | | RS-422 | Wiring diagram 5 - C4 | Wiring diagram 4 - M4 ^{*6} | Wiring diagram 10 - M4 | |
| | | EH-SIO ^{*4} | PORT1 | RS-232C | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | | | PORT2 | RS-422 | Wiring diagram 3 - C4 | Wiring diagram 2 - M4 ^{*6} | Wiring diagram 8 - M4 | |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).

For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*2 Set the slide switch for signal level selection to RS-422 position (lower). For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

*3 For the ladder transfer function, see the TS2060 Reference Manual 2.

*4 For the EH-SIO unit, EH-CPU548 (version E402 or later) and EH-CPU516 (version E202 or later) can only be used.

*5 Communication is also available using the Hitachi's "EH-RS05" cable with the cable used for the wiring diagram 1-C2.

*6 Communication cannot be established when "transmission control protocol 1, without port" is set. Set "transmission control protocol 2, without port". Note that some CPUs do not support "transmission control protocol 2, without port". For more information, refer to the PLC manual issued by the manufacturer.

Ethernet Connection (TS2060i Only)

| PLC Selection on the Editor | CPU | Unit/Port | TCP/IP *1 | UDP/IP | Port No. | Ladder Transfer *2 |
|-----------------------------|----------------|-----------|-----------|--------|-----------------------|--------------------|
| HIDIC-H (Ethernet) | H series | LAN-ETH2 | × | ○ | 3004 to 3005 (1 each) | × |
| | EH-150 | EH-ETH | | | 3004 to 3007 (1 each) | |
| | Web controller | ETHERNET | | | | |
| HIDIC-EHV (Ethernet) | EHV-CPU128 | ETHERNET | | | | |

*1 Only the built-in LAN port of the TS2060i can be used. The "CUR-03" communication unit cannot be used.

*2 For the ladder transfer function, see the TS2060 Reference Manual 2.

25.1.1 HIDIC-H

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-------------------|--|---|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 | |
| Baud Rate | 4800 / 9600 / <u>19200</u> / 38400 / 57600 / 115K bps | |
| Parity | None / Odd / <u>Even</u> | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Target Port No. | 0 to 31 | |
| Transmission Mode | Protocol 2 with port Protocol 1 without port Protocol 2 without port Protocol 1 with port | Protocol 2 achieves higher communication speed, compared to protocol 1. |

COMM-2H

ST No. switch

| ST No. | Setting | Remarks |
|-----------------------------------|---------|--|
| 10 ¹ , 10 ⁰ | 0 to 31 | If a value greater than 31 is set, the unit works as the station No. 31. |

MODE switch

| MODE | RS-232C | RS-422 |
|------|--|---|
| 0 | Transmission control protocol 1 with port | - |
| 2 | Transmission control protocol 1 without port | Transmission control protocol 1 with port |
| 7 | Transmission control protocol 2 with port | - |
| 9 | Transmission control protocol 2 without port | Transmission control protocol 2 with port |

* When connecting to both RS-232C and RS-422, set MODE switch to 9.

DIP switch

| Switch | Setting | Contents |
|--------|---------|----------------|
| 1 | OFF | Bit length 7 |
| 2 | OFF | 19200 bps |
| 3 | ON | |
| 4 | ON | |
| 5 | ON | With parity |
| 6 | ON | Even |
| 7 | OFF | Stop bit 1 |
| 8 | ON | With sum check |

PERIPHERAL Port

No particular setting is necessary on the PLC. The PLC always operates using the parameter shown below. Set the following parameter on TS2060.

| Item | Setting | Remarks |
|-------------------|-------------------------|---------|
| Signal Level | RS-232C | |
| Baud Rate | 19200 bps | |
| Data Length | 7 bits | ASCII |
| Stop Bit | 1 bit | |
| Parity | Even | |
| Transmission Mode | Protocol 1 without port | |
| Sum Check | Provided | |
| Port Operation | Dedicated port | |

EH-150 CPU

PORT1

Set the signal level and the communication protocol as shown below for PORT1 (dedicated port). Other parameters (7 bits, 1 bit, even) are fixed.

| Signal Level | Communication Protocol | CPU Model |
|--------------|---|--|
| RS-232C | Transmission control protocol 1 | EH-CPU104/104A/208/208A/308/308A/316/316A/448/448A/516/548 |
| | Transmission control protocol 2 | EH-CPU104A/208A/308A/316A/448/448A/516/548 |
| RS-422 | Transmission control protocol 1 | EH-CPU308A/316A/448/448A/516/548 |
| | Transmission control protocol 2 | |
| | Transmission control protocol 1 with port | |
| | Transmission control protocol 2 with port | |
| RS-485 | Transmission control protocol 1 with port | |
| | Transmission control protocol 2 with port | |

Procedure

1. Turn the PLC off and set the "Mode setting switch" (page 25-3).
2. Turn the power on and check the value for "Special internal output: WRF037" (page 25-4).
3. When the signal level and the communication control protocol have correctly been selected, setting is completed. If they are wrong, set a correct value and turn the power off and back on again.
4. Check the value set for WRF037.

Mode setting switch

| SW3 | SW4 | SW5 | Contents |
|-----|-----|-----|----------------------------|
| ON | ON | ON | Dedicated port, 4,800 bps |
| OFF | ON | | Dedicated port, 9,600 bps |
| ON | OFF | | Dedicated port, 19,200 bps |
| OFF | OFF | | Dedicated port, 38,400 bps |

Special internal output: WRF037

| Device Memory | Setting | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|---|-------------------|---|--------------|--------------------------------|-------|---------|---------|---------------------------------|--------|-------|---------------------------------|---------------|---------------|--------|---------------------------------|---------------|---------------|---------------------------------|---------------|---------------|---|---------------|---------------|---|---------------|---------------|--------|---|---------------|---------------|---|
| WRF037 | <div><div><div><div>1514131211109870</div><div>a b c d e f g h Station number 00 to 31 (BCD)</div></div><div><div>Communication interface setting (to be set by user)</div><table><tr><th>g</th><th>h</th><th>Interface</th></tr><tr><td>0</td><td>0</td><td>RS-232C</td></tr><tr><td>0</td><td>1</td><td>RS-422</td></tr><tr><td>1</td><td>0</td><td>RS-485</td></tr><tr><td>1</td><td>1</td><td>Not to be changed</td></tr></table></div><div><div>Communication interface status display (to be set by system)</div><table><tr><th>e</th><th>f</th><th>Interface</th></tr><tr><td>0</td><td>0</td><td>RS-232C</td></tr><tr><td>0</td><td>1</td><td>RS-422</td></tr><tr><td>1</td><td>0</td><td>RS-485</td></tr><tr><td>1</td><td>1</td><td>-</td></tr></table></div><div><div>Built-in terminating resistance 0: None 1: Provided</div><div>Station number 0: Without station number 1: With station number</div><div>Transmission control protocol 0: Transmission control protocol 1 1: Transmission control protocol 2</div><div>Bit setting 1: Set (when setting has been completed, the system sets this value to "0".)</div></div></div></div> | g | h | Interface | 0 | 0 | RS-232C | 0 | 1 | RS-422 | 1 | 0 | RS-485 | 1 | 1 | Not to be changed | e | f | Interface | 0 | 0 | RS-232C | 0 | 1 | RS-422 | 1 | 0 | RS-485 | 1 | 1 | - | |
| | g | h | Interface | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | RS-232C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | RS-422 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | RS-485 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | Not to be changed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| e | f | Interface | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | RS-232C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | RS-422 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | RS-485 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <div>Setting example</div> <table><tr><th>User Setting</th><th>After Turning the Power Back ON</th><th>Signal Level</th><th>Communication Control Protocol</th></tr><tr><td>H8000</td><td>H0000</td><td rowspan="2">RS-232C</td><td>Transmission control protocol 1</td></tr><tr><td>HC000</td><td>H4000</td><td>Transmission control protocol 2</td></tr><tr><td>H8100 (H9100)</td><td>H0500 (H1500)</td><td rowspan="4">RS-422</td><td>Transmission control protocol 1</td></tr><tr><td>HC100 (HD100)</td><td>H4500 (H5500)</td><td>Transmission control protocol 2</td></tr><tr><td>HA1** (HB1**)</td><td>H25** (H35**)</td><td>Transmission control protocol 1 with port</td></tr><tr><td>HE1** (HF1**)</td><td>H65** (H75**)</td><td>Transmission control protocol 2 with port</td></tr><tr><td>HA2** (HB2**)</td><td>H2A** (H3A**)</td><td rowspan="2">RS-485</td><td>Transmission control protocol 1 with port</td></tr><tr><td>HE2** (HF2**)</td><td>H6A** (H7A**)</td><td>Transmission control protocol 2 with port</td></tr></table> <div>Inside the parentheses () shows cases where the terminating resistance is provided.</div> | User Setting | After Turning the Power Back ON | Signal Level | Communication Control Protocol | H8000 | H0000 | RS-232C | Transmission control protocol 1 | HC000 | H4000 | Transmission control protocol 2 | H8100 (H9100) | H0500 (H1500) | RS-422 | Transmission control protocol 1 | HC100 (HD100) | H4500 (H5500) | Transmission control protocol 2 | HA1** (HB1**) | H25** (H35**) | Transmission control protocol 1 with port | HE1** (HF1**) | H65** (H75**) | Transmission control protocol 2 with port | HA2** (HB2**) | H2A** (H3A**) | RS-485 | Transmission control protocol 1 with port | HE2** (HF2**) | H6A** (H7A**) | Transmission control protocol 2 with port |
| User Setting | After Turning the Power Back ON | Signal Level | Communication Control Protocol | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H8000 | H0000 | RS-232C | Transmission control protocol 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HC000 | H4000 | | Transmission control protocol 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H8100 (H9100) | H0500 (H1500) | RS-422 | Transmission control protocol 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HC100 (HD100) | H4500 (H5500) | | Transmission control protocol 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HA1** (HB1**) | H25** (H35**) | | Transmission control protocol 1 with port | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HE1** (HF1**) | H65** (H75**) | | Transmission control protocol 2 with port | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HA2** (HB2**) | H2A** (H3A**) | RS-485 | Transmission control protocol 1 with port | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HE2** (HF2**) | H6A** (H7A**) | | Transmission control protocol 2 with port | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

* If the setting is undefined upon power-up, the default setting (transmission control protocol 1, without port, RS-232C) is applied.

PORT2

PORT2 settings are defined as "dedicated port, RS-232C, transmission control protocol 1, 7 bits, 1 bit, even", regardless of the CPU model.

Mode setting switch, PHL switch

| SW6 | PHL Switch | Baud Rate | Remarks |
|-----|------------|-----------|----------------------------------|
| OFF | OFF (Low) | 4800 bps | PHL signal (pin 4 at PORT2) Low |
| ON | OFF (Low) | 9600 bps | |
| OFF | ON (High) | 19200 bps | PHL signal (pin 4 at PORT2) High |
| ON | ON (High) | 38400 bps | |

EH-SIO

PORT1/PORT2

The following table shows the signal level and the communication protocol for each port. Other parameters (7 bits, 1 bit, even) are fixed.

| Port | Signal Level | Communication Protocol | EH-SIO Version |
|-------|--------------|---|-----------------------|
| PORT1 | RS-232C | Transmission control protocol 1 | Version 2.0 and later |
| | | Transmission control protocol 2 | Version 2.1 and later |
| PORT2 | RS-232C | Transmission control protocol 1 | Version 2.0 and later |
| | | Transmission control protocol 2 | Version 2.1 and later |
| | RS-422 | Transmission control protocol 1 | Version 2.0 and later |
| | | Transmission control protocol 2 | Version 2.1 and later |
| | | Transmission control protocol 1 with port | Version 2.0 and later |
| | | Transmission control protocol 2 with port | Version 2.1 and later |
| | RS-485 | Transmission control protocol 2 | Version 2.1 and later |
| | | Transmission control protocol 1 with port | Version 2.0 and later |
| | | Transmission control protocol 2 with port | Version 2.1 and later |

DIP switch 1/2

Set the baud rate for PORT1/2 using the DIPSW1/2 attached to the side of EH-SIO. For more information, refer to the PLC manual issued by the manufacturer.

Ladder program

Make initial settings for the transmission control protocol and the station number.
For more information, refer to the PLC manual issued by the manufacturer.

MICRO EH

The following table shows the signal level and the communication protocol for each port. Other parameters (7 bits, 1 bit, even) are fixed.

| CPU Model | Port | Signal Level | Communication Protocol |
|--|-------|--------------|---|
| EH-D10 EH-D14 / EH-A14 EH-D20 / EH-A20 EH-D23 / EH-A23 EH-D28 / EH-A28 EH-D40 / EH-A40 EH-D64 / EH-A64 | PORT1 | RS-232C | Transmission control protocol 1 |
| | | | Transmission control protocol 2 |
| EH-D23 / EH-A23 EH-D28 / EH-A28 | PORT2 | RS-422 | Transmission control protocol 1 |
| | | | Transmission control protocol 2 |
| | | | Transmission control protocol 1 with port |
| | | | Transmission control protocol 2 with port |
| EH-x64xxx + EH-OB232 | PORT2 | RS-232C | Transmission control protocol 1 |
| | | | Transmission control protocol 2 |
| EH-x64xxx + EH-OB485 | | RS-422 | Transmission control protocol 1 |
| | | | Transmission control protocol 2 |
| | | | Transmission control protocol 1 with port |
| | | | Transmission control protocol 2 with port |

PORT1

Procedure

1. Turn the PLC off and set the baud rate using the DIPSW.
 2. Turn the power on and check the value set for "Special internal output: WRF01A".
 3. When the transmission control protocol has correctly been selected, setting is completed. If it is wrong, set a correct value.
 4. Set the bit "R7F6" (setting write request) to save the setting in the flash memory.
- * It is not necessary to make the setting again upon next power-up once the setting has been saved in the flash memory.
Note that the ladder tool cannot be connected when the setting has been saved using the transmission control protocol 2.

DIPSW

| SW1 | SW2 | SW3 | SW4 | Baud Rate |
|-----|-----|-----|-----|-----------|
| ON | OFF | ON | OFF | 38.4 kbps |
| ON | OFF | OFF | OFF | 19.2 kbps |
| OFF | OFF | ON | OFF | 9600 bps |
| OFF | OFF | OFF | OFF | 4800 bps |

Special internal output: WRF01A

| Device Memory | Setting | Contents |
|---------------|---------|---------------------------------|
| WRF01A | H0000 | Transmission control protocol 1 |
| | H8000 | Transmission control protocol 2 |

PORT2

Procedure

1. Check the value set for special internal output "WRF03D".
 2. When the setting, such as transmission control protocol or baud rate, has correctly been defined, the setting is completed. If it is wrong, set a correct value. See "User Setting" described in "Special internal output: WRF03D".
 3. Check that the value set for WRF03D has been changed to the one shown in the "System Setting" column.
 4. Set the bit "R7F6" (setting write request) to save the setting in the flash memory.
- * It is not necessary to make the setting again upon next power-up once the setting has been saved in the flash memory.

Special internal output: WRF03D

| Device Memory | Setting | | | | | | | | | | | | | | | | | | | |
|--|---|---|-----------|--------------|----------------|-----------|-----------|-------|-----------|---------------------------------|-----------|-------|-------|---------------------------------|-------|-------|---|-------|-------|---|
| WRF03D | <div><div><div>15141312870</div><div>a b c d Station number 00 to 31 (BCD)</div></div><div><div>Station number</div><div>0: Without station number</div><div>1: With station number</div></div><div><div>Transmission control protocol</div><div>0: Transmission control protocol 1</div><div>1: Transmission control protocol 2</div></div><div><div>Bit setting</div><div>1: Set (when setting completed, the system sets this value to "0")</div></div><div><div>Baud rate</div><table><thead><tr><th>d</th><th>Baud Rate</th></tr></thead><tbody><tr><td>00000</td><td>4800 bps</td></tr><tr><td>00001</td><td>9600 bps</td></tr><tr><td>00010</td><td>19.2 kbps</td></tr><tr><td>00011</td><td>38.4 kbps</td></tr></tbody></table></div></div> | d | Baud Rate | 00000 | 4800 bps | 00001 | 9600 bps | 00010 | 19.2 kbps | 00011 | 38.4 kbps | | | | | | | | | |
| | d | Baud Rate | | | | | | | | | | | | | | | | | | |
| 00000 | 4800 bps | | | | | | | | | | | | | | | | | | | |
| 00001 | 9600 bps | | | | | | | | | | | | | | | | | | | |
| 00010 | 19.2 kbps | | | | | | | | | | | | | | | | | | | |
| 00011 | 38.4 kbps | | | | | | | | | | | | | | | | | | | |
| Setting example | | | | | | | | | | | | | | | | | | | | |
| <table><thead><tr><th>User Setting</th><th>System Setting</th><th>Interface</th><th>Baud Rate</th></tr></thead><tbody><tr><td>H8300</td><td>H0300</td><td>Transmission control protocol 1</td><td rowspan="4">38.4 kbps</td></tr><tr><td>HC300</td><td>H4300</td><td>Transmission control protocol 2</td></tr><tr><td>HA300</td><td>H2300</td><td>Transmission control protocol 1 with port</td></tr><tr><td>HE300</td><td>H6300</td><td>Transmission control protocol 2 with port</td></tr></tbody></table> | | | | User Setting | System Setting | Interface | Baud Rate | H8300 | H0300 | Transmission control protocol 1 | 38.4 kbps | HC300 | H4300 | Transmission control protocol 2 | HA300 | H2300 | Transmission control protocol 1 with port | HE300 | H6300 | Transmission control protocol 2 with port |
| User Setting | System Setting | Interface | Baud Rate | | | | | | | | | | | | | | | | | |
| H8300 | H0300 | Transmission control protocol 1 | 38.4 kbps | | | | | | | | | | | | | | | | | |
| HC300 | H4300 | Transmission control protocol 2 | | | | | | | | | | | | | | | | | | |
| HA300 | H2300 | Transmission control protocol 1 with port | | | | | | | | | | | | | | | | | | |
| HE300 | H6300 | Transmission control protocol 2 with port | | | | | | | | | | | | | | | | | | |

Web Controller

The following table shows the signal level and the communication protocol for each PLC. Other parameters (7 bits, 1 bit, even) are fixed.

| PLC | Port | Signal Level | Communication Protocol |
|-----------|--------|--------------|---|
| EH-WD10DR | SERIAL | RS-232C | Transmission control protocol 1 |
| | | | Transmission control protocol 2 |
| EH-WA23DR | PORT1 | RS-232C | Transmission control protocol 1 |
| | | | Transmission control protocol 2 |
| | | RS-422 | Transmission control protocol 1 |
| | | | Transmission control protocol 2 |
| | | | Transmission control protocol 1 with port |
| | | | Transmission control protocol 2 with port |
| | | RS-485 | Transmission control protocol 2 |
| | | | Transmission control protocol 1 with port |
| | | | Transmission control protocol 2 with port |

Procedure

Connect the computer (PC) to the web controller and make the setting for the PLC with the web browser. For more information, refer to the PLC manual issued by the manufacturer.

System configuration (RS-232C protocol/serial protocol → passive HI protocol)

Make settings for "Interface Type", "Transmission Control Procedure", "Transmission Speed".

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------------|------|-------------------|
| WR (internal output/word) | 00H | |
| X (external input) | 01H | WX as word device |
| Y (external output) | 02H | WY as word device |
| L (CPU link area) | 03H | WL as word device |
| M (data area) | 04H | WM as word device |
| TC (timer, counter/elapsed time) | 05H | |
| R (internal output/bit) | 06H | |
| TD (timer, counter/contact) | 07H | |
| WN (network input/output) | 08H | |

25.1.2 HIDIC-H (Ethernet)

Communication Setting

Editor

Make the following settings on the editor. For more information, see “1.3.2 Ethernet Communication (TS2060i Only)”.

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

LAN-ETH2 (H Series)

The IP address setting tool can be downloaded from the Hitachi Industrial Equipment Systems website.

Connect the computer (PC) to the RS-232C port of PORT1 and specify the IP address and the task port. For more information, refer to the PLC manual issued by the manufacturer.

EH-ETH (EH-150)

Make settings using the web server function incorporated in EH-ETH. For more information, refer to the PLC manual issued by the manufacturer.

IP address information setup

Set the IP address and the subnet mask.

Task code information setup

Select [UDP/IP] for [Protocol] and specify the port number.

Web Controller

Connect the computer (PC) to the web controller and make the setting for the PLC with the web browser. For more information, refer to the PLC manual issued by the manufacturer.

System configuration (IP address)

Specify the IP address and the subnet mask.

System configuration (ethernet protocol → passive HI protocol)

Select [UDP/IP] for [Task code port] and specify the port number.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | | TYPE | Remarks |
|---------------|-------------------------------|------|-------------------|
| WR | (internal output/word) | 00H | |
| X | (external input) | 01H | WX as word device |
| Y | (external output) | 02H | WY as word device |
| L | (CPU link area) | 03H | WL as word device |
| M | (data area) | 04H | WM as word device |
| TC | (timer, counter/elapsed time) | 05H | |
| R | (internal output/bit) | 06H | |
| TD | (timer, counter/contact) | 07H | |
| WN | (network input/output) | 08H | |

25.1.3 HIDIC-EHV

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-------------------|---|---|
| Connection Mode | 1 : 1 / <u>1 : n</u> / Multi-link2 | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / 19200 / <u>38400</u> / 57600 bps | |
| Data Length | 7 bits | |
| Stop Bit | 1 bit | |
| Parity | Even | |
| Target Port No. | 0 to 31 | |
| Transmission Mode | <u>Protocol 2 with port</u> Protocol 1 without port Protocol 2 without port Protocol 1 with port | Protocol 2 achieves higher communication speed, compared to protocol 1. |

EHV-CPU

CPU communication setting on control editor

| Item | Setting | | | | | | | | | | | | | | |
|------------------------------|---|-----------|------------------------|---------|---|---|--------|---|---|---|---|--------|---|---|---|
| Serial communication setting | Dedicated | | | | | | | | | | | | | | |
| Port type | RS-232C/RS-422/RS-485 The following table shows the combination of port type and communication protocols available. <table border="1"> <thead> <tr> <th>Port Type</th><th>Communication Protocol</th></tr> </thead> <tbody> <tr> <td rowspan="2">RS-232C</td><td>Transmission control protocol 1 (1 : 1)</td></tr> <tr> <td>Transmission control protocol 2 (1 : 1)</td></tr> <tr> <td rowspan="4">RS-422</td><td>Transmission control protocol 1 (1 : 1)</td></tr> <tr> <td>Transmission control protocol 2 (1 : 1)</td></tr> <tr> <td>Transmission control protocol 1 (1 : n)</td></tr> <tr> <td>Transmission control protocol 2 (1 : n)</td></tr> <tr> <td rowspan="3">RS-485</td><td>Transmission control protocol 2 (1 : 1)</td></tr> <tr> <td>Transmission control protocol 1 (1 : n)</td></tr> <tr> <td>Transmission control protocol 2 (1 : n)</td></tr> </tbody> </table> | Port Type | Communication Protocol | RS-232C | Transmission control protocol 1 (1 : 1) | Transmission control protocol 2 (1 : 1) | RS-422 | Transmission control protocol 1 (1 : 1) | Transmission control protocol 2 (1 : 1) | Transmission control protocol 1 (1 : n) | Transmission control protocol 2 (1 : n) | RS-485 | Transmission control protocol 2 (1 : 1) | Transmission control protocol 1 (1 : n) | Transmission control protocol 2 (1 : n) |
| Port Type | Communication Protocol | | | | | | | | | | | | | | |
| RS-232C | Transmission control protocol 1 (1 : 1) | | | | | | | | | | | | | | |
| | Transmission control protocol 2 (1 : 1) | | | | | | | | | | | | | | |
| RS-422 | Transmission control protocol 1 (1 : 1) | | | | | | | | | | | | | | |
| | Transmission control protocol 2 (1 : 1) | | | | | | | | | | | | | | |
| | Transmission control protocol 1 (1 : n) | | | | | | | | | | | | | | |
| | Transmission control protocol 2 (1 : n) | | | | | | | | | | | | | | |
| RS-485 | Transmission control protocol 2 (1 : 1) | | | | | | | | | | | | | | |
| | Transmission control protocol 1 (1 : n) | | | | | | | | | | | | | | |
| | Transmission control protocol 2 (1 : n) | | | | | | | | | | | | | | |
| Baud rate | 4800 / 9600 / 19200 / <u>38400</u> / 57600 bps | | | | | | | | | | | | | | |
| Communication protocol | See "Port Type" shown above. | | | | | | | | | | | | | | |
| Station number | 0 to 31 (to be specified when "with port" is selected) | | | | | | | | | | | | | | |

EH-SIO**PORT1/PORT2**

The following table shows the signal level and the communication protocol for each port. Other parameters (7 bits, 1 bit, even) are fixed.

| Port | Signal Level | Communication Protocol | EH-SIO Version |
|-------|--------------|---|-----------------------|
| PORT1 | RS-232C | Transmission control protocol 1 | Version 2.0 and later |
| | | Transmission control protocol 2 | Version 2.1 and later |
| PORT2 | RS-232C | Transmission control protocol 1 | Version 2.0 and later |
| | | Transmission control protocol 2 | Version 2.1 and later |
| | RS-422 | Transmission control protocol 1 | Version 2.0 and later |
| | | Transmission control protocol 2 | Version 2.1 and later |
| | | Transmission control protocol 1 with port | Version 2.0 and later |
| | | Transmission control protocol 2 with port | Version 2.1 and later |
| | | Transmission control protocol 2 | Version 2.1 and later |
| | | Transmission control protocol 1 with port | Version 2.0 and later |
| | RS-485 | Transmission control protocol 2 | Version 2.1 and later |
| | | Transmission control protocol 1 with port | Version 2.0 and later |
| | | Transmission control protocol 2 with port | Version 2.1 and later |

DIP switch 1/2

Set the baud rate for PORT1/2 using the DIPSW1/2 attached to the side of EH-SIO. For more information, refer to the PLC manual issued by the manufacturer.

Ladder program

Make initial settings for the transmission control protocol and the station number.
For more information, refer to the PLC manual issued by the manufacturer.

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------------|------|--------------------|
| WR (internal output/word) | 00H | |
| X (external input) | 01H | WX as word device |
| Y (external output) | 02H | WY as word device |
| L (CPU link area) | 03H | WL as word device |
| M (data area) | 04H | WM as word device |
| TC (timer, counter/elapsed time) | 05H | |
| R (internal output/bit) | 06H | |
| TD (timer, counter/contact) | 07H | |
| WN (network input/output) | 08H | |
| CL (counter clear) | 09H | |
| EX (extensional external input) | 0BH | WEX as word device |
| EY (extensional external output) | 0CH | WEY as word device |

25.1.4 HIDIC-EHV (Ethernet)

Communication Setting

Editor

Make the following settings on the editor. For more information, see "1.3.2 Ethernet Communication (TS2060i Only)".

- IP address for the TS2060i unit
 - When specified on the screen program:
[System Setting] → [Hardware Setting] → [Local Port IP Address]
 - When specified on the TS2060i unit:
Main Menu screen → [Ethernet Information] → [Ethernet]
- Port number for the TS2060i unit (for communication with PLC)
[System Setting] → [Hardware Setting] → [PLC Properties] → [Communication Setting]
- IP address and port number of the PLC
Register on the [PLC Table] in [System Setting] → [Hardware Setting] → [PLC Properties] → [Target Settings].

PLC

Control Editor

IP address setting

| Item | Contents | |
|-----------------|---------------------------------------|--|
| IP address | Specify the IP address for the PLC. | |
| Subnet mask | Specify the subnet mask for the PLC. | |
| Default gateway | Specify according to the environment. | |

Ethernet communication (task code) setting

| Item | Contents | |
|----------|---|--|
| Valid | Select a port to which the TS2060i unit is connected and make the port enabled. | |
| Port No. | Set the port number of the PLC. | |
| Protocol | UDP/IP | |

Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|----------------------------------|------|--------------------|
| WR (internal output/word) | 00H | |
| X (external input) | 01H | WX as word device |
| Y (external output) | 02H | WY as word device |
| L (CPU link area) | 03H | WL as word device |
| M (data area) | 04H | WM as word device |
| TC (timer, counter/elapsed time) | 05H | |
| R (internal output/bit) | 06H | |
| TD (timer, counter/contact) | 07H | |
| WN (network input/output) | 08H | |
| CL (counter clear) | 09H | |
| EX (extensional external input) | 0BH | WEX as word device |
| EY (extensional external output) | 0CH | WEY as word device |

25.1.5 Wiring Diagrams


When Connected at CN1:




- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C


Wiring diagram 1 - C2



Wiring diagram 2 - C2




Wiring diagram 3 - C2




RS-422/RS-485


Wiring diagram 1 - C4




Wiring diagram 2 - C4




Wiring diagram 3 - C4




Wiring diagram 4 - C4



Wiring diagram 5 - C4




Wiring diagram 6 - C4











When Connected at MJ1/MJ2:

RS-232C





Wiring diagram 1 - M2




Wiring diagram 2 - M2**Wiring diagram 3 - M2****RS-422/RS-485****Wiring diagram 1 - M4****Wiring diagram 2 - M4**

Wiring diagram 3 - M4**Wiring diagram 4 - M4****Wiring diagram 5 - M4****Wiring diagram 6 - M4**

* Slide switch: RS-422 (lower)

Wiring diagram 7 - M4**Wiring diagram 8 - M4****Wiring diagram 9 - M4****Wiring diagram 10 - M4**

Wiring diagram 11 - M4



* Slide switch: RS-422 (lower)

25.2 Temperature Controller/Servo/Inverter Connection

Inverter

| PLC Selection on the Editor | Model | Port | Signal Level | Connection | | | Lst File |
|--------------------------------|------------------|------|-----------------|-----------------------|-----------------------|--------------|-------------|
| | | | | CN1 TS2060i+DUR-00 | MJ1/MJ2 *1 | MJ2 (4-wire) | |
| SJ300 series | SJ300 SJH300 | TM2 | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | H_SJ300.Lst |
| SJ700 series | SJ700 SJ700-2 | TM2 | RS-485 | Wiring diagram 1 - C4 | Wiring diagram 1 - M4 | | H_SJ700.Lst |

*1 Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

25.2.1 SJ300 Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>4800</u> / 9600 / 19200 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 32 | |

Inverter

Parameter

The communication parameters can be set using keys attached to the inverter.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | | Function Name | Setting | Remarks |
|-----------------------------------|------|--|---|--|
| Basic setting | A001 | Frequency command selection | 03: RS-485 | To give the frequency command from TS2060, always select "03". |
| | A002 | Operation command selection | 03: RS-485 | To give the operation command from TS2060, always select "03". |
| Communication function adjustment | C070 | Data command selection | 03: RS-485 | |
| | C071 | Baud rate selection | <u>04: 4800 bps</u> 05: 9600 bps 06: 19200 bps | |
| | C072 | Communication station number selection | <u>1</u> to 32. | |
| | C073 | Communication bit length selection | <u>7: 7 bits</u> 8: 8 bits | |
| | C074 | Communication parity selection | <u>00: No parity</u> 01: Even parity 02: Odd parity | |
| | C075 | Communication stop bit selection | <u>1: 1 bit</u> 2: 2 bits | |
| | C078 | Communication latency | <u>0</u> to 1000. (msec) | |

Terminating resistance

Short-circuit RP-SN (control terminal block) on the terminal inverter.

Available Device Memory


The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|------------------|------|------------------------|
| d | 00H | Double-word, read only |
| F | 01H | Double-word |
| A | 02H | Double-word |
| b | 03H | Double-word |
| C | 04H | Double-word |
| H | 05H | Double-word |
| P | 06H | Double-word |
| T (trip history) | 07H | Double-word, read only |

Indirect Device Memory Designation

| | | | |
|-------|-------------------|-----|-----------------|
| | 15 | 8 7 | 0 |
| n + 0 | Models (11 to 18) | | Device type |
| n + 1 | Address No. | | |
| n + 2 | Expansion code * | | Bit designation |
| n + 3 | 00 | | Station number |

* In the expansion code, set which word, higher or lower, is to be read when a double-word address is specified.



| Contents | F0 | F1 (= \$u n) | | F2 |
|---|---------------------|--------------|--|----|
| Inverter status readout | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 4 | |
| | | n + 2 | Status A (BCD) 00: Initial status 01: Waiting for Vdc establishment 02: Stopping 03: Running 04: FRS in progress 05: JG in progress 06: DB in progress 07: F acquisition in progress 08: Retry in progress 09: UV in progress 10: Tripping 11: Waiting for reset | |
| | | n + 3 | Status B (BCD) 00: Stopping 01: Running 02: Tripping | |
| | | n + 4 | Status C (BCD) 00: -- 01: Stop 02: Deceleration 03: Constant speed 04: Acceleration 05: Normal turn 06: Reverse turn 07: Normal to reverse turn 08: Reverse to normal turn 09: Normal turn start 10: Reverse turn start | |
| Resetting of setting value to default * | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 8 | |
| Check for EEPROM availability | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 9 | |
| | | n + 2 | 01: Allowed | |
| Storing of setting values in EEPROM | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 10 | |
| Re-calculation of internal constant | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 11 | |

Return data: Data stored from inverter to TS2060

* When the initialize parameter of "b084" is set to "00", only trip history is cleared.

25.2.2 SJ700 Series

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|---|---------|
| Connection Mode | 1 : 1 / <u>1:n</u> / Multi-link2 / Multi-link2 (Ethernet) | |
| Signal Level | RS-232C / <u>RS-422/485</u> | |
| Baud Rate | <u>4800</u> / 9600 / 19200 bps | |
| Data Length | <u>7</u> / 8 bits | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 32 | |

Inverter

Parameter

The communication parameters can be set using keys attached to the inverter.

Be sure to match the settings to those made under [Communication Setting] of the editor.

(Underlined setting: default)

| Function Code | Function Name | Setting | Remarks |
|-----------------------------------|---------------|--|---|
| Basic setting | A001 | Frequency command selection | 03: RS-485 |
| | A002 | Operation command selection | 03: RS-485 |
| Communication function adjustment | C071 | Baud rate selection | <u>04: 4800 bps</u> 05: 9600 bps 06: 19200 bps |
| | C072 | Communication station number selection | <u>1</u> to 32. |
| | C073 | Communication bit length selection | <u>7: 7 bits</u> 8: 8 bits |
| | C074 | Communication parity selection | <u>00: No parity</u> 01: Even parity 02: Odd parity |
| | C075 | Communication stop bit selection | <u>1: 1 bit</u> 2: 2 bits |
| | C076 | Communication error selection | 02: Ignored |
| | C077 | Communication trip time | <u>0.00</u> - 99.99 (s) |
| | C078 | Communication latency | <u>0</u> - 1000. (ms) |
| | C079 | Communication mode selection | 00: ASCII |

Terminating resistance

Short-circuit RP-SN (control terminal block) on the terminal inverter.

Available Device Memory

The available setting range of device memory varies depending on the model. Be sure to set within the range available for the model to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|------------------|------|------------------------|
| d | 00H | Double-word, read only |
| F | 01H | Double-word |
| A | 02H | Double-word |
| b | 03H | Double-word |
| C | 04H | Double-word |
| H | 05H | Double-word |
| P | 06H | Double-word |
| T (trip history) | 07H | Double-word, read only |

Indirect Device Memory Designation

| | | | |
|-------|-------------------|-----|-----------------|
| | 15 | 8 7 | 0 |
| n + 0 | Models (11 to 18) | | Device type |
| n + 1 | Address No. | | |
| n + 2 | Expansion code * | | Bit designation |
| n + 3 | 00 | | Station number |

* In the expansion code, set which word, higher or lower, is to be read when a double-word address is specified.

| | | | | | | | | |
|----|---|---|---|---|---|---|---|---|
| 15 | | | | | | | | 8 |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |

└─ 0: 0 to 15 bits (lower)
1: 16 to 31 bits (higher)


PLC_CTL

Macro command "PLC_CTL F0 F1 F2"

| Contents | F0 | F1 (= \$u n) | | F2 |
|---|---------------------|--------------|--|----|
| Normal turn, reverse turn or stop command | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 0 | |
| | | n + 2 | 0: Stop command 1: Normal turn command 2: Reverse turn command | |
| Frequency command setting | 1 - 8 (PLC1 - 8) | n | Station number | 3 |
| | | n + 1 | Command: 1 | |
| | | n + 2 | Frequency (0 to 400 Hz) | |

| Contents | F0 | F1 (= \$u n) | | | | | | | | | | | | | | | F2 | | | | | | | | | | | | | | | | |
|--|---------------------|--------------|---|----|----|----|----|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|
| Intelligent terminal status setting | 1 - 8 (PLC1 - 8) | n | Station number | | | | | | | | | | | | | | | 6 | | | | | | | | | | | | | | | |
| | | n + 1 | Command: 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | n + 2 | Data (HH) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | <table><tr><td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Bit 0: "STAT" Pulse train position command enabled Bit 1: -- Bit 2: "ADD" Set frequency addition Bit 3: "F-TM": Forced terminal Bit 4: "ATR" Torque command input enabled Bit 5: "KHC" Integral power clear Bit 6: "SON" Servo ON Bit 7: "FOC" Pre-excitation Bit 8: "MI1" General-purpose input 1 Bit 9: "MI2" General-purpose input 2 Bit 10: "MI3" General-purpose input 3 Bit 11: "MI4" General-purpose input 4 Bit 12: "MI5" General-purpose input 5 Bit 13: "MI6" General-purpose input 6 Bit 14: "MI7" General-purpose input 7 Bit 15: "MI8" General-purpose input 8</div> | | | | | | | | | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | |
| n + 3 | Data (HL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table><tr><td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Bit 0: "SF1" Multistep speed (bit operation) Bit 1: "SF2" Multistep speed (bit operation) Bit 2: "SF3" Multistep speed (bit operation) Bit 3: "SF4" Multistep speed (bit operation) Bit 4: "SF5" Multistep speed (bit operation) Bit 5: "SF6" Multistep speed (bit operation) Bit 6: "SF7" Multistep speed (bit operation) Bit 7: "OLR" Overload limitation selection Bit 8: "TL" Torque limitation valid/invalid Bit 9: "TRQ1" Torque limit selection 1 Bit 10: "TRQ2" Torque limit selection 2 Bit 11 "PPI" P/PI selection Bit 12: "BOK" Brake check Bit 13: "ORT" Orientation Bit 14: "LAC" LAD cancel Bit 15: "PCLR" Positioning deviation clear</div> | | | | | | | | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | |
| n + 4 | Data (LH) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table><tr><td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Bit 0: "AT" Analog input selection Bit 1: -- Bit 2: "RS" Reset Bit 3: -- Bit 4: "STA" 3-wire start Bit 5: "STP" 3-wire retain Bit 6: "F/R" 3-wire normal/reverse turn Bit 7: "PID" PID selection (valid/invalid) Bit 8: "PIDC" PID integral reset Bit 9: -- Bit 10: -- Bit 11: "UP" Remote control acceleration Bit 12: "DWN" Remote control deceleration Bit 13: "UDC" Remote control data clear Bit 14: -- Bit 15: "OPE" Forced operation</div> | | | | | | | | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | |
| n + 5 | Data (LL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table><tr><td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr></table> <div>Bit 0: "FW" Normal turn command Bit 1: "RV" Reverse turn command Bit 2: "CF1" Multistep speed 1 (binary operation) Bit 3: "CF2" Multistep speed 2 (binary operation) Bit 4: "CF3" Multistep speed 3 (binary operation) Bit 5: "CF4" Multistep speed 4 (binary operation) Bit 6: "JG" Jogging (inching operation) Bit 7: "DB" External DC braking Bit 8: "SET" 2nd control Bit 9: "2CH" 2-step acceleration/deceleration Bit 10: -- Bit 11: "FRS" Free-run stop Bit 12: "EXP" External trip Bit 13: "USP" Unattended start protection function Bit 14: "CS" Commercial switching Bit 15: "SFT" Soft lock (control terminal block)</div> | | | | | | | | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | |

| Contents | F0 | F1 (= \$u n) | | F2 |
|---|---------------------|--------------|--|----|
| Inverter status readout | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 4 | |
| | | n + 2 | Status A (BCD) 00: Initial status 01: Waiting for Vdc establishment 02: Stopping 03: Running 04: FRS in progress 05: JG in progress 06: DB in progress 07: F acquisition in progress 08: Retry in progress 09: UV in progress 10: Tripping 11: Waiting for reset | |
| | | n + 3 | Status B (BCD) 00: Stopping 01: Running 02: Tripping | |
| | | n + 4 | Status C (BCD) 00: -- 01: Stop 02: Deceleration 03: Constant speed 04: Acceleration 05: Normal turn 06: Reverse turn 07: Normal to reverse turn 08: Reverse to normal turn 09: Normal turn start 10: Reverse turn start | |
| Resetting of setting value to default * | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 8 | |
| Check for EEPROM availability | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 9 | |
| | | n + 2 | 01: Allowed | |
| Storing of setting values in EEPROM | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 10 | |
| Re-calculation of internal constant | 1 - 8 (PLC1 - 8) | n | Station number | 2 |
| | | n + 1 | Command: 11 | |

 Return data: Data stored from inverter to TS2060

* When the initialize parameter of "b084" is set to "00", only trip history is cleared.

25.2.3 Wiring Diagrams


When Connected at CN1:



- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-485


Wiring diagram 1 - C4



When Connected at MJ1/MJ2:


RS-485

Wiring diagram 1 - M4



MEMO

MONITOUCH



26. HYUNDAI

26.1 PLC Connection

26.1 PLC Connection

Serial Connection

| PLC Selection on the Editor | CPU | Unit/Port | Signal Level | Connection | | | Ladder Transfer ^{*2} |
|-----------------------------|---|----------------|--------------|---------------------------|--------------------------|--------------------------|-------------------------------|
| | | | | CN1 TS2060i+ DUR-00 | MJ1/MJ2 ^{*1} | MJ2 (4-wire) | |
| Hi4 Robot (MODBUS RTU) | Hi4-0010 Hi4-A010 Hi4-0018 Hi4-A018 Hi4-0002 Hi4-0000-CP | Serial port #1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | × |
| | | Serial port #2 | | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| Hi5 Robot (MODBUS RTU) | Hi5 | Serial port #1 | RS-232C | Wiring diagram 1 - C2 | Wiring diagram 1 - M2 | | |
| | | Serial port #2 | | Wiring diagram 2 - C2 | Wiring diagram 2 - M2 | | |
| | | Serial port #1 | RS-422/485 | Wiring diagram 1 - C4 | × | Wiring diagram 1 - M4 | |
| | | Serial port #2 | | Wiring diagram 2 - C4 | × | Wiring diagram 2 - M4 | |

^{*1} Set the slide switch for signal selection of the MJ2 port to the RS-232C/485 position (upper).
For details, refer to "1.2.2 MJ1/MJ2" (page 1-6).

^{*2} For the ladder transfer function, see the TS2060 Reference Manual 2.

26.1.1 Hi4 Robot (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--------------|
| Connection Mode | <u>1:1</u> / 1 : n / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / 19200 / <u>38400</u> / 57600 / 76800 / 115K bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 247 | 0: Broadcast |

PLC

Serial Port #1 / Serial Port #2

DIP switches of built-in PLC

| DIPSW | Setting |
|-------|---------|
| SW1 | OFF |
| SW2 | OFF |
| SW3 | OFF |
| SW4 | OFF |
| SW5 | ON |
| SW6 | OFF |
| SW7 | OFF |
| SW8 | OFF |

Communication setting

Set parameters using the dedicated controller.

Turn the key on the upper right of the controller clockwise to switch to manual mode. Press the "F2 System" button to display the system menu. Then select "2: Control parameter" with the cursor keys.

For more information, refer to the manual issued by HYUNDAI.

| Item | Setting | Remarks |
|------------------|---|---------|
| Baud rate | 4800 / 9600 / 19200 / <u>38400</u> / 57600 / 76800 / 115K bps | |
| Character length | <u>8 bits</u> | |
| Stop bit | <u>1</u> / 2 bits | |
| Parity bit | <u>Disable</u> / Odd / Even | |
| Port usage | <u>MODBUS</u> | |
| Slave address | <u>1</u> to 247 | |

Calendar

This model is not equipped with the calendar function. Use the calendar function of the TS2060.

Available Device Memory


The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|------------------------------|------|-------------------------------------|
| X (External Input) | 00H | XW as word device, read only |
| D0 (PLC Input) | 01H | D0W as word device, read only |
| FBn.X (Fieldbus Input) | 02H | FBn.XW as word device, read only *1 |
| T (Timer (Contact)) | 04H | Read only |
| C (Counter (Contact)) | 05H | Read only |
| AI (Analog Input) | 06H | Read only |
| Y (External Output) | 07H | YW as word device |
| DI (PLC Output) | 08H | DIW as word device |
| FBn.Y (Fieldbus Output) | 09H | FBn.YW as word device, read only *1 |
| SP (Special) | 0BH | SPW as word device |
| R (Auxiliary) | 0CH | RW as word device |
| K (Keep) | 0DH | KW as word device |
| TW (Timer (Current Value)) | 0EH | |
| CW (Counter (Current Value)) | 0FH | |
| A0 (Analog Output) | 10H | |
| SW (System Memory) | 11H | |
| MW (Data Memory) | 12H | |
| V% (V% variable) | 13H | |
| RN (RN Register) | 14H | |
| V\$ (V\$ Variable) | 15H | *2 |
| V! (V! Variable) | 16H | Real number |

*1 Specify the array number for the data number.

Example: FBn.XW

Data No. of FBn device memory: 1 to 5



*2 The assigned device memory is expressed as shown on the right when editing the screen.
The address range available on MONITOUCH is V\$1.0 to V\$65536.17.

Example: V\$1.17

0 to 17
1 to 65536

Indirect Device Memory Designation


| | | | | |
|-----|-------------------|---|-----------------|---|
| | 15 | 8 | 7 | 0 |
| n+0 | Model | | Device type | |
| n+1 | Address No. *1 | | | |
| n+2 | Expansion code *2 | | Bit designation | |
| n+3 | 00 | | Station number | |

*1 Address numbers

- Other than V\$ device memory:
Specify the value obtained by subtracting "1" from the actual address.
- V\$ device memory:
V\$20.17
[B]: 0 to 17
[A]: 1 to 65536

Designate the address number as follows: $([A] - 1) * 18 + [B] = (20 - 1) * 18 + 17 = 359$ (DEC)

*2 FBn.XW, FBn.YW device memory



26.1.2 Hi5 Robot (MODBUS RTU)

Communication Setting

Editor

Communication setting

(Underlined setting: default)

| Item | Setting | Remarks |
|-----------------|--|--------------|
| Connection Mode | <u>1:1</u> / 1 : n / Multi-link2 / Multi-link2 (Ethernet) / 1 : n Multi-link2 (Ethernet) | |
| Signal Level | <u>RS-232C</u> / RS-422/485 | |
| Baud Rate | 4800 / 9600 / 19200 / <u>38400</u> / 57600 / 76800 / 115K bps | |
| Data Length | <u>8 bits</u> | |
| Stop Bit | <u>1</u> / 2 bits | |
| Parity | <u>None</u> / Odd / Even | |
| Target Port No. | <u>1</u> to 247 | 0: Broadcast |

PLC

Serial Port #1 / Serial Port #2

DIP switches of built-in PLC

| DIPSW | Setting |
|-------|---------|
| SW1 | OFF |
| SW2 | OFF |
| SW3 | OFF |
| SW4 | OFF |
| SW5 | ON |
| SW6 | OFF |
| SW7 | OFF |
| SW8 | OFF |

Communication setting

Set parameters using the dedicated controller.

Turn the key on the upper right of the controller clockwise to switch to manual mode. Press the "F2 System" button to display the system menu. Then select "2: Control parameter" with the cursor keys.

For more information, refer to the manual issued by HYUNDAI.

| Item | Setting | Remarks |
|------------------|---|---------|
| Baud rate | 4800 / 9600 / 19200 / <u>38400</u> / 57600 / 76800 / 115K bps | |
| Character length | <u>8 bits</u> | |
| Stop bit | <u>1</u> / 2 bits | |
| Parity bit | <u>Disable</u> / Odd / Even | |
| Port usage | <u>MODBUS</u> | |
| Communication | <u>RS-232C</u> / RS-422 / RS-485 | |
| Slave address | <u>1</u> to 247 | |

Calendar

This model is not equipped with the calendar function. Use the calendar function of the TS2060.


Available Device Memory

The available setting range of device memory varies depending on the PLC model. Be sure to set within the range available for the PLC to be used. Use [TYPE] when assigning indirect device memory for macro programs.

| Device Memory | TYPE | Remarks |
|---------------------------------------|------|-------------------------------------|
| X (External Input) | 00H | XW as word device, read only |
| D0 (PLC Input) | 01H | D0W as word device, read only |
| FBn.X (Fieldbus Input) | 02H | FBn.XW as word device, read only *1 |
| FNn.X (Fieldbus Node Input) | 03H | FNn.XW as word device, read only *1 |
| T (Timer (Contact)) | 04H | Read only |
| C (Counter (Contact)) | 05H | Read only |
| AI (Analog Input) | 06H | Read only |
| Y (External Output) | 07H | YW as word device |
| DI (PLC Output) | 08H | DIW as word device |
| FBn.Y (Fieldbus Output) | 09H | FBn.YW as word device, read only *1 |
| FNn.Y (Fieldbus Node Output) | 0AH | FNn.YW as word device, read only *1 |
| SP (Special) | 0BH | SPW as word device |
| R (Auxiliary) | 0CH | RW as word device |
| K (Keep) | 0DH | KW as word device |
| TW (Timer (Current Value)) | 0EH | |
| CW (Counter (Current Value)) | 0FH | |
| A0 (Analog Output) | 10H | |
| SW (System Memory) | 11H | |
| MW (Data Memory) | 12H | |
| V% (V% Variable) | 13H | |
| RN (RN Register) | 14H | |
| V\$ (V\$ Variable) | 15H | *2 |
| V! (V! Variable) | 16H | Real number |
| XL (External Input (Dword)) | 17H | Read only, double-word |
| D0L (PLC Input (Dword)) | 18H | Read only, double-word |
| FBn.XL (Fieldbus Input (Dword)) | 19H | Read only, double-word *1 |
| FNn.XL (Fieldbus Node Input (Dword)) | 1AH | Read only, double-word *1 |
| YL (External Output (Dword)) | 1BH | Double-word |
| DIL (PLC Output (Dword)) | 1CH | Double-word |
| FBn.YL (Fieldbus Output (Dword)) | 1DH | Double-word *1 |
| FNn.YL (Fieldbus Node Output (Dword)) | 1EH | Double-word *1 |
| SPL (Special (Dword)) | 1FH | Double-word |
| RL (Auxiliary (Dword)) | 20H | Double-word |
| KL (Keep (Dword)) | 21H | Double-word |
| TL (Timer (Current Value) (Dword)) | 22H | Double-word |
| CL (Counter (Current Value) (Dword)) | 23H | Double-word |
| SL (System Memory (Dword)) | 24H | Double-word |
| ML (Data Memory (Dword)) | 25H | Double-word |

*1 Specify the array number for the data number.

Data No. of FBn: 1 to 5
Data No. of FNn: 1 to 64



*2 The assigned device memory is expressed as shown on the right when editing the screen.
The address range available on MONITOUCH is V\$1.0 to V\$65536.17.

Example: V\$1.17

0 to 17
1 to 65536

Indirect Device Memory Designation

| | | | | |
|-----|-------------------------------|---|-----------------|-------------|
| | 15 | 8 | 7 | 0 |
| n+0 | Model | | | Device type |
| n+1 | Address No. * ¹ | | | |
| n+2 | Expansion code * ² | | Bit designation | |
| n+3 | 00 | | Station number | |

*1 Address numbers


- Other than V\$ device memory:
Specify the value obtained by subtracting "1" from the actual address.
- V\$ device memory:

V\$20.17

[B]: 0 to 17
[A]: 1 to 65536

Designate the address number as follows: $[(A) - 1] * 18 + [B] = (20 - 1) * 18 + 17 = 359$ (DEC)

*2 FBn.XW, FNn.XW, FBn.YW, FNn.YW, FBn.X, FNn.XL, FBn.YL, FNn.YL device memory



26.1.3 Wiring Diagrams

When Connected at CN1:




CAUTION


- The CN1 port is available only when the TS2060i is attached the optional "DUR-00".
- The "DUR-00" cannot be attached to the TS2060 (model name without "i"). Use the MJ1 and MJ2 ports for connection.

RS-232C

Wiring diagram 1 - C2




Wiring diagram 2 - C2




RS-422/RS-485

Wiring diagram 1 - C4




Wiring diagram 2 - C4




When Connected at MJ1/MJ2:

RS-232C

Wiring diagram 1 - M2




Wiring diagram 2 - M2




RS-422/RS-485

Wiring diagram 1 - M4




Wiring diagram 2 - M4



MEMO

MONITOUCH



Connection Compatibility List

December, 2017

| Manufacturer | Models | 1 : 1 | 1 : n Multi-drop | n : 1 Multi-link2 | Multi-link2 Ethernet | 1 : n Multi-link2 Ethernet | n : 1 Multi-link | Network |
|------------------------|--|-------|---------------------|----------------------|-------------------------|----------------------------------|---------------------|---------|
| A&D | AD4402 (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | AD4404 (MODBUS RTU) | ○ | ○ | ○ | | | | |
| Agilent | 4263 series | ○ | | ○ | ○ | | | |
| Allen-Bradley | PLC-5 | ○ | ○ | ○ | ○ | ○ | ○ | |
| | PLC-5 (Ethernet) | ○ | ○ | | | | | |
| | Control Logix / Compact Logix | ○ | | ○ | | | | |
| | Control Logix (Ethernet) | ○ | ○ | | | | | |
| | SLC500 | ○ | ○ | ○ | | | | |
| | SLC500 (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | NET-ENI (SLC500 Ethernet TCP/IP) | ○ | ○ | | | | | |
| | NET-ENI (MicroLogix Ethernet TCP/IP) | ○ | ○ | | | | | |
| | Micro Logix | ○ | ○ | ○ | | | | |
| | Micro Logix (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | Micro800 Controllers | ○ | | ○ | | | | |
| | Micro800 Controllers (Ethernet TCP/IP) | ○ | ○ | | | | | |
| Automationdirect | Direct LOGIC (K-Sequence) | ○ | | ○ | | | | |
| | Direct LOGIC (Ethernet UDP/IP) | ○ | ○ | | | | | |
| | Direct LOGIC (MODBUS RTU) | ○ | ○ | ○ | | | | |
| Azbil | MX series | ○ | ○ | ○ | ○ | ○ | | |
| | SDC10 | ○ | ○ | ○ | ○ | | | |
| | SDC15 | ○ | ○ | ○ | ○ | ○ | | |
| | SDC20 | ○ | ○ | ○ | ○ | | | |
| | SDC21 | ○ | ○ | ○ | ○ | | | |
| | SDC25/26 | ○ | ○ | ○ | ○ | ○ | | |
| | SDC30/31 | ○ | ○ | ○ | ○ | | | |
| | SDC35/36 | ○ | ○ | ○ | | | | |
| | SDC45/46 | ○ | ○ | ○ | ○ | ○ | | |
| | SDC40A | ○ | ○ | ○ | ○ | | | |
| | SDC40G | ○ | ○ | ○ | ○ | | | |
| | DMC10 | ○ | ○ | ○ | | | | |
| | DMC50(COM) | ○ | ○ | ○ | | | | |
| | AHC2001 | ○ | ○ | ○ | | | | |
| | AHC2001+DCP31/32 | ○ | ○ | ○ | | | | |
| | DCP31/32 | ○ | ○ | ○ | ○ | | | |
| | NX(CPL) | ○ | ○ | ○ | ○ | ○ | | |
| | NX(MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | NX(MODBUS TCP/IP) | ○ | ○ | | | | | |
| Banner | PresencePLUS (Ethernet/IP (TCP/IP)) | ○ | ○ | | | | | |
| Baumuller | BMx-x-PLC | ○ | | ○ | | | | |
| BECKHOFF | ADS protocol (Ethernet) | ○ | ○ | | | | | |
| Bosch Rexroth | Indra Drive | | ○ | | | | | |
| CHINO | LT400 Series (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | DP1000 | ○ | ○ | ○ | ○ | | | |
| | DB100B (MODBUS RTU) | ○ | ○ | ○ | ○ | | | |
| | KR2000 (MODBUS RTU) | ○ | ○ | ○ | ○ | | | |
| | LT230 (MODBUS RTU) | ○ | ○ | ○ | ○ | | | |
| | LT300 (MODBUS RTU) | ○ | ○ | ○ | ○ | | | |
| | LT830 (MODBUS RTU) | ○ | ○ | ○ | ○ | | | |
| CIMON | BP series | ○ | | ○ | ○ | | | |
| | CP series | ○ | | ○ | ○ | | | |
| | S series | ○ | ○ | ○ | ○ | ○ | | |
| | S series (Ethernet) | ○ | ○ | | | | | |
| DELTA | DVP series | ○ | ○ | ○ | | | | |
| | DVP-SE (MODBUS ASCII) | ○ | ○ | ○ | ○ | ○ | | |
| | DVP-SE (MODBUS TCP/IP) | ○ | ○ | | | | | |
| DELTA TAU DATA SYSTEMS | PMAC | ○ | | ○ | ○ | | | |
| | PMAC(Ethernet TCP/IP) | ○ | ○ | | | | | |
| EATON Cutler-Hammer | ELC | ○ | ○ | ○ | | | | |
| EMERSON | EC10/20/20H (MODBUS RTU) | ○ | ○ | ○ | ○ | | | |
| FANUC | Power Mate | ○ | | ○ | | | | |
| Fatek Automation | FACON FB Series | ○ | ○ | ○ | | | | |

| Manufacturer | Models | 1 : 1 | 1 : n Multi-drop | n : 1 Multi-link2 | Multi-link2 Ethernet | 1 : n Multi-link2 Ethernet | n : 1 Multi-link | Network |
|---------------|--------------------------------------|-------|---------------------|----------------------|-------------------------|----------------------------------|---------------------|---------|
| FESTO | FEC | ○ | | ○ | ○ | | | |
| FUFENG | APC Series Controller | ○ | ○ | ○ | ○ | ○ | | |
| Fuji Electric | MICREX-F series | ○ | ○ | ○ | | | ○ | |
| | MICREX-F series V4-compatible | ○ | ○ | ○ | | | | |
| | MICREX-F T-Link | | | | | | | ○ |
| | MICREX-F T-Link V4-compatible | | | | | | | ○ |
| | SPB (N mode) & FLEX-PC series | ○ | ○ | ○ | | | | |
| | SPB (N mode) & FLEX-PC CPU | ○ | | ○ | | | | |
| Fuji Electric | MICREX-SX (T-Link) | | | | | | | ○ |
| | MICREX-SX (OPCN1) | | | | | | | ○ |
| | MICREX-SX (SX BUS) | | | | | | | ○ |
| | MICREX-SX SPH/SPB/SPM/SPE/SPF series | ○ | | ○ | | | | |
| | MICREX-SX SPH/SPB/SPM/SPE/SPF CPU | ○ | | ○ | | | | |
| | MICREX-SX (Ethernet) | ○ | ○ | | | | | |
| | PYX (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | PXR (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | PXF (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | PXG (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | PXH (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | PUM (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | F-MPC04P (loader) | ○ | ○ | ○ | | | | |
| | F-MPC series / FePSU | ○ | ○ | ○ | | | | |
| | FVR-E11S | ○ | ○ | ○ | ○ | ○ | | |
| | FVR-E11S (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FVR-C11S (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FRENIC5000 G11S/P11S | ○ | ○ | ○ | ○ | ○ | | |
| | FRENIC5000 G11S/P11S (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FRENIC5000 VG7S (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FRENIC-Ace (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | FRENIC-HVAC/AQUA (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | FRENIC-Mini (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FRENIC-Eco (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FRENIC-Multi (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FRENIC-MEGA (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FRENIC-MEGA SERVO(MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | FRENIC-VG1(MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | FRENIC series (loader) | ○ | ○ | ○ | ○ | ○ | | |
| | HFR-C9K | ○ | ○ | ○ | | | | |
| | HFR-C11K | ○ | ○ | ○ | | | | |
| | HFR-K1K | ○ | ○ | ○ | | | | |
| | PPMC (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FALDIC-α series | ○ | ○ | ○ | | | | |
| | FALDIC-W series | ○ | ○ | ○ | ○ | ○ | | |
| | PH series | ○ | ○ | ○ | ○ | ○ | | |
| | PHR (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | WA5000 | ○ | ○ | ○ | | | | |
| | APR-N (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | ALPHA5 (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | ALPHA5 Smart (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | WE1MA (Ver. A)(MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | WE1MA (Ver. B)(MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | WSZ series | ○ | ○ | ○ | ○ | ○ | | |
| | WSZ series (Ethernet) | ○ | ○ | | | | | |
| Gammaflux | TTC2100 | ○ | ○ | ○ | | | | |
| GE Fanuc | 90 series | ○ | ○ | ○ | ○ | | | |
| | 90 series (SNP-X) | ○ | | ○ | | | | |
| | 90 series (SNP) | ○ | ○ | ○ | ○ | ○ | | |
| | 90 series (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | RX3i (Ethernet TCP/IP) | ○ | ○ | | | | | |
| Hitachi | HIDIC-S10/2α, S10mini | ○ | | ○ | | | | |
| | HIDIC-S10/2α, S10mini (Ethernet) | ○ | ○ | | | | | |
| | HIDIC-S10/4α | ○ | | ○ | ○ | | | |
| | HIDIC-S10 (OPCN-1) | | | | | | | ○ |
| | HIDIC-S10V | ○ | | ○ | | | | |
| | HIDIC-S10V (Ethernet) | ○ | ○ | | | | | |

| Manufacturer | Models | 1 : 1 | 1 : n Multi-drop | n : 1 Multi-link2 | Multi-link2 Ethernet | 1 : n Multi-link2 Ethernet | n : 1 Multi-link | Network |
|---|--|-------|---------------------|----------------------|-------------------------|----------------------------------|---------------------|---------|
| Hitachi Industrial Equipment Systems | HIDIC-H | ○ | ○ | ○ | | | ○ | |
| | HIDIC-H (Ethernet) | ○ | ○ | | | | | |
| | HIDIC-EHV | ○ | ○ | ○ | | | ○ | |
| | HIDIC-EHV (Ethernet) | ○ | ○ | | | | | |
| | SJ300 series | ○ | ○ | ○ | ○ | | | |
| | SJ700 series | ○ | ○ | ○ | ○ | | | |
| HYUNDAI | Hi5 Robot (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | Hi4 Robot (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| IAI | X-SEL controller | ○ | ○ | ○ | | | | |
| | ROBO CYLINDER (RCP2/ERC) | ○ | ○ | ○ | ○ | ○ | | |
| | ROBO CYLINDER (RCS/E-CON) | ○ | ○ | ○ | ○ | ○ | | |
| | PCON/ACON/SCON (MODBUS RTU) | ○ | ○ | ○ | | | | |
| IDEC | MICRO 3 | ○ | ○ | ○ | | | | |
| | MICRO Smart | ○ | ○ | ○ | | | | |
| | MICRO Smart pentra | ○ | ○ | ○ | ○ | | | |
| Jetter | JetControl Series2/3 (Ethernet UDP/IP) | ○ | ○ | | | | | |
| JTEKT | TOYOPUC | ○ | ○ | ○ | | | ○ | |
| | TOYOPUC (Ethernet) | ○ | ○ | | | | | |
| | TOYOPUC (Ethernet PC10 mode) | ○ | ○ | | | | | |
| | TOYOPUC-Plus | ○ | ○ | ○ | ○ | ○ | | |
| | TOYOPUC-Plus (Ethernet) | ○ | ○ | | | | | |
| | TOYOPUC-Nano (Ethernet) | ○ | ○ | | | | | |
| KEYENCE | KZ Series Link | ○ | ○ | ○ | ○ | ○ | ○ | |
| | KZ-A500 CPU | ○ | | ○ | | | | |
| | KZ/KV series CPU | ○ | | ○ | ○ | | | |
| | KZ24/300 CPU | ○ | | ○ | ○ | | | |
| | KV10/24 CPU | ○ | | ○ | | | | |
| | KV-700 | ○ | | ○ | | | | |
| | KV-700 (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | KV-1000 | ○ | | ○ | | | | |
| | KV-1000 (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | KV-3000/5000 | ○ | | ○ | | | | |
| | KV-3000/5000 (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | KV-7000 (Ethernet TCP/IP) | ○ | ○ | | | | | |
| Koatsu Gas Kogyo | R-BLT | ○ | | | | | | |
| KOGANEI | IBFL-TC | ○ | ○ | ○ | ○ | ○ | | |
| KOYO ELECTRONICS | SU/SG | ○ | ○ | ○ | ○ | | | |
| | SR-T (K protocol) | ○ | | ○ | ○ | | | |
| | SU/SG (K-Sequence) | ○ | | ○ | | | | |
| | SU/SG (Modbus RTU) | ○ | ○ | ○ | | | | |
| Lenze | ServoDrive9400 (Ethernet TCP/IP) | ○ | ○ | | | | | |
| LS | MASTER-KxxxS | ○ | | ○ | | | | |
| | MASTER-KxxxS CNET | ○ | ○ | ○ | | | | |
| | MASTER-K series (Ethernet) | ○ | ○ | | | | | |
| | GLOFA CNET | ○ | ○ | ○ | ○ | | ○ | |
| | GLOFA GM7 CNET | ○ | ○ | ○ | ○ | ○ | | |
| | GLOFA GM series CPU | ○ | | ○ | ○ | | | |
| | GLOFA GM series (Ethernet UDP/IP) | ○ | ○ | | | | | |
| | XGT/XGK series CNET | ○ | ○ | ○ | | | | |
| | XGT/XGK series CPU | ○ | | ○ | | | | |
| | XGT/XGK series (Ethernet) | ○ | ○ | | | | | |
| | XGT/XGI series CNET | ○ | ○ | ○ | ○ | ○ | | |
| | XGT/XGI series CPU | ○ | | ○ | ○ | | | |
| | XGT/XGI series (Ethernet) | ○ | ○ | | | | | |

| Manufacturer | Models | 1 : 1 | 1 : n Multi-drop | n : 1 Multi-link2 | Multi-link2 Ethernet | 1 : n Multi-link2 Ethernet | n : 1 Multi-link | Network |
|------------------------|--|-------|---------------------|----------------------|-------------------------|----------------------------------|---------------------|---------|
| MITSUBISHI ELECTRIC | A series link | ○ | ○ | ○ | | | ○ | |
| | A series CPU | ○ | | ○ | | | | |
| | A series (OPCN1) | | | | | | | ○ |
| | QnA series link | ○ | ○ | ○ | ○ | ○ | | |
| | QnA series CPU | ○ | | ○ | ○ | | | |
| | QnA series (Ethernet) | ○ | ○ | | | | | |
| | QnH (Q) series link | ○ | ○ | ○ | ○ | ○ | | |
| | QnH (Q) series CPU | ○ | | ○ | ○ | | | |
| | QnU series CPU | ○ | | ○ | ○ | | | |
| | Q00J/00/01CPU | ○ | | ○ | ○ | | | |
| | QnH (Q) series (Ethernet) | ○ | ○ | | | | | |
| | QnH (Q) series link (multi CPU) | ○ | ○ | ○ | ○ | ○ | | |
| | QnH (Q) series (multi CPU) (Ethernet) | ○ | ○ | | | | | |
| | QnH (Q) series CPU (multi CPU) | ○ | | ○ | ○ | | | |
| MITSUBISHI ELECTRIC | QnH (Q) series (Ethernet ASCII) | ○ | ○ | | | | | |
| | QnH (Q) series (multi CPU) (Ethernet ASCII) | ○ | ○ | | | | | |
| | QnU series (built-in Ethernet) | ○ | ○ | | | | | |
| | L series link | ○ | ○ | ○ | ○ | | | |
| | L series (built-in Ethernet) | ○ | ○ | | | | | |
| | L series CPU | ○ | | ○ | ○ | | | |
| | A series (CC-Link) | | | | | | | ○ |
| | QnA series (CC-Link) | | | | | | | ○ |
| | QnH (Q) series (CC-LINK) | | | | | | | ○ |
| | FX series CPU | ○ | | ○ | | | | |
| | FX2N/1N series CPU | ○ | | ○ | | | | |
| | FX1S series CPU | ○ | | ○ | | | | |
| | FX series link (A protocol) | ○ | ○ | ○ | | | ○ | |
| | FX-3U/3UC/3G series CPU | ○ | | ○ | | | | |
| | FX-3U/3GE series (Ethernet) | ○ | ○ | | | | | |
| | FX3U/3UC/3UG series link(A protocol) | ○ | ○ | ○ | | | ○ | |
| | FX-5U/5UC series | ○ | ○ | ○ | | | | |
| | FX-5U/5UC series (Ethernet) | ○ | ○ | | | | | |
| | A-Link + Net10 | | ○ | | | | | |
| | Q170MCP (multi CPU) | ○ | | ○ | ○ | | | |
| | Q170 series (multi CPU) (Ethernet) | ○ | ○ | | | | | |
| | iQ-R series (Built-in Ethernet) | ○ | ○ | | | | | |
| | iQ-R series link | ○ | ○ | ○ | ○ | ○ | | |
| | iQ-R series (Ethernet) | ○ | ○ | | | | | |
| | FR-*500 | ○ | ○ | ○ | | | | |
| | FR-V500 | ○ | ○ | ○ | | | | |
| | MR-J2S-*A | ○ | ○ | ○ | ○ | | | |
| | MR-J3-*A | ○ | ○ | ○ | ○ | | | |
| | MR-J3-*T | ○ | ○ | ○ | ○ | | | |
| | MR-J4-*A | ○ | ○ | ○ | ○ | | | |
| | FR-E700 | ○ | ○ | ○ | ○ | | | |
| MODICON | Modbus RTU | ○ | | ○ | ○ | | | |
| MOELLER | PS4 | ○ | | ○ | ○ | | | |
| MOOG | J124-04x | ○ | ○ | ○ | ○ | | | |
| M-SYSTEM | R1M series (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |

| Manufacturer | Models | 1 : 1 | 1 : n Multi-drop | n : 1 Multi-link2 | Multi-link2 Ethernet | 1 : n Multi-link2 Ethernet | n : 1 Multi-link | Network |
|----------------|--|-------|---------------------|----------------------|-------------------------|----------------------------------|---------------------|---------|
| OMRON | SYSMAC C | ○ | ○ | ○ | | | ○ | |
| | SYSMAC C (OPCN-1) | | | | | | | ○ |
| | SYSMAC CV | ○ | ○ | ○ | | | ○ | |
| | SYSMAC CS1/CJ1 | ○ | ○ | ○ | | | | |
| | SYSMAC CS1/CJ1 DNA | ○ | ○ | | | | | |
| | SYSMAC CS1/CJ1 (Ethernet) | ○ | ○ | | | | | |
| | SYSMAC CS1/CJ1 (Ethernet Auto) | ○ | ○ | | | | | |
| | SYSMAC CS1/CJ1 DNA (Ethernet) | ○ | ○ | | | | | |
| | NJ Series (EtherNet/IP) | ○ | ○ | | | | | |
| | ESAK | ○ | ○ | ○ | ○ | | | |
| | ESAK-T | ○ | ○ | ○ | ○ | ○ | | |
| | ESAN/E5EN/E5CN/E5GN | ○ | ○ | ○ | | | | |
| | ESAR/E5ER | ○ | ○ | ○ | | | | |
| | E5CK | ○ | ○ | ○ | ○ | | | |
| | E5CK-T | ○ | ○ | ○ | ○ | ○ | | |
| | E5CN-HT | ○ | ○ | ○ | ○ | ○ | | |
| | E5EK | ○ | ○ | ○ | ○ | | | |
| | E5ZD | ○ | ○ | ○ | ○ | | | |
| | E5ZE | ○ | ○ | ○ | ○ | | | |
| | E5ZN | ○ | ○ | ○ | ○ | | | |
| Oriental Motor | V600/620/680 | ○ | ○ | ○ | | | | |
| | KM20 | ○ | ○ | ○ | ○ | | | |
| Panasonic | KM100 | ○ | ○ | ○ | ○ | | | |
| | V680S (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | High-efficiency AR series (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | CRK series (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | FP Series (RS232C/422) | ○ | ○ | ○ | | | ○ | |
| | FP Series (TCP/IP) | ○ | ○ | | | | | |
| | FP Series (UDP/IP) | ○ | ○ | | | | | |
| | FP-X (TCP/IP) | ○ | ○ | | | | | |
| | FP7 Series (RS232C/422) | ○ | ○ | ○ | ○ | ○ | | |
| RKC | FP7 Series (Ethernet) | ○ | ○ | | | | | |
| | LP-400 | ○ | | ○ | | | | |
| | KW Series | ○ | ○ | ○ | ○ | ○ | | |
| | MINAS A4 series | ○ | ○ | ○ | ○ | ○ | | |
| | SR-Mini (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | CB100/CB400/CB500/CB700/CB900 (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | SR-Mini (Standard Protocol) | ○ | ○ | ○ | | | | |
| | REX-F400/F700/F900(Standard Protocol) | ○ | ○ | ○ | ○ | | | |
| | REX-F9000 (Standard Protocol) | ○ | ○ | ○ | ○ | ○ | | |
| RS Automation | SRV (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | MA900/MA901 (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | SRZ (MODBUS RTU) | ○ | ○ | ○ | | | | |
| | FB100/FB400/FB900 (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | NX7/NX Plus Series (70P/700P/CCU+) | ○ | ○ | ○ | ○ | ○ | ○ | |
| | N7/NX Series (70/700/750/CCU) | ○ | ○ | ○ | | | ○ | |
| | NX700 Series (Ethernet) | ○ | ○ | | | | | |
| | X8 Series | ○ | ○ | ○ | ○ | ○ | ○ | |
| SAIA | X8 Series (Ethernet) | ○ | ○ | | | | | |
| | CSD5 (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | Moscon-F50 (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| SAMSUNG | PCD | ○ | ○ | ○ | | | | |
| | PCD S-BUS (Ethernet) | ○ | ○ | | | | | |
| | SPC series | ○ | ○ | ○ | ○ | ○ | ○ | |
| SANMEI | N_plus | ○ | ○ | ○ | ○ | ○ | ○ | |
| | SECNET | ○ | ○ | ○ | | | ○ | |
| SanRex | Cutty Axis | ○ | ○ | ○ | ○ | ○ | | |
| | DC AUTO (HKD type) | ○ | ○ | ○ | | | | |

| Manufacturer | Models | 1 : 1 | 1 : n Multi-drop | n : 1 Multi-link2 | Multi-link2 Ethernet | 1 : n Multi-link2 Ethernet | n : 1 Multi-link | Network |
|--------------------------------|--|-------|---------------------|----------------------|-------------------------|----------------------------------|---------------------|---------|
| SHARP | JW series | ○ | ○ | ○ | | | ○ | |
| | JW100/70H COM port | ○ | ○ | ○ | | | ○ | |
| | JW20 COM port | ○ | ○ | ○ | | | ○ | |
| | JW series (Ethernet) | ○ | ○ | | | | | |
| | JW300 series | ○ | ○ | ○ | ○ | | ○ | |
| | JW311/312/321/322 series (Ethernet) | ○ | ○ | | | | | |
| | JW331/332/341/342/352/362 series (Ethernet) | ○ | ○ | | | | | |
| | DS-30D | ○ | ○ | ○ | ○ | ○ | | |
| | DS-32D | ○ | ○ | ○ | ○ | ○ | | |
| SHIMADEN | SHIMADEN standard protocol | ○ | ○ | ○ | ○ | | | |
| SHINKO TECHNOS | C Series | ○ | ○ | ○ | ○ | ○ | | |
| | FC Series | ○ | ○ | ○ | ○ | ○ | | |
| | GC Series | ○ | ○ | ○ | ○ | ○ | | |
| | DCL-33A | ○ | ○ | ○ | | | | |
| | JCx-300 Series | ○ | ○ | ○ | ○ | ○ | | |
| | PC-900 | ○ | ○ | ○ | ○ | ○ | | |
| | PCD-33A | ○ | ○ | ○ | ○ | ○ | | |
| | ACS-13A | ○ | ○ | ○ | ○ | ○ | | |
| | ACD/ACR Series | ○ | ○ | ○ | ○ | ○ | | |
| | WCL-13A | ○ | ○ | ○ | ○ | ○ | | |
| Siemens | S5 PG port | ○ | ○ | ○ | ○ | ○ | | |
| | S7 | ○ | | ○ | | | | |
| | S7-200 PPI | ○ | ○ | | | | ○ | |
| | S7-200 (Ethernet ISOTCP) | ○ | ○ | | | | | |
| | S7-300/400 MPI | ○ | ○ | | | | | |
| | S7-300/400 (Ethernet ISOTCP) | ○ | ○ | | | | | |
| | S7-300/400 (Ethernet TCP/IP PG protocol) | ○ | ○ | | | | | |
| | S7-1200/1500 (Ethernet ISOTCP) | ○ | ○ | | | | | |
| | S7 PROFIBUS-DP | | | | | | | ○ |
| | TI500/505 | ○ | ○ | ○ | ○ | ○ | | |
| | TI500/505 V4-compatible | ○ | ○ | ○ | ○ | ○ | | |
| | S120 (Ethernet ISOTCP) | ○ | ○ | | | | | |
| SINFONIA TECHNOLOGY | SELMART | ○ | ○ | ○ | | | ○ | |
| SUS | XA-A* | ○ | | ○ | ○ | | | |
| TECO | TP-03 (MODBUS RTU) | ○ | ○ | ○ | | | | |
| Telemecanique | TSX Micro | | | | | | ○ | |
| TOHO | TTM-000 | ○ | ○ | ○ | ○ | ○ | | |
| | TTM-00BT | ○ | ○ | ○ | | | | |
| | TTM-200 (MODBUS RTU) | ○ | ○ | ○ | | | | |
| Tokyo Chokoku Marking Products | MB3315/1010 | ○ | | | | | | |
| TOSHIBA | T series / V series (T compatible) | ○ | ○ | ○ | ○ | | ○ | |
| | T series / V series (T compatible) (Ethernet UDP/IP) | ○ | ○ | | | | | |
| | EX series | ○ | ○ | ○ | ○ | | | |
| | nv series (Ethernet UDP/IP) | ○ | ○ | | | | | |
| | VF-S7 | ○ | ○ | ○ | ○ | | | |
| | VF-S9 | ○ | ○ | ○ | ○ | | | |
| | VF-S11 | ○ | ○ | ○ | ○ | | | |
| | VF-S15 | ○ | ○ | ○ | ○ | ○ | | |
| | VF-A7 | ○ | ○ | ○ | | | | |
| | VF-AS1 | ○ | ○ | ○ | ○ | | | |
| | VF-P7 | ○ | ○ | ○ | ○ | | | |
| | VF-PS1 | ○ | ○ | ○ | ○ | | | |
| | VF-FS1 | ○ | ○ | ○ | ○ | | | |
| | VF-MB1 | ○ | ○ | ○ | ○ | ○ | | |
| | VF-nC1 | ○ | ○ | ○ | ○ | | | |
| | VF-nC3 | ○ | ○ | ○ | ○ | ○ | | |
| TOSHIBA MACHINE | TC200 | ○ | ○ | ○ | | | | |
| | VELCONIC series | | ○ | | | | | |
| TOYO DENKI | μGPCsx (OPCN-1) | | | | | | | ○ |
| | μGPCsx (SX BUS) | | | | | | | ○ |
| | μGPCsx series | ○ | | ○ | ○ | | | |
| | μGPCsx CPU | ○ | | ○ | ○ | | | |
| | μGPCsx series (Ethernet) | ○ | ○ | | | | | |
| TURCK | BL Series Distributed I/O (MODBUS TCP/IP) | ○ | ○ | | | | | |
| Ultra Instruments | UICCPU (MODBUS RTU) | ○ | | ○ | ○ | | | |

| Manufacturer | Models | 1 : 1 | 1 : n Multi-drop | n : 1 Multi-link2 | Multi-link2 Ethernet | 1 : n Multi-link2 Ethernet | n : 1 Multi-link | Network |
|-------------------|--|-------|---------------------|----------------------|-------------------------|----------------------------------|---------------------|---------|
| ULVAC | G-TRAN series | ○ | ○ | ○ | ○ | ○ | | |
| UNIPULSE | F340A | ○ | ○ | ○ | ○ | | | |
| | F371 | ○ | ○ | ○ | ○ | | | |
| | F800 | ○ | ○ | ○ | ○ | | | |
| | F805A | ○ | ○ | ○ | ○ | ○ | | |
| | F720A | ○ | ○ | ○ | ○ | | | |
| UNITRONICS | M90/M91/Vision Series (ASCII) | ○ | ○ | ○ | | | | |
| | Vision Series (ASCII Ethernet TCP/IP) | ○ | ○ | | | | | |
| VIGOR | M series | ○ | ○ | ○ | ○ | ○ | | |
| WAGO | 750 series (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | 750 series (MODBUS ETHERNET) | ○ | ○ | | | | | |
| XINJE | XC Series (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| YAMAHA | RCX142 | ○ | | ○ | | | | |
| Yaskawa Electric | Memobus | ○ | ○ | ○ | | | | |
| | CP9200SH/MP900 | ○ | ○ | ○ | | | | |
| | MP2000 series | ○ | ○ | ○ | ○ | ○ | | |
| | MP2300 (MODBUS TCP/IP) | ○ | ○ | | | | | |
| | CP MP expansion memobus (UDP/IP) | ○ | ○ | | | | | |
| | MP2000 series (UDP/IP) | ○ | ○ | | | | | |
| | MP3000 Series | ○ | ○ | ○ | ○ | ○ | | |
| | MP3000 series (Ethernet UDP/IP) | ○ | ○ | | | | | |
| | MP3000 series expansion memobus (Ethernet) | ○ | ○ | | | | | |
| | DX200 (high-speed Ethernet) | ○ | ○ | | | | | |
| Yokogawa Electric | FA-M3 | ○ | ○ | ○ | | | ○ | |
| | FA-M3R | ○ | ○ | ○ | | | ○ | |
| | FA-M3/FA-M3R (Ethernet UDP/IP) | ○ | ○ | | | | | |
| | FA-M3/FA-M3R (Ethernet UDP/IP ASCII) | ○ | ○ | | | | | |
| | FA-M3/FA-M3R (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | FA-M3/FA-M3R (Ethernet TCP/IP ASCII) | ○ | ○ | | | | | |
| | FA-M3V | ○ | ○ | ○ | ○ | ○ | ○ | |
| | FA-M3V (Ethernet) | ○ | ○ | | | | | |
| | FA-M3V(Ethernet ASCII) | ○ | ○ | | | | | |
| | UT100 | ○ | ○ | ○ | | | | |
| | UT750 | ○ | ○ | ○ | | | | |
| | UT550 | ○ | ○ | ○ | | | | |
| | UT520 | ○ | ○ | ○ | | | | |
| Yokogawa Electric | UT350 | ○ | ○ | ○ | | | | |
| | UT320 | ○ | ○ | ○ | | | | |
| | UT2400/2800 | ○ | ○ | ○ | | | | |
| | UT450 | ○ | ○ | ○ | | | | |
| | UT32A/35A (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | UT52A/55A (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | UT75A (MODBUS RTU) | ○ | ○ | ○ | ○ | ○ | | |
| | μR10000/20000 (Ethernet TCP/IP) | ○ | ○ | | | | | |
| | | | | | | | | |
| None | Universal serial | ○ | ○ | | | | | |
| | Universal FL-Net | | | | | | | ○ |
| | General-purpose PROFIBUS-DP | | | | | | | ○ |
| | Universal DeviceNet | | | | | | | ○ |
| | Without PLC Connection | | | | | | | |
| | MODBUS RTU | ○ | ○ | ○ | ○ | ○ | | |
| | MODBUS RTU EXT Format | ○ | ○ | ○ | ○ | ○ | | |
| | MODBUS TCP/IP (Ethernet) | ○ | ○ | | | | | |
| | MODBUS TCP/IP (Ethernet) Sub Station | ○ | ○ | | | | | |
| | MODBUS TCP/IP (Ethernet) EXT Format | ○ | ○ | | | | | |
| | MODBUS ASCII | ○ | ○ | ○ | ○ | ○ | | |
| | | | | | | | | |

Slave Communication

| Manufacturer | Models | Setting | Remarks |
|--------------|-----------------------|---------|---------|
| None | Universal serial | ○ | |
| | V-Link | ○ | |
| | Modbus slave (RTU) | ○ | |
| | Modbus slave (TCP/IP) | ○ | |
| | Modbus slave (ASCII) | ○ | |

Hakko Electronics Co., Ltd.
www.monitouch.com

Sales 890-1, Kamikashiwano-machi, Hakusan-shi, Ishikawa,
924-0035 Japan
TEL +81-76-274-2144 FAX +81-76-274-5136