

The following table provides a drawing cross-reference for Fuji Electric's **FRENIC-Multi** open chassis drives.

<i>FRENIC-Multi</i> (Open Chassis)			
Voltage/Phase	Hp	Drive Model Number	Drawing Number
230V 1-phase	1/8	FRNF12E1S-7U	ROA701306
	1/4	FRNF25E1S-7U	
	1/2	FRNF50E1S-7U	ROA701307
	1	FRN001E1S-7U	ROA701308
	2	FRN002E1S-7U	ROA701309
	3	FRN003E1S-7U	ROA701310
230V 3-phase	1/8	FRNF12E1S-2U	ROA701311
	1/4	FRNF25E1S-2U	ROA701312
	1/2	FRNF50E1S-2U	
	1	FRN001E1S-2U	ROA701305
	2	FRN002E1S-2U	ROA701301
	3	FRN003E1S-2U	
	5	FRN005E1S-2U	ROA701302
	7.5	FRN007E1S-2U	ROA701303
	10	FRN010E1S-2U	
	15	FRN015E1S-2U	ROA701304
	20	FRN020E1S-2U	
460V 3-phase	1/2	FRNF50E1S-4U	ROA701300
	1	FRN001E1S-4U	ROA701301
	2	FRN002E1S-4U	
	3	FRN003E1S-4U	
	5	FRN005E1S-4U	ROA701302
	7.5	FRN007E1S-4U	ROA701303
	10	FRN010E1S-4U	
	15	FRN015E1S-4U	ROA701304
	20	FRN020E1S-4U	

Notes:

1. For additional product information please see the *FRENIC-Multi* instruction manual INR-SI47-1204-E.