



NOTE:

* THIS DIAGRAM IS PROVIDED FOR REFERENCE USE ONLY AND SHOWS THE MOST COMMON CONNECTIONS UTILIZED FOR TYPICAL APPLICATIONS. FOR DETAILED SPECIFICATIONS AND ADDITIONAL INFORMATION PLEASE SEE THE FRENIC-Ace DRIVE INSTRUCTION MANUAL AND USER'S MANUAL.



DESCRIPTION: FRENIC-Ace
ALL DRIVES 230V & 460V

INSTRUCTION BOOK: INR-SI47-1204-E

DRN. BY:

J. ORLICKI

REV. DATE:

0

DATE:

03/31/17

REV. BY:

DWG. NO.:

ROA701519

SHT. 1 OF 1