



The Following Table Provides a Drawing Number Cross Reference Guide for Fuji Electric's FRENIC-Mini (C2) Open Chassis Drives

FRENIC-Mini (C2) Drives			
Voltage/Phase	Hp	Drive Model Number	Drawing Number
115V 1-phase	1/8	FRN0001C2S-6U	ROA701230
	1/4	FRN0002C2S-6U	
	1/2	FRN0003C2S-6U	ROA701231
	1	FRN0005C2S-6U	ROA701232
230V 1-phase	1/8	FRN0001C2S-7U	ROA701233
	1/4	FRN0002C2S-7U	
	1/2	FRN0004C2S-7U	ROA701234
	1	FRN0006C2S-7U	ROA701235
	2	FRN0010C2S-7U	ROA701236
	3	FRN0012C2S-7U	ROA701237
230V 3-phase	1/8	FRN0001C2S-2U	ROA701233
	1/4	FRN0002C2S-2U	
	1/2	FRN0004C2S-2U	ROA701234
	1	FRN0006C2S-2U	ROA701238
	2	FRN0010C2S-2U	ROA701243
	3	FRN0012C2S-2U	
	5	FRN0020C2S-2U	ROA701237
	8	FRN0025C2S-2U	ROA701239
	10	FRN0033C2S-2U	
	15	FRN0047C2S-2U	ROA701240
20	FRN0060C2S-2U		
460V 3-phase	1/2	FRN0002C2S-4U	ROA701241
	1	FRN0004C2S-4U	ROA701244
	2	FRN0005C2S-4U	ROA701043
	3	FRN0007C2S-4U	
	5	FRN0011C2S-4U	ROA701237
	7.5	FRN0013C2S-4U	ROA701239
	10	FRN0018C2S-4U	
	15	FRN0024C2S-4U	ROA701240
20	FRN0030C2S-4U		

Voltage	Hp	Electrical Submittal	Drawing Number
ALL	ALL	FRENIC-Mini (C2)	ROA701242

Notes:

1. For additional product information please see the FRENIC-Mini instruction manual INR-SI47-1729a-E.

47520 Westinghouse Drive, Fremont, CA 94539
 Tel: 510.440.1060
 Fax: 510.440.1063
www.americas.fujielectric.com

