

The following table provides a drawing cross-reference for Fuji Electric's DC reactors provided as standard and for separate mounting with **FRENIC-Eco** and **FRENIC-MEGA** series drives.

<b>DC Reactors</b>				
<b>Voltage</b>	<b>DC Reactor Model Number</b>	<b>Provided with FRENIC-Eco Model Nbr.</b>	<b>Provided with FRENIC-MEGA Model Nbr.</b>	<b>DC Reactor Drawing Number</b>
230VAC	DCR2-75C	FRN075F1S-2U	FRN100G1S-2U	ROA701400
		FRN100F1S-2U		
	DCR2-90C	-	FRN125G1S-2U	ROA701401
	DCR2-110C	FRN125F1S-2U	FRN150G1S-2U	ROA701402
460VAC	DCR4-75C	FRN100F1S-4U	FRN100G1S-4U	ROA701410
	DCR4-90C	FRN125F1S-4U	FRN125G1S-4U	ROA701411
	DCR-110C	FRN150F1S-4U	FRN150G1S-4U	ROA701412
	DCR4-132C	FRN200F1S-4U	FRN200G1S-4U	ROA701403
	DCR4-160C	-	FRN250G1S-4U	ROA701404
	DCR4-200C	FRN250F1S-4U	FRN300G1S-4U	ROA701405
		FRN300F1S-4U		
	DCR4-220C	FRN350F1S-4U	FRN350G1S-4U	ROA701406
	DCR4-280C	FRN400F1S-4U	FRN450G1S-4U	ROA701407
		FRN450F1S-4U		
	DCR4-355C	FRN500F1S-4U	FRN500G1S-4U	ROA701408
	DCR4-400C	FRN600F1S-4U	FRN600G1S-4U	ROA701409
	DCR4-450C	FRN700F1S-4U	FRN700G1S-4U	ROA701413
	DCR4-500C	FRN800F1S-4U	FRN800G1S-4U	ROA701414
	DCR4-560C	FRN900F1S-4U	-	ROA701415
	DCR4-630C	-	FRN900G1S-4U	ROA701416
	DCR4-710C	-	FRN1000G1S-4U	ROA701417

Notes:

- For additional product information please see the FRENIC-Eco instruction manual INR-SI47-1225-E or the FRENIC-MEGA instruction manual INR-SI47-1457-E.