












Terminal Cover Constructions for Orange line & Odyssey







Contactors

4NC0A0, 4NC0F0, 4SH4** 	Terminal Cover Part # SZ-T1 (3 pcs in 1 pack)	4NC0G0, 4SH5** 	Terminal Cover Part # SZ-T2 (3 pcs in 1 pack)
4NC0Q0, 4NC0R0 	Terminal Cover Part # SZ-T3 (3 pcs in 1 pack)	4NC0H0 	Terminal Cover Part # SZ-T4 (3 pcs in 1 pack)
3NC0T0, 3NC1Q0 	Terminal Cover Part # SZ-T22 (12 pcs in 1 pack)	3NC2F0, 3NC2H0 	Terminal Cover Part # SZ-T23 (12 pcs in 1 pack)





3NC2T0, 3NC3F0	Terminal Cover Part #		3NC3H0	Terminal Cover Part #	
	Line side	Load side		Line side	Load side
	SZ-N4T (1 pc)	SZ-N4T (1 pc)		SZ-N6T (1 pc)	SZ-N6T (1 pc)
3NC4F0	Terminal Cover Part #		3NC4Q0, 3NC4H0	Terminal Cover Part #	
	Line side	Load side		Line side	Load side
	SZ-N7T (1 pc)	SZ-N7T (1 pc)		SZ-N8T (1 pc)	SZ-N8T (1 pc)
3NC5F0, 3NC5H0	Terminal Cover Part #				
	Line side	Load side			
	SZ-N11T (1 pc)	SZ-N11T (1 pc)			

Motor Starters

4NW0A0, 4NW0F0	<table><tr><th colspan="2">Terminal Cover Part #</th></tr><tr><th>Contactors</th><th>Overload</th></tr><tr><td>SZ-T1 (3 pcs in 1 pack)</td><td>SZ-T12 (2 pcs in 1 pack)</td></tr></table>	Terminal Cover Part #		Contactors	Overload	SZ-T1 (3 pcs in 1 pack)	SZ-T12 (2 pcs in 1 pack)	4NW0G0	<table><tr><th colspan="2">Terminal Cover Part #</th></tr><tr><th>Contactors</th><th>Overload</th></tr><tr><td>SZ-T2 (3 pcs in 1 pack)</td><td>SZ-T12 (2 pcs in 1 pack)</td></tr></table>	Terminal Cover Part #		Contactors	Overload	SZ-T2 (3 pcs in 1 pack)	SZ-T12 (2 pcs in 1 pack)
Terminal Cover Part #															
Contactors	Overload														
SZ-T1 (3 pcs in 1 pack)	SZ-T12 (2 pcs in 1 pack)														
Terminal Cover Part #															
Contactors	Overload														
SZ-T2 (3 pcs in 1 pack)	SZ-T12 (2 pcs in 1 pack)														
4NW0Q0, 4NW0R0	<table><tr><th colspan="2">Terminal Cover Part #</th></tr><tr><th>Contactors</th><th>Overload</th></tr><tr><td>SZ-T3 (3 pcs in 1 pack)</td><td>SZ-T13 (2 pcs in 1 pack)</td></tr></table>	Terminal Cover Part #		Contactors	Overload	SZ-T3 (3 pcs in 1 pack)	SZ-T13 (2 pcs in 1 pack)	4NW0H0	<table><tr><th colspan="2">Terminal Cover Part #</th></tr><tr><th>Contactors</th><th>Overload</th></tr><tr><td>SZ-T4 (3 pcs in 1 pack)</td><td>SZ-T13 (2 pcs in 1 pack)</td></tr></table>	Terminal Cover Part #		Contactors	Overload	SZ-T4 (3 pcs in 1 pack)	SZ-T13 (2 pcs in 1 pack)
Terminal Cover Part #															
Contactors	Overload														
SZ-T3 (3 pcs in 1 pack)	SZ-T13 (2 pcs in 1 pack)														
Terminal Cover Part #															
Contactors	Overload														
SZ-T4 (3 pcs in 1 pack)	SZ-T13 (2 pcs in 1 pack)														
3NW0T0, 3NW1Q0	<table><tr><th colspan="2">Terminal Cover Part #</th></tr><tr><th>Contactors</th><th>Overload</th></tr><tr><td>SZ-T22 (12 pcs in 1 pack)</td><td>SZ-T16 (2 pcs in 1 pack)</td></tr></table>	Terminal Cover Part #		Contactors	Overload	SZ-T22 (12 pcs in 1 pack)	SZ-T16 (2 pcs in 1 pack)	3NW2F0, 3NW2H0	<table><tr><th colspan="2">Terminal Cover Part #</th></tr><tr><th>Contactors</th><th>Overload</th></tr><tr><td>SZ-T23 (12 pcs in 1 pack)</td><td>SZ-T17 (3 pcs in 1 pack)</td></tr></table>	Terminal Cover Part #		Contactors	Overload	SZ-T23 (12 pcs in 1 pack)	SZ-T17 (3 pcs in 1 pack)
Terminal Cover Part #															
Contactors	Overload														
SZ-T22 (12 pcs in 1 pack)	SZ-T16 (2 pcs in 1 pack)														
Terminal Cover Part #															
Contactors	Overload														
SZ-T23 (12 pcs in 1 pack)	SZ-T17 (3 pcs in 1 pack)														

3NW2T0, 3NW3F0	Terminal Cover Part #		3NW3H0	Terminal Cover Part #	
	Contact	Overload		Contact	Overload
	SZ-N4T (1 pc)	SZ-WN4T (1 pc)		SZ-N6T (1 pc)	SZ-WN6T (1 pc)
3NW4F0	Terminal Cover Part #		3NW4Q0	Terminal Cover Part #	
	Contact	Overload		Contact	Overload
	SZ-N7T (1 pc)	SZ-WN7T (1 pc)		SZ-N8T (1 pc)	SZ-WN8T (1 pc)
3NW4H0	Terminal Cover Part #		3NW2F0, 3NW2H0	Terminal Cover Part #	
	Contact	Overload		Contact	Overload
	SZ-N8T (1 pc)	SZ-WN10T (1 pc)		SZ-N11T (1 pc)	SZ-WN11T (1 pc)

Overload Relay Stand Alone Type

4NK0A* + SZ-HB	Terminal Cover Part #		4NK0H* + SZ-HC	Terminal Cover Part #						
	Line side	Load side		Line side	Load side					
	SZ-T10 (1 pc)	SZ-T12 (2 pcs)		SZ-T11 (1 pc)	SZ-T13 (2 pcs)					
										
3NK1Q* + SZ-HD	Terminal Cover Part #		3NK2H* + SZ-HE	Terminal Cover Part #						
	SZ-T14 (3 pcs in 1 pack)			SZ-T15 (3 pcs in 1 pack)						
										
3NK3H*H	Terminal Cover Part #									
	SZ-RN6T (1 pc)									
	