

To: Distributor

Rep No. 16092024

September 20, 2024

Fuji Electric Corp. of America

47520 Westinghouse Drive

Fremont ,CA 94538

Notification regarding discontinuation on 16mm series accessories

We would like to thank you for your continued efforts in promoting the sales of Fuji products.
We would like to notify the discontinuation of some of our products as described below.
Please review the following information and take appropriate actions.
Please also inform all related sections of your company and your customers regarding this notification.

Product name	16 mm Pushbutton accessories
Series name	AH164,AH165,AH165-2,AH16-P
Types	Please see following pages for the part numbers and replacements
Reason for termination	In 2022 there was a design change and these products would not fit the new pushbutton We sincerely apologize for the inconvenience caused by this situation.
Replacement model	You need to order the whole pushbutton rather than purchase the lens
Date of production discontinuation	September 20,2024
Attachments	List of discontinued items and series they are associated with
Last order date	September 20,2024
Replacement parts	There is no replacement lens at this time the customer would need to purchase a new pushbutton
Others	

Fuji Electric FA Components & Systems Co., Ltd.

Attachment List of Change Details

For the AH164, AH165 Series

Color chips

	Fuji Part number	Series
Round	AHX656-G	L,L5,E,E5,Z
	AHX656-R	
	AHX656-W	
	AHX656-S	
	AHX656-Y	
For Neon (Round)	AHX819-G	
	AHX819-R	
	AHX819-W	
	AHX819-S	
	AHX819-Y	
	AHX819-O	

	Fuji Part number	Series
Square	AHX657-G	SL,SL5,SGL,SG L5,SF,SF5,SGF, SGF5,ZS
	AHX657-R	
	AHX657-W	
	AHX657-S	
	AHX657-Y	
	AHX657-O	
For Neon (Square)	AHX820-G	
	AHX820-R	
	AHX820-W	
	AHX820-S	
	AHX820-Y	
	AHX820-O	

Legend Sheet

	Fuji Part number	Series
Round	AHX615-ON	L,L5,E,E5,Z,
	AHX615-OFF	2FL,2FL5,2EL,2
	AHX615-UP	EL5,2F,2F5,2E,
	AHX615-DOWN	2E5,2Z,2ZE
	Square	AHX616-ON
AHX616-CLOSE		
AHX616-DOWN		
AHX616-OPEN		
AHX616-RESET		
AHX616-START		
AHX616-STOP		
AHX616-UP		
Rectangular	AHX617	TL,TL5,TGL,TGL 5,TF,TF5,TGF,T GF5,TM,TM5,Z T
	AHX617-AUTO	
	AHX617-DOWN	
	AHX617-FORWARD	
	AHX617-MAN	
	AHX617-OFF	
	AHX617-ON	
	AHX617-REVERSE	
	AHX617-START	
	AHX617-STOP	
AHX617-UP		

Color Chips

	Fuji Part number	Series
Rectangular	AHX658-G	TL,TL5,TGL,TG L5,TF,TF5,TGF, TGF5,ZT
	AHX658-R	
	AHX658-W	
	AHX658-S	
	AHX658-Y	
	AHX658-O	
For Neon (Rectangular)	AHX821-G	
	AHX821-R	
	AHX821-W	
	AHX821-S	
	AHX821-Y	
	AHX821-O	

Attachment List of Change Details

Legend Plate

	Fuji Part number	Series
Acrylic resin Round	AHX665	L,L5,E,E5,Z, 2FL,2FL5,2EL,2EL5,2F,2F5,2E,2E5,2Z,2 ZE
	AHX665-B	
Acrylic resin Square	AHX666	SL,SL5,SGL,SGL5,SF,SF5,SGF,SGF5,ZS, 2SFL,2SFL5,2SEL,2SEL5,2SF,2SE,2SE5, 2SZ,2SZE
	AHX666-B	
Acrylic resin Rectangular	AHX667	TL,TL5,TGL,TGL5,TF,TF5,TGF,TGF5,TM , TM5,ZT
	AHX667-B	
For symbol mark Square ○	AHX666-E	SL,SL5,SGL,SGL5,SF,SF5,SGF,SGF5,ZS, 2SFL,2SFL5,2SEL,2SEL5,2SF,2SE,2SE5, 2SZ,2SZE
For symbol mark Rectangular ○	AHX667-E	TL,TL5,TGL,TGL5,TF,TF5,TGF,TGF5,TM , TM5,ZT
For symbol mark Square	AHX666-H	SL,SL5,SGL,SGL5,SF,SF5,SGF,SGF5,ZS, 2SFL,2SFL5,2SEL,2SEL5,2SF,2SE,2SE5, 2SZ,2SZE
For symbol mark Rectangular	AHX667-H	TL,TL5,TGL,TGL5,TF,TF5,TGF,TGF5,TM , TM5,ZT
For symbol mark Square ⊕	AHX666-T	SL,SL5,SGL,SGL5,SF,SF5,SGF,SGF5,ZS, 2SFL,2SFL5,2SEL,2SEL5,2SF,2SE,2SE5, 2SZ,2SZE
For symbol mark Rectangular ⊕	AHX667-T	TL,TL5,TGL,TGL5,TF,TF5,TGF,TGF5,TM , TM5,ZT

Dust Cover

	Fuji Part number	Series
Dust tight cover	AHX822	L,L5,E,E5,Z, 2FL,2FL5,2EL,2EL5,2F,2F5,2E,2E5,2Z,2 ZE,SL,SL5,SGL,SGL5,SF,SF5,SGF,SGF5, ZS,2SFL,2SFL5,2SEL,2SEL5,2SF,2SE,2SE 5,2SZ,2SZE
	AHX668	TL,TL5,TGL,TGL5,TF,TF5,TGF,TGF5,TM , TM5,ZT
	AHX649	M,M5,2ML,2M,2YM

Attachment List of Change Details

Button Replacment

	Fuji Part number	Series
Mushroom Head button	AHX682-G	M,M5
	AHX682-R	
	AHX682-W	
	AHX682-S	
	AHX682-Y	
	AHX682-O	
Convex Rectangular Head button	AHX684-G	TM, TM5
	AHX684-R	
	AHX684-W	
	AHX684-S	
	AHX684-Y	
	AHX684-O	
	AHX684-B	

AH165-2

Color lens For Flush head

	Fuji Part number	Series
Round	AHX2604-G	2F, 2F5,2FL,2FL 5,2Z
	AHX2604-R	
	AHX2604-Y	
	AHX2604-S	
	AHX2604-O	
	AHX2604-C	

	Fuji Part number	Series
For Extended Head	AHX2605-G	2E, 2E5,2EL,2EL 5,2ZE
	AHX2605-R	
	AHX2605-Y	
	AHX2605-S	
	AHX2605-O	
	AHX2605-C	
For Flush head	AHX2606-G	2F, 2F5,2FL,2FL 5,2Z
	AHX2606-R	
	AHX2606-Y	
	AHX2606-S	
	AHX2606-O	
	AHX2606-C	

Color lens

	Fuji Part number	Series
For Extended Head	AHX2607-G	2E, 2E5,2EL,2EL5,2ZE
	AHX2607-R	
	AHX2607-Y	
	AHX2607-S	
	AHX2607-O	
	AHX2607-C	
	AHX2607-W	

Legend Plate

	Fuji Part number	Series
For Flush Head	AHX2609-W	TL,TL5,TGL,TGL5,TF,TF5,TGF, TGF5,ZT,2FL,2FL5,2F,2F5,2Z
	AHX2609-B	
For Extended Head	AHX2610-W	L,L5,E,E5,2EL,2EL5,2F,2E5,2ZE
	AHX2610-B	
For Flush Square	AHX2611-W	SL,SL5,SGL,SGL5,SF,SF5,SGF,S GF5,ZS,2SFL,2SFL5,2SF,2SF5,2 SZ
	AHX2611-B	
For Extended concave square	AHX2612-W	Z,2SEL,2SEL5,2SE,2SE5,2SZE
	AHX2612-B	

Replacement button

	Fuji Part number	Series
Mushroom Illuminated pushbuttons	AHX2614-G	2ML,2YML
	AHX2614-R	
	AHX2614-W	
	AHX2614-Y	
	AHX2614-S	
	AHX2614-O	
Mushroom Non Illuminated pushbuttons	AHX2613-G	2M,2YM
	AHX2613-R	
	AHX2613-W	
	AHX2613-Y	
	AHX2613-S	
	AHX2613-O	
	AHX2613-B	

Attachment
List of Change Details

Dust Tight cover

For flush	Fuji Part number	Series
round	AHX2603-2	2,2FL,2F5,2FL5
For flush Square	AHX2603-2S	2SF,2SFL,2SF5,2SFL5

Sockets for LED

	Fuji Part number	Series
Solder/Tab	AHX697-SH3	Was used for all series except for pilot lights or AH165-2PL
Wire-wrap	AHX697-WH3	
Sockets		
	Fuji Part number	Series
Pushbuttons	AHX697-S	Solder/Tab
	AHX697-W	Wire-wrap
	AHX697-P	PC board
Illuminated Pushbuttons	AHX697-SL	Solder/Tab
	AHX697-WL	Wire-wrap
	AHX697-PL	PC board

Was used for all series except for AH165-2PL

	Fuji Part number	Series
Other accessories discontinued	AHX650	Old Legend Plate for round pushbuttons
	AHX651	Old Legend Plate for square pushbuttons
	AHX653-G	AH164-L,L5,E,E5,Z, AH165-L,L5,E,E5,Z
	AHX653-SG	AH164-SL,SL5,SGL,SGL5,SF,SF5,SG F,SGF5,ZS AH165-SL,SL5,SGL,SGL5,SF,SF5,SG F,SGF5,ZS
	AHX653-TG	AH164-TL,TL5,TGL,TGL5,TF,TF5,TG F,TGF5,ZT AH165-TL,TL5,TGL,TGL5,TF,TF5,TG F,TGF5,ZT
	AHX813	AH164-TF,TGF,TL,TGL,ZT AH165-TF,TGF,TL,TGL,ZT
	AHX822	AR16F0M,F5M,F0S,F5S AR16E0L,E5L,E0R,E5R