

Paperless Recorder Type: PHF

Long Term Record Data Saving

Ayears in Compact Flash (In case of using 512MB Compact Flash)

Saved Data playback

Saved data in Memory card can be easily called out and played back on display

Communication

Ethernet (10Base-T) is available. (option)

Screen saver Period of non-operation exceeds the setting value of parameter, recorder turns off the backlight of LCD.

PC support softwares (Data Viewer/Parameter Loader) Supplied in a CD-ROM as a part of standard accessory

Compact size

160 (W) X 144 (H) X 185 (D) mm (Panel mount) 1.5 kg compact size

3-point recording and 6-point max. recording


12 types of thermocouples, 5 types of resistance bulbs and voltage/current input are available



Type: PHF




Provides flexibility and variety in the handling of record data.



Communication

• Ethernet (10Base-T) is available. It has FTP, HTTP (Web server), SMTP and MODBUS-TCP protocols.



Calculation function offered as standard


Subtraction

Difference between the values of each channel can be calculated.


Square root extraction

Square root extraction of the input value of each channel can be performed.


Wide variety of display mode



Trend recording (horizontal) Measured result is horizontally displayed in real time.



Bar graph Measured values are displayed in bar graph.




Historical trend display

Past data saved to Compact Flash can be viewed. Scroll function is usable.



Trend recording (vertical)

Measured result is vertically displayed in real time.



Digital display

Channel No., Tag No. engineering unit, and alarm information are displayed in digital form, in addition to measured values.


Steam-	-1 Ov	er Hish L	imit	
2004/	3/17	13:09:32	A.start	CH2 -4H
2004/	3/17	13:09:32	A.start	CH2 -3H
2004/	3/17	13:09:32	A.start	CH2 -2H
2004/	3/17	13:09:32	A.start	CH2 -1H
2004/	3/17	13:09:32	A.start	CH1 -4H
2004/	3/17	13:09:32	A.start	CH1 -3H
2004/	3/17	13:09:32	A.start	CH1 -2H
2004/	3/17	13:09:32	A.start	CH1 -1H
2004/	3/17	13:09:32	Power &	Rec. ON

Event summary display


Alarm status and external control input status for each channel are displayed.

Easy operation without the help of the instruction manual

The onscreen guidance enables you to set/change various parameter data easily.



Ethernet




Standard Loader software enables reading/writing of the

The record files in Compact Flash can be listed, downloaded to PC and deleted from Internet Explorer. Recorder configuration can also

PHF's parameter settings


Web function

You can display process values and/or event summary using Internet Explorer. (Netscape is not supported)



E-mail function


PHF recorder can send E-mails to maximum 8 addresses at up to 10




► MODBUS-TCP function

► FTP function

You can link the recorder with all network, supervisor or SCADA system by MODBUS TCP/IP protocol.



trigger timings through a mail server on the same LAN.



[Items sent] • Subject

- Contents (32 characters per set × 2)
 Process values
- Name of sender and time


- [Timing of sending] E-mail can be sent when either of the following events occurs. • Alarm ON / Alarm OFF

 - DI ON / DI OFF
 Specified intervals

 - (every 1, 2, 3, 4, 6, 12, 24 hours) Failure of PHF
 - (No battery, run out of memory, etc.)

Easy connection

Ethernet communication need no communication software.



Internet Explorer can be used as a browser (Netscape is not supported). Ethernet specification : Windows 2000 or XP/7 is required.

Http (server)

You can browse the following screens by setting PHF's IP address on Internet Explorer (ver.6). (Change of setting value is not possible)

[Measured value display screen]

- •PV value for each channel (instantaneous value) •Recording condition
- •Memory usage of Compact Flash •Alarm Status

[Event summary screen] •The information on the event summary screen of the recorder.

◆FTP (server: read only)

FTP server function allows you the followings by setting PHF's IP address on Internet Explorer. Browse of file names in the Compact

Flash •Files can be downloaded to PCs. deleted or changed their names

It's also available to access by using command prompt. User ID and password are needed to access

to recorder. (simultaneous access by multiple users is inhibited)

SMTP (client)

E-mail can be sent when the mail server is available in the same LAN network. E-mail cannot be received from an external network. The items sent and timing of sending are as follows

- [Timing of sending] •DI ON, DI OFF •Alarm ON, Alarm OFF •Failure occurred in main unit (no battery, memory card is full, etc.) •Periodic
- [Items sent] •Subject of E-mail (32 characters) •Message (32 characters × 2) •PV value (instantaneous value) Sent time Name of sender
- [Number of registered recipient addresses] •8 (the items and timing can be set for each recipient)

MODBUS-TCP

Communication with MODBUS-TCP protocol through Ethernet is available. Reading from each parameter, and writing/reading is enabled (for details, refer to the separate communication manual).

Loader software

Loader software installed as standard enables parameter settings to be read and written, but writing is not allowed during recording.

Communication medium


Ethernet (10BASE-T)

Specifications

Specifications				
General specification	tions	Amount of memory	The display unit displays how much the memory	
Mounting method	Panel flush mounted	used	card has been used via bar graphs. The recording	
Material	Molding resin (case, bezel)		will stop if the amount of recorded data exceeds	
External dimensions	<panel mount=""></panel>	-	the capacity.	
and mass	160 x 144 x 185 mm, about 1.5 kg (6-point input)	Alarm function		
Power supply voltage	100V to 240V AC, 50/60 Hz	No. of settings	Up to 4 alarms are settable for each channel.	
Power consumption	About 42VA (at 240VAC)	Type of alarm	High/Low limits	
External terminals	Screw terminals (M3 thread)	Indication	Alarm status is displayed on digital display unit	
Operate temperature	0 to 50°C (in case the 12th digits of code symbols is "Y".)		when an alarm occurs. Histories are displayed in	
operate temperature	0 to 40 $^{\circ}$ C (in case the 12th digits of code symbolic is "E".)		the alarm summary.	
		Output	10 points as relay output (option)	
	Note: In case of 30 degree C or more for ambient temperature. This display might be fogged little bit. (This is not out of order.)	Reference perforn		
Input unit		Indication accuracy	±(0.15%+1 digit) of input range	
No. of inputs	3 or 6 points	Indication accuracy	Accuracy of the next range is $\pm (0.3\%+1 \text{ digit})$.	
Measuring cycles	100ms	-	Thermocouple B: 400°C to 600°C, thermocouples	
Recording cycle	1sec to 12hours	-	R and S: 0°C to 300°C, thermocouples K, E, J, T,	
Input signal	Thermocouple: 12 types	-	L, and U: -200°C to -100°C	
input signal		Indication resolution	0.1°C	
	(B, R, S, K, E, J, T, N, W, L, U, PN)	Indication resolution		
	Resistance bulb: 5 types	Reference junction	±0.5°C	
	(Pt100, JPt100, Ni100, Pt50, Cu50)	Compensation accuracy		
	DC voltage:	Input resistance	About 1MΩ	
	(0 to 50mV, 0 to 500mV, 0 to 5V or 1 to 5V)	Others		
	DC current:	Clock	With calendar function	
	(connecting optional shunt resistor to input terminal)	Memory backup	Parameter settings are saved to the internal non-	
Input types	Selected from the key panel		volatile memory. The clock is backed up by a	
	(the same type should be set for every 2 channels)		built-in lithium battery. Trend data is back up	
Burn-out function	Equipped with thermocouple and resistance bulb		only 400 samplings.	
	inputs as standard.	Memory full alarm	When the amount of recorded data exceeds the	
Calculation function	Primary delay filter, scaling, calculation of		capacity of memory card, recorder can energize	
	difference between channels, and square root		the alarm output.	
	extraction	Low battery alarm	When the battery for backup of clock and SRAM	
Display unit			becomes low, recorder can energize the alarm output.	
Display	5.7" STN color LCD (320 X 240 dots) (The LCD may	Optional specifica		
	have some pixels that do not stay on or off.		10 relay outputs and 5 DI are added.	
	Due to the characteristics of liquid crystal, the		Alarm output: SPST Output for each channel or	
	brightness may not be uniform, which is not a failure.)		common channel is possible.	
Life of backlight	50.000 hours	-	DI input: 5 no-voltage contact input points,	
Display contents	•Trend display	-	Recording start/stop, or LCD turning on functions	
	(in vertical and horizontal direction) selected in		can be performed.	
	the refreshment cycles of 1 sec to 12 hours.	Communication		
	Scale display/non-display selectable	Communication	10Base-T	
	•Bar graph display (refresh cycle: 1 second)	(Ethernet)	FTP server * (Internet Explorer 6. FFFTP or	
	•Digital display (in refreshment cycle of 1 sec)		Comand Prompt are available)	
	· · · · · · · · · · · · · · · · · · ·			
	•Event summary display (alarm and message summary)		HTTP server * (Web server. Internet Explorer 6 is	
Recording functio	•Historical trend display (Compact Flash memory data.)		available)	
			SMTP (e-mail client)	
Recording medium	Compact Flash card (Format as FAT16 or FAT, or		MODBUS-TCP	
Mana	recorder can't read and write.)		* Netscape and Mozilla Firefox are not available	
Memory capacity	2GB, max.		are (standard-supplied CD-ROM)	
Recording method	Writing starts in fixed cycles by turning ON the	O/S	Windows XP/2000/7	
	REC key on the front panel.	PC/AT-compatible	Operation on PC98-series machines by NEC is	
	Data is recorded in a new file every time the	machine	not guaranteed.	
	recording starts.		Operation on self-made or shop-brand PCs is	
Data save cycles	Links to refreshment cycle of the trend display		not guaranteed.	
Data format	 ASCII About 118 bytes per sampling 	Required memory	64 MB or more	
	(at 6 channel inputs)	capacity		
	•Binary (Data cannot be read directly into Excel, etc.)	Contents	The following types are included as standard.	
	About 28 bytes per 1 sampling (6-channel input)		1) Data viewer software	
Trend data	Maximum value and minimum value are saved from		It allows you to view the past trend recorded data	
	the data that are sampled in measuring cycles.		from the data saved to the Compact Flash on PC.	
Event data	Alarm data and message data are saved.		Historical trend and event display functions are	
Storage capacity	•About 4 years at display refresh cycle of 30		provided.	
	seconds (ASCII)		2) Parameter loader software	
	•About 16 years (Binary)		It allows you to perform setting/change of various	
	(6-channel recording, 512MB compact flash used)		parameters on PC.	
	(o charmer recording, orzivid compact hash used)		purameters office.	

A convenient PC support software package is included as standard

Past data saved to Compact Flash can be viewed on personal computer.



Historical trend data screen



- Before use, install PC support software supplied as standard. • O/S: Windows XP/2000/7
- Required storage capacity: 64 MB
- Provide PC card adapter separately.
- Recomended type: SDAD-38 PC/AT-compatible machine
- Operation on PC98-series machines by NEC is not guaranteed.
- Operation on self-made or shop-brand PCs is not guaranteed.

Parameters for the recorder can be easily set and changed from personal computer.

easuring Channel	PV SMI	Alarm Setting Alarm No 1
Channel Teg	Shift Yakus 1 0.0	Alarm Mode OFF +
Inpld Type	instantion(%) 100.00	ALatm Set Value 0.0
K-Type Thermo Couple	Display Range	DO Resay No. None
Input Unit TC Select	Lower Limit Value 0.0	Alam No.2
Tana In Inter	Upper Limit Value 1200.0	Alarm Mode OFF
	The stand stand	Alarm Set Value 0.0
Scaing CEF	Recording Made	DO Remy No None +
Measuring Ranga	Record Start With Record	- Alarm Tile 3
Upper Limit Value		
		Alarm Mode OFF +
Engineering Unil		
Upper Limit Value 00		DO Relay No. None +
state sum cost of		Alarm No.4
Decimal		Alarm Mode OFF -
Pant Poeton J		Jalann Set Vajun 0.0
		DO Relay No.
ut type has to be common for each 2cha	renals withing flems decend on the providus odd n	

Parameter setting screen



Before use, install PC support software supplied as standard. • O/S: Windows XP/2000/7

- Required capacity of memory: 64 MB
- A communication cable between recorder and pc is optional. Type: PHZP1801


PC/AT-compatible machine

- Operation on PC98-series machines by NEC is not guaranteed.
- Operation on self-made or shop-brand PCs is not guaranteed.


Outline Diagram and Panel Cut (Unit: mm)

Panel mount type

3 or 6-points input



Note: When placing the main unit on another instrument or on the floor, allow a space of 100mm or more between the unit and instrument or the floor.



External connection diagram

3 or 6-points input

231	Ь	́0-	211	DI1
232	6	́о-	212	DI2
233	6	́о-	213	DI3
234	L.	́о-	214	DI4
234	Ľ	∕o-	215	DI5
235	G	6-	216	DO1
236 237	6	6-	217	DO2
	6	6	218	DO3
238		6	219	DO4
239	-	6	220	DO5
240	-ó	6	221	DO6
241	-ó	6	222	D07
242	-ó	6	223	DO8
243	ŀó	- 	224	DO9
244	ŀÓ	<u>_</u>	224	DO9
245	ЬÓ	5	225	001

ALARM OUTPUT / DIGITAL INPUT TERMINAL






Ð

0

•

AC100~240V 50/60Hz



Note 1: For current input, connect an optional shunt resistance to a voltage input terminal. Note 2: Please do not use any input terminal which is not needed.

Code Symbols

4 5 6 7 8 9 10 11 12 13 PHF 1 B 1 1 E 1 V

Digit	Specifications	Note	
4	<number input="" of="" points=""></number>		$\neg \downarrow$
	3		5
	6		6
11	<alarm (relay)="" di="" input="" output=""></alarm>		
	Without		Ŏ
	With		1
12	<communication></communication>		
	Without		Ý
	With Ethernet		E

Note 1: Input signals are classified into the following 4 groups. Make the setting so that channel 4 and 5 are assigned the input signal categorized in the same group. Group 1: Thermocouple (12 kinds), 50mV Group 2: Pt100. JPt100, Ni100, Cu50, Pt50 Group 3: 500mV Group 4: 1-5V, 0-5V

Scope of supply		
Item	Quantity	
Main unit	1	
Panel mounting bracket	1	
CD-ROM (PC software and Instruction manual)	1	
Noise filter for power cable	1	

Option

Item	Туре	Specifications
Shunt resistor for DC current input	PHZP0101	10Ω±0.1%
PC loader communication cable	PHZP1801	With USB A and USB miniB Connector (3m)
CD-ROM	PHZP2101	Instruction manuals and softwares
PC card adapter for Compact flash	SDAD-38	Maker : Sandisk
Compact flash (512MB)	PHZP1301-512	
Compact flash (1GB)	PHZP1301-01G	

Note 1: Windows, Excel and Internet Explorer are registered trademarks of Microsoft Corporation. Note 2: SanDisk compact flash is a trademark of SanDisk. Note 3: PC98 series are registered trademarks of NEC Corp. Note 4: MODBUS® is the registered trademark of AEG Schneider Autmation International.

Note 5: Netscape is the registered trademark of Netscape Communication Corp. Note 6: Mozilla Firefox is the registered trademark of Mozilla Foundation.

For Fuji Electric Co., Ltd.

International Sales Div. Sales Group Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome, Shinagawa-ku, Tokyo 141-0032, Japan http://www.fujielectric.com Phone: 81-3-5435-7280, 7281 Fax: 81-3-5435-7425 http://www.fujielectric.com/products/instruments/